

USER'S MANUAL

SRP-275

IMPACT PRINTER



All specifications are subjected to change without notice

Table of contents

Chapter 1 Setting up the printer

1.1	Unpacking	1-1
1.2	Choosing a place for the printer	1-1
1.3	Connecting the cables	1-2
1.3.1	Connecting the AC adaptor	1-2
1.3.2	Connecting the interface cable and drawer kick-out cable	1-2
1.4	Installing the ribbon cassette	1-3
1.5	Installing the paper roll	1-4
1.6	Changing the paper width	1-5
1.7	Installing the wall mount (Option)	1-6
1.8	Using the operation panel	1-7
1.9	Self test	1-8

Chapter 2 Troubleshooting

2.1	ERROR LED blinking pattern	2-1
2.2	The printer does not start printing	2-2
2.3	The printer stops printing	2-3
2.4	You want to check the operation of the printer by itself	2-3
2.5	Printing is poor	2-4
2.6	You want to check a software program	2-4

Chapter 3 Setting the switches

3.1	Setting the DIP Switch	3-1
3.1.1	DIP Switch setting for Epson(ESC/POS) mode	3-1
3.1.2	DIP Switch setting for Citizen(iDP 3550) mode	3-2
3.1.3	DIP Switch setting for Star(SP500) mode	3-3
3.1.4	Changing the DIP Switch setting	3-4
3.2	Setting the Memory Switches	3-5
3.2.1	Memory Switch setting for Epson(ESC/POS) mode	3-5
3.2.2	Memory Switch setting for Star mode	3-9

Chapter 4 Control commands list

4.1	Command notation	4-1
4.2	Explanation of term	4-1
4.3	Exception processing	4-2
4.4	Commands for SRP-275 series	4-3
4.4.1	Commands list for EPSON mode (TM-U220)	4-3
4.4.2	Command description for EPSON mode (TM-U220)	4-4
4.4.3	Commands list for STAR mode (SP500)	4-28
4.4.4	Commands list for CITIZEN mode (iDP3550/3551)	4-30

Chapter 5 Reference information

5.1	Printing specification	5-1
5.2	Paper specifications	5-1
5.3	Ribbon cassette specification	5-1
5.4	Electrical characteristics	5-2

5.5	Reliability	5-2
5.6	Environment conditions	5-2
5.7	Environment conditions	5-3
5.8	Optional features	5-3

Appendix A Code table

A.1	Page 0 (PC 437 : USA, Standard Europe(International Character Set : USA))	A-1
A.2	Page 1 (Katakana)	A-2
A.3	Page 2 (PC850 : Multilingual)	A-3
A.4	Page 3 (PC860 : Portuguese)	A-4
A.5	Page 4 (PC863 : Canadian-French)	A-5
A.6	Page 5 (PC865 : Nordic)	A-6
A.7	Page 16 (WPC1252 : Latin1)	A-7
A.8	Page 17 (PC866 : Russian)	A-8
A.9	Page 18 (PC852 : Latin2)	A-9
A.10	Page 19 (PC858 : Euro)	A-10
A.11	Page 21 (PC862 : Israel)	A-11
A.12	Page 22 (PC864 : Arabic)	A-12
A.13	Page 23 (Thai character code 42)	A-13
A.14	Page 24 (WPC1253 : Greek)	A-14
A.15	Page 25 (WPC1254 : Turkish)	A-15
A.16	Page 26 (WPC1257 : Baltic)	A-16
A.17	Page 27 (Farsi)	A-17
A.18	Page 28 (WPC1251 : Russian)	A-18
A.19	Page 29 (PC737 : Greek)	A-19
A.20	Page 30 (PC775 : Baltic)	A-20
A.21	Page 31 (Thai character code 16)	A-21
A.22	Page 32 (OldCode : Israel)	A-22
A.23	Page 33 (WPC 1255 : Israel)	A-23
A.24	Page 34 (Thai character code 11)	A-24
A.25	Page 35 (Thai character code 18)	A-25
A.26	International character code table	A-26

Appendix B Connectors

B.1	RS-232C Serial I/F	B-1
B.1.1	RS-232C Serial I/F cable connection	B-1
B.1.2	RS-232C Serial I/F signal descriptions	B-1
B.2	IEEE 1284 Parallel I/F	B-2
B.2.1	IEEE 1284 Parallel I/F signal specification (Compatibility / Nibble / Byte mode)	B-2
B.3	USB I/F	B-3
B.3.1	USB I/F signal description	B-3
B.4	Drawer kick-out	B-3
B.4.1	Drawer kick-out connection	B-3

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*