


IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

Some of the following information may not apply to your particular product; however, as with any electronic product, precautions should be observed during handling and use.



WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

- Read these Instructions.
- Keep these Instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

ADDITIONAL SAFETY INFORMATION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not attempt to disassemble the cabinet. This product does not contain customer serviceable components.

Precautions for the unit

- Do not use the unit immediately after transportation from a cold place to a warm place; condensation problems may result.
- Do not store the unit near fire, places with high temperature or in direct sunlight. Exposure to direct sunlight or extreme heat (such as inside a parked car) may cause damage or malfunction.
- Clean the unit with a soft cloth or a damp chamois leather. Never use solvents.
- The unit must only be opened by qualified personnel.

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by VOXX Accessories Corporation could void the user's authority to operate the equipment.

Industry Canada Regulatory Information

CAN ICES-3 (B)/NMB-3 (B)

Avis d'Industrie Canada

CAN ICES-3 (B)/NMB-3 (B)

Important battery Information

Warning: Your product contains a battery and charging system which is designed to work in temperatures that do not exceed 50°C (122°F). Leaving this product in a closed automobile or the trunk of an automobile where temperatures may exceed 50°C may result in permanent battery damage, fire, or explosion. Please remove your product from the automobile when you exit, do not place your product in the trunk of your automobile, and do not leave your product in any location where temperatures may exceed 50°C.

Ecology

Your product must be disposed of properly according to local laws and regulations. Because this product contains a battery, the product must be disposed of separately from the household waste.

Emergencies happen.

Be prepared. The Emergency Lighting has been designed to help you in a power outage.

What's in this package?

- AC power adapter (Fig. 1)
- Mounting screws [4] (Fig. 2)
- Emergency Lighting
- Hanging bracket (pre-attached to the emergency lighting unit)
- This user guide




Figure 1






Figure 2

Tour of the Emergency Lighting



Hanging Bracket

AC adapter charging

1. Plug the tip of the AC power adapter into the DC Input jack on the emergency lighting unit.
2. Plug the other end of the AC power adapter into a working power outlet. The emergency lighting unit's indicator light will turn red to indicate that the unit is charging. This light will turn green when the unit is fully charged (usually within 24 hours). Leave the unit plugged in if you would like to use the AUTO ON function (see the Lighting function section below)

Note: The AC adapter should be plugged in so that it stays vertical or lies flat.

Hand-Crank Charging


The hand crank charges the Emergency Lighting's internal battery.

1. Take out the hand-crank from the initial position and tilt it at its 180° position.
2. Crank at a speed of 130-150 rpm (rotations per minute) (either clockwise or counter-clockwise).
3. The indicator light will turn red, which shows the battery inside is being charged.

Note: If you don't reach a turning speed of at least 130 rpm, the battery won't charge as quickly.

IMPORTANT: Don't force the hand crank. Make sure you turn from the handle only--don't grab the entire crank.

Lighting Function



1 light or 2 lights button



- ☾ turns on the right-side light only
- ☾☾ turns on both lights

ON/OFF/AUTO button



- ON turns the lights on
- OFF turns the lights off
- AUTO automatically turns the light on when the emergency lighting's power source is cut off (leave the unit plugged into a power source to use this feature)


Mounting the Emergency Lighting Unit

This Emergency Lighting device offers three placement options:

- keep the unit on a horizontal surface (like a desk or table--no mounting required)
- hang the unit temporarily
- mount the hanging bracket permanently

To keep the unit on a horizontal surface: There's no mounting or further installation required. However, you can remove the hanging bracket from the back of the unit if you'd like. Simply push down on the bracket to snap it off of the unit.


To hang the unit temporarily: On the wall where you'd like to hang the unit. Insert two of the screws from this package roughly 3.5 inches apart from each other. Then place the emergency lighting unit over the screws and gently pull the unit down onto the screws.




To mount the hanging bracket permanently:

1. Push down on the emergency lighting unit's hanging bracket to snap it off of the unit.
2. Insert the four include screws through the hanging bracket's holes as shown here.

If you're hanging on a flat surface: use the four holes on the bracket's flat surface as shown here.



If you're hanging on a corner: use the four holes on the inside of the bracket's v-niche as shown here.



3. Once you've mounted the bracket, slide the emergency lighting unit back onto the bracket until it clicks into place.

Specifications

Built-in battery: 1500mAh/3.7V DC input: 6.0V 300mA Maximum power consumption of LED lighting: 1.2W LED: lifespan 50,000hrs Weight: 400g Size: 140.6mm x 76.9mm x 161mm	Conditions	Capabilities	Time of use
	Full capacity of 1C (1500mAh) battery	2 lights 1 light	200 mins 420 mins
Cranking 1 minute (130-150rpm) when the lighting is below 100 LUX		2 lights 1 light	10 mins 15 mins

For additional support, call our Consumer Help Line at 1-888-217-7900 or visit Champ-Eprep.com

Limited 12 Month Warranty

Voxx Accessories Corp. warrants that for 12 months from date of purchase, it will replace this product if found to be defective in materials or workmanship. Return it to the address below for a replacement with a current equivalent. This replacement is the company's sole obligation under this warranty. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE IS DISCLAIMED. This warranty excludes defects or damage due to misuse, abuse, or neglect. Incidental or consequential damages are disclaimed where permitted by law. This warranty does not cover product purchased, serviced or used outside the United States or Canada.

U.S.A.: Audiovox Return Center, 150 Marcus Blvd., Hauppauge, New York 11788

CANADA: Audiovox Return Center, c/o Genco, 6685 Kennedy Road, Unit #3 Door 14, Mississauga Ontario L5T 3A5