


# SPINPOD

## USER MANUAL YOUR GUIDE TO MAKING NEW MEMORIES

THESPINPOD.COM | INFO@THESPINPOD.COM | #THESPINPOD | @SPINPOD


## MEET THE SPINPOD

Spinpod is a slim motion control unit designed for smart phones and compact cameras. It can either run continuously when taking panoramic pictures or step at very small angles when taking rotational motion time-lapse videos. If combined with a dolly system, it is even capable of taking linear and curved motion time-lapse and is DSLR ready.



SIMPLE

## IN THE SPINPOD BOX



### UNDERSTAND THE TOUCH CONTROL & LED



## X TIMFR

- SHORT PRESS CHANGES MODE

-SHORT PRESS TO SET COUNTDOWN TIMER

- SHORT PRESS TURNS MOTOR OFF WHEN RUNNING
- LONG PRESS ON THE MODE BUILTON STARTS THE MOTOR

## PANORAMIC





DELAY (SECONDS)

Set countdown timer 0 | 5 | 10 | 15


## ROTATIONAL TIME-LAPSE





Short press Set rotation speed

SPEED (HOUR/REV)









## \*LINEAR TIME-LAPSE (DOLLY SYSTEM)





Long Press



Simultaneous Set linear speed

SPEED (FEET/HOUR)

100 | 60 | 45 | 25 | 15






## CHARGING

Use the included microUSB cable to charge the Spinpod via your computer, wall adapter or any other USB port.


Make sure the main Spinpod switch (thumb wheel) is in the off position (position locker fully retracted) during charging.

The right LED will turn solid red while charging and solid purple when charging has completed.


It will take approximately 2.5 hours to fully charge a depleted battery and should provide enough power last a few months of typical use.




MICROUSB CABLE



PLUG THE CABLE INSIDE THE SPINPOD DOCK PORT






CHARGE VIA YOUR COMPUTER, WALL ADAPTER OR ANY USB PORT

## MOUNTING ADAPTER


Attach the mount to your spinpod to use




## TAKING PANORAMIC PHOTOS

Using smart phone

1. Lock phone into slot (device turns on)









3. Set countdown timer



4. Swipe to select direction



5. Start panorama on phone





6. Long press to start Spinpod (Spins 1 full rotation)

#### APP STORE & GOOGLE PLAY STORE



Top 3 iOS Panorama Apps: Photosynth, 360 Panorama & Pano

#### TIPS FOR A GREAT SHOT:

- 1. Keep spinpod leveled will create better pictures.
- When using the iPhone's build-in panorama function, the scene where the blue LED points to before starting a shot will be close to the center of the image.


## TAKING TIME-LAPSE VIDEOS

Using iPhone, Andriods & compact cameras




1. If using phone put landscape mount on


**Note:** you can use the landscape mount for phones & the mount for cameras



2. Attach mount (for phones & cameras)



4. Select time-lapse mode (red LED)



3. Lock phone in slot (device turns on)



5. Select rotation speed





6. Swipe to select direction





7. Long press to start Spinpod (Spins until stopped)



8. Start time-lapse app on phone or Start intervalometer on camera

#### APP STORE & GOOGLE PLAY STORE




Top 3 iOS time-lapse apps are: OSnap!, Timelapse & Lapse it

#### TIPS FOR A GREAT SHOT:

- 1. Use the pano mode to quickly adjust the initial position
- At a given speed on Spinpod, the longer the time interval between each shot, the faster the scene will rotate in the final video.
- 3. Lock the focus, exposure and white balance before recording

## CONNECTING TWO SPINPODS

L-bracket must be purchased separately



Connect two Spinpods together with an L-bracket to take Pan &Tilt video.

## DOLLY SYSTEM

## USER MANUAL

YOUR GUIDE TO TAKING VIDEOS IN MOTION


PURCHASED SEPARATELY



## IN THE DOLLY SYSTEM BOX


Dolly system can take linear and curved motion timelapse video when driven by Spinpod. It can also be used to record regular videos when moved manually.


#### Dolly system needs to be purchased separately



## DOLLY SYSTEM - SPINPOD DOLLY MOUNT









## **DOLLY SYSTEM - OPERATION**

1. Lock Spinpod on dolly mount (device turns on) Warning: Do not over tighten thumb lock



2. Select linear time-lapse mode (purple LED)









#### APP STORE & GOOGLE PLAY STORE



Top 3 iOS time-lapse apps are: OSnap!, Timelapse & Lapse it

#### TIPS FOR DOLLY

- 1. Try to put the weight of the camera toward the side where the Spinpod is mounted. This will make sure the driving wheel always touches the ground
- 2. Do not use Spinpod to drive the dolly on ramp. Even the moderate inclination (10 degrees) may damage the internal gear of Spinpod.
- 3. Use Spinpod dolly mount as a handle to move the dolly when taking regular videos.
- 4. Put the included rubber band around Spinpod to keep it clean.


## DIMENSION & TECH SPECS

Weight and Dimensions

Diameter: 3.75 inches (95 mm)

Depth: 0.7 inches (18mm)


Weight: 3.3 ounces (92 grams)



Dock

2.5 inches x 0.5 inches (64mm x 13mm)

Fits iPhone 4s, 5 and most android phones



Mounting adapter

Mounting adapter (included) for cameras and landscape mounts




3.75 IN.

MOUNTING ADAPTER

Power source

Built-in rechargeable battery





Battery Life

Panoramic mode: 10 hours (~2000 panoramic photos)

Time-lapse mode: 100 hours

UΙ

Capacitive touch buttons and multicolor LEDs

Mounting

Tripod threading on bottom for mounting



TRIPOD THREADING

### WARNINGS

- Do not over tighten thumb-wheel.
- Do not over tighten the mounting adapter.
- Do not leave the Spinpod charging overnight.
- Do not manually rotate the Spinpod disk.
- Avoid water entering internal structure of Spinpod. If it does, turn off immediately and let sit for 48 hours.

## TROUBLES HOOTING

- Ball-head mount is not fitting on dolly:
  - o Make sure the ball-head mount has a  $\frac{1}{4}$ " thread adapter installed and remove the left and right  $\frac{1}{4}$ "-20 bolts from the dolly body.
- Dolly loses contact with ground and stops moving:
  - o Make sure the center of mass of the Dolly System and camera is centered over the wheel being driven by the Spinpod. You can also wrap a rubber band around the driving wheel to increase grip with the ground.
- Smart phone does not fit into Spinpod dock:
  - o Use a Landscape Mount (sold separately through www.thespinpod.com or Amazon) with the included mounting adapter to mount larger phones and devices.

## FA0

- Where can I buy Spinpod Accessories?
  - o www.thespinpod.com
- What dollies does the Spinpod Dolly Mount work with?
  - o Currently the Dolly Mount only works with the dolly sold in our shop and the dolly from iStabilizer. Contact us for tips on mounting Spinpod on other dollies.
- How do I pan and tilt with Spinpod?
  - o Using the Spinpod L-Bracket (sold separately) you can attach 2 Spinpods to produce pan + tilt time-lapse photography.