

ROAD HOG™ & ROAD HOG™ FULL BOAR

Quick Start Guide

Wholehog Compatibility

Road Hog and Road Hog Full Boar console show files are completely compatible with show files programmed on any Wholehog control system console, but NOT compatible with older Wholehog 2 systems. Since the Road Hog console uses the standard Wholehog control system, you can refer to the Wholehog User Manual (<http://www.flyingpig.com/support/hog3/manuals/>) for detailed software information.

The User Manual is available in several languages and is also accessible within the Wholehog software by pressing the Help key located within most windows as well as the upper left corner of the right touchscreen.

Patching

The Wholehog application pre-configures the Road Hog console's four internal DMX outputs, mapping them to the first four DMX outputs of DP #1 in the Wholehog control system. The Wholehog software utilizes one "virtual" DP when patching to these four outputs. Road Hog Full Boar utilizes two virtual DPs for its eight DMX outputs. Refer to the Wholehog user manual or help system for details on patching fixtures to a DP for DMX output.

Trackball Preferences

Changes made to the pointer mode for the trackball in the **Preferences** window regarding the bottom two buttons will be ignored by the Road Hog console. They will always behave as left and right click options when in pointer mode. These buttons can still be modified when in ball mode.

Shutting Down the Console

To exit the show file, press **Setup** then **Quit**. A dialog appears with the following options:

- **Shut Down** quits the application and shuts down the Road Hog console.
- **Restart Console** reboots the Road Hog console.
- **Log Off** exits the current show and returns to the Wholehog start screen.
- **Cancel** cancels the exit procedure.

Timecode Input

The Road Hog console supports one input of timecode in a SMPTE format via the optional USB LTC Widget. Road Hog Full Boar has direct SMPTE input on the back panel of the console. Other timecode formats available with the Wholehog control system are not available with the Road Hog console.

Desklights

You can adjust the brightness of the desklights by holding down the **Setup** key and adjusting the third parameter wheel. By default, the desklights are on while the console is being used and turn off after a period of inactivity; the period is determined by the **Desk and Worklight Off** setting in the **Appearance** pane of the User Preferences window. You can also use the fourth (right hand) wheel on the front panel to adjust the LED brightness.

Worklight

The front white worklight of the Road Hog console provides illumination of paperwork and the table surface. You can adjust the brightness of the worklight by holding down the **Setup** key and adjusting the second wheel. By default, the work light is on while the console is being used and turns off after a period of inactivity; the period is determined by the **Desk and Worklight Off** setting in the **Appearance** pane of the User Preferences window. The worklight can also be quickly toggled On or Off by pressing **PIG+Setup**. The blue side marker lights on the front of the console are always on when the console is powered on.

Setting up the Console

Unpacking

Road Hog™ and Road Hog™ Full Boar consoles ship with the following components:

- Console, with two LED desk lights and desk cover
- European and Edison power cords
- 1GB USB Flash Drive inserted in top of console
- End cap for USB Flash Drive

Road Hog Full Boar consoles include these additional items:

- 2 VGA to DVI adaptors
- Full Boar Road Case

If you find components missing or damaged, notify both the shipping agent and the sales agent immediately. Before sending anything to the factory, call your High End Systems dealer/distributor for a Return Material Authorization (RMA) number.

The factory cannot accept any goods shipped without an RMA number.


| Road Hog and Road Hog Full Boar Consoles and Accessories | |
|--|----------|
| Road Hog Console | A2020001 |
| Road Hog Full Boar Console * | A6020001 |
| Road Hog Road Case | A2070001 |
| USB Flash Drive | 90903025 |
| USB LTC Widget | 61040028 |
| USB Playback Wing | 61040039 |
| USB Expansion Wing | 75020001 |
| USB Hub | 61040035 |
| DP2000 * | 61040035 |
| 17" USB TouchScreen monitor * | 61040021 |

* For Full Boar Console only

Configuring the Console

Hardware Configuration

As part of setting up your Road Hog console, you may want to calibrate the touchscreens and set the time and date. These and other hardware settings are configured in the software's **Control Panel**. For information on other hardware settings, see the *Wholehog User Manual*.




Setting Time and Date

Selecting the **Time and Date** tab of the **Control Panel** displays dialog boxes to set the time, date, and time zone as well as daylight savings options. After making needed adjustment, press **OK** to **Apply**.

Calibrating Touchscreens

Select the **Displays** tab of the **Control Panel** then, Press the **Calibrate Touchscreen** button. A screen with directions to touch a target at each corner of the monitor screen will appear. After the first touchscreen calibration is completed, the calibration screen closes and calibration of the second screen begins. The calibration will terminate if no touch is received on the screen within 10 seconds.




Hardware Diagnostics

When the **Control Panel** is launched from the Start screen, a Diagnostics tab allows you to access tools for several functional categories. These tests are primarily for use by authorized HES technicians. For further details email support@flyingpig.com.

Road Hog Information

The System Info tab of the **Control Panel** displays important version information for this Road Hog console. Note: You will need the information on this screen whenever contacting High End Systems for support.



ROAD HOG™ FULL BOAR



System Restore

The Road Hog system restore routine allows reinstallation of the software from a location on the internal hard drive or from external USB drives.

System Restore from Internal Drive

The Road Hog console includes a system restore routine that can restore the original software and XPe image on the console. A protected partition on the hard drive stores the files needed to create a clean restore of the Road Hog console software. Newer versions of software may be available at www.flyingpig.com. To restore your system files from the hard drive, you'll need a USB Keyboard.

Using the Road Hog System Restore Image

1. Connect a keyboard to the console.
2. As the system boots up, press any key on the keyboard when the boot manager screen is displayed. **Note: This screen is displayed for only one second during the boot process.**
3. Select **Road Hog System Restore** from the boot manager screen and press Enter on the keyboard. **Note: Selecting Road Hog Console will boot the console normally.**
4. A recovery screen will prompt you to select a Partial recovery or Exit. **Note: The partial recovery process will reinstall the XPe image and the Wholehog software without erasing your show files.**
5. The console immediately begins drive restoration. The process may take anywhere from 10-15 minutes, and will automatically reboot your console when finished. Do not touch any keys or attempt to interrupt the restore process. If the process is interrupted for any reason, simply reboot and return to Step 1 to ensure the Road Hog console is completely restored.

System Restore from USB Drive

The Road Hog console system restore routine can restore the original software or upgrade the XPe image from external USB drives (Flash, CD, ZIP, etc). Newer versions of software may be available at www.flyingpig.com. To restore your system files, you'll need a USB keyboard and a Road Hog System Restore image on a USB drive (flash, CD, or Zip drive) **Note: The image must be an ISO image properly extracted to a CD or bootable flash drive. Instructions on creating a bootable flash drive follow.**

Using the Road Hog System Restore Image

1. Connect a keyboard and your USB drive containing the System restore image.
 2. As the system boots up, press F8 on the keyboard to display the boot device selection screen.
 3. Select the USB device that contains the system restore image from the list.
 4. A recovery screen will prompt you to select a Full or Partial recovery. A full recovery will erase the show files on the hard drive and a partial will not.
- CAUTION: The Full recovery process will remove ALL data from the Road Hog hard drive including show files.**

The partial recovery process will reinstall the XPe image and the Wholehog software without erasing your show files.

5. The console immediately begins drive restoration. The process may take anywhere from 10-15 minutes, and will automatically reboot your console when finished. Do not touch any keys or attempt to interrupt the restore process. If the process is interrupted for any reason, simply reboot and return to Step 1 to ensure the Road Hog console is completely restored.
6. Once the system is restored and rebooted, remove the System Restore USB drive and store in a safe place.

Restoring Touchscreen Configuration after a Full Restore

- Following the completion of a full system restore process, use the following steps to calibrate the touchscreens.
1. Navigate to the **Displays** tab in the **Control Panel**.
 2. Press the **Calibrate Touchscreens** button and follow the on-screen instructions.
 3. Press **Setup -> Quit** then select **Shutdown**. Once shutdown, reboot the console to confirm the screens are calibrated.

Creating a Bootable USB Flash Drive

The Road Hog console system restore routine also contains a utility to create bootable USB flash drives with or without a restore image.

CAUTION: This process will remove ALL files from the USB flash drive.

To create a bootable USB flash drive, you'll need: a Road Hog System flash drive or other bootable capable flash drive greater than 500 MB and a USB Keyboard.

Using the Road Hog System Restore Utility

1. Connect a keyboard and make sure the bootable USB flash drive is not connected to the console.
2. As the system boots up, press any key on the keyboard when the boot manager screen is displayed. **Note: This screen is displayed only for one second during the boot process.**
3. Select **Road Hog System Restore** from the boot manager screen and press Enter on the keyboard. **Note: Selecting Road Hog Console will boot the console normally.**

4. The recovery screen will be displayed; at the bottom of the screen select the button labeled *Create bootable flash drive*.


5. Insert the USB flash drive and select it from the drop down list to make bootable.
6. To place the current XPe image from this Road Hog console on the flash drive, select the check box labeled *Add restore files to the flash drive*.

7. Press **Select** to create the USB bootable flash drive image.
8. When complete, select **Exit** from the restore screen to boot the console.

CAUTION: The Full recovery process will remove ALL data from the Road Hog hard drive including show files.

Monitor Controls

On Screen Display (OSD) menu control buttons are located on the top of the console above each monitor screen. Use these buttons to access the OSD menu system's monitor controls.



- Displays and exits the OSD Screen
- Navigates the OSD options clockwise and increases value of a selected OSD control option
- Navigates the OSD options counterclockwise and decreases value of a selected OSD control option
- Auto centers screen when OSD screen is not displayed.
When the OSD screen displayed, use SEL to select an OSD control option and then select the option value you choose

To adjust an OSD option:

1. Press the **MENU** button to display the OSD Menu.
2. Press the **UP** button or the **DOWN** button to navigate to a OSD control option.
3. When the function you want to change is displayed, press the **SELECT** button.
4. To adjust the Value of the function:
5. Press the **UP** button increases the value of the selected OSD control option.
6. Press the **DOWN** button decreases the value of the selected OSD control option.
7. After adjusting the values, press the **SELECT** button again and the monitor automatically saves the changes.

OSD Control Option Descriptions

| | |
|------------------------|---|
| Contrast | adjusts the contrast or the values of color gain (RED, GREEN or BLUE) |
| Brightness | adjusts the background Luminance of the LCD panel |
| V-Position | adjusts the display window vertically on the screen |
| H-Position | adjusts the display window horizontally on the screen |
| Recall Defaults | resets the factory OSD default settings. |
| RGB | selects Color Temperature and sets R, G, B gain. |
| Volume | (not used) |
| Sharpness | adjusts the color intensity and tint |
| Phase | (not used) |
| Clock | (not used) |
| OSD H-Position | positions the OSD menu screen horizontally in the monitor display |
| OSD V-Position | positions the OSD menu screen vertically in the monitor display |
| OSD Timeout | adjusts the amount of time in which the OSD will disappear |
| Auto Adjust | automatically refreshes the screen and exits the OSD |
| Language | chooses between English, French, German, Spanish and Japanese for OSD |
| Info | displays the current monitor resolution and refresh rate |

Note: The OSD screen will disappear if no input activities are detected for 45 seconds.

Troubleshooting

The table below describes basic troubleshooting for the Road Hog console hardware. For software troubleshooting, refer to the Wholehog User Manual or on-line help.

If a problem persists after you try the suggestions listed in the following table, contact High End Systems Support at 800.890.8989 or support@flyingpig.com.

| Problem | Suggestion(s) |
|--|---|
| The console does not boot | Check that the AC power switch at the back of the console is ON. Press the power button to boot the console. |
| No DMX output | Check that fixtures are properly patched Turn the AC power switch at the back of the console to OFF, wait 10 seconds and turn it back on. Look for DMX indicators on fixtures or with a DMX tester. |
| No Timecode Input | Check that timecode is properly enabled and that the USB LTC widget is properly connected. Turn the AC power switch at the back of the console to OFF, wait 10 seconds and turn it back on. Confirm timecode source is valid with a timecode tester. Confirm the Grand Master fader (usually master #1) is up. |
| No intensity control on fixtures | Confirm the master for the cue list is up. If fixtures are in the programmer or editor, turn off the Blind function. Check to ensure intensity values are not parked. |
| The software has frozen or quit unexpectedly | Press Pig + Open + Backspace to open the Launched Processes window and kill processes that are not responding by right clicking on them and selecting Kill. Then restart the process by right clicking and selecting Restart. |
| The process window will not open after the software has frozen or quit unexpectedly | Press and hold the power button located on the top of the console for 10 seconds to reboot the console. |

Cleaning the Road Hog Console and Touchscreens

To clean the console and touchscreens, use only a soft cloth damped with water. Glass cleaner or other solvents will dull the finish of the console. **Do not** use alcohol (methyl, ethyl or isopropyl) or any strong solvent. **Do not** use thinner or benzene, abrasive cleaners or compressed air. Do not wipe the screens with a cloth or sponge that could scratch the surface.

Upgrading the Wholehog Application



The Wholehog control software is being upgraded continually and it is likely that there is a newer version available. You can find the latest versions at the Flying Pig Systems website (<http://www.flyingpig.com/support/hog3/downloads/index.shtml>)

Refer to Section 37 of the Wholehog user manual for a description of how to upgrade the Wholehog application.

Copyright © 2008 by High End Systems, Inc.

Printed in the USA All Rights Reserved. Information and specifications in this document are subject to change without notice. Certain specifications may be the result of future software releases. High End Systems, Inc. assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual.

Trademarks

High End Systems, the Flying Pig Systems logo, the WHOLEHOG, Road Hog and WHOLEHOG III logos are registered trademarks of High End Systems, Inc., or High End Systems, Europe Ltd. Flying Pig Systems, Effects Engine, and Hog are registered trademarks of Flying Pig Systems. Road Hog is a trademark of High End Systems, Inc. Windows is a registered trademark of Microsoft corporation. IntelliTouch, SecureTouch, AccuTouch, Entuitive, and MonitorMouse are trademarks of Elo TouchSystems, Inc.

All other brand names and product names used in this book are trademarks, registered trademarks, or trade names of their respective holders.

Warranty Information

Limited Warranty: Unless otherwise stated, your product is covered by a one year parts and labor limited warranty. It is the owner's responsibility to furnish receipts or invoices for verification of purchase, date, and dealer or distributor. If purchase date cannot be provided, date of manufacture will be used to determine warranty period.

Returning an Item Under Warranty for Repair: It is necessary to obtain a Return Material Authorization (RMA) number from your dealer or point of purchase BEFORE any units are returned for repair. The manufacturer will make the final determination as to whether or not the unit is covered by warranty.

Any Product unit or parts returned to High End Systems must be packaged in a suitable manner to ensure the protection of such Product unit or parts, and such package shall be clearly and prominently marked to indicate that the package contains returned Product units or parts and with an RMA number. Accompany all returned Product units or parts with a written explanation of the alleged problem or malfunction. Ship returned Product units or parts to: High End Systems, 2105 Gracy Farms Lane, Austin, Texas 78758.

Note: Freight Damage Claims are invalid for products shipped in non-factory boxes and packing materials.

Freight: All shipping will be paid by the purchaser. Under no circumstances will freight collect shipments be accepted.

REPAIR OR REPLACEMENT AS PROVIDED FOR UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. HIGH END SYSTEMS, INC. MAKES NO WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO ANY PRODUCT, AND HIGH END SPECIFICALLY DISCLAIMS ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. HIGH END SHALL NOT BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGE, INCLUDING LOST PROFITS, SUSTAINED OR INCURRED IN CONNECTION WITH ANY PRODUCT OR CAUSED BY

PRODUCT DEFECTS OR THE PARTIAL OR TOTAL FAILURE OF ANY PRODUCT REGARDLESS OF THE FORM OF ACTION, WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE, AND WHETHER OR NOT SUCH DAMAGE WAS FORESEEN OR UNFORESEEN.

Warranty is void if the product is misused, damaged, modified in any way, or for unauthorized repairs or parts. This warranty gives you specific legal rights, and you may also have other rights specific to your locality.

Product Modification Warning

High End Systems products are designed and manufactured to meet the requirements of United States and International safety regulations. Modifications to the product could affect safety and render the product non-compliant to relevant safety standards.

Mise En Garde Contre La Modification Du Produit

Les produits High End Systems sont conçus et fabriqués conformément aux exigences des règlements internationaux de sécurité. Toute modification du produit peut entraîner son non-conformité aux normes de sécurité en vigueur.

製品変更に対する警告

High End Systems 製品はアメリカ合衆国及び、国際安全基準の必要条件を満たすよう設計及び製造されています。この為、製品に対する変更是安全に対して影響を及ぼす場合及び、関連安全基準に満たない状態にする場合があります。

Produktmodifikationswarnung

Design und Herstellung von High End Systems entsprechen den Anforderungen der U.S. Amerikanischen und internationalen Sicherheitsvorschriften. Abänderungen dieses Produktes können dessen Sicherheit beeinträchtigen und unter Umständen gegen die diesbezüglichen Sicherheitsnormen verstößen.

Avvertenza Sulla Modifica Del Prodotto

I prodotti di High End Systems sono stati progettati e fabbricati per soddisfare i requisiti delle normative di sicurezza statunitensi ed internazionali. Qualsiasi modifica al prodotto potrebbe pregiudicare la sicurezza e rendere il prodotto non conforme agli standard di sicurezza pertinenti.

Advertencia De Modificación Del Producto

Los productos de High End Systems están diseñados y fabricados para cumplir los requisitos de las reglamentaciones de seguridad de los Estados Unidos e internacionales. Las modificaciones al producto podrían afectar la seguridad y dejar al producto fuera de conformidad con las normas de seguridad relevantes.