



PRIMAR Chart Catalogue

User Manual

Document date:02.06.14
Ed. 4.7.3

**PRIMAR Chart Catalogue is developed by Electronic Chart Centre,
and used by customers of the PRIMAR services.**



1.0 PRIMAR CHART CATALOGUE.....	4
1.1 THE TOOL AND ITS USERS	4
1.2 SPECIFICATIONS	4
1.3 SECURITY.....	4
1.4 SUPPORT	4
2.0 START UP.....	5
2.1 THE APPLICATION.....	5
2.2 PROCESS.....	5
2.3 PROXY SETUP	6
2.4 UNINSTALL PRIMAR CHART CATALOGUE.....	7
3.0 DESCRIPTION OF PRIMAR CHART CATALOGUE	8
3.1 FILE MENU	8
3.2 MAP VIEW	9
3.2.1 TOOLBAR IN THE MAP VIEW	9
3.2.2 ENC VIEW.....	10
3.2.3 ROUTE/AREA SELECTION	10
3.2.4 PICK A PRODUCT	10
3.2.5 INFORMATION MODE	10
3.2.6 SEARCH MODE.....	11
3.2.7 SHOW, USAGE BANDS, SELECTION AND INFORMATION	13
3.3 BASKET VIEW.....	14
3.3.1 TOOLBAR IN THE BASKET VIEW	14
3.3.2 DESCRIPTION OF THE BASKET FILE	15
3.3.3 ADD/EDIT/DISABLE/ENABLE CUSTOMER AND LICENSEE (FOR DISTRIBUTORS)	17
3.3.4 QUOTATION/ORDER (FOR DISTRIBUTORS).....	27
3.3.5 EXPORT BASKET TO OTHER LICENSEES/COPY ORDER (FOR DISTRIBUTORS).....	33
3.4 REPORT VIEW (FOR DISTRIBUTORS)	35
3.4.1 QUERY	35
3.4.2 ORDER LIST	36
3.4.3 SALES GRAPH	36
3.5 STATUS VIEW (FOR DISTRIBUTORS)	37
3.5.1 QUERY	37
3.5.2 STATUS REPORT - ACTIVE	38
3.5.3 STATUS REPORT – EXPIRED	38
3.5.4 STATUS REPORT – MISSING IMO	39
3.5.5 STATUS REPORT – DISABLED.....	40

3.6 PRIMAR ONLINE SERVICE DESCRIPTIONS (FOR LICENSEES AND DISTRIBUTORS)	41
3.6.1 PRIMAR ONLINE USING ECDIS/ECS	42
3.6.2 PRIMAR ONLINE USING E-MAIL NOTIFICATION	42
3.6.3 PRIMAR ONLINE USING CHART CATALOGUE	43
<u>4.0 PRIMAR CHART CATALOGUE USER GUIDES:</u>	46
4.1 HOW TO ORDER ENCs AS A PRIMAR DISTRIBUTOR	46
4.2 HOW TO EXPORT BASKET TO OTHER VESSELS	47
4.3 HOW TO ACTIVATE PRIMAR ONLINE AND SUPPORT A LICENSEE	49
4.4 PRIMAR ONLINE – ENC UPDATING SERVICE FOR LICENSEES	52
4.5 HOW TO ORDER A WMS LICENSEE	58
4.6 HOW TO CANCEL AN ORDER	59
4.7 HOW TO ACTIVATE/DEACTIVATE AUTO RENEWAL	60
4.8 HOW TO AMEND THE BASKET WITHIN THE RENEWAL PERIOD	62
4.9 DESCRIPTION OF SERVICE RELATED E-MAILS	63
4.9.1 ORDER ENC	63
4.9.2 RENEWAL NOTIFICATION ENC	64
4.9.3 RENEWAL ORDER ENC	65
4.9.4 WEEKLY CD PERMIT	66
4.9.5 PRIMAR AREA OF INTEREST – NEW ENCs AVAILABLE	67
4.9.6 AUTO ORDER	68
4.9.7 ORDER WMS	69

1.0 PRIMAR Chart Catalogue

1.1 *The tool and its users*

This tool offers a number of opportunities, depending on the level of the user's agreement with PRIMAR or a PRIMAR distributor/partner.

A) A general user of PRIMAR Chart Catalogue will be able to:

- *view ENC coverage graphically*
- *choose between actual coverage/cell structure*
- *plan a route*
- *secure a detailed list of selected cells*
- *send orders to an authorised distributor*

B) Authorised ENC distributors will also be able to:

- *manage orders directly*
- *register new customers*
- *view orders*
- *produce quotations*
- *create sales reports*

D) Authorised licensees will be able to:

- *update the PRIMAR ENC folio by using PRIMAR Online*

All user information and folios in the PRIMAR Chart Catalogue are protected with a secure login functionality that ensures the authorized users full security of their customer and licensee information.

1.2 *Specifications*

To launch PRIMAR Chart Catalogue, see the specifications at <http://www.primar.org>.

1.3 *Security*

PRIMAR Chart Catalogue uses a secure ID system for secure login to its services.

1.4 *Support*

For support or comments on PRIMAR Chart Catalogue:

E-mail: support@ecc.no

Telephone: +47 51 93 95 00


2.0 Start up

2.1 The application


The user will find specifications on how to start the application at <http://www.primar.org>, or on the weekly PRIMAR Update CD.


2.2 Process

1. Start the application by using the description on the web or the readme.txt file on the CD.
2. The first time the user starts the application a security warning will be visible, with the statement: “You should only install and run this application if you trust **Electronic Chart Centre A/S** to make this assertion”:




3. The user will be asked to have PRIMAR Chart Catalogue integrated into the desktop environment. Depending on the version of Java the user has installed, one of the pictures below will show up:






4. The user will then be asked to update the catalogue file:



- A) Yes, download updated catalogue file from server:**
Download the latest version of the catalogue file from PRIMAR and store the file in the user's profile.
- B) No, use the current catalogue file:**
If the user has downloaded a catalogue file earlier this will always be used.
- C) Browse for a catalogue file on your computer:**
The user gets the opportunity to browse for the catalogue file on the local PC or the CD from PRIMAR.

2.3 Proxy setup

If your network uses a proxy for http or https you may have to set this up inside the Chart Catalogue to be able to log in. Please fill out the needed information in the preference dialogue and restart the Chart Catalogue.



2.4 Uninstall PRIMAR Chart Catalogue

If the user needs to uninstall the PRIMAR Chart Catalogue, please follow the instruction below:

1. Start menu (on your computer) -> Settings -> Control Panel
2. Java
3. General -> Temporary Internet Files -> Delete Files...
4. Make sure all check boxes are checked and click ok

3.0 Description of PRIMAR Chart Catalogue

3.1 File menu

New basket: Start new basket (not available when logged in).

Open basket: Open a basket that is saved on your computer.

Import permit: Import a csv or permit file into a basket

Import basket: Import a csv or permit file into a basket

Save basket: Save the basket on your computer

Save basket as: Save the basket on your computer

Export Basket: Export the basket to another file format

Preferences: specify where to store ENC's downloaded to cache in the PRIMAR Online service, and set size of route buffer used in route selection mode*

PRIMAR Online: Start login to PRIMAR Online

Search: start a search window, used to locate an ENC or an area requested, and add the ENC's to basket file.

Options: *Only available for authorised users for viewing basket files that are expired from subscription and view/enable disabled customers and licensees.*

Download Catalogue: Download an updated catalogue file from the Internet


Open Catalogue: Open an existing catalogue, saved on your computer.

Print: Print the view chosen.

Exit: Exit the application.

File	Help
<u>N</u> ew Basket	Ctrl-N
O <u>p</u> en <u>B</u> asket...	Ctrl-O
I <u>m</u> port permit...	
I <u>m</u> port basket...	
<u>S</u> ave Basket	Ctrl-S
<u>S</u> ave Basket as...	
E <u>x</u> port B <u>a</u> s <u>k</u> et	
P <u>r</u> eferences...	
P <u>R</u> IMAR Online...	
S <u>e</u> arch...	Ctrl-F
<u>D</u> ownload Catalogue...	
<u>O</u> pen Catalogue...	
<u>P</u> rint...	Ctrl-P
E <u>x</u> it	

* Preferences



3.2 Map view

The user can choose a folio in the map view by:










- planning a route using way-points
- selecting an area
- using the select mode to pick a product
- search for ENC names and titles

NB! When selecting a folio the user can choose the background map to show the actual coverage or the cell structure (see 3.2.2/3.2.5).

3.2.1 Toolbar in the map view



Menu description:

	Zoom in mode
	Zoom out mode
	Pan mode
	Select mode
	Route selection mode, buffer zone is set using file - preferences
	Information mode
	Search and add product to basket functionality
	Login to the PRIMAR Online service
	Provides the latitude and longitude at the position of the cursor in the graphic view.


NOTE!

In the select and zoom mode the arrow buttons can be used to “navigate” north/south and east/west in the map view.


If ENC information is turned on in select mode, the ENC name and title will be available in the ENC information list to the right.

To view more details about the ENC choose information mode and click on the map on the ENC you would like to get information about. Then choose the ENC name/title in the ENC information list, detailed information and a thumbnail of the ENC will be available in pop up box.

3.2.2 ENC view



Actual coverage



Cell structure

3.2.3 Route/area selection

To enter the area selection mode, the user can choose “select” mode by clicking on the select button. They then have the opportunity either to pick product by product, or to mark an area they want to view or order.


Click on “route selection” mode using the route button, and start entering your route using way-points, to deselect use “backspace” button on your keyboard. All selected ENCs will be listed in the basket view (see 3.3.2).

3.2.4 Pick a product


Use the select button and select a product by clicking on it with the left-hand mouse button – deselect by using the right-hand mouse button.

3.2.5 Information mode

Click on map to get product ID and name information about the ENC (1), to get detailed information click on the ENC name in the ENC information list (2);



1) [Press ESC to stop]




3.2.6 Search mode

Use file – search, or the binocular button to start the search functionality.

To find/locate and/or add an ENC to a basket the user can locate the area or the specific ENC by using (full name or parts of the names):


- cell name
- unit name
- cell title
- unit title
- names on the background map

The search option is available in both map and basket view.



Show on map

To view the requested ENC/area double click on the ENC/Unit/area, or right click and choose “show on map”. When choosing “show on map” in basket view, the view will automatically change to map.



Add to basket

When choosing “add to basket” the product will be added to the basket file, and the view will automatically change to basket view.

3.2.7 Show, usage bands, selection and information

Use the different options below to set some rules for the graphical view.

Show:

- All cells: show all cells in the service
- New cells: show new cells released after the set date
- Updated cells: show new cells updated after the set date
- Apply date setting: apply specified date filtering
- Show coverage areas: toggle coverage area display on/off

Usage bands:


- All: toggle all usage bands on/off
- Overview: toggle the overview band on/off
- General: toggle the general band on/off
- Coastal: toggle the coastal band on/off
- Approach: toggle the approach band on/off
- Harbour: toggle the harbour band on/off
- Berthing: toggle the berthing band on/off


Selection:

- Deselect all: deselect all cells selected by the user
- Show only selected cells: obtain a graphical view of the selected cells only
- Show only not selected: obtain a graphical view of the cells not selected

ENC Information:

When information mode is activated, product Id and name will be available in the ENC information box when clicking an ENC in the map view. By clicking on an ENC in the ENC information list more detailed information and a thumbnail of the ENC will be available.

When select mode is active, and the  is ticked on in the ENC information view, product Id and name will be available in the ENC information box when moving the cursor in map view.









3.3 Basket view

The basket view lists the selections made in the map view or from the add products list, and gives the user detailed information on the products selected.

3.3.1 Toolbar in the basket view



Menu description:


	Add products from a list, ENCs, ENC units or WMS
	Remove selected products from the list
	Login as a distributor
	Print
	Search mode/add to basket
	Login to the PRIMAR Online service

Note! An ENC is one cell based on normal S57 cell structure. A unit consists of several ENCs that is grouped together and determine a specific area for sale. When pointing on an Unit or an ENC in the list a tooltip will describe further product information.

The user also has different options in the file menu to:

- create a new shopping basket
- open a shopping basket file
- import a permit file
- save the current shopping basket file
- export the basket to another file format
- download an updated catalogue file from the server
- browse for a catalogue file
- print the content of the basket as a report

3.3.2 Description of the basket file



Product	Title	Usage Band	Price Band	Existing Subs...	Existing Qua...	Expire Date	Auto Renewal	New Quantity	Status
NO2A0404	Nordsjøen	General	Large					1	Order
NO2A2804	Norskehavet	General	Large					1	Order
NO2A2820	Malangsgrunnen	General	Large					1	Order
NO2A2836	Lopphavet	General	Large					1	Order
NO2A2852	Østhavet	General	Large					1	Order
NO2A3204	Norskehavet	General	Large					1	Order
NO2A3220	Norskehavet	General	Large					1	Order
NO2A3236	Trømsøflaket	General	Large					1	Order
NO2A3252	Nordkappbanken	General	Large					1	Order
NO2A3268	Skolpenbanken	General	Large					1	Order

Product

This column shows the product Id of the ENC's or the Id of the ENC units in the selected basket file.

Title

This column shows the name of the ENC's in the selected basket file.

Usage band

This column shows which usage band the ENC's belong to.

Overview

General

Coastal

Approach

Harbour

Berthing

Price band

This column shows the price band to which the ENC's belong:

1. Large cell
2. Medium cell
3. Small cell
4. Unit

Existing subscription

This column shows which type of subscription the licensee has chosen or holds.

Existing quantity

Quantity on valid subscription (PRIMAR web chart service, additional licenses)

Expiry date

This column shows the subscription expiry date (only for authorised users).

Auto renewal

This column shows the auto renewal status of each ENC cell. Each ENC cell can be activated/deactivated for renewal. The ENC cell with on auto renewal will always be renewed according to the latest expiry date on the active folio.

“On” indicates auto renewal

“Off” indicates no auto renewal.

New quantity

Specify new quantity to be ordered (PRIMAR web chart service, additional licenses)

Status

This column shows the status of the ENC's in the basket file.

Sort the basket view

By clicking on the different column headings in the basket view, you can change the way the views are sorted – ascending and descending by column.

Product information

By pointing at an ENC or a UNIT name the product information will be shown in a tooltip.

Product ▲	Title	Usage Band	Price Band
GB1001	Scotland - North		Unit
GB1003	England & Scotland - South &...		Unit
GB1007			Unit
GB1500			Unit
GB2008			Unit
GB2009			Unit
GB2010			Unit
GB2011			Unit
GB2012			Unit
GB2222			Large
GB3015			Unit
GB3016			Unit
GB3017			Unit
GB3018			Unit
GB4017			Unit
GB4019			Unit
GB4020			Unit
GB4053			Unit
GB4086			Unit
GB4087			Unit
GB4089			Unit
GB4090			Unit
GB4092			Unit
GB5008			Unit
GB5009	Scottish Harbours - Sullom Voe		Unit
GB5061	Scottish Harbours - Orkneys		Unit

Product ID: GB1003
 Title: England & Scotland - South & East
 ProductType: ENC unit
 Country: GB United Kingdom

 Cell Name: GB100001
 Title: English Channel to the Median Line - Western Entrance
 Usage Band: Overview
 Compilation scale: 325000

 Cell Name: GB100002
 Title: English Channel to median line
 Usage Band: Overview
 Compilation scale: 325000

 Cell Name: GB100004
 Title: North Sea - Farne Islands to Dover
 Usage Band: Overview
 Compilation scale: 750000

 Cell Name: GB100005
 Title: North Sea - Frigg Gas Field to Farne Islands
 Usage Band: Overview
 Compilation scale: 750000

Description of compilation scale (M_CSCL from S-57):

An area within which the data was originally compiled at a uniform scale. For example, it may define the scale of the paper chart from which the data was digitised.

3.3.3 Add/edit/disable/enable customer and licensee (for distributors)

When using the key button and secure login, the user interface in the basket view will be extended with more functionality.

A drop-down list with the distributor's customers and licensees belonging to the various customers will be displayed. The user can also add new or edit current customer/licensee, and disable customer and licensee.




Map	Basket	Report	Status
Distributor	PRIMAR Internal	Add	Edit
Customer	Demo	Add	Edit
Licensee	Vessel 1	Add	Edit

New customer:

Add

To add a customer, click the Add button, provide the required information by filling in the various fields, and click Save.



Customer Name	<input type="text"/>	Distributor	Datema Delfzijl BV
E-Mail	<input type="text"/>		
Contact Information			
Address	<input type="text"/>	Post Code	<input type="text"/>
City	<input type="text"/>	Country	<input type="text"/>
Phone	<input type="text"/>	Fax	<input type="text"/>
Comments			
<input type="text"/>			
		Save	Cancel

Customer name

This field identifies the individual or company with whom the distributor has signed the subscriber contract.

If the subscriber is a company, enter its name. If the subscriber is an individual (such as the private owner of a licensee), enter the person's name.

Address, postcode, city, country

These fields identify address details for the customer.

Phone, fax, e-mail, contact

These fields identify contact details for the customer. If PRIMAR Online e-mail notification is activated and e-mail is registered service information will be received.

Comments

This field is for your comments.

Edit button

To alter any of the information, click on the Edit button to return to the previous view. Remember to press the Save button in order to save changes.


New licensee:

Add

Click the Add button and enter the requested information.

There are two options to fill in information in the licensee card:

1. Type in the IMO number – choose “tab” and the mandatory licensee details fields will be filled in automatically.
2. Type in information manually




IMO number

Enter the licensee's IMO number; the number must consist of seven digits with the prefix IMO. Registration of IMO number is mandatory for applicable licensees.

Licensee name

Please enter the name of the unit which will be using the PRIMAR service. This will typically be the name of the ship using the service, but may equally be the location of the shore establishment.

Customer name

Information of the licensee’s customer name Note! Customer group can be changed by using the following button , and choose customer group from drop down menu.

Call sign

The licensee’s unique call sign.

Tonnage/flag/category/year built:

Clicking the tonnage, flag or category field activate a drop-down menu providing various choices. Click on the arrow to the right of the field and make a selection. Remember to click on the Save button to save the data entered.

PRIMAR will use this information to analyse the profile of typical customers. Together with the national location of subscribers, this will help the service to target its promotional activities more carefully – deciding which journals should be used for advertising in terms of their readership profiles, and so forth.

Contact

Please fill in the contact information.

E-mail


Please enter the licensee e-mail address, if PRIMAR Online e-mail notification is activated; full and update ENC dataset will be sent to this address.

Phone

Please enter a phone number.

Area of interest

Area of interest is a possibility for the distributor to get information about new ENCs available in specified areas for licensees. The new ENCs in the specified areas can also be automatically ordered if wanted.




Area

List the 10 predefined areas which can be selected as area of interest, and auto ordered if chosen as a selected area.

Country

List all the countries/and specified areas within a country which can be selected as area of interest, and auto ordered if chosen as a selected area.



Selected

If area/country is active the distributor will receive an e-mail when new ENC's in the area is available on the PRIMAR ENC service.

Auto order

If auto order is selected new ENC's (available from the date of activation) in the selected area will be automatically ordered. An order e-mail will be sent.


For more information about the "Area of interest e-mails" (see chapter 4.5).

Area of interest in map view

When an area is selected "Show area of interest" (1) will be available as an option in the selection menu in map view.

This option will highlight (2) all ENC's available in the selected area.

Note! If Auto order is active the new ENC's in the selected area will be automatically ordered, if this is not active the ENC's needs to be selected using standard selection tools in map or basket view. To view the new ENC's open the licensee in the PRIMAR Chart Catalogue, and identify the ENC's using map view and the selection show area of interest, use this function together with **Show** and view **New cell** according to a date setting.



Comments and Options

The screenshot shows the 'Add Licensee' dialog box with the 'Comments & Options' tab selected. The breadcrumb path is 'License \ Area of Interest \ Comments & Options \ ECS/ECDIS \'. The 'Comments' section contains a large empty text area. Under 'Licensee Options', 'PRIMAR Online e-mail notification' is unchecked and 'Weekly Permit' is checked. 'Save' and 'Cancel' buttons are located at the bottom right.

Comment

Please enter any comments.

Licensee options

PRIMAR Online e-mail notification

Activate/deactivate PRIMAR Online e-mail notification service for the licensee.

Weekly Permit

Activate/deactivate permit distribution in relation to PRIMAR CD service.

ECS/ECDIS

The screenshot shows the 'Add Licensee' dialog box with the 'ECS/ECDIS' tab selected. The breadcrumb path is 'License \ Area of Interest \ Comments & Options \ ECS/ECDIS \'. Below the breadcrumb is a dropdown menu labeled 'ECS/ECDIS' and three buttons: 'Add', 'Edit', and 'Delete'. 'Save' and 'Cancel' buttons are located at the bottom right.

ECS/ECDIS

Please enter the ECS/ECDIS information.

Add

Add ECS/ECDIS information (after the ECS/ECDIS information has been saved).


Edit

Edit ECS/ECDIS information.


Delete

Delete ECDIS


Edit licensee:



Note!

- The ECS/ECDIS cannot be registered until the licensee details have been saved. Once that is done, click on the Add button in the main view to add ECS/ECDIS information.
- Customer group can be changed by using the following button , and choose customer group from drop down menu.

Add ECS/ECDIS



User permit

This field defines the 28-character code which uniquely identifies the equipment system the end-user will be using. Without this information, PRIMAR cannot generate any of the cell permits which allow the end-user to decrypt their ENC cells.

The manufacturer of the end-user's system will supply this code when the system is purchased.

Four backup systems with different user permits can be registered in addition to the end-user's main system. When an order is completed, permits will automatically be sent to the registered main and backup systems.

Name

Please enter the unique description of the ECDIS. The navigator will use this description onboard to identify which ECDIS the received permit files belongs to.

Protection scheme

Dropdown including:

- PRIMAR Security Scheme
- IHO S63 v 1.0
- IHO S63 v 1.1

PRIMAR security scheme is set as default. Please choose the version the ECDIS/ECS system supports/requires.

Protection scheme	Certificate	permit.txt	enc.pmt	Data server code in permit
PRIMAR Security Scheme	Primar.crt	X	X	
IHO S63 v 1.0	IHO.CRT	X	X	
IHO S63 v 1.1	IHO.CRT	X		X

Function

Indicate if the registered user permit is for a main or backup system.


In order to comply with SOLAS chart carriage regulations, users wishing to utilise ENC and ECS/ECDIS, as their primary aid to navigation must also be running a suitable back-up system.

This will typically be a second ECDIS or ECS system installed on the same ship. The PRIMAR service supports such back up free of charge. If the registered end-user plans to use a back-up system on the same licensee, please follow the guidelines for Add ECS/ECDIS and check the Backup option.

Comments


An optional comment field.

Edit ECS/ECDIS




By choosing Edit ECS/ECDIS you can change the Name of the registered User Permit and Protection Scheme.

Delete ECS/ECDIS



The delete ECS/ECDIS button gives you the possibility to delete the registered ECS/ECDIS to the chosen licensee.

Disable customer/licensee





To disable customer or licensee in the PRIMAR Chart Catalogue choose the “Disable” button.


The disabled customer or licensee will be visible in the licensee status report, under the record for disabled.

NOTE! No information will be deleted or lost, the disabled licensee /customer can be enabled when necessary, ref instructions below or chapter 3.5.5.

Enable customer/licensee

To get information about disabled licensee and/or customer choose file – options – disabled.

A dialog box listing disabled customers or licensee is then available, and functionality to search, view information , and enable  chosen customer/licensee.



3.3.4 Quotation/order (for distributors)

A quotation must be run in order to place an order. The quotation will calculate the wholesale and retail price (only if price information has been defined by the distributor) based on the ENC's selected, and the subscription type/expiry date chosen to the ENC in the quotation.

Quotation/order process:

1. Start
2. Set retail price
3. Complete order

Step 1: Start

Quotation
Start - Set Retail Price - Complete Order

Welcome to the quotation wizard

Set Auto Renewal

On
 Off

Subscription Type

Subscription Type 12 months
 Expire date 31.12.2013

Additional Order Information

Reference Number
Additional E-Mail

Permit Handling

Default
 Generate permit for week
Select Week Year 2012, Week 52. Update

Back Next Cancel

Set Auto Renewal:

Auto Renewal on/of

Activate/deactivate automatic renewal of the ENC cells ordered.

On: will always be set as default, and when active will automatically auto renew the ENC's 14 days before expiry date.

Off: indicates deactivation of auto renewal, ENC(s) will not be automatically renewed.

Subscription Type:

Subscription type

Drop down list including all subscription types available for the ENC/WMS in the folio chosen.

Expire date

Specify an expiry date for the folio chosen.

Note!

Subscription type 12 months will always be set as default when first ordering an ENC to a licensee. When reordering the expiry date field will be set as default, and will automatic suggest the latest existing expiry date present in the current chart portfolio.

Additional order information:

Reference Number: distributor reference number used internally for instance towards accounting

Additional E-mail: register additional e-mail to receive permit information related to the order

Permit Handling

Default: standard permit generation

Generate permit for week: generate permit files for selected weekly CD

The screenshot shows a 'Quotation' wizard window with the following sections:

- Start - Set Retail Price - Complete Order**
- Welcome to the quotation wizard
- Set Auto Renewal**
 - On
 - Off
- Subscription Type**
 - Subscription Type: 12 months (dropdown menu)
 - Expire date: 31.12.2013 (calendar icon)
- Additional Order Information**
 - Reference Number: [text input]
 - Additional E-Mail: [text input]
- Permit Handling**
 - Default
 - Generate permit for week
 - Select Week: Year 2012, Week 52. Update (dropdown menu)
 - Year 2012, Week 52. Update
 - Year 2012, Week 51. Update
 - Year 2012, Week 48. Update
 - Year 2012, Week 50. Update
 - Year 2012, Week 49. Base

Buttons at the bottom: Back, Next, Cancel

Step 2: Set Retail Price

Product	Country	Subscription	Price band	Quantity	Wholesale p...	Retail Price	Wholesale D...	Wholesale T...	Retail Total
ENC	NO Norway	12 months	Large	8				0.00	0.00
Sum:								0.00	0.00
Margin(%):		0.00							

Currency: US Dollar

Preview Export... Back Next Cancel

This option allows ENC/WMS suppliers to enter a margin in % in the Margin field or set a price in the retail total, and display and create reports on retail price.

Reports for retail price and wholesale price will be available in the Report view for each individual order.

Preview

View the retail price report, which can be exported to Excel, PDF, CSV and HTML files

Export

Export the retail price report (PDF and XLS)

Step 3: Complete Order

The screenshot shows a 'Quotation' window with the following details:

- Quotation** (Title bar)
- Start - Set Retail Price - **Complete Order** (Progress indicator)
- Distributor**
 - Distributor name: Datema Delfzijl BV
- Customer**
 - Customer name: Spliethoff
 - Licensee name: HAPPY DIAMOND
- Elements**

Product	Subscription type	Price band	Permit end date	Amount	Price	Wholesale Disco...	Wholesale ...
ENC	12 months	Large	31.des.2013	8		0.00	
Sum:						0.00	
- Currency: US Dollar
- Navigation buttons: Back, Next, Cancel (The 'Back' and 'Next' buttons are circled in red).

Distributor name

Displays the distributor name for the active basket file.

Customer name

Displays the customer name for the active basket file.

Licensee name

Displays the licensee name for the active basket file.

Elements in the quotation


Product and price information are assembled from the basket file and subscription type or expiry date is set in the quotation process. On the basis of these data, the amount and price are calculated to obtain the wholesale price for the total selection of ENC's.

If the quotation is accepted, press the Order button to commit the order for the selected products. This will save the selection and update the chart portfolio. The status should now have changed from Order to Valid. When the order is committed, the user will receive an e-mail which includes permit files for the ENC's in a portfolio. If ordering the WMS product an e-mail including an URL to be used in the WMS client and username/password to get access to the service is sent.

The order will be automatically registered at PRIMAR, and an invoice sent the distributor.

NOTE!

The following warning will appear if an ECDIS/ECS system has not been registered with a User Permit during licensee registration (ref Edit Licensee in section 3.3.3):



Continue:


Continue the order process, but no permit files will be created due to missing User Permit.

Cancel:

Cancel the order process, choose edit licensee and add User Permit to continue the order process and generate permit files.

Finish:


Press finish to end the order process




The window above will appear when the order has been successfully completed. The order number will appear in all reports and invoices from PRIMAR. Press the finish button to complete the order.

3.3.5 Export basket to other licensees/copy order (for distributors)

The purpose with this functionality is to export and order a user's folio to other licensees or customers.




Step 1: Select




Select customer group or licensees.

Step 2: Options



View amount of ENC's in the basket, option to set subscription type according to your licensee's chosen.

Step 3: Complete order



Orders are being processed, and order e-mails will be sent. For details about the orders done see order list in report view.

3.4 Report view (*for distributors*)

3.4.1 Query

In the report view, the user will be able to raise queries concerning licensees, customer and distributor level within a specific period of time.

The result of the query is a detailed order list, including invoice detail reports for retail price and wholesale price and a sales graph presenting transactions in the service. This means that only processed orders will be displayed in the report and sales graph.

Please note: the information in the report view does not present the selected information in the same way as it appears in the basket view – the user must select the information from the drop-down lists in the report view.

Print options: to print out information from the report view, select File and Print.

Distributor:

Drop-down list of distributors. Note that a distributor will only be able to see his customers and licensees.

Customer:

Drop-down list of customers for the selected distributor.

Licensee:

Drop-down list of licensees for the chosen customer.

From:

Year/month.

To:

Year/month.

Query:

Ask the database for order/sales information relating to the information selected in the drop-down lists and within the specified time period – the product of the query will be a detailed order list and a sales graph.

3.4.2 Order list

The order list displays all registered orders, depending on the level (distributor, customer or licensee) at which the query is run. If you select a distributor and then customer = all and licensee = all, the resulting order list will show all the orders executed by the selected distributor. If you select a distributor and a customer, and licensee = all, the resulting order list will show all the orders executed for the selected customer.

Order ID

A unique ID for a specific order, generated automatically by the system.

Date

Date of the order.

Distributor

Lists the name(s) of the distributor(s) specified by the user from the drop-down list.

Customer

Lists the name(s) of the customer(s) specified by the user from the drop-down list.

Licensee

Lists the name(s) of the licensee(s) specified by the user from the drop-down list.

Products

Indicates the number of cells in the order.

Total

Indicates the total wholesale price for the order in USD.

Credit date

Date of the credit invoice.

Retail order details

This function views a detailed report containing invoice details. This document is opened in a viewer, and allows the user to print or save the report. The price indicated in the report is the *retail price* in USD from the data supplier.

Wholesale order details

This function views a detailed report containing invoice details. This document is opened in a viewer, and allows the user to print or save the report. The price indicated in the report is the *wholesale price* in USD from PRIMAR.

3.4.3 Sales graph

The sales graph gives the user a graphical view of sales in USD for each licensee per month in unique colour codes by distributor, customer or licensee, depending on the selection criteria chosen when raising the query.

3.5 Status view (*for distributors*)

3.5.1 Query

In the licensee status view, the distributor is able to get information on licensees which have an active subscription, licensees with expired subscription, licensees with missing IMO numbers and disabled licensees.

Distributor

Name of the distributor.

Customer

Choose the name of a specified customer or all

Licensee

Choose the name of a specified licensee or all

Choose “**query**” to do a request on the settings above.

Active:

Will show a list of licensees with active ENC subscription for the service, meeting the query parameters.

Expired:

Will show a list of licensees where the subscription has expired. There is a shortcut in the list to disable a licensee.

Missing IMO:

Will show a list of licensees with active ENC subscriptions for the service but with missing IMO number registration. There is a shortcut in the list to the licensee card for immediate IMO number registration.

Disabled:

Will show a list of licensees which have been disabled from the ENC service. There is a shortcut in the list to re-activate a licensee to continue its ENC services.

Print options: to print out information from the licensee status view, select File and Print.

3.5.2 Status report - Active

Map \ Basket \ Report \ Status \

Distributor: PRIMAR Internal
 Customer: All
 Licensee: All

Query

Active \ Expired \ Missing IMO \ Disabled \

Distributor	Customer	Licensee	IMO Number	Next Expire	Last Online	To Basket
-------------	----------	----------	------------	-------------	-------------	-----------

Distributor

Name of distributor

Customer

List the customer(s) chosen

Licensee

List the licensee(s) chosen

IMO number

List the IMO number registered

Next Expire

The date for next expire date in the folio

Last Online

For PRIMAR Online customers, reports the date when the licensee last did a request for updates (not applicable for PRIMAR Online e-mail notification users).

To Basket

Go to basket for the selected licensee.

The user can sort the list by clicking the column headings.

3.5.3 Status report – Expired

Map \ Basket \ Report \ Status \

Distributor: PRIMAR Internal
 Customer: All
 Licensee: All

Query

Active \ Expired \ Missing IMO \ Disabled \

Distributor	Customer	Licensee	Licensee Category	IMO Number	Expired	Disable
-------------	----------	----------	-------------------	------------	---------	---------

Distributor

Name of distributor

Customer

List the customer(s) chosen

Licensee

List the licensee(s)

Licensee Category

View the licensee category registered

IMO Number

View the IMO number if registered

Expired

View date of expiration

Disable

Short cut to disable licensee

3.5.4 Status report – Missing IMO

The screenshot shows a software interface with a menu bar at the top containing 'Map', 'Basket', 'Report', and 'Status'. Below the menu bar are three dropdown menus: 'Distributor' (set to 'PRIMAR Internal'), 'Customer' (set to 'All'), and 'Licensee' (set to 'All'). To the right of these menus is a 'Query' button. Below the filters is a horizontal navigation bar with tabs: 'Active', 'Expired', 'Missing IMO', and 'Disabled'. The 'Missing IMO' tab is highlighted with a red circle. Below the navigation bar is a table header with columns: 'Distributor', 'Customer', 'Licensee', 'Licensee Category', 'IMO Number', and 'Edit'.

Distributor

Name of distributor

Customer

List the customer(s) chosen

Licensee

List the licensee(s)

Licensee Category

View the licensee category registered

IMO Number

Field empty

Edit

Short cut to edit licensee card for registering IMO number

3.5.5 Status report – Disabled

Map \ Basket \ Report \ Status \

Distributor: PRIMAR Internal

Customer: All

Licensee: All

Query

Active \ Expired \ Missing IMO \ Disabled \

Distributor	Customer	Licensee	IMO Number	Enable
-------------	----------	----------	------------	--------

Distributor

Name of distributor

Customer

List the customer(s) chosen

Licensee

List the licensee(s)

IMO Number

View the IMO number if registered

Enable

Short cut to enable licensee

3.6 PRIMAR Online service descriptions (for licensees and distributors)

1. PRIMAR Online using PRIMAR Chart Catalogue

PRIMAR Online is an integrated part of the PRIMAR Chart Catalogue, available to the licensee, for downloading of ENC's and permit files.

Each licensee utilises the PRIMAR Online service by using the PRIMAR Chart Catalogue to download a full ENC exchange set or an update ENC exchange set related to the CD service. Supported media like memory stick or CD is used to transfer the ENC's into the ECDIS/ECS for updating the portfolio of ENC data.

2. PRIMAR Online using e-mail notification

PRIMAR Online is also an e-mail service, easily administrated by the distributor using PRIMAR Chart Catalogue, for more effective distribution of ENC's to the end-users.

In this service the distributors include e-mail details in the customer or the licensee card, and activate the option *PRIMAR Online e-mail notification* in the licensee card.

The customer or licensee will regularly receive an e-mail including a link to a web page where a full ENC data set, an update ENC data set and permit files for the licensee will be available for download. Supported media like memory stick or CD is used to transfer the ENC's into the ECDIS/ECS for updating the portfolio of ENC data.

3. PRIMAR Online using ECDIS/ECS

PRIMAR Online can also be an integrated part of the ECS/ECDIS.

In this service the End-User have functionality in their ECDIS/ECS to directly interface and download ENC's and ENC permit files from PRIMAR.

Manufacturers can contact PRIMAR to receive copies of relevant interface protocols. The protocols support deliveries using http and e-mail communication.

Each licensee uses functionality in the ECDIS/ECS for updating its portfolio of ENC data.

3.6.1 PRIMAR Online using ECDIS/ECS

In this service the End-User have functionality in their ECDIS/ECS to directly interface and download ENC's and ENC permit files from PRIMAR.

How to do this is specified by the manufacturer.

3.6.2 PRIMAR Online using e-mail notification

In this service the customer or End-User will regularly receive an e-mail including a link to a web page where a full ENC data set, an update ENC data set and permit files for the licensee will be available for download.

The specified receiver will regularly receive an e-mail;

Dear

“LICENSEE”


ENC updates and belonging permits, according to your ENC license are now available.

Please use the following link to enter web page for download:

<https://services.ecc.as/qastable/vexport/37c28a22-5807-491d-a206-662b7378ed5a>

Your ENC distributor “NAME OF DISTRIBUTOR”

By choosing the link, the user will enter a web page where an update dataset and/or a full dataset including permit files for the licensee will be available for download:




3.6.3 PRIMAR Online using chart catalogue

The End-User can either register his User Permit by selecting File – Primar Online or pressing the globe button in the toolbar. He will then be requested to enter the 28 character User Permit for his main ECDIS system as shown below:



Pressing the globe button on the toolbar will activate the PRIMAR Online service:



When logged in as a licensee the basket window views a list of the licensee’s ENCs on valid subscription, and the map view shows the portfolio graphically.

Details

Distributor: the licensee’s distributor is listed

Customer: name of the customer is listed

Licensee: licensee name is listed

Valid subscriptions: number of ENC’s on valid subscription

Last successful download: a date telling when the last download was performed

Update


Chart system status: The user informs about ENC status on the chart system:

Last CD installed: gives the user a dropdown list – to choose the last **BASE CD** installed on the chart system

No installed CD: is chosen if no CD is installed in the chart system


Store the ENC exchange set locally: User browses to an area locally to store the ENC exchange set.


Check for updates: Check if new updates are available from the PRIMAR ENC service according to the licensees portfolio and chosen chart status.




Dialog boxes:

If updates are available the user will have this message, and continue to download by pressing OK:





If no updates are available since chosen CD, or last download the user will have the following message from the system:




NOTE:

Local cache:

First time a file is downloaded it will be stored both in ENC Root and Cache Root. Second time this file is needed in an exchange set, the local version in Cache Root will be copied to ENC Root, if not the central version of the file has been modified.

Cache Root must point to a folder with at least 2 GB of free disk space. The files in this folder shall not be used directly by end user, only as a local storage for the Chart Catalogue application. The files will be stored with cryptic filenames to avoid file name conflicts. If the 2 GB limit of disk space is reached, the Chart Catalogue will delete the files that have been inactive for the longest period.

File – Preferences can be used to define the location of the cache root.



For more detailed explanation on how to use these updating service see chapter 4, PRIMAR Chart Catalogue user guides part 4.3 and 4.4.

4.0 PRIMAR Chart Catalogue user guides:

4.1 How to order ENC's as a PRIMAR distributor

This chapter describes the process for ordering ENC's. Users will find more detailed explanations of the different product functions described in this documentation in the general user guide.

1. Start by logging in with the user name, pin code and Secure ID provided when signing the authorised distributor agreement.

Click on the key button to log in.




2. Use the drop-down menu in the basket view to select the customer and/or licensee for which cells are to be ordered. If this is a new customer/licensee, it must first be registered. See the general user guide for a detailed explanation of how to add/edit customer/licensee information.
3. Select the ENC's from the basket view or by route planning in the map view.
4. A quotation can now be run in the basket view on the selected folio. The status of the chosen ENC's will be Order.
5. To run the quotation, press the Quotation button. A quotation process can now be started including the following steps:
 - Start
 - Set retail price
 - Complete order

For details on how to proceed this process see *3.3.4 Quotation/order*.


The distributor will receive an ENC order e-mail when the order is processed containing the necessary permit files for the licensees subscription.

4.2 How to export basket to other vessels


1. Choose the user who has the folio you want to export
2. Choose copy order.




This will result in a list of all customers and users registered:




3. From the list pick the customer or users to whom you will export the folio



4. Choose next in the dialog box to continue the copy order process.
5. In the next dialog box the administrator will have the opportunity to set subscription type.



6. Continue with next and the order process will be done for all the users/customer.



7. Complete the process by pressing the finish button.

4.3 How to activate PRIMAR Online and support a licensee

This chapter describes the process for activating the PRIMAR Online options, some support information and how to handle an “emergency situation” where a licensee is not able to update his ENC folio. Users will find more detailed explanations of the different product functions described in this documentation in the general user guide.

1. All licensees registered with a valid folio have access to PRIMAR Online interface in the PRIMAR Chart Catalogue.
2. Licensees with systems which support PRIMAR Online using ECDIS/ECS will have access to all updates related to the valid folio.
3. Licensees using PRIMAR Online e-mail notification must be activated in the PRIMAR Chart Catalogue;

4.3.1 Activate PRIMAR Online e-mail notification

1. Start by logging in with the user name, pin code and secure ID provided when signing the authorised distributor agreement.

Click on the key button to log in.



2. Add/edit licensee

Open the licensee card and activate the PRIMAR Online e-mail notification option as shown below: An ECS/ECDIS system must be registered for the licensee.

Edit Licensee

License \ Area of Interest \ Comments & Options \ ECS/ECDIS \

IMO Number Customer name CNS Sweden AB

Licensee name 04975 Call sign

Licensee Details

Tonnage <500grt Category Miscellaneous

Year Built Flag Unknown

Contact Information

Contact

Email Phone

Save Cancel

Edit Licensee

License \ Area of Interest \ Comments & Options \ ECS/ECDIS \

Comments

Licensee Options

PRIMAR Online e-mail notification

Weekly Permit

Save Cancel

3. Add e-mail address

To be able to send e-mail notification including full and update ENC data set, an e-mail address must be added to the licensee card. The e-mail address registered in the licensee card will be the receiver of this information. If an e-mail is registered in the customer card this e-mail will be the receiver of this information.

4.3.2 Support PRIMAR Online using PRIMAR Chart Catalogue

- To test that the service is operative for the licensee the distributor can log into the service as the licensee using the user permit.
- When a licensee is registered for the service, please send information regarding the service as specified by PRIMAR to the end user.

- Customers using PRIMAR Online chart catalogue do not need update CDs and permits from the distributor, only **BASE CDs** needs to be sent the user by the distributor.
- Customers using PRIMAR Online e-mail notification do not need CD and permits distribution from the distributor
- Customers using PRIMAR Online in ECDIS/ECS do not need CD and permits distribution from the distributor
- Study chapter “**4.3 PRIMAR Online – ENC updating service for licensees**” to be familiar with the service.

4.3.3 Backup procedures PRIMAR Online using chart catalogue

If your customer reports an error when trying to connect to the PRIMAR Online service, or is unable to install the downloaded exchange set or permit files on their ECDIS/ECS:

1. Verify that the customer has a working internet connection.
2. Verify that the customer has installed the latest version of the PRIMAR Chart Catalogue.
3. Verify that the licensee user permit registered in the PRIMAR Chart Catalogue is identical with the licensee user permit installed on the ECDIS.
4. Verify that the customer has correctly configured all the parameter settings as described in the *PRIMAR Online Technical Guide* and the *PRIMAR Chart Catalogue User Manual*, which are both available on the PRIMAR web site.

Should the error/failure persist, adopt one of these two options:

1. Use the PRIMAR Online service

- a) Log onto PRIMAR Online using the licensee’s user permit.
- b) Download an exchange set based on information from the user about which Base CD is installed on the ECDIS/ECS.
- c) Burn the exchange set and permits files to a CD.
- d) Deliver the new CD to the customer.

2. Use PRIMAR CD service support

Use the PRIMAR Chart Catalogue to run a quotation and order new permits for the customer, and deliver the latest Base and Update CDs to them.

Alternatively, should your customer have an internet connection and sufficient bandwidth, they can download the latest Base or Update CD from the PRIMAR web site.

For more detailed procedure on using the PRIMAR Online service see next chapter “**4.3 PRIMAR Online – ENC updating service for licensees**”.

4.4 PRIMAR Online – ENC updating service for licensees

4.4.1 How to update ENC portfolio using PRIMAR Online e-mail notification

Sign up as a valid user:

Before you can start using this service you have to get your distributor to sign you up as a valid user. If PRIMAR Online e-mail notification has not been activated, and e-mail address is not set in the licensee card the user will not receive the service.

When the service is activated the licensee will receive an e-mail including a link to a web page where a full ENC data set, an update ENC data set and permit files for the licensee will be available for download;

Dear

“LICENSEE”

ENC updates and belonging permits, according to your ENC License are now available.


Please use the following link to enter web page for download:

<https://services.ecc.as/qastable/vexport/37c28a22-5807-491d-a206-662b7378ed5a>

Your ENC distributor “NAME OF DISTRIBUTOR”

How to process:

1. Choose the link received in the e-mail
2. Decide which dataset to download
3. Download the zipped file (update or full)
4. Unzip the file
5. Transfer the dataset and the permit files to your ECDIS/ECS



4.4.2 How to update ENC portfolio by using PRIMAR Online in the PRIMAR Chart Catalogue


NOTE (local cache):

First time a file is downloaded using this service it will be stored both in ENC Root and Cache Root. Second time this file is needed in an exchange set, the local version in Cache Root will be copied to ENC Root.

Cache Root must point to a folder with at least 2 GB of free disk space. The files in this folder shall not be used directly by end user, only as a local storage for the Chart Catalogue application itself. The files will be stored with cryptic filenames to avoid

file name conflicts. If the 2 GB limit of disk space is reached, the Chart Catalogue will delete the files that have been inactive for the longest period.

File – Preferences:



1. Start PRIMAR Chart Catalogue

2. Start PRIMAR Online:

- choose File menu and select PRIMAR Online...
- or the following button



If you have not agreed with your distributor to use this service you will get the error message; service not activated.


If you are registered as a valid user, but type in the wrong user permit you will get the error message; invalid user permit.

If your subscription has expired you will get the message; subscription expired. Contact your PRIMAR ENC distributor.


3. PRIMAR Online Login

Please enter/verify the 28-character code registered in the PRIMAR service, known as the “user permit”. Contact your system manufacturer for more information.

When downloading ENC’s the system also support for you to have more than one ECDIS on one ship – the user permit used **during login** is considered as the **main ECDIS**. The PERMIT.TXT file to this ECDIS is stored in the root folder. More details in part 8.




When identified a dialog box for PRIMAR Online will be available:



- When logged in you will be able to view your portfolio in the map and basket view.
- You will be able to use the map view in order to see new cells available since last update, by using the date filter.

3. PRIMAR Online user interface



1. Chart system status:

User indicates the status in the chart system

- choose from the drop down list which **BASE CD** from PRIMAR was last installed in the chart system
- choose no installed CD if no data from PRIMAR is in the chart system


2. Store the ENC exchange set locally

Browse to an area locally on the computer where you wish to store the ENC exchange set.


Please note that the folder needs to be empty.

3. Check for updates

Press OK and the system will check if new updates are available from the PRIMAR ENC service according to the licensee’s portfolio and chosen chart status.




4. If no updates are available since last download, the user will get this message:




Chose cancel to end the process, or OK if a new exchange set is needed from the local cache (meaning the ENCs which have been downloaded to your computer earlier)


5. If updates are available the user will have a message similar to this, depending on the amount of new ENCs available:



Chose cancel to end the process, or OK to continue to download the ENC exchange set containing updates to your portfolio:




6. Dialog box for download complete



The ENC exchange set, including **permit.txt** and **enc.pmt for main and backup systems**, is now downloaded to your computer.

7. Browse on your computer to the folder chosen for storage of the exchange set.




As in the picture above you can see that the **PERMIT.TXT** and **ENC.PMT** file is on the root level of the downloaded files. Please install these files in the ECDIS before you update the ENC's to your portfolio.

Transfer the data from your “planning station” to the ECDIS using the media available onboard, as USB, CD, local network.

If you have more than one ECDIS system registered onboard and in the PRIMAR Chart Catalogue, a folder for the PERMIT.TXT and ENC.PMT files for each ECDIS will be provided as shown below:

INFO\OTHER_PERMITS\'ECDIS NAME\'



NOTE!

Always install the latest BASE CD from your distributor, and use this as a request for updates. When a new base CD is received delete the content in the “cache” set in File – Preferences, as described, and start from scratch.

If you experience any problems with the ENC updating service contact your distributor.

4.5 How to order a WMS licensee

This chapter describes the process for ordering WMS. Users will find more detailed explanations of the different product functions described in this documentation in the general user guide.

1. Start by logging in with the user name, pin code and Secure ID provided when signing the authorised distributor agreement.

Click on the key button to log in.



2. Use the drop-down menu in the basket view to select the customer and/or licensee for which WMS are to be ordered. If this is a new customer/licensee, it must first be registered. See the general user guide for a detailed explanation of how to add/edit customer/licensee information. No User Permit is needed for WMS ordering.
3. Select the WMS product by clicking on the green plus button in the basket view.
4. A quotation can now be run in the basket view. The status of the chosen WMS products will be Order.
5. To run the quotation, press the Quotation button. A quotation process can now be started including the following steps:
 - Start
 - Set retail price
 - Complete order


For details on how to proceed this process see *3.3.4 Quotation/order*.

When ordering the WMS product an e-mail including an URL to be used in the WMS client and username/password to get access to the service is sent to the distributor.


4.6 How to cancel an order

This chapter describes the process for order cancellation. Please note the rules for order cancellation is set in the agreement between the chart supplier and NHS.


1. Log in to the PRIMAR Chart Catalogue
2. Go to report view
3. Choose the customer and licensee to which you want to cancel order
4. Select a period based on dates and do a query
5. Orders done in the period selected will be viewed:




6. If correct order is selected, choose the cancel order button at the end of the order line:



7. You will be asked to confirm the order cancellation by a dialog box:



8. Yes: the order will be cancelled and confirmed, and the date for cancellation will be visible in the column credit date.



4.7 How to activate/deactivate auto renewal

This chapter describes how to activate or deactivate auto ordering of an ENC when status is valid or order, and how to set auto renewal when ordering ENC(s).

Rules for Auto Renewal:

- The ENC subscription(s) will be automatically renewed if the ENC(s) have auto renewal set on.
- If auto renewal is on, an order will be done automatically 14 days before expiry date, and an invoice is sent to the distributor.
- If auto renewal is changed from off to on during the last 14 days before expiry, an order will be done automatically, and an invoice is sent to the distributor.
- Where the auto renewal is activated= on, ENCs will be automatically renewed to align with the latest existing expiry date present in the current chart portfolio.
- If no future expiry date in the current chart portfolio exists, the ENCs will be renewed for a 12 months subscription period.
- To stop auto renewal for one or more ENCs the auto renewal field must be changed to off.

Set Auto Renewal when ordering:

1. Go to the licensee
2. Select the basket to be ordered
3. Start the quotation process
4. Set Auto Renewal: Auto renewal is always set default as on; please choose off if auto renewal is not wanted for the ENC(s) to be ordered.


The screenshot shows a 'Quotation' window with the following sections:

- Quotation**: Start - Set Retail Price - Complete Order
- Welcome to the quotation wizard
- Set Auto Renewal**:
 - On
 - Off
- Subscription Type**:
 - Subscription Type: 12 months
 - Expire date: 31.12.2013
- Additional Order Information**:
 - Reference Number: [text input]
 - Additional E-Mail: [text input]
- Permit Handling**:
 - Default
 - Generate permit for week
 - Select Week: Year 2012, Week 52, Update

Buttons at the bottom: Back, Next, Cancel.


5. When order completed the ENCs in basket view will be viewed as “on” for ENC(s) ordered with auto renewal on, and “off” if auto renewal is set as off in

the auto renewal column;




Amend auto renewal on ENC(s) in folio with status valid:

1. Go to the licensee
2. Select the ENC(s) with status valid which you want to amend from the basket
3. Right click with the mouse button in the auto renewal field to change auto renewal on or off;



4. Click “turn auto renewal on” – the auto renewal column will no change for the selected ENCs;



4.8 How to amend the basket within the renewal period

In the renewal period, 30 days before the ENC(s) expiry date, a renewal notification will be sent to the distributor on e-mail.

In this period the ENC status will change from valid to order.

ENCs with status order and auto renewal on will be re-ordered 14 days before expiry, and an invoice is sent to the distributor.

In the automatic order done the ENCs will automatically be renewed to align with the latest existing expiry date present in the current chart portfolio.

If no future expiry date in the current chart portfolio exists, the ENCs will be renewed for a 12 months subscription period.

ENCs with status order and auto renewal off will end their subscription at expiry date.

Example of renewal notification e-mail: see chapter 4.8.2 Renewal notification.

Scenario 1: Increasing the basket/folio by adding ENCs

- Go to the licensee basket, add the new ENCs from the product list in basket view or by selection in map view.
- Start quotation, **NOTE!** The default expiry date will be set to latest existing expiry date present in the current chart portfolio – edit the subscription type/expiry date as wanted and fulfill your order.
- Order e-mail with the necessary permits will be provided
- If ENCs with status auto renewal off needs to be reordered please change auto renewal from off to on. **NOTE** if this is changed less than 14 days before expiry an automatic order is done.

Scenario 2: Decreasing the basket/folio by stopping ENCs to be reordered

- Go to the licensee basket and mark the ENCs you want to remove, then press “minus-button” to change auto renewal from on to off.
- Start quotation, **NOTE!** The default expiry date will be set to latest existing expiry date present in the current chart portfolio – edit the subscription type/expiry date as wanted and fulfill your order.
- If no quotation is done, the ENCs remaining in the basket with status auto renewal on will be automatically renewed 14 days before expiry.
- Order e-mail with the necessary permits will be provided

Scenario 3: Stop all ENCs to be reordered

- If all your subscribed ENCs needs to be stopped, go to the licensee basket and mark the ENCs, then press “minus-button” to change auto renewal from on to off .
- The subscribed ENC(s) will then stop at expiry date.

4.9 Description of service related e-mails

4.9.1 Order ENC

The order e-mail is a confirmation of the requested ENCs. The relevant permit file for this order is enclosed in the e-mail.

The e-mail also informs the distributor which CDs, both parts of base CDs needed & which weekly update CD, these permits can be used in relation to.

Example of content:

“PRIMAR permits for (licensee name)

Dear distributor

Thank you for your ENC request, which has now been successfully processed.

Customer:	customer name
Licensee:	licensee name
ECDIS:	user permit name
Manufacturer:	user permit manufacturer
User Permit:	user permit
Protection Scheme:	protection scheme chosen for the ECDIS/ECS
Order no:	order ID
Reference no:	order reference number
IMO number:	registered IMO number

Please be advised that the 'Terms and Conditions for PRIMAR ENC users', which is a part of the distributor agreement, have been amended to include a new mandatory requirement; To register IMO number of the vessels in the PRIMAR Chart Catalogue, where available. This procedure is mandatory for all SOLAS vessels.

Attached please find the permit file(s) required by your registered end user() to decrypt the relevant ENC cells on its system.

The permit files are created to work with Update CD week ()/ year (), Type CD week or later.

Your portfolio contains of ENCs from the following Base CDs:

Base CD part () – ()

Yours sincerely
PRIMAR”

4.9.2 Renewal notification ENC

The renewal notification e-mail, is an e-mail warning to you as a distributor regarding that an ENC or more in the licensees portfolio is about to expire. This e-mail will be sent due to ENCs which have auto renewal on, and issued 30 days before expiry date. The ENCs will be automatically renewed 14 days before the expiry date.

Example of content:

“PRIMAR renewal notification for (licensee name)

Dear distributor

ENC(s) on subscription or trial period with PRIMAR for your registered end user, (licensee name), will expire in 30 days.

Customer: customer name
Licensee: licensee name

If you wish to cancel the subscription, or amend the folio, please use the PRIMAR Chart Catalogue to make the required changes.

Without a cancellation, the subscription will automatically be renewed 14 days before the expiry date, as specified in the distributor pricing schedule.

Yours sincerely

PRIMAR

4.9.3 Renewal order ENC

The renewal order e-mail is a confirmation of the renewal order. A renewal notification e-mail has been sent out 30 days prior to the licensee's expiry date. The relevant permit file for this order is enclosed in the e-mail. The e-mail also informs the distributor which CDs, both parts of base CDs needed & which weekly update CD, these permits can be used in relation to.

Example of content:

“Renewed PRIMAR ENC permits for (licensee name)

Dear distributor

Thank you for your ENC request, which has now been successfully processed.

Customer:	customer name
Licensee:	licensee name
ECDIS:	user permit name
Manufacturer:	user permit manufacturer
User Permit:	user permit
Protection Scheme:	protection scheme chosen for the ECDIS/ECS
Order no:	order Id
Reference no:	Renewal
IMO number:	registered IMO number

Please be advised that the 'Terms and Conditions for PRIMAR ENC users', which is a part of the distributor agreement, have been amended to include a new mandatory requirement; To register IMO number of the licensees in the PRIMAR Chart Catalogue, where available. This procedure is mandatory for all SOLAS licensees.

Attached please find the permit file(s) required by (licensee name) to decrypt the relevant ENC cells on its system for another 12 months.

The permit files are created to work with CD Week ()/Year () or later.

Your portfolio contains of ENCs from the following Base CDs:

Base CD () – ()

Yours sincerely
PRIMAR”

4.9.4 Weekly CD permit

Weekly CD permit e-mail is sent to the distributor when necessary due to newer editions of ENC's in the licensees folio are available in the CD service.

Every permit file contains decryption keys for two editions of a cell (current and next edition).

These files should be sent to the licensee together with the weekly CD to which they correspond.

In the e-mail the distributor/user can find information on the specific CD in the field "Weekly CD no".

Example of content:

"PRIMAR permits for weekly CD () for (licensee name)

Dear distributor

Your registered end user, (licensee name), currently subscribes to one or more ENC's which are the subject either of several new editions during the subscription period or of cell replacements from a hydrographic office.

Customer:	customer name
Licensee:	licensee name
ECDIS:	user permit name
Manufacturer:	user permit manufacturer
User Permit:	user permit
Protection Scheme:	protection scheme chosen for the ECDIS/ECS
Weekly CD no.:	week ()

(licensee name) will consequently need an updated set of permits to access all the new editions released by the PRIMAR service on its latest CD.

Please find attached the updated permit file(s) for your registered end user, (licensee name). You will need to supply this new permit to your customer together with the PRIMAR CD week ().

A complete list of all cell replacements and cancellations are available on www.PRIMAR.org.

Please contact PRIMAR at sales@primar.org should you have any questions regarding this e-mail.

Yours sincerely
PRIMAR"

4.9.5 PRIMAR Area of Interest – New ENC's available

PRIMAR Area of Interest-New ENC's available e-mails will be sent to the distributor if new ENC's are released in the PRIMAR ENC service in a selected area for the licensee. This information will only be sent if the licensee has one or more active/selected area of interests.

To view the new ENC's open the licensee in the PRIMAR Chart Catalogue, and identify the ENC's using map view and the selection show area of interest, use this function together with Show and view New cell according to a date setting.

[Example of content:](#)

Dear "Distributor"

New ENC's, due to selected area of interest, are available to order for the following licensees:

Licensee: licensee name	Customer: customer name
Licensee: licensee name	Customer: customer name
Licensee: licensee name	Customer: customer name
Licensee: licensee name	Customer: customer name

Please use the PRIMAR Chart Catalogue to view and to order the ENC's.

Yours sincerely

PRIMAR

4.9.6 Auto order

If auto order is selected in Area of Interest new ENC's (available from the date of activation) in the selected area will be automatically ordered. An order e-mail will be sent including the permit file(s) for the new ENC's ordered.

Please note *reference no* in these e-mails will be registered as *Auto Area*.

[Example of content:](#)

PRIMAR Permit files for “licensee” ENC order

Dear “distributor”

Thank you for your ENC request, which has now been successfully processed.

Customer:	customer name
Licensee:	licensee name
ECDIS:	user permit name
Manufacturer:	user permit manufacturer
User Permit:	user permit
Protection Scheme:	protection scheme chosen for the ECDIS/ECS
Order no:	order ID
Reference no:	Auto Area
IMO number:	registered IMO number

Please be advised that the 'Terms and Conditions for PRIMAR ENC users', which is a part of the distributor agreement, have been amended to include a new mandatory requirement; To register IMO number of the vessels in the PRIMAR Chart Catalogue, where available. This procedure is mandatory for all SOLAS vessels.

Attached please find the permit file(s) required by your registered end user, licensee name, to decrypt the relevant ENC cells on its system.

Your portfolio contains of ENC's from the following Base CD's:

- Base CD part 1: - NO Norway
- Base CD part 3: - FR France
- Base CD part 4: - AR Argentina

Yours sincerely

PRIMAR

4.9.7 Order WMS

The order e-mail is a confirmation of the requested WMS products. An url for accessing the WMS service in the client is attached, and also an activation URL for setting password. Please note you only activate password when first ordering a WMS product for a licensee/customer.

[Example of content:](#)

Dear
Demo
PRIMAR Internal

Thank you for your WMS order, which has now been successfully processed.

Order details:
Customer Name: Sølvi
License Name: WMS user
Order no: 595369

Product information:
Product: WMS FINLAND, Subscription: 12 months
Product: WMS NO, Subscription: 12 months

PRIMAR Web Chart Service:
The PRIMAR WMS can be accessed using the following URL from a WMS client ([\(\)](#))

Username: WMS-user-wms

Activation URL: ([\(\)](#))

Click on this activation url and input your password to activate your user.

Yours sincerely

PRIMAR