

**EW3590/91/92**

**Bluetooth Headset with microphone**

**en**

Manual

# EW3590/91/92 Bluetooth Headset with microphone

## Table of contents

1.0 Introduction .....	2
1.1 Packing contents .....	2
2.0 Connecting to a Bluetooth device .....	2
3.0 Control and Function .....	3
4.0 Charging the Bluetooth headset .....	3
5.0 Frequently Asked Questions and other related information .....	3
6.0 Service and support.....	3
7.0 Warning and points of attention .....	4
8.0 Warranty conditions.....	4

## 1.0 Introduction

Congratulations with the purchase of this high-quality Ewent product! This product has undergone extensive testing by Ewent's technical experts. Should you experience any problems with this product, you are covered by a five-year Ewent warranty. Please keep this manual and the receipt in a safe place.

*Register your product now on [www.ewent-online.com](http://www.ewent-online.com) and receive product updates!*

### 1.1 Packing contents

The following parts need to be present in the packing:

- EW3590 or EW3591 or EW3592 Bluetooth Headset with microphone
- USB Cable for charging
- Manual

## 2.0 Connecting to a Bluetooth device

1. Press and hold the power button for 5 seconds, the blue and red Led will begin to flash alternately
2. Activate the Bluetooth feature on the mobile device, such a Smartphone, Tablets etc.
3. Start the searching of Bluetooth device
4. After a few second the phone will list "eGlamour EW3590" (EW3591 or EW3592 depending on the model purchased)
5. Select "eGlamour EW3590" to connect to your device

## 3.0 Control and Function

- Keep pressing the power button for 3 seconds to turn ON the Bluetooth Headset (the blue Led will begin to flash slowly). Press again for 3 seconds to turn OFF the device (the blue Led will turn off)
- Press the power button to play when the device is pause, press the power button to pause when device is playing
- Short press “<” for last music
- Short press “>” for next music
- Keep pressing “-“ volume down
- Keep pressing “+” volume up
- Press the power button to answer/hang up the phone

## 4.0 Charging the Bluetooth headset

1. Insert the USB charging cable into the USB charger or USB port of a computer
2. Connect charging cable with the charging port of Headset

*Note: When the battery of the headset is low, it will beep 3 times. Please recharge as soon as possible. The charging time may vary from 2 to 3 hours at first use, it is advisable to charge them for at 12 hours.*

## 5.0 Frequently Asked Questions and other related information

The latest Frequently asked questions for your product can be found on the support page of your product. Ewent will update these pages frequently to assure you have the most recent information. Visit [www.ewent-online.com](http://www.ewent-online.com) for more information about your product.

## 6.0 Service and support

This user's manual has been carefully written by Ewent's technical experts. If you have problems installing or using the product, please fill out the support form at the website [www.ewent-online.com/](http://www.ewent-online.com/)

You can also contact us by phone. Please check [www.ewent-online.com/](http://www.ewent-online.com/) for the helpdesk phone number and opening hours.

## 7.0 Warning and points of attention



Due to laws, directives and regulations set out by the European parliament, some (wireless) devices could be subject to limitations concerning its use in certain European member states. In certain European member states the use of such devices could be prohibited. Contact your (local) government for more information about this limitations.

Always follow up the instructions in the manual\*, especially where it concerns devices which need to be assembled.

Warning: In most cases this concerns an electronic device. Wrong/improper use may lead to (severe) injuries!

Repairing of the device should be done by qualified Ewent staff. The warranty immediately voids when products have undergone self repair and/or by misuse. For extended warranty conditions, please visit our website at [www.ewent-online.com](http://www.ewent-online.com).

*\*Tip: Ewent manuals are written with great care. However, due to new technological developments it can happen that a printed manual does not longer contain the most recent information.*

*If you are experiencing any problems with the printed manual or you cannot find what you are looking for, please always check our website [www.ewent-online.com](http://www.ewent-online.com) first for the newest updated manual.*

*Also, you will find frequently asked questions in the FAQ section. It is highly recommended to consult the FAQ section. Very often the answer to your questions will be found here.*

## 8.0 Warranty conditions

The five-year Ewent warranty applies to all Ewent products, unless mentioned otherwise before or during the moment of purchase. After buying a second-hand Ewent product the remaining period of warranty is measured from the moment of purchase by the product's initial owner. Ewent warranty applies to all Ewent products and parts, indissolubly connected or mounted to the product it concerns. Power supply adapters, batteries, antennas and all other products not directly integrated in or connected to the main product or products of which, without reasonable doubt, can be assumed that wear and tear during use will show a different pattern than the main product, are not covered by the Ewent warranty. Products are not covered by the Ewent warranty when exposed to incorrect/improper use, external influences or when opening the service parts of the product by parties other than Ewent. Ewent may use refurbished materials for repair or replacement of your defective product. Ewent cannot be held responsible for changes in network settings by internet providers. We cannot guarantee that the Ewent networking product will keep working when settings

are changed by the internet providers. Ewent cannot guarantee the working of web services, apps and other third party content that is available through Ewent products. Ewent products with an internal hard disk have a limited warranty period of two years on the hard disk. Ewent could not be held responsible for any data lost. Please make sure that if the product stores data on a hard drive or other memory source, you will make a copy before you return the product for repair.

**When my product gets defective**

Should you encounter a product rendered defective for reasons other than described above: Please contact your point of purchase for taking care of your defective product.

e'went  
by eminent

[www.ewent-online.com](http://www.ewent-online.com)

Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.

The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Ewent is a member of the Eminent Group