HDMI Splitter 1*2 User Manual

I .INTRODUCTION

1 × 2 HDMI splitter distributes 1 HDMI source to 2 HDMI displays simultaneously. It offers HD video solution for super market; shopping m all; HDTV, STB, DVD, projector factory; data control center; information distribution; conference room presentation; education and training; corporation show room; home theater, etc.

II. SPECIFICATIONS:


. 20. 10. 110.10.			
Input Video Signal	0.5 -1.0 volts p-p		
Input DDC Signal	5 volts p-p (TTL)		
Max Single Link Range	1920X1080, 1080P		
Output Video	HDMI 1.3 + HDCP1.0/1.1/1.2		
Resolutions DTV/HDTV	480p/576i/576p/720p/1080i/1080P		
HDMI Version	HDMI 1.3		
Operating Frequency	Up to 225MHz		
EIDI Duration	4 seconds		
Power supply	DC 5V		

III.CONNECTION

- a) . Connect the input source and output displays to the HDMI Splitter .
- *Please refer to the Connection Image.
- b) . Connect the DC 5V power supply to the splitter. Please kindly note that power supply with higher voltage may damage the splitter.
- c) . When input source and output displays are connected and turned on, the corresponding LED will light.

Attention: In order to protect the splitter and your devices, p lease make sure the splitter is powered off before you attach in or extract video source and displays . Please insert and extract HDMI cables gently.

IV.INTERFACE



- ① Power LED
- ② Power Supply Socket
- ③ HDMI Input
- LED of HDMI Input
 ED of HDMI1 Output
- ⑤ HDMI1 Output
- © LED OF HEIMIT O
- ② LED of HDMI2 Output

V .BOX CONTENTS:

Item	Qty	Remark
HDMI splitter 1 × 2	1 PCS	
Power	1 PCS	DC5V/1A
User Manual	1 PCS	en

VI.FAO

A). The splitter doesn't appear to be functioning.

Firstly, check if the LED lights, if the power supply is in good condition and well connected. Secondly, make sure all cables are in good condition and well connected.

Thirdly, make sure the length of the cables is within the maximum supported length of this splitter.

Lastly, please try to connect the input source to the display directly to see if it display normally.

B) If the maximum resolution the two displays supported is not the same, what resolution be displayed?

The splitter will display at the lower one to both displays.

VII.CONNECTION



HDMI Splitter 1*2 User Manual

I .INTRODUCTION

1 × 2 HDMI splitter distributes 1 HDMI source to 2 HDMI displays simultaneously. It offers HD video solution for super market; shopping m all; HDTV, STB, DVD, projector factory; data control center; information distribution; conference room presentation; education and training; corporation show room; home theater, etc.

II. SPECIFICATIONS:


Input Video Signal	0.5 -1.0 volts p-p	
Input DDC Signal	5 volts p-p (TTL)	
Max Single Link Range	1920X1080, 1080P	
Output Video	HDMI 1.3 + HDCP1.0/1.1/1.2	
Resolutions DTV/HDTV	480p/576i/576p/720p/1080i/1080P	
HDMI Version	HDMI 1.3	
Operating Frequency	Up to 225MHz	
EIDI Duration	4 seconds	
Power supply	DC 5V	

Ⅲ.CONNECTION

- a) . Connect the input source and output displays to the HDMI Splitter
- *Please refer to the Connection Image.
- b) . Connect the DC 5V power supply to the splitter. Please kindly note that power supply with higher voltage may damage the splitter.
- c) . When input source and output displays are connected and turned on, the corresponding LED will light.

Attention: In order to protect the splitter and your devices, p lease make sure the splitter is powered off before you attach in or extract video source and displays . Please insert and extract HDMI cables gently.

IV.INTERFACE



- ① Power LED
- 2 Power Supply Socket
- ③ HDMI Input
- ④ LED of HDMI Input
- ⑤ HDMI1 Output
- 4) LED of HDMI Input
- HDMIT Output
- ⑥ LED of HDMI1 Output⑧ HDMI2 Output
- 7 LED of HDMI2 Output
- V.BOX CONTENTS:

Item	Qty	Remark	
HDMI splitter 1 × 2	1 PCS		
Power	1 PCS	DC5V/1A	
User Manual	1 PCS	en	

VI.FAC

A). The splitter doesn't appear to be functioning.

Firstly, check if the LED lights, if the power supply is in good condition and well connected. Secondly, make sure all cables are in good condition and well connected.

Thirdly, make sure the length of the cables is within the maximum supported length of this splitter. Lastly, please try to connect the input source to the display directly to see if it display normally.

B) If the maximum resolution the two displays supported is not the same, what resolution be displayed?

The splitter will display at the lower one to both displays.

VII.CONNECTION

