



User's Manual



The Pipeline family:



Pipeline Paddles:



Congratulations on your purchase of Pipeline Paddle Board's Stand Up Paddle Board! This product has been designed to perform and last. Please review the following information to better acclimate you to its use, storage and care:


Part # Model Name and dimensions UPC

- M100H Mushy 10' (10' x 31" x 4.5" @ 24lbs) 850309005127
- M100H Weight Capacity 165lbs for Beginner
- M100H Weight Capacity 190lbs for Advanced



- M110H: Mushy 11' (10'11" x 31"x 4.5" @26lbs) 850309005134
- M110H Weight Capacity 210lbs for Beginner
- M110H Weight Capacity 240lbs for Advanced

Contents (may vary): SUP, removable fin, leash and paddle if purchased. The middle fin is installed by sliding it in the rails. Simply tighten the screw through the fin to the sliding metal rectangular fastener to secure the fin.



Construction: Pipeline Paddle Boards are engineered to be the most technologically advanced boards in the market. The Mushy is made of High Density Soft IXPE Polyethylene Deck, EPS Core, 4mm Slick, Skin HDPE Bottom.

How to SUP!: Before proceeding, be sure to read all safety cautions and warnings at the end of this manual and navigate to www.pipelinepaddleboards.com for additional help. Lay paddle across board and start on knees. Slowly stand up placing feet shoulder length apart in approximately the center of the board. As you become balanced you may change your position on the board to suit the conditions and increase your speed or turning radius. The paddle is gripped at the top with one hand and about 24-36" below with the other hand. To maintain a straight course, switch between paddling on left and right sides by switching top and bottom hands and paddling on opposite sides evenly, accounting for any conditions such as wind and wake. Paddling forward on one side will cause the SUP to change course to the opposite side. Paddling backwards will cause SUP to turn sharply on the same side. This can be a useful maneuver in tight areas. Dismount the board in the opposite fashion of starting. Be careful in shallow water or near shore or docks.



Maintenance: SUP should be dry before storing. Do not leave exposed to direct sunlight or elements for extended periods. The one-way vent plug near top of deck side MUST NOT get covered! It helps the Styrofoam inside the board exhaust gases. "Blistering" is not covered under warranty and is caused by excessive exposure to sun and heat.

Warranty: See www.pipelinepaddleboards.com for most recent warranty details. Paddle boards carry a six (6) month limited warranty from date of purchase, from an authorized distributor only, covering manufacturer defects due to materials or workmanship but NOT end user abuse or miss-use, normal wear and tear of the product, modifications, repairs, accidents, heat, excessive exposure to weather elements ("blistering" is not covered under warranty and is caused by excessive exposure to sun and heat), improper storage or handling, incorrect set-up, use in commercial activities and minor cosmetic flaws that do not affect performance. The warranty is only for the original purchaser and is not transferable. Claims should be made in writing to: info@pipelinepaddleboards.com. End user is responsible for expenses related to the return of the defective product. Pipeline Paddle Boards has the sole discretion to replace or repair any warranty claims after product inspection.

Usage Warnings:



WARNING

DISREGARDING ANY OF THE SAFETY PRECATIONS AND INSTRUCTIONS CONTAINED IN THE OWNER'S MANUAL, WEBSITE (<u>WWW.PIPELINEPADDLEBOARDS.COM</u>) OR ON THE PRODUCT MAY RESULT IN INJURY INCLUDING THE POSSIBILITY OF DEATH.

- PADDLE BOARD IS INTENDED FOR RECREATIONAL AND HEALTH AND FITNESS USE ONLY
- REVIEW THE WEIGHT CAPACITY LIMITATION OF PADDLE BOARD AND NEVER EXCEED IT
- ALWAYS WEAR A COAST GUARD APPROVED PERSONAL FLOTATION DEVICE (PFD)



- DO NOT USE PADDLE BOARD WITHOUT A THIRD PARTY OBSERVING OR KNOWING YOUR TIMING AND WHEREABOUTS
- DO NOT USE DURING SEVERE WEATHER OR DURING ROUGH CONDITIONS
- ALWAYS USE LEASH AND STAY CONNECTED WIND AND CURRENT CAN POSSIBLY CARRY PADDLE BOARD FASTER THAN YOU CAN SWIM
- NEVER DIVE HEAD FIRST FROM PADDLE BOARD
- USE CAUTION AROUND REEFS, BARRIERS AND OBSTRUCTIONS
- DO NOT USE IN SHALLOW WATER
- DO NOT USE IN ROUGH AND/OR FAST CURRENTS
- DO NOT PULL PADDLE BOARD WITH BOAT OR MOTORIZED VEHICLE
- DO NOT LET MINORS USE PADDLE BOARD WITHOUT PROPER SUPERVISION AND USAGE TRAINING
- DO NOT USE PADDLE BOARD AFTER CONSUMING ALCOHOL OR SUBSTANCES WHICH INDUCE IMPAIRMENT
- DO NOT USE PADDLE BOARD BEYOND TRAINING AND SKILLS
- DO NOT USE PADDLE BOARD BEFORE DAWN OR AFTER SUNSET OR IN POOR LIGHTING
- CHECK LOCAL LAWS AND REGULATIONS FOR PROPER AND SAFE USAGE OF PADDLE BOARD
- DO NOT LEAVE PADDLE BOARD EXPOSED TO DIRECT SUNLIGHT
- MAKE SURE PADDLE BOARD IS DRY BEFORE STORING
- REGULARLY INSPECT PADDLE BOARD FOR CRACKS



