

INTRODUCTION

The GV-NVR (Network Video Recorder) records video and audio data over TCP/IP networks. With up to 32 channels of pure IP surveillance, the GV-NVR offers the same functions as GV-Series Surveillance System. From monitoring features to video analytics as well as integration with LPR, POS/ATM and Access Control systems, it stands as one of the most comprehensive IP surveillance software in the security market.

Combined with GeoVision IP camera, the GV-NVR takes advantage of a better image quality thanks to the progressive scan technology and allows advanced video features such as Picture-In-Picture and Picture-And-Picture. Compatibility with a wide range of third party IP cameras makes the GV-NVR the ultimate solution for pure IP surveillance environments.

Supported IP Camera List

VERSION 8.4 KEY FEATURES

Built upon comprehensive and easy-to-integrate hardware and supporting technologies, the GV-Surveillance and Video Management Platform is the core system platform that provides performance-optimized video monitoring and various advanced video analytics/control features to support many of enterprise's management functions. It is a scalable, extensible platform that can be customized and seamlessly integrated with other security system applications, such as:

- 1. POS/ ATM/ EAS for loss prevention
- 2. Access Control for building automation
- 3. License Plate Recognition system for law enforcement, entrance control and revenue collection
- 4. Megapixel IP devices for critical area and mobile object monitoring
- 5. Central Monitoring stations for high profile security areas in commercial, industrial and residential markets

In addition the remote management WebCam and versatile storage system framework offer high scalability and extensibility for future integration with other functions or systems at remote sites.



VERSION 8.4 NEW FEATURES

	Nain System: Support for GV-FE110 fisheye camera and ImmerVision	0	Support for more Axis IP cameras: M1011, M3011,
0	IMV1 Panomorph lens	0	M3014, P1311, P1343, P1344, P1346, P3343, P3344,
0	Video compacting by keeping key frames only		P5534 and Q1755
0	Schedule center for compacting video, merging video, and fast backup and restore	0	Support for more Canon IP cameras: VB-C500D and VB-C60B
0	Face count function	0	Support for more CNB IP cameras: IVP4030VR KC1 and
0	Compatibility with IP devices using ONVIF/PSIA		INS2000 KC1
	standards	0	Support for more D-Link IP cameras: DCS-3415,
0	On demand display to automatically adjust live view resolution for dual-stream video	0	DCS-5230, DCS-6110 and DCS-3411 Support for more EtroVision IP cameras: EV6150A,
0	Economic mode to customize recording frame rate for	-	EV6151A, EV6250A and EV8150A
0	IP devices	0	Support for more MOBOTIX IP cameras: D12 and Q24
0	Listing tampering alarm events from GV-IP devices in	0	Support for Panasonic BB-HCM715
-	system log	0	Support for more Pelco IP cameras: IXSOC and IXE2OC
0	Round-the-clock audio recording	0	Support for more Sanyo IP cameras: VCC-HD2100P an
0	Support for AMR and AAC audio codec		VCC-HD2300P
0	Support for new PTZ cameras: VDI CT-58SPD, Bosch G3 and COP 15-CD55TW Pelco D	0	Support for more Sony IP cameras: SNC-DH140, SNC-RH124 and SNT-EX104
0	Support for new GeoVision IP cameras: GV-BL110D,	0	Support for UDP NVC1000
	GV-BX120D, GV-BX220D, GV-BX320D, GV-FE110,	0	Support for Vivotek IP cameras: FD7131, FD7132,
	GV-PT110D and GV-PTZ010D		FD7141, FD8161, FD8361, IP7130, IP7133, IP7137,
0	Support for more ACTi IP cameras: CAM-6610N, TCD-2500, TCM-1511, TCM-3511 and TCM-5611		IP7160, IP7330, IP8330, IP8332, IZ7151, PZ7122, SD7313 and SD7323
Vie	ewLog		
0	Bookmark function		
Ce	nter V2		
0	Event Chart	0	Playback using Remote ViewLog
0	Display of Wiegand cardholder data from the GV-System	0	QView for channel display on another monitor
Dis	spatch Server		
0	Event Chart	0	Playback using Remote ViewLog
VS	M		
0	Event Chart	0	Up to 5 connections to VSM centers from one GV-System
Со	ntrol Center		
0	Up to 2 monitors supported for VMD event pop-up	0	Audio broadcasting
GI	s		
0	Input-triggered live view on mobile hosts		
Ac	cessory		
0	GV-Keyboard V3		

FULL FEATURE LIST

Monitoring

- Support for 32 channels in GV-System and CMS applications
- Digital Matrix, support maximum 8 monitors display
- Higher Screen Resolutions (1920 x 1200, 1680 x 1050, 1600 x 1200, 1280 x 800, 1440 x 900 and 1920 x 1080)
- Noise Tolerance for Motion Detection
- Report Generator
- Support for Cardholder data from GV-Video Server
- Touch Screen Support
- Full screen view
- Dual display operation for live monitoring and ViewLog playback on two monitors
- Screen pop-ups on motion or alarm activation
- Advanced Motion Detection
- Digital watermark
- Video lost detection
- On screen video loss message
- Video de-interlace filter
- E-map
- Windows lockup
- Image size indicator

Intelligent Recording & Playback

- Recording trigger by round-the-clock, motion detection, alarm and schedule
- Adjustable recording quality and frame rate for each camera
- Pre-motion and post-motion recording
- Supports Windows XP / Server 2003 burning software
- Instant Playback
- Audio
 - 32 channels of live audio streaming and recording
- Video Analytics
 - Advanced Motion Detection (**)
 - Face Detection
 - Advanced Scene Change Detection (**)
 - Advanced Unattended Object Detection (**)
 - Advanced Missing Object Detection (**)
 - Privacy Mask
 - Enhanced Object Counting

Intrusion Alarm

Server

•

- People Counting
- Panorama View (**)
- Video Stabilization (**)

Synchronized video an audio

Multi level passwords protection

Embedded I/O devices control

Embedded PTZ control panel

Support dynamic IP address

System Idle Protection

Spot Monitor Controller

Authentication Server

Photo-ID Integration (GV-WT)

Colorful Mode to enhance video color

Splitting Files for Backup onto Multiple Discs

Support for Daylight Saving Time (DST)

Extracting Frames from a Video Clip During Playback

Playback of GPS tracks from GV-Compact DVR and GV-Video

Time Merge From Different Clips

POS Live Viewer

Password Expiration Management

Support 1,000 accounts for logins and passwords

Use Microsoft Remote Desktop to control another

Backlight compensation

Video scaling filter

AVI repair utility

System log

GV-System

Twin DVR

- Defog Function (**)
- Crowd Detection (**)
- Digital Object Tracking
- Face Count

Note: The feature with (**) mark needs to work with an AVP dongle which you need to purchase additionally.

Smart Search & Ease Playback

- Timeline Search
- Face Detection for Object Index
- Object search
- Index search
- Object Index
- Thumbnail browse for ease of search for specific frames within video footage
- Export a video footage within a specified time range
- Synchronized audio and video for both live and playback modes

- Continues playback of set frames A to B
- EXE format export, playable with any third-party players
- AVI format export in multiple screens mode
- DVD format export for Hybrid Card format files
- Option for recycling the input-triggered events (Never recycle function)
- Backup, save AVI and BMP functions accessible in LAN ViewLog
- Automatic refresh of the video event list in LAN ViewLog

GeoUision

Notification					
•	E-mail notification with attached video images on motion and alarm activation E-mail or telephone notification on video lost or I/O error Directs PTZ dome to a preset location on motion and alarm activation	Sign N	ilerts available in Main System, Center V2 and Vital Aonitor is on objects that pass between predefined regions		
► We	ebCam - Remote Surveillance				
• • • • • • •	POS Live View via IE Browser 3G Mobile Phone Support (3GPP) SSL Encrypt Connection Support UPnP™ Support Control Panel on Single View to Provide Instant Information and Operation Support PIP, PAP, Defogging Live Videos, and Video Stabilizer in Single View Restricting Power User and User to Access WebCam Server at Specified Time Length	 Down Drag- the 2 Remo Pop-u Multi 	List Query load Center and-Drop Support for Camera, PTZ and I/O Icons on Windows of MPEG4 Encoder Viewer te E-Map Ip Live Images upon Input Trigger in Remote E-Map cast Broadcast		
► Ad	vanced I/O Control				
• •	Visual Automation Virtual I/O Control One-Click I/O Status Control		ple I/O Types Selection Trigger Feature		
► Mo	bbile Phone Application				
•	Support 4, 9, and 16 screen divisions		nel switch via middle button		
•	PTZ control via directional buttons	 Support 	ort for Nokia S60 3rd Edition		
 Pro • • • 	ofile Management Selectable GUI Skin Custom Start-Up Splash Screen, Non-Active Video & Video Lost Screen Customizing System Features		Configuration Backup & Restore m DVR Setting's Template		
🕨 Re	mote Monitoring Software				
• •	WebCam Remote Playback System G-View for WinCE PDA Technology	I-MocBlack	le Berry phones		
•	RSA Network Security		entication Server: central control of password settings al GV-DVRs		
Ce	ntral Monitoring Station (CMS)				
•	Center V2 Vital Sign Monitor Dispatch Server		ol Center S (Geographic Information System)		
🕨 Int	egration Solution				
•	Point-Of-Sale	• Mega	pixel Integration		
٠	EAS Integration	• Licene	ce Plate Recognition		
٠	Access Control	• Centr	al Monitoring Station		

VERSION 8.4 GV-NVR Specifications

NVR					
Model	GV-NVR (GV)	GV-NVR			
Video Input	4, 8, 12, 16, 20, 24, 28, 32	1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32			
Audio Input	4, 8, 12, 16, 20, 24, 28, 32	1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32			
Video Compression	MJPEG, MPEG4, H.264				
Video Resolution	From CIF to 5 Mega pixel				
Networking	TCP / IP, LAN, WAN, Internet, Modem Dial-up, Modem-to-Modem, ISDN				
Backup Device	HDD, NAS, CD-R / R-W, DVD+R / +RW, DVD+R (DL), ZIP, JAZ, Blu-ray, GV-Storage System				
Mobile Phone / PDA	Symbian S60 (2.X~3.X), Windows Mobile (5.0~6.1), Blackberry (4.2.1~4.7), iPhone (2.2~3.1)				
Language	Czech / Danish / English / French / German / Hebrew / Hungarian / Italian / Japanese / Polish / Portuguese / Russian / Serbian / Simplified Chinese / Spanish / Traditional Chinese				

	Minimum System Requirements				
05	32-bit	Windows XP, Windows Vista, Windows 7, Windows Server 2008			
OS	64-bit	Windows 7, Server 2008			
CPU		Core 2 Duo, 2.4 GHz / Core 2 Quad, 2.4 GHz / Core i7, 2.8 GHz			
RAM		2 X 1 GB Dual Channels / 2 x 2 GB Dual Channels (see IMPORTANT 2)			
VGA		ATI X 1300			

Important :

- To connect IP cameras with H.264 codec and GV-IP Speed Dome (no matter which codec you select), the minimum CPU requirement of Core 2 Quad can only support up to 8 channels. With CPU of Core i7 or higher, you can record up to 32 channels but note the following limit for live viewing:
 - For live viewing of 32 channels, you need to lower the resolution and change the codec to MPEG 4 or MJPEG.
- 2. For the users of 32-bit Windows, the memory limit of GV-NVR is 1.7 GB with 2 GB RAM. For the users of 64-bit Windows, the memory limit of GV-NVR is 1.7 GB with 2 GB RAM and 3 GB with 4 GB RAM. If the high memory issue persists, the GV-NVR will become unstable.

Frame rate limit in a single hard disk

Since the size of transmitted data from IP cameras may be quite large and reach beyond the transfer rate of a hard disk, you should note the total of recording frame rates that you can assign to a single hard disk, as listed below:

Video resolution	MJPEG		H.264		MPEG4	
video resolution	Frame Rate	Bit Rate	Frame Rate	Frame Rate	Bit Rate	Frame Rate
2560x1920 (5M)	30 fps	102.26Mbit/s	240 fps	21.24Mbit/s	-	-
2560x1600 (4M)	60 fps	73.49Mbit/s	240 fps	15.28Mbit/s	-	-
2048x1536 (3M)	60 fps	64.73Mbit/s	480 fps	10.52Mbit/s	-	-
1600x1200 (2M)	120 fps	41.16Mbit/s	480 fps	9.16Mbit/s	-	-
1280x960 (1.3M)	200 fps	30.04Mbit/s	480 fps	5.77Mbit/s	480 fps	6.30Mbit/s
640x480 (VGA)	480 fps	11.42Mbit/s	640 fps	2.54Mbit/s	640 fps	3.27Mbit/s
320x240 (CIF)	480 fps	5.16Mbit/s	640 fps	0.75Mbit/s	640 fps	1.03Mbit/s

Note: The above data was determined using the bit rate listed above and hard disks with average R/W speed above 80MB/s.

The frame rate limit is based on the resolution of video sources. The higher video resolutions, the lower frame rates you can assign to a single hard disk. In other words, the higher frame rates you wish to record, the more hard disks you need to install. For the information of recording frame rates, you may consult the user's manual of the IP camera that you wish to connect to.

GV-DONGLE POLICY

Dongle Type

An appropriate USB dongle is required for the computer to run the Hybrid and NVR solutions. There are three types of USB dongles available for both Hybrid and NVR solutions.

- 1. NVR (GV) Dongle: This is used only for GeoVision IP video devices, including GV-IP Camera, GV-Compact DVR and GV-Video Server.
 - The dongle options include: 4, 8, 12, 16, 20, 24, 28, 32 IP channels.
- 2. NVR Dongle: This is used for third-party IP devices.
 - The dongle options include: 1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32 IP channels.
- 3. **Combo Dongle:** This is used for a mix of GeoVision and third-party IP video devices.

It is required to install drivers from the software CD for above three dongles to work.

The three dongles can be upgraded to include the AVP (Advanced Video Process) functions.

Hybrid Solution Description

1. Specifications of the Hybrid solution. The Hybrid solution provides you 8 free IP channels for GeoVision IP video devices, with the limit of 32 channels in total.

For example:

Number of analog channels + 8 free GV IP channels + Number of channels in USB dongle (NVR(GV), NVR or Combo Dongle) <= 32 channels.

- 2. Connection of GeoVision IP devices to GV-System. To receive the video streaming of 8 channels or less from GeoVision IP video devices, there is no need to use an extra USB dongle. If more than 8 GV IP channels are required, you need a NVR (GV) Dongle.
 - The dongle options include: 4, 8, 12, 16, 20, 24 IP channels.

In this case, the total number of channels for your Hybrid system is: Number of analog channels + 8 free GV IP channels + Number of channels in your NVR (GV) Dongle <= 32 channels.

3. Connection of third-party IP devices to GV-System. To implement the Hybrid solution with third-party IP video devices, you need a NVR Dongle.

• The dongle options include: 1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32 IP channel(s).

In this case, the total number of channels for your Hybrid system is: Number of analog channels

(+ 8 free GV IP channels) + Number of channels in your NVR Dongle <= 32 channels.

- Connection of both GV and third-party IP devices to GV-System. To implement the Hybrid solution with a mix of GeoVision and third-party IP video devices, you need a Combo Dongle.
 - The dongle options are the combined options of NVR (GV) Dongle and NVR Dongle. Inform your sales representative the exact number of third-party IP channels and additional GV IP channels you need, so the Combo Dongle can be delivered upon your requirements.
 For example, you need 8 third-party IP channels plus 8 additional GV IP channels, so the number of channels in the requested Combo Dongle is 16. The total number of channels for your Hybrid system will be: Number of analog channels + 8 free GV IP channels + Number of channels in your Combo Dongle (e.g. 16) <= 32 channels.

NVR Solution Description

- 1. Specifications of the NVR solution: When an appropriate USB dongle is attached to GV-NVR System, it can support up to 32 IP video channels.
- Connection of Geovision IP devices to GV-NVR. To implement the GV-NVR solution with GeoVision IP video devices, you need a NVR (GV) Dongle.
 - Dongle options include: 4, 8, 12, 16, 20, 24, 28, 32 IP channels.
- 3. Connection of third-party IP devices to GV-NVR. To implement the GV-NVR solution with third-party IP video devices, you need a NVR Dongle.
 - Dongle options include: 1, 2, 4, 6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30, 32 IP channel(s).
- 4. Connection of both GV and third-party IP devices to GV-System. To implement the NVR solution with a mix of GeoVision and third-party IP video devices, you need a Combo Dongle.
 - The dongle options are the combined options of NVR (GV) Dongle and NVR Dongle. Inform your sales representative of the exact number of GV IP channels and third-party IP channels you need, so the Combo Dongle can be delivered upon your requirements.

For example, you need 12 GV IP channels plus 8 third-party IP channels. Therefore, the number of channels in the requested Combo Dongle is 20, and the total number of channels for your NVR system is 20.