



User Manual

Rechargeable Vibration Bluetooth Speaker



AIR04

Table of Contents

GENERAL INFORMATION	2
Introduction	
Features	2
Bluetooth Wireless Communication Technology	2
Parts Included in the Box	3
OPERATION INSTRUCTION	4
Switching on/off AIR04	4
Pairing AIR04 with Bluetooth Devices	4
Music Playback	5
Battery Charging	6
MAINTENANCE	7
Battery Precautions	8
Product Registration	9
Limited Warranty	9
Specifications	10
Trouble Shooting / FAQ	11
Contacting Customer Service	13

Introduction

Thank you for purchasing this Airing Vibration Bluetooth Speaker. This product has been manufactured with the highest standards of safety and quality, can play music on any hard surface, such as a wooden desk or a glass table, you surely will enjoy using this speaker!

Features

- Collapsible design for ultimate portability, twist to expand in use, close for travel
- Bluetooth Class 2, transmitting / receiving working distance up to 10m
- Support Bluetooth V2. 1+EDR
- Supports A2DP, AVRCP Bluetooth wireless audio profile for use with iPhone, iPod touch, iPad and other Bluetooth enabled devices
- Pure digital technology, DSP gives your music purity and clarity
- Vibration driver technology to enrich bass sound quality
- Mini hamburger design to enhance high frequency
- BQB approved and fully compatible with other Bluetooth enabled devices


Bluetooth Wireless Communication Technology


Bluetooth is a standard of close range radio-communication technology that was drawn up by Ericsson, IBM, Intel, Nokia and Toshiba. With Bluetooth technology, we can achieve the highest transmission rate among cell phones, computers, printers, PDAs and other devices. The max transmission range of class II is 10 meters while the max transmission ranges of class I can reach up to 100 meters.

Parts Included in the Box

- A: Bluetooth Speaker (x1)
- B. 2-in-1 USB cable (x1)
- C. AC adapter (x1)
- D. Wooden socket (Optional)
- E. Suction cup(Optional)

Overview:





Operation Instruction

1. Switching on/off AIR04

Function	Operation	LED indicator
Switching on	Switch ON/OFF/BT	Bluetooth LED indicator is on in
AIR04	button to ON	green
Switching off	Switch ON/OFF/BT	Bluetooth LED indicator is off
AIR04	button to OFF	
Switching	Switch ON/OFF/BT	Bluetooth LED indicator is flashing
AIR04 to	button to BT	in green
pairing mode		

2. Pairing AIR04 with Bluetooth devices

A. Pairing with a Bluetooth cell phone

Please make sure your cell phone is Bluetooth-enabled. Specific pairing steps may vary with different cell phones. Please refer to your cell phone's user's manual for further information. The general pairing steps are as follows:

- a) Keep AIR04 and Bluetooth cell phone within 1 meter when pairing.
- b) Slide the switch to "BT" and let it enter pairing mode (Bluetooth LED will flash in green).
- c) Switch on your cell phone's Bluetooth function and search for Bluetooth devices. After the search is completed, select "Bluetooth" from the Bluetooth device list.
- According to indication, enter password or PIN No: "0000" and press "Yes" or "confirm".
- e) After successful pairing, select "Bluetooth" from the Bluetooth device list and press "connect". The Bluetooth LED indicator will remain green on when connected successfully.

B. Pairing with a Bluetooth stereo transmitter

Different Bluetooth transmitters have different pairing ways. Please refer to the user manual of your Bluetooth transmitter for further information. The general pairing steps are as follows:

- a) Keep AIR04 and Bluetooth transmitter within 1 meter when pairing.
- b) Slide the switch to "BT" and let it enter pairing mode (Bluetooth LED will flash in green).
- c) Switch on your cell phone's Bluetooth function and search for Bluetooth devices. After the search is completed, select "Bluetooth" from the Bluetooth device list.
- d) According to indication, enter password or PIN No: "0000" and press "Yes" or "Confirm".
- e) After successful pairing, select "Bluetooth" from the Bluetooth device list and press "Connect". The Bluetooth LED indicator will remain green when connected successfully.

3. Music Playback

A. Connecting with a A2DP cell phone or Bluetooth transmitter

- a) Connect your cell phone or Bluetooth transmitter with AIR04.
- b) You can listen to your music from AIR04 now when playing it back.
- c) Long press + to turn up the volume, and long press to turn down the volume.
- d) Short press +▶▶ to skip to the next song, and short press -▶ to skip to the previous song.
- e) Press ▶ II to pause, and then press ▶ II to resume the playing.

B. Connecting with a non-Bluetooth music player

- a) Connect your music player with AIR04 by using the Micro USB to 3.5mm audio cable, and slide the switch to "ON".
- b) You can listen to your music from AIR04 now when playing it back.

Remarks:

- If there is an incoming call while AIR04 is connected to your cell phone for music playback, the call (subject to the phone settings) will be automatically transferred to AIR04, press ▶ to answer a call, and long press ▶ to reject a call. After finish the call, press ▶ again to end.
- When AIR04 is connected to a non-Bluetooth audio device, the Bluetooth is off and the Bluetooth function will not be available. If you want to play music from a Bluetooth device you have to slide the switch to "BT" and reconnect AIR04 with your Bluetooth device.
- The "Play/Pause" "Next" "Previous" "VOL+" "VOL-" buttons are unavailable when you connect AIR04 with a non-Bluetooth music player.

4. Battery Charging

AIR04 has a built-in rechargeable lithium battery. This can be charged by supplied AC adaptor or connecting to the USB port of your computer. Refer to the battery indicator (The LED indicator will change to red color) for the charging status.

LED indicator → quick green light	→ Needs charging
LED indicator → stays at Red color	→ Charging in progress
LED indicator → turns off	→ Charging completed

After charging, AIR04 can be used without the power connection. Charge AIR04 again when you see the LED indicator flashes quick green light.

Maintenance

Read the following recommendations before using AIR04. Following these you will be able to enjoy our product for many years.

- Keep it dry and don't take it to damp places so as to avoid the product's internal circuit being affected.
- Keep the product away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't expose the product to cold areas. It may damage the internal circuit board.
- Don't try to disassemble the product as it may get damaged if you are not professional.
- Don't let it fall down onto the floor or other hard surfaces. The internal circuit might get damaged.
- Don't use intensive chemical products or detergent to clean the product.
- Don't scratch the surface with sharp things.

Battery Precautions

The device can be powered by a built-in rechargeable lithium battery. Please charge the battery for at least 8 hours before your first use of the device.

- If the device is not used for a long period of time, the battery may lose its charge. Please recharge the battery.
- Rechargeable batteries are only to be charged under adult supervision.
- Use only the supplied USB cable or AC adapter to recharge the battery. Improperly charging a battery may damage it or the device.
- Do not attempt to open the rechargeable battery or battery pack. There are no user serviceable parts inside.
- Should a battery leak, the device may become damaged. Clean the battery compartment immediately, avoiding contact with your skin.
- Keep batteries out of reach of small children. If swallowed, consult a physician immediately.
- Leaving the battery in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
- DO not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Do not dispose as household waste.

Product Registration

- Thank you for purchasing Airing Indoor Bluetooth Speaker. Please register your product at www.airing.nl for your warranty.
- Please reference your item# (AIR04) and/or UPC (851489004047) to register it.
- For technical assistance and more information, please feel free to contact UniStrong technical support or customer service at www.airing.nl

Limited Warranty

The manufacturer warrants this product to be free from defects in materials and workmanship for a period of one (1) year from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specially disclaims any warranty, whether expressed or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including any labor/ expense costs involved in the replacement or repair of said product.

Specifications

Bluetooth Version	Bluetooth V 2.1+EDR
Bluetooth Profile	A2DP, AVRCP
Frequency Response	40Hz-20KHz
Operating Distance	10 meters, class II
Power Supply	USB cable or AC adaptor
Working Temperature	0°C~55°C
Storage Temperature	-20℃~70℃
Dimensions	Ф2.16" х 2.79"Н
Weight	0.6 lbs

Trouble Shooting / FAQ

Problem/Question	Solution/Answer
AIR04 cannot be powered	1. Make sure the battery of AIR04 has power.
on.	2. Ensure that the Power ON / OFF switch is at
	ON position. When the speaker is powered
	ON, the LED Indicator will be lighted up.
AIR04 cannot connect to a	1. Ensure AIR04 already entered pairing mode.
Bluetooth device.	2. Ensure the Bluetooth device is in the
	effective working range.
	3. Delete the AIR04 name entry from your
	Bluetooth device paired memory list and
	re-pair your device with AIR04.
	4. Ensure that both your Bluetooth device and
	AIR04 are not connected to any other devices
	5. On some Bluetooth device, you may need to
	select AIR04 as your default output device
	after pairing is completed.
AIR04 is connected to a	Ensure your cell phone supports Bluetooth
Bluetooth cell phone but	A2DP or AVRCP profile.
doesn't play music.	2. Ensure your cell phone is in the effective
1 3	Bluetooth working range.
The sound of AIR04 crackles	Turn your Bluetooth device or other source
or has a loud hum or	component's volume down.
buzzing.	2. Move unit away from potential sources of
	interference, such as microwave ovens,
	fluorescent lights, etc.
The adhesive base is dirty.	Turn off the speaker, and then use a slightly
	damp micro fiber towel to clean the area
	carefully. Avoid any liquid contact with any
	electronic components.

6

Trouble Shooting / FAQ

Problem/Question	Solution/Answer
The sound of the speaker is	Put the speaker anywhere in the house to find your
low.	preferred resonance surface. Our favorites are
	glass, wooden desk, and filing cabinets. Twist and
	extend the top tweeter for a bigger sound.
AIR04 has no sound.	1. Verify that the volume is not muted.
	2. Verify that there is no other device connected to
	AIR04.
	3. Check the connection between your Bluetooth
	device and AIR04.
	4. Try restarting AIR04 or your Bluetooth device.
How far is the effective	According to the Bluetooth standard, the maximum
range between AIR04 and a	controllable range of Class II speaker is 10 meters.
Bluetooth device?	But it varies under different environments and
	depends on the paired cell phone.
What is A2DP?	A2DP means the Advanced Audio Distribution
	Profile. It's a Bluetooth profile that allows for the
	wireless transmission of stereo audio from an
	A2DP source to an A2DP receiver.
What is AVRCP?	AVRCP means the Audio/Video Remote Control
	Profile. It's a Bluetooth profile that allows
	Bluetooth devices to control media playback on
	remote devices. It's typically used with A2DP
	devices for next/previous track selection and
	pause/play functions.

Contacting Customer Service

Still have questions?

Please feel free to contact our customer service.



Airing The Netherlands

website: www.airing.nl email: info@airing.nl