

- Do not drop, sit on, or allow the headphone to be immersed in water.
- Keep away from fire, water, and high voltage equipment.



Not suitable for children under age three. Contains small parts, which may be a choking hazard.



Long-term exposure to loud music or sounds may cause hearing loss. To prevent possible hearing damage, do not listen at high volume levels for long periods.



This is not household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. This product was produced after Jan 1 2006.

For any questions or concerns contact: support@urbanears.com
Zound Industries International AB
Box 6063
10231 Stockholm, Sweden

FCC WARNING

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different

Designed in Stockholm • Produced in China
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Zound Industries AB is under license.

from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

IC WARNING


This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
The device is compliance with RF field strength limits, users can obtain Canadian information on RF exposure and compliance.

Le présent appareil est conforme de ce matériel aux conformités ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondante.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

INTERFACES



- 1 Machine Washable Headband – Detachable fabric headband for easy wash and wear.
- 2 LED indicator – Discrete and unlit during normal operation.
- 3 Built-in touch interface
- 4 Power button
- 5 Micro USB connector for charging the battery.
- 6 Zound Plug – Instant music sharing or wired connection to the sound source

SWITCH ON

Press and hold the power button for 1 second

SWITCH OFF

Press and hold the power button for 2 seconds or leave the headphone inactive and disconnected for 10 minutes

CONNECTING TO A BLUETOOTH® ENABLED SOUND SOURCE

Follow the steps below when pairing the headphone with your sound source (smartphone, tablet or computer) for the first time. Activate the Bluetooth® feature on your sound source, according to its user manual.

1. Set the headphone in pairing mode.
2. If the headphone is switched off: Press and hold the power button for 6 seconds.
 - The 'power on' tone will sound after 1 second and when entering pairing mode, a second tone will sound.
 - If the headphone is switched on: Double-click the power button.

Note: This method does not work if the headphone is already paired to another sound source.

The LED indicator blinks blue when in pairing mode.

3. Select and connect to *Plattan ADV Wireless* on your sound source, according to its user manual.

After the initial pairing, the two devices will auto-connect when they are switched on and within range of each other (10 meters).

CONTROLS



**PLAY/PAUSE/
ANSWER CALL**

Single tap




**HANG UP/
REJECT CALL**

Double tap



**DECREASE
VOLUME**

Swipe downward
or press and hold
the lower part.



PREVIOUS SONG

Swipe backward




NEXT SONG

Swipe forward



**INCREASE
VOLUME**

Swipe upward or
press and hold the
upper part.



CHARGING

Plug the headphone into a USB power source using the micro USB cable. 2 hours charge gives approximately 8 hours of playback at medium volume.



CLEANING THE HEADPHONE

Detach the washable headband and machine wash 30° C (Cold/Cool). Clean the headphone with a soft, dry cloth. Note! Do not use liquids or sprays.



LED INDICATOR

Status

- Red (continuous)
- White (continuous)
- Blue (blinking)
- White (blinking)
- White (10s interval)
- Off

Indicates

- Battery charging
- Fully charged and connected to a USB power source
- Pairing mode, waiting to pair
- Waiting to connect
- Connected and switched on
- Headphones is switched off or in normal operation

TROUBLE SHOOTING

Problem

- Not powering on
- Not charging
- Not pairing
- No sound
- Poor sound quality

Action

- Charge the headphone using the USB cable.
- Make sure the headphone is off before turning it on.
- Make sure the USB power source is switched on.
- The LED indicator is red while charging and white when fully charged.
- Move the devices closer to each other and away from any interference or obstruction.
- Make sure the headphone is not connected to a different sound source when entering the pairing mode.
- Disable and enable Bluetooth® communication on your sound source.
- Make sure the headphone is on and connected.
- Make sure the sound source is playing.
- Move the devices closer to each other and away from any interference or obstruction.

IMPORTANT SAFETY INSTRUCTIONS

- Set your sound source to low volume before using the headphone.
- Do not use this headphone when operating a motor vehicle, a bicycle, or machinery or where your inability to hear outside sounds may present a danger to you or others.
- Using this headphone limits your ability to hear noises around you, regardless of listening volume. Please use caution when using this headphone.