



- OwnIndex™ to reliably predict your VO_{2max}



- OwnCal™ the most accurate calorie consumption calculation



- OwnCode™ locks out possible interference from other heart rate monitors



- Computer communication via audible SonicLink™ and Uplink™



- Cycling features - speed and optional cadence

S510™
HEART RATE MONITOR

POLAR®




S510™
HEART RATE MONITOR

POLAR®

GBR
USER'S MANUAL

Quick Guide



Signal/Light

Up

- move onward
- increase the selected value

Down

- move backward
- reduce the selected value

Stop

- exit the displayed mode
- return to the Time of day display

OK

- start measuring the heart rate
- lock in your selection

How to start measuring your heart rate (BasicUse)

1. Place the transmitter around your chest and wet its electrodes. Wear the wrist receiver on your wrist.
2. Press and hold the OK button to start the measurement. The stopwatch and the exercise recording start. Your heart rate will appear in max. 15 seconds.

How to stop measuring your heart rate

1. Press the stop button. The stopwatch and other calculations stop. Heart rate measurement continues but exercise data is not recorded into a file anymore.
2. Press the stop button again. The receiver returns to the Time of day display.



The Polar S510 offers you various possibilities on customising exercise sessions to fit your personal needs.

For example, use the Interval Trainer function to guide you through a complete interval training session. Or, you can choose the functions that suit you best: OwnCal calorie calculation, timers, recovery calculation, speed, cadence, etc. After training, you can review your exercise file and transfer it to your computer for analysis with PC Coach Light™ software. Monitor your fitness level, and any long-term changes in it, by performing the quick and easy Polar Fitness Test™.

Please read this manual carefully to familiarise yourself with the Polar S510. Here is where you can find the information you need to use and maintain your equipment. The function road map on the front cover is a quick guide to the versatile features of the Polar S510; please tear it off.

Please refer to the glossary for special terms, display symbols and text explanations. The alphabetical index will help you quickly find answers to any questions that you might encounter while using your Polar S510.

Thank you for choosing Polar!



CONTENTS

A. Getting going 5

Heart rate monitor parts	5
Buttons and their functions	6
Easy start	8
How to prepare the wrist receiver	8
Installing the Polar Bike Mount	9
Installing the Polar Speed Sensor	9
How to put the transmitter on	11
How to start measuring your heart rate	11
How to stop measuring your heart rate	12
After exercising	12
Modes and their functions	13

B. How to enter settings 18

User information settings	20
Exercise settings	23
Selecting exercise type	23
Setting exercise sets	24
Setting timers	26
Setting heart rate limits	26
Turning heart rate limits on/off ...	26
Setting interval type	27

Setting the number of intervals ..	28
Setting recovery calculation	29
Naming exercise sets	30
Turning functions on/off	31
OwnCal calorie counter on/off	31
Fitness test on/off	32
Predicted maximum heart rate on/off	32
Bicycle feature settings	33
Wheel size	34
Cadence on/off	36
Autostart on/off	36
Naming bike 1 or 2	37
Monitor settings	38
Turning activity/button sound on/off	38
Selecting measuring units	38
Turning Help on/off	39
Watch settings	40
Setting alarm	40
Setting time of day	41
Setting date	41
Setting tips	42
Swap time 1 or time 2	42

Shortcut to watch settings	42
Swap measuring units	42
Swap date and user ID	42
C. Exercise 43	
Measure mode	43
Autostart for recording a cycling exercise	46
Exercise recording mode	47
Illuminating the display	48
Turning heart rate zone alarm on/off	48
Swapping the heart rate limits	48
Storing lap and split time	49
Pausing the exercise	49
Swapping the displayed exercise information	50
Resetting the stopwatch to zero	51
Starting an exercise set	52
Exercising with Interval Training Set ...	52
Warm-up phase	53
Interval phase	54
Cool-down phase	56

Interrupting an interval training exercise	57
Exercising with BasicSet	57
Starting the timers	57
Starting the recovery calculation	58
Stopping the exercise	58
Tips during exercise	59
Checking the heart rate limits	59
Swapping the exercise type	59
Swapping the bike setting	59
Resetting the trip distance	59
Restarting the interval or recovery calculation	59
Interrupting an interval or recovery calculation	59
Interrupting a phase of an interval training exercise	59

D. How to recall training information 60

Exercise time	63
Recovery information of BasicSet	63
Exercise distance	63
Speed information	63



Cadence information	64
Heart rate limits	64
Exercise time within, above and below the heart rate zones	64
Calorie expenditure	64
Cumulative calorie count	64
Cumulative exercise time count	64
Cumulative riding time	65
Odometer	65
Interval training information	65
Warm-up phase	65
Interval phase	66
Cool-down phase	67
Lap information	67
Resetting cumulative counts to zero ...	68

E. Connection to computer	69
Downloading training data to computer	69
Uploading settings from computer	71

F. Polar Fitness Test	73
OwnIndex	73
Predicted maximum heart rate	75
Fitness test settings	76
Carrying out the test	76
Update OwnIndex and HR _{max} -p	78
Fitness classes	79

G. Care and maintenance	81
--------------------------------------	-----------

H. Precautions	84
-----------------------------	-----------

I. Frequently asked questions	88
--	-----------

J. Technical specifications	93
--	-----------

K. Limited Polar Warranty	96
--	-----------

L. Disclaimer	97
----------------------------	-----------

M. Polar glossary	98
Display symbols	100
Display texts	101
Index	104




A. GETTING GOING

Heart rate monitor parts and their functions

The elastic strap holds the transmitter comfortably, yet firmly, in the correct position.

The Polar T61™ transmitter detects your heart rate and transmits it to the wrist receiver.

The Polar wrist receiver displays your heart rate and cycling data during exercise. Enter your personal settings into the receiver and analyse the exercise files after you're done.





Buttons and their functions

Signal/ Light Turns the beep on or off.
Turns the backlight on.

Reset Resets the heart rate monitor.

Stop Return - Stops measuring the heart rate.
Exits the displayed mode and returns to the previous mode level.
Returns to the Time of day display from any mode by pressing and holding the stop button.

OK Accept - Starts measuring the heart rate (start).
Enters the displayed mode shown on the lower level (start). Locks in your selection (ok). Records lap information (lap). The Help text (start, ok or lap) that appears on the display above the button indicates its use.

 **SIGNAL/ LIGHT**

RESET

 **STOP**

OK



Useful tips

- Briefly pressing a button (approximately 1 second) will do different things than pressing and holding the button for a longer period of time (approximately 2 to 5 seconds). If you press the button for a longer period of time, you can use shortcuts.
- The buttons are slightly stiffer than those of an ordinary watch to prevent them from being pressed accidentally.
- You can always return to the Time of day display from the Options setting or File recalling loops by pressing and holding the stop button.
- See the glossary for display symbols and text interpretation.

 **Up**

Moves to the following mode. Increases the selected value.

 **Down**

Returns to the previous mode. Decreases the selected value.

A 6

A 7





Easy start

How to prepare the wrist receiver


1. Since the display is blank when the receiver leaves the factory, you have to activate the wrist receiver by pressing the OK button twice, after which the Time of day display appears. This is a one-off procedure; once you have turned on your receiver you can not turn it off anymore.
2. You may start measuring your heart rate right away using the default settings. However, the following settings are ones that it would be useful to change as soon as possible: Time of day (see section Watch settings) and personal user settings (see section User information settings).
3. Polar S510 has various functions that you can use according to your personal training needs. For more information, see section Modes and their functions. You can either manually enter the settings by pressing the receiver buttons or you can define your settings using PC Coach Light software, after which the data should be transferred from your computer to the wrist receiver.
4. Wear the wrist receiver as you would wear an ordinary watch. If you go biking, we recommend attaching the wrist receiver to a Polar Bike Mount™.

A 8



Installing the Polar Bike Mount



Use cable ties to secure the bike mount snugly on the rubber pad. Attach the receiver by securing the wrist strap.



Installing the Polar Speed Sensor™



The Polar Speed Sensor measures speed and distance when cycling.

1. Check the front side of the front fork to find a suitable place for the speed sensor. The sensor should be attached 20-50 cm/ 8"-1'8" from the mounted wrist receiver.
2. Clean and dry the area underneath the rubber pad before you attach it to the front fork.
3. Adjust the angle of the sensor at 45-90 degrees as shown in the illustrations.
4. Pass the cable ties through the sensor holes and loosely adjust the



A 9





- ties. Do not tighten fully yet. If the cable ties are too short for your bicycle, put two of them together to make them longer.
5. There are two spoke magnet options. You only need to install one of them. One is installed by rotating it around the spoke before putting the metal cover on, another by tightening the screw. The magnet must be facing the speed sensor.
 6. Fine-tune the positioning of both the magnet and the sensor so that the magnet passes the sensor closely but does not touch it. The maximum distance between the speed sensor and the spoke magnet should be 5 mm / 0,2". Once positioned correctly, tighten the cable ties securely and cut off any excess cable tie ends.

! Your safety is important to us. While riding your bike, please keep your eyes on the road to prevent possible accidents and injury. Check that you can turn the handle bar normally and cable wires for brakes or gearing donot catch on the sensor. Check also that the sensor does not disturb pedalling or the use of brakes or gearing.

A 10



How to put the transmitter on

1. Attach the transmitter to the elastic strap.
2. Adjust the strap length to fit snugly and comfortably. Secure the strap around your chest, just below the chest muscles, and buckle it.
3. Lift the transmitter off your chest and **moisten the grooved electrode areas** on the back.
4. Check that the wet electrode areas are firmly against your skin and the Polar logo is in a central, upright position.

How to start measuring your heart rate

1. Begin with the display that shows the time of day.
2. Keep the wrist receiver within 1 metre/ 3 feet of your transmitter.
3. Check that you are not near other people that have heart rate monitors, high voltage power lines, televisions, mobile phones or other sources of electromagnetic disturbance.



A 11





4. Press the OK button to start measuring your heart rate. A heart symbol will start flashing and your heart rate (beats per minute) will appear in a maximum of 15 seconds.
5. Press OK again. The stopwatch starts running and you can start exercising. The exercise data will only be stored in a file if you have turned the stopwatch on.

How to stop measuring your heart rate

1. Press the stop button. The stopwatch and other calculations stop. The heart rate measuring continues, although exercise data is no longer recorded.
2. Press the stop button again. The heart rate measuring stops. The receiver shows the Time of day display again.

After exercising

1. Carefully wash the transmitter with a mild soap and water solution.
2. Rinse it with pure water.
3. Dry the transmitter carefully with a soft towel.
4. Store the transmitter in a clean and dry place. Dirt impairs the elasticity and functioning of the transmitter. Sweat and moisture can keep the electrodes wet and the transmitter activated, which shortens battery life.

A 12



Modes and their functions

Your Polar S510 has six main modes: Time of day, Exercise, File, Options, Fitness test and Connection.

1. TIME OF DAY

You can use your Polar heart rate monitor as an ordinary watch with date, weekday indicator and alarm function. You can also change between two different countries' time zones.

2. EXERCISE

In the Exercise mode, you measure your heart rate and exercise information is recorded in the File mode. You can preset up to five exercise sets for your personal needs. When you start exercising, just select one of the saved sets. Or, you can select BasicUse (heart rate measurement without heart rate limits, timers or other exercise guiding functions).

A 13



A. During BasicUse, you can save 99 split and lap times with current, maximum and average heart rates for each lap. You can configure the display to show information on the following:

- your current heart rate, average heart rate or a reading of your maximum heart rate in percentages
- the current exercise time (stopwatch)
- time of day
- current lap and split time as well as the lap number
- calorie count for your exercise session
- current, average and maximum speed
- trip distance
- cadence*

B. Freely programmable BasicSet will automatically guide you through your exercise session with the help of the following functions:

- three adjustable target heart rate limits
- three adjustable, alternating timers
- time-based or heart-rate-based recovery calculation

C. Freely programmable Interval Trainer will automatically guide you through your interval training session with the help of the following, preset exercise phases:

- warm-up with a target heart rate zone and a countdown timer
- up to 30 intervals with a target heart rate zone. After each interval you have a recovery calculation option.
- cool-down with a target zone and a countdown timer

*Optional Polar Cadence Sensor required

A 14



3. FILE

Your receiver stores the latest exercise information in one **complete file**:

- the start date and time of the exercise
- total exercise time
- the average and maximum heart rate readings for the exercise session
- the recovery value (only BasicSet)
- your heart rate limits used during the exercise
- total distance of the exercise
- average and maximum speed
- average and maximum cadence*
- your time spent in, above and below your target zones during exercise
- OwnCal calorie expenditure
- your cumulative calorie expenditure
- your cumulative exercise time
- cumulative riding time
- odometer
- your interval training information: warm-up, interval and cool-down phases
- your lap information: best lap time; lap and split times; and current, average and maximum heart rate for each lap; and speed at the end of the lap

In addition to a complete file, your five previous exercise sessions will be saved in five **summary files**. These record:

- the start date and time of the exercise
- total exercising time
- the average and maximum heart rate readings for the exercise session

A 15





4. OPTIONS

In the Options mode, you can enter the following settings:

Exercise settings: you can select BasicUse with no settings or 5 freely programmable BasicSets or Interval Training Sets

Turning the functions on/off: OwnCal calorie counter, fitness test, predicted maximum heart rate

Bicycle feature settings: Bike 1 or 2 on/off, wheel size, cadence* on/off, autostart on/off

User-specific information: weight, height, date of birth, gender, activity level, maximum heart rate and maximal oxygen uptake

Monitor settings: activity/button sound on/off, measurement units, Help on/off

Watch settings: alarm, time of day and date

*Optional Polar Cadence Sensor required



5. FITNESS TEST

In this mode you can:

- perform the Polar Fitness Test
- recall your latest test results; OwnIndex and HR_{max} -p values
- update your user information to reflect your most recent OwnIndex and HR_{max} -p values

6. CONNECTION

In this mode you can:

- upload your receiver settings from your computer with PC Coach Light version 3.0 or later
- download recorded exercise information to your computer for detailed analysis with PC Coach Light version 3.0 or later






B. HOW TO ENTER SETTINGS



This section describes how to manually enter settings by pressing the receiver buttons. However, Polar S510 offers you another way as well: prepare your settings with PC Coach Light software and upload them to your receiver from your computer. See chapter Uploading settings from computer.

B 18



1. In the Time of day display, scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode. EXERCISE SET is displayed.
3. Scroll up or down until the desired setting mode is displayed.
4. Press OK to start the settings.

- Move forward and backward by using the up or down buttons.
- Press OK to start adjusting the value.
- Scroll up or down to adjust the value.
- Press OK to lock in your selection.
- Move backward to the previous setting level by pressing the stop button.
- To return to the Time of day display, wherever you are in the Options settings: Press and hold the stop button.
- The digits run faster if you press and hold the up or down button as you adjust the value. Release the button when approaching the desired value.
- On the display each function is presented by an abbreviated text.
A flashing block on the display indicates how far you are in the setting mode.

B 19





User information settings

Options

User Set

kg/ lbs → cm/ feet inch → Birthday → Sex → Activity → HR_{max} → VO_{2max}

! In the User Set loop you can move forward only by pressing OK.

Measuring units depend on the settings in Options/ Monitor Set/ Unit 1 or Unit 2.

	Units 1	Units 2
Weight	kg	lbs
Height	cm	ft/ inch
Date of Birth setting order	day - month - year	month - day - year

1. In the Time of day display scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode. EXERCISE SET is displayed.
3. Scroll up or down until USER SET is displayed.
4. Press OK to start the user information settings.

Weight (kg or lbs)

5. Scroll up or down to adjust your weight. Press OK.

Height (cm or ft/ inch)

6. Scroll up or down to adjust your height. Press OK.

B 20



Date of birth (Birthday)

7. Scroll up or down to adjust your day of birth. Press OK.
8. Month appears. Scroll up or down to select your month of birth. Press OK.
9. Year appears. Scroll up or down to adjust the year of birth. Press OK.

Units 2: setting order is month - day - year.

Sex

10. Scroll up or down to select your gender. Press OK.

Activity level (Activity)

11. Scroll up or down to select your activity level for Polar Fitness Test. Press OK.

Assess your long-term physical activity level. Do not change your activity level description if your regular exercise habits have changed during the last six months.

- Low You do not participate regularly in programmed recreational sport or heavy physical activity. E.g. you walk only for pleasure or occasionally exercise sufficiently to cause heavy breathing or perspiration.
- Middle You participate regularly in recreational sports. E.g. you cycle 15-30 km per week or spend 1/2-2 hours per week in comparable physical activity or, your work requires modest physical activity.
- High You participate regularly, at least 3 times a week, in heavy physical exercise. E.g. you cycle 30-60 km per week or spend 2-3 hours per week in comparable physical activity.

B 21



Top You participate regularly in heavy physical exercise at least 5 times a week.
E.g. you exercise to improve performance for competitive purposes.

Maximum heart rate value (HR_{max})

12. Your age-predicted maximum heart rate value is displayed as a default setting when you set this value for the first time. **If you know your exact clinically tested current maximum heart rate value**, set the value by scrolling up or down.
13. Press OK.

If you do not know this value, update it in the Fitness Test mode after having carried out the Polar Fitness Test.

Maximal oxygen uptake value (VO_{2max})

14. The wrist receiver suggests value 35 for females and value 45 for males as a default setting when you set this value for the first time. **If you know your exact clinically tested current maximal oxygen uptake value**, set the value by scrolling up or down.
15. Press OK. USER SET appears.

If you do not know this value, update it in the Fitness Test mode after having carried out the Polar Fitness Test

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.

B 22



Exercise settings

When you start setting your exercise preferences your first choice is to select whether you want to set your personal exercise set or to exercise with BasicUse option. If you select to start setting the exercise sets, your second choice is whether you want to select BasicSet or an Interval Training Set.

Selecting exercise type

BasicUse (E0)

BasicUse is a simple mode for exercising. You do not have to do any settings before exercising with this Exercise mode. While exercising, you can see the following optional values on the display:

- current heart rate or average heart rate of the exercise
- stopwatch
- time of day
- split- and lap times

Additionally, you can follow calories of your exercise session, percentage of your maximum heart rate and cycling information, if you have set all the user information and turned the functions on.

Exercise set (E1-E5)

During exercising with this mode you can see the same optional values as in the BasicUse mode. Additionally, the exercise set will guide you through your exercise according to the settings you have made. You can also name the exercise sets e.g. after an exercise type.

You can set following exercise guiding functions:

- 3 heart rate limits
- 3 countdown timers
- interval function
- recovery calculation

B 23





Setting exercise sets

Preset exercise sets ready for five exercise sets; when you start exercising, just select one of the sets.

Interval Training Set



If you choose interval on, you can set 3 different exercise phases for each exercise set in following order:

Warm-up phase

- countdown timer 1 On/OFF
- heart rate limits 1 On/OFF

Interval phase

- interval calculation type
- number of repeated interval phases
- heart rate limits 2 On/OFF
- recovery calculation On/OFF

Cool-down phase

- countdown timer 3 On/OFF
- heart rate limits 3 On/OFF

If you set the countdown timers of the phase off, you have to manually stop the phase.

BasicSet

If you choose interval off, you can set the following functions to your exercise:

- timer 1 On/OFF
- timer 2 On/OFF
- timer 3 On/OFF
- heart rate limits 1 On/OFF
- heart rate limits 2 On/OFF
- heart rate limits 3 On/OFF
- recovery calculation On/OFF

You should select the timers on sequentially. E.g. you cannot set timer 3 on if timer 1 is off.

B 24



1. In the Time of day display scroll up or down until **OPTIONS** is displayed.
2. Press OK to enter the Options mode. **EXERCISE SET** is displayed.
3. Press OK to start the exercise settings. BasicUse E0 or exercise set E1-E5 is displayed.
4. Scroll up or down until the desired exercise type is displayed. Press OK.

Options

Exercise Set


E0 ↔ E1 ↔ E2 ↔ E3 ↔ E4 ↔ E5

If you chose BasicUse (E0): to return to the Time of day display, press and hold the stop button and skip the rest of the exercise settings.

If you chose exercise set (E1-E5) Interval On/OFF is displayed.

5. Scroll up or down to turn the interval function on or off. Press OK. Timer 1 is displayed.

Exercise Set 1 - 5



B 25





Setting timers

If you start from the Time of day display, repeat steps 1-5.

6. Scroll up or down until desired timer is displayed. Press OK to start setting the timer.
7. Scroll up or down to turn the timer on or OFF. Press OK.
Timer OFF: Skip steps 8-9.
8. Scroll up or down to adjust minutes. Press OK.
9. Scroll up or down to adjust seconds. Press OK.

Setting heart rate limits

If you start from the Time of day display, repeat steps 1-5.

6. Scroll up or down until desired Limits is displayed.
7. Press OK to enter the limits loop.
8. Lim High appears. Scroll up or down to adjust your upper limit. Press OK.
9. Lim Low appears. Scroll up or down to adjust your lower limit. Press OK.

Turning heart rate limits on/off

If you start from the Time of day display, repeat steps 1-5.


6. Scroll up or down until Limits is displayed.
7. Press and hold the signal/light button to turn limits on or off. Release.

B 26



Setting interval type

You can select 4 optional types of intervals:

- | | |
|-------------------------------------|--|
| A. Time-based interval | Ends your interval when you have used the selected time. |
| B. Heart-rate-based interval | Ends your interval as you reach the selected heart rate.
 When selecting heart-rate-based interval, recovery calculation must be set on. |
| C. Distance-based interval | Ends your interval as you reach the selected distance. |
| D. Manual interval | End the interval training session by pressing OK. |

If you start from the Time of day display, repeat steps 1-5.

6. Scroll up or down until Interval TIMER/ Hr/ DIST/ MANUAL is displayed. Press OK to start setting the interval type. TIMER/ Hr/ DIST/ MANUAL is flashing.
7. Scroll up or down to select the interval type that will be used to end the interval. Press OK. If you chose manual interval skip steps 8 - 9.

B 27



A. Time-based interval

8. Scroll up or down to adjust minutes. Press OK.
9. Scroll up or down to adjust seconds. Press OK. Interval TIMER appears.

Or

B. Heart-rate-based interval

8. Scroll up or down to adjust the heart rate that will end your interval. Press OK. Interval Hr appears.

Or

C. Distance-based interval

8. Scroll up or down to adjust kilometres. Press OK.
9. Scroll up or down to adjust hundreds of metres. Press OK.

Units 2: Adjustable units are miles and feet.

Setting the number of intervals


If you start from the Time of day display, repeat steps 1-5.

You can set up to 30 intervals.

6. Scroll up or down until Repeat is displayed.
7. Press OK to start setting the number of intervals.
8. Scroll up or down to adjust the number of intervals. Press OK.

Or

If you do not know in advance the precise amount of the desired intervals select continuous interval. The intervals will succeed until you manually stop the interval phase or until 30 intervals have been made.

8. Scroll down until Cont  appears. Press OK.

B 28



Setting recovery calculation

A. Recovery timer

Ends your recovery as you reach the preset time.

Or

B. Recovery heart rate

Ends your recovery as you reach the preset heart rate.

Or

C. Recovery distance

Ends your recovery as you reach the selected distance.

If you start from the Time of day display, repeat steps 1-5.

6. Scroll up or down until Recovery TIMER/ Hr/ DIST is displayed.
7. Press OK to start setting recovery calculation on or off. On/OFF is flashing.
8. Scroll up or down to turn the recovery calculation on or off. Press OK. OFF: skip steps 9-11. On: TIMER/ Hr/ DIST is flashing.
9. Scroll up or down to select recovery timer, heart rate or distance. Press OK.

A. RecoTime is displayed.

10. Scroll up or down to adjust minutes. Press OK.
11. Scroll up or down to adjust seconds. Press OK. Recovery TIMER appears.

Or

B 29





B. RecoHr is displayed.

10. Scroll up or down to adjust the value. Press OK. Recovery Hr appears.

Or

C. Rec. Dist is displayed.

10. Scroll up or down to adjust kilometres.

Press OK.

11. Scroll up or down to adjust hundreds of metres. Press OK. Recovery DIST appears.

Units 2: Adjustable units are miles and feet.

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.

Naming exercise sets

You can name the exercises, with seven letters, numbers or punctual marks. The available digits are: 0-9, space, A-Z, a-z, - % / () * + : ?.


1. In the Time of day display scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode. EXERCISE SET is displayed.
3. Press OK. E0 - E5 is displayed.
4. Scroll up or down until desired exercise set (E1 - E5) is displayed.
5. Press and hold signal/light button. Adjustable letter is flashing.
6. Scroll up or down to select the desired mark. Press OK.
7. Repeat previous step until you have chosen all 7 letters.

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.

B 30



Turning functions on/off



1. In the Time of day display scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode. EXERCISE SET is displayed.
3. Scroll up or down until FUNCTION SET is displayed.
4. Press OK to start the function settings. OwnCal is displayed.



To set the following functions on you have to set your user information. If kg/lbs are displayed as you start setting the function on, the wrist receiver points out that you have not set your all user information.

OwnCal calorie counter on/off

If you start from the Time of day display, repeat steps 1-4.

5. Press OK to start setting the OwnCal function. On/OFF starts to flash.
6. Scroll up or down to set the OwnCal on or off. Press OK.

For getting the most accurate OwnCal results, update the VO_{2max} setting and the HR_{max} setting with clinically measured values (if available). If you do not know your clinically measured values perform Polar Fitness Test and update the OwnIndex and HR_{max-p} settings in Fitness test mode.

B 31





Fitness test on/off

If you start from the Time of day display, repeat steps 1-4.

5. Scroll up or down until Fit. Test is displayed.
6. Press OK to start setting the fitness test. On/OFF starts to flash.
7. Scroll up or down to set the fitness test on or off. Press OK.

Predicted maximum heart rate on/off (HR_{max}-p)

If you start from the Time of day display, repeat steps 1-4.

5. Scroll up or down until HRmax-p is displayed.
6. Press OK to start setting the HR_{max}-p. On/OFF starts to flash.
7. Scroll up or down to set the HR_{max}-p on or off. Press OK.


HR_{max}-p can be turned on only if Polar Fitness Test is on.

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.



Bicycle feature settings

Options



1. In the Time of day display scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode. EXERCISE SET is displayed.
3. Scroll up or down until BIKE SET is displayed.
4. Press OK to start the bike settings.
5. Scroll up or down to start setting the Bike 1 or 2 or turn the bike features off. Press OK. If you selected bike features off skip the rest of the bike settings.

You can set two bike preferences for the S510. Make the settings ready for both bikes; when you start exercising, just select bike 1 or 2. As you take the bike settings 1 or 2 in use your speed and distance measuring functions are always on. Before you can use the Polar S510 to measure distance, speed and cadence* information, you should adjust the wheel size information of your bike.

*Optional Polar Cadence Sensor required.





Adjusting the wheel size (Wheel)

If you start from the Time of day display, repeat steps 1-5.

6. Start with the display showing Wheel.
7. Press OK to start setting the wheel size.
8. Scroll up or down to adjust the wheel size. Press OK.

You have the following alternatives to find out the wheel size of your bike:

METHOD 1.

Look at the wheel of your bike and find the wheel diameter printed on it. On the chart below, find your wheel diameter in inches or in ERTRO reading. Match it to the wheel size in millimetres on the right.

ERTRO	Wheel size diameter (inches)	Wheel size setting
30-559	26x1.25	1953
35-559	26x1.5	1985
44-559	26x1.75	2030
47-559	26x1.95	2050
	26x1 1/8 Tubular	1970
	650-20C	1952
622-20	700x20C	2086
622-23	700x23C	2096
622-25	700x25C	2105
	700C Tubular	2130
	28 (700 B)	2237

B 34



METHOD 2.

Mark the tread of the front tire with a line and roll the tire perpendicular to the ground. You can also use the valve as a mark. Mark a line on the ground. Move your bike on a flat surface straight ahead for one complete wheel rotation. Check that the tire is perpendicular to the ground. Draw another line on the ground exactly where the mark on the front tire touches the ground.

Measure the distance between the two lines on the ground. _____ mm

Substract 4 mm to account for your weight on the bike to get your wheel circumference.

- 4 mm

This is the value you must set on the meter.

_____ mm

- ! The wheel size is always indicated in millimetres as this is more accurate. Resetting the monitor enters the default values.

B 35





Cadence* on/off (Cadence)

If you start from the Time of day display, repeat steps 1-5.

6. Scroll up or down until Cadence is displayed.
7. Press OK to start setting the Cadence. On/OFF starts to flash.
8. Scroll up or down to set the Cadence on or off. Press OK.

Autostart on/off (AutoStrt)

If you start from the Time of day display, repeat steps 1-5.

6. Scroll up or down until AutoStrt is displayed.
7. Press OK to start setting the autostart. On/OFF starts to flash.
8. Scroll up or down to set the autostart on or off. Press OK.

Autostart means that the receiver automatically starts or stops the exercise recording, as you start or stop moving your bicycle.

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.

*Optional Polar Cadence Sensor required.

B 36



Naming Bike 1 and Bike 2

You can name the bikes with four letters, numbers or marks.

The number in the right corner of the display indicates, which bike settings are in use. (b0=Bike off, b1= Bike 1, b2=Bike 2)

1. In the Time of day display scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode. EXERCISE SET is displayed.
3. Scroll up or down until BIKE SET is displayed.
4. Press OK to start the bike settings.
5. Scroll up or down until Bike 1 or 2 is displayed.
6. Press and hold signal/light button. Adjustable letter is flashing.
7. Scroll up or down to select the desired mark. Press OK.
8. Repeat previous step until you have chosen all four letters.

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.

B 37





Monitor settings

1. In the Time of day display scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode.
EXERCISE SET is displayed.
3. Scroll up or down until MONITOR SET is displayed.
4. Press OK to start the monitor settings. Sound is displayed.

Options

↓
Monitor Set

↓
Sound On/OFF ↔ Units 1/2 ↔ Help On/OFF

↑

Turning activity/button sound on/off

If you start from the Time of day display, repeat steps 1-4.

5. Press OK to start setting the sound. On/OFF starts to flash.
6. Scroll up or down to set sound on or off. Press OK.

Activity/button sound consists of the button sound and in the Measure and Exercise modes the following activity sounds: start, stop and lap recording, phase start, interval phase end and recovery calculation end sounds. Does not consist of heart rate zone alarms, watch alarm or fitness test alarm.

Selecting measuring units

If you start from the Time of day display, repeat steps 1-4.

5. Scroll up or down until Units is displayed.
6. Press OK to start setting the units. 1 or 2 starts to flash.
7. Scroll up or down to select the desired unit. Press OK.

B 38



The units settings affect the following features:

	Units 1:	Units 2:
User information	kg, cm	lbs, feet
Date of birth	day-month-year	month-day-year
Speed	km/h	mph
Distance	km, hundreds of metres	miles, feet
Wheel size	mm	mm (NOTE!)

Turning Help on/off

If you start from the Time of day display, repeat steps 1-4.

5. Scroll up or down until Help is displayed.
6. Press OK to start setting the Help function. On/OFF starts to flash.
7. Scroll up or down to set the Help on or off. Press OK.

If you turn Help on, the flashing arrows guide you to use the correct buttons in the Options and File modes. During the exercise, when you are changing the middle row information, you can see the name of the function for few seconds.

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.


B 39





Watch settings

1. In the Time of day display scroll up or down until OPTIONS is displayed.
2. Press OK to enter the Options mode. EXERCISE SET is displayed.
3. Scroll up or down until WATCH SET is displayed.
4. Press OK to start the watch settings. ALARM is displayed.



Setting alarm

If you start from the Time of day display, repeat steps 1-4.

5. Press OK to start alarm settings. On/OFF starts to flash.
6. Scroll up or down to set alarm on or off. Press OK. 24h: skip step 7.
7. 12h: AM/PM starts to flash. Scroll up or down to select AM or PM. Press OK.
8. The hours start to flash. Scroll up or down to adjust the hours. Press OK.
9. The minutes start to flash. Scroll up or down to adjust the minutes. Press OK.

OFF: skip steps 6- 9.

When the alarm comes on, it will sound for one minute or you can turn it off by pressing any of the five buttons.

B 40



Setting time of day

If you start from the Time of day display, repeat steps 1-4.

5. Scroll up or down until TIME1/ TIME2 is displayed.
6. Press OK to start setting the Time of day.
7. Time is flashing. Scroll up or down to select time 1 or time 2. Press OK.
8. 12h/ 24h starts to flash. Scroll up or down to select 12h or 24h time mode. Press OK. 24h: skip step 9.
9. AM/ PM starts to flash. Scroll up or down to select AM or PM. Press OK.
10. The hours start to flash. Scroll up or down to adjust the hours. Press OK.
11. The minutes start to flash. Scroll up or down to adjust the minutes. Press OK.

Setting date

If you start from the Time of day display, repeat steps 1-4.

5. Scroll up or down until DATE is displayed.
6. Press OK to start adjusting the date.
7. Day appears. Scroll up or down to select the desired value. Press OK.
8. Month appears. Scroll up or down to select the desired value. Press OK.
9. Year digits start to flash. Scroll up or down to select the year. Press OK.

12h Time mode:
month - day - year.

To continue your settings, press the stop button or to return to the Time of day display, press and hold the stop button.

B 41





Setting tips

Swap time 1 or time 2

In the Time of day display press and hold the down button. Time 1 or Time 2 is displayed in the uppermost row for a couple of seconds. Displayed time will now be used in all watch and alarm functions. If you chose time 2, "2" is displayed in the Time of day display.

Shortcut to watch setting loop

Press and hold the signal/light button for a couple of seconds to enter to watch setting loop. If you want to skip some parts and go directly to set a particular watch function, scroll up or down button until the desired watch function is displayed. Set the function as in the "Watch settings" section.

Swap measuring units

- as you set user information on weight and height.
 - as you set an Interval Training Set on distance-based interval or recovery.
- Press and hold the signal/light button until the units are swapped. Release the button.


Swap date and user ID

You are able to set a user ID by PC Coach Light software. When set, the user ID number is shown on the upper row of the Time of day display. You can swap the user ID and date by pressing and holding the up button.

B 42



C. EXERCISE



You can use two modes in your exercise: Measure or Exercise mode. In the Measure mode you can see your heart rate but your exercise is not recorded. In the Exercise mode your exercise is recorded and stopwatch and other calculations are started.

Measure mode

1. Wear the transmitter and the wrist receiver as described in "Easy start" section.
2. To make sure that the code search will be successful:
 - Keep the wrist receiver within 1 metre/ 3 feet of your transmitter.
 - Check that you are not near to other people with heart rate monitors, high voltage power lines, televisions, mobile phones, cars, motor driven exercise equipment or other electromagnetic disturbance.

C 43





3. Start from the Time of day display by pressing the OK to start measuring your heart rate. A heart symbol will start flashing and your heart rate in beats per minute will appear in max. 15 seconds. You have now entered to the Measure mode. The receiver returns automatically to the Time of day display within 5 minutes if there is no heart rate reception.


The following display appears as you enter the Measure mode. You can change this display to Stopwatch display by pressing the up or down button.



C 44



The following displays start to alternate, if you have bike 1 or 2 on, as you enter the Measure mode.



4. If you want to record cycling information, keep the bike still until your heart rate appears on the display. Press OK to start recording your exercise.

Or

If you want to record cycling information without heart rate measurement: after the heart rate reading 00 appears press OK and start cycling.

! If your preset exercise requires cycling settings Set bike is displayed for a few seconds. In order to start the exercise set you need to select bike 1 or 2 by pressing and holding the down button.

C 45





Autostart for recording a cycling exercise

If you start from the Time of day display, press OK briefly to enter the Measure mode. Your exercise recording automatically starts/ pauses as you start/ stop cycling.

If you want to record cycling information only, start cycling after the heart rate reading 00 appears on the display. If you want to record both cycling and heart rate information keep the bike still until your heart rate appears on the display.

C 46



Exercise recording mode

If you are starting from the Time of day display, press and hold OK.

Exercise information will be stored in an exercise file only when the stopwatch is running. The ongoing recording is indicated with a graphic bar that runs continuously on the display.

If your preset exercise requires cycling settings, Set Bike is displayed for a few seconds. In order to start the exercise set you need to select bike 1 or 2 by pressing and holding the down button until the desired Bike is displayed.

If there is 00 / - - reading on the display, there is no heart rate reception. Bring the wrist receiver up to your chest near the transmitter's Polar logo. The receiver starts looking for the heart rate signal again.



In the beginning of your exercise, when it has lasted less than 60 minutes, the exercise time is displayed in minutes and seconds. When you have exercised more than 60 minutes, the exercise time is displayed in hours and minutes.

You have three optional Exercise modes depending on the selected exercise:

- BasicUse
- Interval Training Set (Int On)
- BasicSet (Int OFF)

C 47





The following functions can be used during all three optional Exercise modes.

Illuminating the display

Press the signal/light button.

After you use backlight once in the Measure mode, Polar S510 automatically illuminates the display if you: start or stop the exercise session, store lap information and at the end of an interval and a recovery calculation.

Turning the heart rate zone alarm on/off

Press and hold the signal/light button.

When «» appears on the display the zone alarm is on. You will hear a beeping sound with each heartbeat if your heartbeat is outside the heart rate limit. If you do not want to use the zone alarm the flashing heart rate reading indicates if your heartbeat is outside the heart rate limit. This function can be used if you have set heart rate limits on.

In addition to the alarm you can see:

- ▲ if you are exercising above heart rate zone.
- ▼ if you are exercising below heart rate zone.

Swapping the heart rate limits

Press and hold the up button. Repeat until the desired limits are displayed. In the Interval Training mode the limits are automatically swapped when the phase changes to the preset limits.

C 48



Storing lap and split time

Press OK to store lap and split time.

First

Lap time
Average heart
rate of the lap
Number of
the lap



Then

Split time



Polar S510 automatically stores a lap time when you stop recording an exercise. Polar S510 can store 99 laps if you have not used the interval function. After storing 99 laps FULL appears for a few seconds every time you take a lap. You can continue taking laps but they will not be stored. The wrist receiver continues recording all other information of the exercise, except lap and interval information.

Pausing the exercise

Press the stop button.

The exercise recording, stopwatch and other calculations are paused. To continue them, press OK. Or, to return to the Time of day display, press and hold the stop button.



The receiver automatically returns to the Time of day display within 5 minutes if you forget to quit the heart rate measuring after having stopped the stopwatch and taken the transmitter off your chest.





C 49





Swapping the displayed exercise information

There are four display options, which you can swap between by pressing the down button. Once you have configured the display options, Polar S510 saves the settings. If the Help function is on, the name of the selected function appears for a few seconds.



! When you have set your Interval Training Set on, you will have one extra display in addition to the four displays. You can only change the middle and lower rows for this display.



See the alternative phase displays from “Exercising with Interval Training Set” section. You can also choose which information you want to be on the three display rows.



You can configure the middle and upper rows either in the Measure mode or during the exercise.

C 50



Select the middle row information

1. Press the down button to select the desired display alternative. When you swap the middle row information, the upper and lower rows change also. Continue selecting the upper and lower rows.

Select the upper row information

2. Press the up button to select from the following: Time of day (Time), stopwatch (Sw), lap time (Lp), or if you have turned the functions on select from: calorie expenditure (Cal), trip (Trip), current speed (Spd), average speed (Avg speed), maximum speed (Max speed) and cadence* (Cad).

You cannot select the same displayed function to the upper and middle row i.e. the option on the middle row is no longer available for the upper row.

Select the lower heart rate information row

3. Press and hold the down button to select from the following: Current heart rate, average heart rate (avg) or the reading in percentage of your maximum heart rate (% max) if you have set your user information.

You can only change the displayed function of the lower row if the stopwatch is on.

Resetting the stopwatch to zero

1. Pause your exercise.
2. Press and hold the down button until the stopwatch is reset. Release.

*Optional Polar Cadence Sensor required

C 51






- Press OK to restart the stopwatch and recording. Or, to return to the Time of day display, press and hold the stop button. As a result of resetting your stopwatch the previous file is deleted.

Starting an exercise set

- Start from the Time of day display. Press OK to enter the Measure mode.
- If you want to swap the preset exercise set, press and hold the up button until the exercise set (E1-E5) is swapped. Release. Repeat until desired exercise set is displayed.
- To start exercising and recording the preset exercise type press OK.

Exercising with Interval Training Set (Int On, E1-E5)


In this mode you can also use the functions in "Exercise recording mode" section.

The Interval Trainer automatically guides you through your exercise. In order to hear the activity sounds when the phase starts and stops make sure the activity/button sound is on. If you have turned the countdown timer of the phase off, you have to stop the phase manually by pressing the OK button. When the stopwatch starts running  indicates that Interval Trainer is on. As the interval training exercise ends the Polar S510 automatically starts a BasicUse exercise, which is recorded to the same file as your interval training exercise.

C 52



Structure of an interval training exercise:



Warm-up phase

- First
Heart rate limits 1 (if set on).



- Then
Countdown timer 1.
Heart rate information.



Countdown timer starts running if you have set the timer 1 on. If you have set the timer off, press OK and continue from the interval phase.

- At the end of warm-up phase
Warm-up phase duration.
Average heart rate of the warm-up phase.



C 53





Interval phase

The Polar S510 records up to 30 repeated interval phases. Your interval phase is divided into interval and recovery calculation (if set on) sections, which alternate continuously through your interval phase.

Interval session

1. First

Preset heart rate limits 2 (if set on).

2. Then

One of the following is displayed depending on your settings:

A. manual, **B.** time-based, **C.** heart-rate-based interval or **D.** distance-based interval.



A. Manual interval

Number of set intervals.

Current interval number.

If you selected manual interval your interval will end as you press OK.

Or

B. Time-based interval

Countdown timer.

If you selected time-based interval your interval will end as you reach the preset time.

Or

C. Heart-rate-based Interval

The difference between the preset interval heart rate and current heart rate.



C 54



If you selected heart-rate-based interval your interval will end as you reach the preset heart rate reading.

Or

D. Distance-based interval

Countdown distance.

Your interval will end as you reach the preset distance.



3. At the end of Interval

Interval duration.

Average heart rate of the interval.



When your interval ends the wrist receiver automatically continues with following preset function: recovery calculation or cool-down phase.

Recovery calculation

One of the following is displayed depending on your settings: **A.** time-based recovery calculation, **B.** heart-rate-based or **C.** distance-based recovery calculation.

A. Time-based recovery.

Recovery countdown timer.

Current heart rate.

Or

B. Heart-rate-based recovery.

The difference between the preset recovery heart rate and current heart rate.

Current heart rate.



C 55



Or

- C. Distance-based recovery**
Recovery countdown distance.
Current heart rate.



At the end of recovery

A. and B.

- Recovery duration.
Drop in your heart rate.

Or

C.


- Recovery distance.



Cool-down phase

1. First


- Preset heart rate limits 3 (if set on).



2. Then

- Countdown timer 3.
Heart rate information.

Countdown timer starts running if you have set the timer 3 on. If you have set the timer off press OK to end a phase.



3. At the end of cool-down phase

- Cool-down phase duration.
Average heart rate of the cool-down phase.



After your cool-down phase has ended the receiver automatically continues exercise recording with BasicUse mode.

C 56



You can continue using the heart rate limits of the previous exercise in this mode too. If you want to do another interval training exercise, press and hold the OK button.

Interrupting an interval training exercise

- Press the stop button to pause the exercise.
- Press and hold the stop button to return to the Time of day display.
Skip step 3.

Or

Press the stop button. BasicUse appears. You can continue measuring your heart rate in this mode (Measure mode) or continue exercising with BasicUse and recording your exercise information.

- Press OK to start recording the BasicUse exercise. Stopwatch is started and you can continue using and swapping the same heart rate limits of the previous exercise.

Exercising with BasicSet (Int OFF, E1-E5)

In this mode you can also use the functions in "Exercise recording mode" section.

Starting the timers

If timers are set on, they automatically start running once you start the stopwatch. Timers alternate in the following order: timer 1, 2, 3, 1, 2, 3, etc. At the end of timer 1 you will hear 1 beep, at the end of timer 2 you will hear 2 beeps and at the end of timer 3 you will hear 3 beeps. Timers stop running when you stop the stopwatch.

C 57





Starting recovery calculation

To start the recovery calculation, press and hold the OK button. See "Exercising with Interval Trainer"/ "Recovery calculation" for the displayed information during the recovery calculation. After the recovery calculation is done the exercise is paused. You can continue the exercise by pressing the OK button after the recovery calculation. If you do another recovery calculation, the recovery information will be deleted in consequence.

Stopping the exercise

1. Press the stop button to pause the exercise.
2. Press and hold the stop button until time of day is displayed.
Your lap and split time are automatically recorded, when you end the exercise.

Tips during the exercise

Checking the heart rate limits and illuminating the display

Bring the wrist receiver near the transmitter's Polar logo. The backlight is turned on for a couple of seconds. The current heart rate limits of the exercise are displayed.

Swapping the exercise type (E0 or E1 - E5)

In the Measure mode press and hold the up button. Release. Repeat until desired exercise set or BasicUse is displayed.

C 58



Swapping the bike setting (b0, b1 or b2)

Start from the Measure mode. Press and hold the down button until Bike 1 or 2 or Bike OFF is displayed. You can now start exercising with the chosen settings. For more information about cycling measurement, see the "Measure mode" and "Swapping the displayed exercise information" sections.

Resetting the trip distance

Pause the exercise, then scroll up until trip is displayed. Press and hold the signal light button until the trip reading is zero. Release. To continue your exercise press OK.

Restarting the interval or recovery calculation

Pause the interval or recovery calculation.
Reset the calculation by pressing and holding the down button. To restart the same calculation press the OK button or to reset the interval training exercise, see "Resetting stopwatch to zero" section.

Interrupting an interval or recovery calculation

Press and hold the OK button during your interval training exercise session to interrupt the calculation. The following section automatically starts. E.g. if you interrupt an interval your recovery calculation (if set on) automatically starts.

Interrupting a phase of an interval training exercise

Press the stop button to pause your phase. Press and hold the OK button. The following phase automatically starts.

C 59






D. HOW TO RECALL TRAINING INFORMATION



The Polar S510 starts saving your exercising information as you start the stopwatch in the Exercise mode. You can recall the information in the File mode. The Polar S510 stores one complete training file at a time. Your latest exercise is stored in a complete file until the next time you start the stopwatch. Then your previous complete file is compressed to a summary file. The summary file includes only the main exercise information (starting date and timer and exercise duration). The Polar S510 saves five summary files.

D 60




Your complete file is F1 the very first time, then F2 and so on, until you have recorded 6 complete files. Then F6 always indicates the latest complete file and F1 to F5 are the summary files. The bigger the file number the more recent it is.



Some information alternates on the display automatically. You can fasten alternation by pressing the OK button. E.g. the target zone information or heart rate information.

1. In the Time of day display scroll up or down until FILE is displayed.
2. Press OK to enter the File mode. The main information of your complete file is displayed.

Starting date and time alternate on the display.




3. If you wish to recall a summary file, scroll up or down until the desired file is displayed.
4. Press OK to start recalling the file. Exe. Time is displayed.

D 61





Complete File



- Move forward and backward within file loops with up or down buttons.
- Press OK to enter a file or to enter a deeper level in the file loop.
- Press the stop button to move backward to the previous file level.
- Press and hold the stop button to return the Time of day display, wherever you are in the File recalling cycle.

D 62



Exercise time (Exe. Time)

The exercise time is the amount of time that you have exercised with the stopwatch running. Average and maximum heart rates of your exercise alternate on the display. To continue recalling the complete file, scroll up or down button.

This is the first opening display that you will see in both summary and complete files. The summary file does not include any more information. To exit the summary file press the stop button.



Recovery information of BasicSet exercise (Reco)

- Recovery time.
- Recovery duration.
- Drop in your heart rate.

Or



- Recovery heart rate.
- Time it took reach the preset heart rate reading.
- Drop in your heart rate.

Exercise distance (Exe. Dist.)

You can see the exercised distance.

Speed information (Spd. Avg/ Max)

Average and maximum speed of the exercise alternate.

D 63



Cadence information* (Cad. Avg/ Max)

Average and maximum cadence of the exercise alternate.

Heart rate limits 1, 2 and 3 (Limits 1/ Limits 2/ Limits 3)

Settings of the heart rate limits alternate on the display. Limits 1 are used for target heart rate zone 1, limits 2 for zone 2 and limits 3 for zone 3.

Exercise time within, above and below the target heart rate zones

Indicates the exercise time, which you have spent within (InZone), above and below each heart rate limits during the entire exercise.

Calorie expenditure (KCal)

You will see how many kilocalories you have expended during the exercise.

Cumulative calorie count (Tot. KCal)

You will have a count for cumulative calories expended during several exercise sessions starting from the previous resetting. This function allows you to follow the calorie count as a gauge of effective exercise e.g. during one week.

Cumulative exercise time count (Tot. Time)

This function counts cumulative exercise time expended during several exercise sessions starting from the previous resetting. It allows you to follow the exercise time count as a gauge of amount of exercise e.g. during one week.

*Optional Polar Cadence Sensor required

D 64



Your cumulative total time is displayed in hours and minutes until 99 hours 59 minutes is reached. After this your cumulative exercise time is displayed in hours 100 h until 9999 hours is reached.

Cumulative riding time (Rid. Time)

You will have a count for cumulative riding time expended during several exercise sessions starting from the previous resetting.


Odometer (Odometer)

Measures cumulative total distance of several exercise sessions starting from the previous resetting.

Interval Training information (EXE. SET)

Start with the display showing EXE. SET.

1. Press OK to start recalling the interval training information.
2. Scroll up or down to see the information on warm-up, interval and cool-down phases.
3. To exit this loop press stop button.



Warm-up phase

Warm-up duration.

The heart rate at the end of the warm-up, average and

maximum heart rates of your warm-up phase.

D 65



Interval phase

Interval phase duration.

Average heart rate of intervals and recoveries.

Start with the display showing Interval.


Continue recalling more detailed information on your Interval phase.

1. Press OK to see details of each interval and recovery.
2. Scroll up or down between intervals and recoveries.
3. To return to the interval phase display press the stop button.

Interval information

Interval number

Split time of the interval



Interval duration.
Speed at the end of an interval (If bike 1/2 was on).
The heart rate at the end of the interval,
average and maximum heart rates of the selected interval.



Recovery information



Time-based recovery
Recovery duration.
Drop in your heart rate.

D 66



Or

Heart-rate-based recovery

Time it took reach the preset heart rate reading.

Drop in your heart rate.




Or

Distance-based recovery

Recovery distance

Drop in your heart rate.



Cool-down phase

Duration of the cool-down.

The heart rate at the end of the cool-down,
average and

maximum heart rates of the cool-down phase.

Lap information (LAPS)

Start with the display showing LAPS and number of the recorded laps.

1. Press OK to start recalling the lap information.
2. Scroll up or down to see the following information:



Best Lap

Shortest lap time.


The number of the best lap.

The best lap information is displayed if you have stored at least 3 laps. The best lap can not be the last lap.

D 67



Laps



Press the stop button to exit the LAPS display.
Press and hold stop to return to the Time of day display.

Resetting your cumulative counts to zero

Once you have reset the cumulative count you cannot retrieve it.
Start with the display showing Tot. KCal, Tot. Time, Rid. Time or Odometer.

1. Press OK to start resetting the desired total count. Reset appears and the value starts to flash.
2. Press and hold the down button. Reset starts to flash. You can still cancel the resetting by releasing the down button before the value is reset. If you are sure that you want to reset the value keep holding the down button until value is reset. Release.
3. Press the stop button to exit the reset display. Press and hold the stop button to return to the Time of day display.

D 68



E. CONNECTION TO COMPUTER



Polar S510 wrist receiver records essential data for your training log. A training log makes it possible to plan future training and to define the most suitable interval training for maximising performance capacity.

Downloading Training Data to Computer

Polar S510 offers an easy way to analyse training data by computer afterwards. It starts recording at a sampling rate of 15 seconds up to 120 samples. When the memory is full, it is compressed and a longer averaging period is used (30 s, 1 min, 2 min, 4 min or 8 min)

depending on the recording time. Maximum recording time is 16 hours. The table shows the exercise times for each sampling rate.

Sampling rate	Exercising time
15 s	- 30 min
30 s	30 min - 1 h
1 min	1 h - 2 h
2 min	2 h - 4 h
4 min	4 h - 8 h
8 min	8 h - 16 h

E 69





! To be able to transfer the recorded training information via SonicLink™ and to analyse it with PC Coach Light software version 3.0 or later, you need a personal computer with a sound card and microphone. To make sure that the training information transfer will be successful, check that there are no interfering sounds near the computer.

1. Start the software.
2. Activate the download function of the software.
3. If the receiver is in the Time of day display scroll up or down until CONNECT is displayed. Make sure that start is displayed.
4. Bring and hold the back cover of the receiver next to the computer's microphone. Keep the back cover of the wrist receiver within 5 cm/ 2" of the microphone until the SonicLink sound has ceased.
5. Press the OK button to start the data transfer. SonicLink and COM appear on the display. You will hear a chirping sound (SonicLink) while the training information is transferred to the computer. You can monitor the transfer percentage from the receiver's display. The receiver returns to the Time of day display after data transfer.

Interrupt the data transfer to the computer by pressing the stop button during data transfer. CONNECT is displayed.



Uploading Settings from Computer

Polar S510 offers you the option of uploading your settings with PC Coach Light software version 3.0 or later to the wrist receiver. You are also able to set a user ID for easier recognition in multi-user situations.

! To be able to upload the settings from PC Coach Light software via Polar Uplink, you need a personal computer with a sound card (compatible with Sound Blaster™) and dynamic loudspeakers or earphones.

1. Start the software.
2. If the receiver is in the Time of day display scroll up or down until CONNECT is displayed.
3. Place the receiver less than 10 cm/ 4" from the loudspeaker.
4. Activate the upload function of the software. Do not move the receiver during the data transfer.
5. The receiver automatically starts to upload the information as UpLink and COM appear and you will hear a chirping sound while information is transferred to the receiver. The receiver returns to the Time of day display after data transfer.





If the data transfer was unsuccessful bring the receiver closer to the loudspeakers or turn the volume level of the loudspeakers up.

Interrupt the data transfer to the computer by pressing the stop button during data transfer. CONNECT is displayed.



F. POLAR FITNESS TEST



Polar Fitness Test is an easy, safe and quick way to estimate individual maximal aerobic power and to get predicted maximum heart rate value. Polar Fitness Test is targeted to healthy adults.

OwnIndex

OwnIndex is a value which is comparable to maximal oxygen uptake (VO_{2max}), a commonly used descriptor of aerobic fitness. Cardiovascular (aerobic) fitness relates to how well your cardiovascular system works to transport and utilize oxygen in your body. The stronger and more efficient your heart is, the better the cardiovascular fitness is. VO_{2max} is a good indicator of performance capability in endurance sports.





If you want to improve your cardiovascular fitness, it takes a minimum of 6 weeks on an average to see a noticeable change in OwnIndex. Less fit individuals see progress even more rapidly and for more fit individuals more time is needed. The better the cardiovascular fitness of an individual, the smaller the improvements in OwnIndex.

Cardiovascular fitness is best improved by exercise types which employ large muscle groups. Such activities include running, swimming, rowing, skating, cross-country skiing, cycling and walking.

To monitor your fitness progress start with measuring your OwnIndex a couple of times during the first two weeks, to get a baseline value. Thereafter, repeat the test approximately once a month. OwnIndex is based on resting heart rate, heart rate variability at rest, age, gender, height, body weight and self-assessed physical activity.



Predicted maximum heart rate (HR_{max-p})

The HR_{max-p} definition is carried out simultaneously with the Polar Fitness Test.

The HR_{max-p} score predicts your individual maximum heart rate value more accurately than the age-based formula ($220 - \text{age}$). The age-based method provides a rough estimation and is thus not very accurate, especially for people who have been fit for many years or for older people. The most accurate way of determining your individual maximum heart rate is to have it clinically measured (in maximal treadmill or bicycle stress test) by a cardiologist or an exercise physiologist.

Your maximum heart rate changes to some extent in relation to your fitness. Regular endurance exercise tends to decrease HR_{max} . There may also be some variation according to the sport you participate in. For example, $\text{running } HR_{max} > \text{cycling } HR_{max} > \text{swimming } HR_{max}$.

HR_{max-p} gives the possibility of defining training intensities as percentages of maximum heart rate and of following maximum heart rate changes due to training, without an exhaustive maximal stress test. HR_{max-p} is based on resting heart rate, heart rate variability at rest, age, gender, height, body weight and maximal oxygen uptake, VO_{2max} (measured or predicted). The most accurate HR_{max-p} is obtained by entering your clinically measured VO_{2max} into the wrist receiver.





Fitness test settings

To be able to carry out the Polar Fitness Test you need to do the following settings in the Options mode:

- Set your personal user information and long-term physical activity level.
- Set the Polar Fitness Test on.
- Set the HR_{max}-p on if you want to get a prediction of your maximum heart rate.

Carrying out the test

To get reliable test results, the following basic requirements apply:

- You should be relaxed and calm.
- The test can take place anywhere – home, office, health club – as long as the testing environment is peaceful. No disturbing noises (e.g. television, radio or telephone), no other people talking to you.
- Keep the testing place, time of day and environment the same every time the test is repeated.
- Avoid eating a heavy meal or smoking 2-3 hours prior to testing.
- Avoid heavy physical effort, alcoholic beverages or pharmacological stimulants on the test day and the day before.

F 76



Time of Day ↔ File ↔ Options ↔ Fit. Test ↔ Connect

1. In the Time of day display scroll up or down until FIT. TEST is displayed. If you cannot find Fitness Test mode check that you have turned the function on in the Options mode.
2. Press OK to enter the Fitness Test mode. Your latest OwnIndex and the testing date are displayed.
3. Scroll up or down to see your latest HR_{max}-p and the testing date.
4. **Lie down and relax** yourself for 1-3 minutes before the test.

Start the test

It takes 3-5 minutes to carry out the test.

5. Press OK to start the test. The wrist receiver starts searching for your heart rate. TEST On and your heart rate are displayed. The test begins.
6. Lie relaxed. Keep your hands beside your body and avoid body movements. Don't communicate with other people.
7. Your current OwnIndex and the testing date are displayed.
8. If HR_{max}-p is on: Scroll up or down to see the HR_{max}-p result and the testing date.

Turn the fitness test sound signal on/off

The sound signal will alarm you at the end of the test. If the sound signal is on «))» appears on the display.

- To turn the sound signal on or off either before or during the test, press and hold the signal/light button.

F 77





Interrupt the test

- You can stop the test any time during the test by pressing the stop button. Failed TEST is displayed for a few seconds. The latest OwnIndex and HR_{max-p} are not replaced.

If the wrist receiver does not succeed in receiving your heart rate at the beginning or during the test, the test will fail. Check that the transmitter electrodes are wet and the elastic strap is snug enough.

Update OwnIndex and HR_{max-p}

You can update your OwnIndex and HR_{max-p} values to the Options mode/ User information. When you update these values regularly, the reading in percentages of your maximum heart rate and calorie calculation give more accurate individual information.

- In the Time of day display scroll up or down until FIT. TEST is displayed.
- Press OK to enter the Fitness Test mode.
- Scroll up or down until Update USER SET is displayed. This display appears if you have not updated your latest test results.
- Press OK to update the OwnIndex and HR_{max-p} values.
- To return to the Time of day display, press and hold the stop button.

! Your maximum heart rate value is updated if the HR_{max-p} is on.

F 78



Fitness classes

The Polar Fitness Test result, your OwnIndex, is most meaningful when comparing your individual values and changes in them. OwnIndex can also be interpreted according to your gender and age. Locate your OwnIndex on the table to find out your current cardiovascular fitness classification, compared with those who are of the same age and gender.

	Age (years)	1 (very poor)	2 (poor)	3 (fair)	4 (average)	5 (good)	6 (very good)	7 (excellent)
MEN	20-24	< 32	32-37	38-43	44-50	51-56	57-62	>62
	25-29	< 31	31-35	36-42	43-48	49-53	54-59	>59
	30-34	< 29	29-34	35-40	41-45	46-51	52-56	>56
	35-39	< 28	28-32	33-38	39-43	44-48	49-54	>54
	40-44	< 26	26-31	32-35	36-41	42-46	47-51	>51
	45-49	< 25	25-29	30-34	35-39	40-43	44-48	>48
	50-54	< 24	24-27	28-32	33-36	37-41	42-46	>46
	55-59	< 22	22-26	27-30	31-34	35-39	40-43	>43
	60-65	< 21	21-24	25-28	29-32	33-36	37-40	>40
WOMEN	20-24	< 27	27-31	32-36	37-41	42-46	47-51	>51
	25-29	< 26	26-30	31-35	36-40	41-44	45-49	>49
	30-34	< 25	25-29	30-33	34-37	38-42	43-46	>46
	35-39	< 24	24-27	28-31	32-35	36-40	41-44	>44
	40-44	< 22	22-25	26-29	30-33	34-37	38-41	>41
	45-49	< 21	21-23	24-27	28-31	32-35	36-38	>38
	50-54	< 19	19-22	23-25	26-29	30-32	33-36	>36
	55-59	< 18	18-20	21-23	24-27	28-30	31-33	>33
	60-65	< 16	16-18	19-21	22-24	25-27	28-30	>30


The classification is based on literature review (Shvartz & Reibold 1990) of 62 studies where VO_{2max} was measured directly in healthy adult subjects in the USA, Canada and 7 European countries. Reference: Shvartz E, Reibold RC: Aerobic fitness norms for males and females aged 6 to 75 years: a review. Aviat Space Environ Med; 61:3-11, 1990.

F 79





For various fitness classes we recommend the following:



Top athletes typically score OwnIndex values above 70 (men) and 60 (women). As high values as 95 can be reached by Olympic level athletes. OwnIndex is highest in sports that involve large muscle groups such as cross-country skiing and cycling.

F 80



G. CARE AND MAINTENANCE

Your Polar heart rate monitor is a high-tech instrument of superior design and workmanship and should be treated with care. The suggestions below will help you fulfill the warranty obligations and enjoy this product for many years to come.

Taking care of your Polar heart rate monitor

- Wash the transmitter regularly after use with a mild soap and water solution. Dry it carefully after washing with soft towel.
- Never store the transmitter wet. Sweat and moisture can keep its electrodes wet and the transmitter activated, which shortens the battery life.
- Store your Polar heart rate monitor in a cool and dry place. Do not store it in any kind of non-breathing material, such as a plastic bag or a sports bag if it is wet.
- Do not bend or stretch the transmitter. This may damage the electrodes.
- Do not dry the transmitter in any other way than with a towel. Hard-handed handling may damage the electrodes.
- Keep your Polar heart rate monitor out of extreme cold and heat. The operating temperature is -10 °C to 50 °C/ 14 °F to 122 °F.
- Do not expose the Polar heart rate monitor to direct sunlight for extended periods, such as by leaving it in a car.
- Do not immerse the speed sensor in water.
- Avoid hard hits to the speed sensor as these may cause damage.

G 81





Batteries

Polar T61 transmitter

The estimated average battery life of the Polar T61 transmitter is 2500 hours of use. Contact your distributor/ dealer for a transmitter replacement. Polar recycles used transmitters. See your Customer Care Charter for detailed instructions.

Polar S510 wrist receiver

The estimated average battery life of the Polar S510 wrist receiver is 2 years in normal use (2h/ day, 7 days a week). Note also that excessive use of the backlight and the alarm signals will use the battery more rapidly. Do not open the Polar wrist receiver yourself. To ensure the water resistance properties and the use of qualified components, the wrist receiver battery should be replaced only by an authorised Polar Service Centre. At the same time a full periodic check of the Polar heart rate monitor will be done.

Battery Replacement for Polar Speed Sensor

The estimated average battery life of the Polar Speed Sensor is 2500 hours of use. We highly recommend you send the speed sensor to an authorised Polar Service Centre for battery replacement, where the unit is water-resistant tested after the battery has been replaced. However, if you prefer changing the battery yourself, please follow these instructions carefully:



Detach the sensor from your bicycle.

1. Open the sensor by removing the two small screws, counter-clockwise, with a small screwdriver.
2. Lift the case off carefully. Hold the sensor cover upwards so that the PCBA (printed circuit board assembled) stays in the case.
3. Remove the PCBA carefully.
4. Press the battery holder gently. Release a hook of the holder from the opposite side of the PCBA and lift the holder upwards. Remove the old battery.
5. Insert a new battery with the plus (+) side facing up and press the battery housing gently so that it is attached to the PCBA at all corners.
6. Put the PCBA back into place.
7. Check that the sealing ring stays in its groove. Replace the cover back.
8. Insert the two screws in their holes and tighten them.
9. Test the sensor by checking that it gives out an orange flash when the spoke magnet passes the speed sensor.
10. Do not throw the replaced battery away with normal waste; take it to a place where problem waste is handled.

Service

Should your Polar heart rate monitor need service, see Customer Care Charter to contact an authorised Polar Service Centre.

! Water resistance cannot be guaranteed after unauthorised service.





H. PRECAUTIONS

Using the Polar S510 in a water environment

Your Polar S510 is water resistant to 20 metres/ 60 feet.

Heart rate measurement in a water environment is technically demanding for the following reasons:

- Pool water with a high chlorine content and seawater may be very conductive and the electrodes of Polar transmitter may get short circuited and ECG signals cannot be detected by the transmitter unit.
- Jumping into the water or strenuous muscle movement during competitive swimming may cause water resistance that shifts the transmitter on the body to a location where it is not possible to pick up ECG signal.
- The ECG signal strength varies depending on the individual's tissue composition and the percentage of people who have problems in heart rate measuring is considerably higher in a water environment than in other use.

H 84

Ma C.pm6

84-85



Polar heart rate monitor and interference

Electromagnetic interference

Disturbances may occur near high voltage power lines, traffic lights, overhead lines of electric railways, electric bus lines or trams, televisions, car motors, bike computers, some motor driven exercise equipment, cellular phones or when you walk through electric security gates.

Exercise equipment

Several pieces of exercise equipment with electronic or electrical components such as LED displays, motors and electrical brakes may cause interfering stray signals. To try to tackle these problems, relocate the Polar wrist receiver as follows:

1. Remove the transmitter from your chest and use the exercise equipment as you would normally.
2. Move the wrist receiver around until you find an area in which it displays no stray reading or flashing of the heart symbol. Interference is often worst right in front of the display panel of the equipment, while the left or right side of the display is relatively free of disturbance.
3. Put the transmitter back on the chest and keep the wrist receiver in this interference-free area as far as it is possible.
4. If the Polar heart rate monitor still does not work with the exercise equipment, this piece of equipment may be electrically too noisy for wireless heart rate measurement.

H 85

8.3.2001, 12:44





Minimising possible risks in exercising with a heart rate monitor

Exercise may include some risk, especially for those who have been sedentary. To minimise possible risks consider the following advice:

Before beginning a regular exercise program consult your doctor

- if you are over 40 years of age and have not been following a regular exercise program during the past 5 years
- if you smoke
- if you have high blood pressure
- if you have high blood cholesterol
- if you have any signs or symptoms of any disease
- if you are recovering from a serious illness or a medical treatment e.g. surgery
- if you use a pacemaker or another implanted electronic device.

Note also that in addition to exercise intensity the heart rate can be affected by, amongst others, heart, circulation (particularly high blood pressure) and asthma and other breathing medications, as well as some energy drinks, alcohol and nicotine.

It is important to be sensitive to your body's reactions during the exercise. If you feel unexpected pain or tiredness regarding your exercise intensity level, it is recommended to stop the exercise or continue at a lighter intensity.

H 86

Ma C.pm6

86-87



If you are allergic to any substance that comes into contact with the skin, check the Polar heart rate monitor materials from the "Technical specifications" chapter. It is recommended that you wear the transmitter against your bare skin to ensure flawless operation. However, if you wish to wear the transmitter over a shirt, moisten the shirt well under the electrodes.

Notice to persons with pacemakers, defibrillator or other implanted electronic device. Persons who have a pacemaker use the Polar heart rate monitor at their own risk. Before starting use, we always recommend an exercise test under doctor's supervision. The test is to ensure the safety and reliability of the simultaneous use of the pacemaker and the heart rate monitor.

H 87

8.3.2001, 12:44





I. FREQUENTLY ASKED QUESTIONS

What should I do if...

...I don't know where I am in the Options or File cycle?

Press and hold the stop button until time of day is displayed.

...I cannot find the previous exercise's file?

You may have used the Measure mode during your exercise, which means that your exercise was not stored. To record the exercise you have to turn the stopwatch on by pressing the OK button in the Measure mode.

...I cannot find the expended calories from my exercise file?

Check that you have set your personal user information and turned the OwnCal function on. Check that your heart rate has reached over 90 bpm or above 60 % of your maximum heart rate during your exercise.

...I cannot turn my HR_{max}-p on?

Check that you have set your personal user information and turned the fitness test on before turning the HR_{max}-p on.



...there is no heart rate reading (- -)?

1. Check that the electrodes of the transmitter are moistened and that you are wearing it as instructed.
2. Check that you have kept the transmitter clean.
3. Check that you are not near other people that have heart rate monitors, high voltage power lines, televisions, mobile phones or other sources of electromagnetic disturbance.
4. Have you had a cardiac event which may have altered your ECG waveform? In this case consult your physician.

...heart symbol flashes irregularly?

1. Check that the wrist receiver is not further than 1 metre/ 3 feet from the transmitter.
2. Check that the elastic strap has not become loose during exercise.
3. Make sure that the electrodes of the transmitter are moistened.
4. Make sure that there is no other heart rate transmitter within 1 metre/ 3 feet.
5. Cardiac arrhythmia may cause irregular readings. In this case consult your physician.





...other person with heart rate monitor is causing interference?

Your training partner may have exactly the same code as you. In this case proceed as follows: Keep a distance from your training partner and continue your training session normally.

Or

1. Take the transmitter off your chest for 30 seconds. Keep a distance from your training partner.
2. Put the transmitter back and bring the receiver up to your chest near the transmitter's Polar logo. The receiver starts looking for a heart rate signal again. Continue your training session normally.

...heart rate reading becomes erratic or extremely high?


You may have come within range of strong electromagnetic signals which cause erratic readings. Check your surroundings and move further away from the source of disturbance.

...the display is blank or fading?

If the display is blank, activate the wrist receiver by pressing the OK button twice, after which the Time of day display appears. The first sign of a discharged battery is the battery symbol on the display. Also the digits fade when the backlight is used. Have the batteries checked.

...there are no reactions to any buttons?

Reset the Polar heart rate monitor. Resetting clears watch settings which will return to the default settings. User information and measuring units settings will be saved.



1. Press the RESET button with a pen tip. Display becomes full of digits. If you don't press any button after reset within one minute the wrist receiver goes to the Time of day display.
2. Press any of the buttons once. The time of day is displayed.

...the battery of the wrist receiver must be replaced?

We recommend having all service done by an authorised Polar Service Centre. This is especially necessary to ensure the warranty remains valid and is not affected by incorrect repair procedures done by an unauthorised agent. Polar Service will test your wrist receiver for water resistance after battery replacement and make a full periodic check of the complete Polar heart rate monitor.

...there are irregular speed, distance or heart rate readings?

You may have come within range of strong electromagnetic-signals, which cause erratic readings. Check your surroundings and move away from the source of disturbance.

Another cyclist may have caused crosstalk with a Polar Speed Sensor. Keep a distance of at least 1 metre/ 3 feet between your wrist receiver and the Polar Speed Sensor of the other cyclist.






...the speed reading is 00 or there is no speed reading on the display while cycling?

1. Check the correct position and distance of the speed sensor with the spoke magnet and the wrist receiver.
2. Check that you have set bike 1 or 2 on.
3. If the 00 reading appears irregularly, this may be due to temporary electromagnetic interference in your current surroundings.
4. If the 00 reading is constant, you may have exceeded 2500 riding hours and the battery of the speed sensor needs to be replaced.

...I have questions concerning the SonicLink or the PC Coach Light software?

Contact your local distributor of PC Coach Light Biometrics Inc., 637 S Broadway, Suite B-156, Boulder, CO 80303, USA. Phone: + 1 (303) 494-9155, Fax: +1 (303) 494-9722, www.pccoach.com. Contact information is found also under the help menu of the PC Coach Light software.



J. TECHNICAL SPECIFICATIONS




Polar heart rate monitor is designed to indicate the level of physiological strain and intensity in sports and exercise. No other use is intended or implied. Heart rate is displayed as number of heartbeats per minute (bpm).

Polar transmitter

Battery type:	Built-in Lithium Cell
Battery life:	Average 2500 hours of use
Operating temperature:	-10 °C to +50 °C/ 14 °F to 122 °F
Material:	Polyurethane

Elastic strap

Buckle material:	Polyurethane
Fabric material:	Nylon, polyester and natural rubber including a small amount of latex





Wrist receiver

Battery type:	CR 2354
Battery life:	Average 2 years (2h/ day, 7 days/ week)
Operating temperature:	-10 °C to +50 °C / 14 °F to 122 °F
Water resistance:	to 20 metres/ 60 feet
Back cover material:	Polycarbonate and glass fibre
Wrist strap material:	Polyurethane
Wrist strap buckle material:	Stainless steel complying with EU Directive 94/27/EU and its amendment 1999/C 205/05 on the release of nickel from products intended to come into direct and prolonged contact with the skin.

Watch accuracy better than $\pm 0,5$ seconds/ day at 25 °C/ 77 °F temperature.
Accuracy of heart rate measurement: $\pm 1\%$ or ± 1 bpm, whichever larger, definition applies to steady state conditions.

Speed sensor

Operating temperature:	-10 °C to +50 °C / 14 °F to 122 °F
Battery type:	CR 2032
Battery life:	average 2500 hours of use
Accuracy:	$\pm 1\%$
Splash proof	

Default Settings

Time of day	24h
Alarm	OFF
Date of Birth	0 (adjustable range for year is 1921 - 2020)
Sex	Male
Weight	0 (kg)
Height	0 (cm)
Activity	Low
HR _{max}	220-age
VO _{2max}	
male (Male)	45
female (Female)	35
Bike 1/2	OFF
Wheel size for bike 1	2000
Wheel size for bike 2	2100
Cadence, autostart	OFF
Activity sound	On
Units	1
Help	On
OwnCal	OFF
Fitness test	On
HR _{max} -p	OFF
Interval function	OFF/ interval timer
Interval heart rate	160



Interval distance	2 km
Number of intervals	3
Timer 1, 2, 3	OFF/ 2 min
Limits 1, 2, 3	80/ 160
Recovery function	OFF/ recovery timer
Recovery heart rate	80
Recovery timer	1 min
Recovery distance	1 km

Limit Values


Exercise time	99 h 59 min 59 s
Heart rate limits	30 - 240
Heart rate zone time	99 h 59 min 59 s
Recovery time	99 min 59 s
Calories	99 999 kcal
Cumulative calories	999 999 kcal
Riding time	9999 h
Odometer	999 999 km/ miles
Cumulative exercise time	9999 h
Laps recorded to memory	99
Interval phases recorded to memory	30



Ma C.pm6

94-95

8.3.2001, 12:44





K. LIMITED POLAR WARRANTY

- Polar Electro Oy warrants to the original consumer/ purchaser of this heart rate monitor that the product will be free from defects in material or workmanship for one year from the date of purchase. **Please keep the receipt which is your proof of purchase!**
- Warranty does not cover receiver battery, damage due to misuse, abuse, accidents or non-compliance with the precautions; improper maintenance, commercial use, cracked or broken cases.
- Warranty does not cover damage or consequential damage caused by service not authorised by Polar Electro Oy.
- During the warranty period the product will be either repaired or replaced at an authorised service centre free of charge.
- This warranty does not affect the consumer's statutory rights under applicable national or state laws in force, or the consumer's rights against the dealer arising from their sales/ purchase contract.



This CE marking shows compliance of this product with Directive 93/42/EEC.

Copyright © 2000, 2001 Polar Electro Oy, FIN-90440 KEMPELE, Finland. All rights reserved. No part of this manual may be used or reproduced in any form or by any means without prior written permission of Polar Electro Oy. Polar logotype is a registered trademark and Polar S510 is a trademark of Polar Electro Oy.

The PC Coach logo is a registered trademark, and SonicLink and PC Coach Light are trademarks of, Biometrics Inc. U.S. Patents. 5 719 825 and 5 848 027. Sound Blaster is a trademark of Creative Technology, Ltd.

K 96

Ma C.pm6

96-97



L. DISCLAIMER



- The material in this manual is for informational purposes only. The products it describes are subject to change without prior notice, due to the manufacturer's continuous development program.
- Polar Electro Oy makes no representations or warranties with respect to this manual or with respect to the products described herein. Polar Electro Oy shall not be liable for any damages, direct or incidental, consequential or special, arising out of, or related to the use of this material or the products described herein.

This product is protected by one or several of the following patents:

FI 88223, DE 4215549, FR 92.06120, GB 2257523, HK 113/1996, SG 9591671-4, US 5491474, FI 88972, FR 92.09150, GB 2258587, HK 306/1996, SG 9592117-7, US 5486818, FI 96380, US 5611346, EP 665947, DE 69414362, FI 68734, DE 3439238, GB 2149514, HK 812/1989, US 4625733, FI 100924, FI 100452, US 5840039, FI 4150, FI 4069, DE 29910633, FI 104463.

Other patents pending.

L 97

8.3.2001, 12:44





M. POLAR GLOSSARY

Activity level: Your long-term physical activity level you need to assess in order to do the Polar Fitness Test.

BasicSet mode: Exercise set, which interval is set off.

Coded heart rate transmission: Polar T61 transmitter automatically locks in a code to transmit your heart rate to the wrist receiver. In a coded transmission the receiver accepts heart rate data only from the Polar T61 transmitter. Coding significantly reduces crosstalk caused by other users of heart rate monitors. However, it does not necessarily reduce all environmental interference.

Configuring the display: During the exercise you can modify four display options by selecting information to the lower and upper rows.

Electrodes: The grooved areas of the transmitter, against the skin. Pick up the heart rate.

Exercise mode: The stopwatch is on and your exercise is recorded. You can select between the BasicUse, Interval Training Set and BasicSet.

Heart rate: The number of heart beats per minute (bpm).

Interval training: Seeks to improve your race pace with different periods of work and rest.

Maximal oxygen uptake: (maximal aerobic power, VO_{2max}) Is the maximal rate at which oxygen can be used by the body during maximal work. VO_{2max} is a good index of aerobic fitness.

Maximum heart rate: (HR_{max}) Is the highest number of heart beats per minute of a person.

Measure mode: Measuring your heart rate without recording the exercise.



OwnIndex: Result of Polar Fitness Test and comparable score with maximal oxygen uptake (VO_{2max}).

Summary file: Presents the main information of your exercise.

Target heart rate zone: The area between the upper and lower heart rate limits. Target zone selection is based on personal fitness goals.





Display symbols

♥ Indicates an ongoing heart rate measurement and flashes to the beat of your heart.

▬▬ Indicates there has not been heart rate reception for less than 5 minutes.

-- Indicates there has not been heart rate reception for at least 5 minutes.

⚙ Options mode: indicates that you are setting the bike functions
Exercise mode: indicates that bike 1 or 2 is on.
File mode: indicates speed, cadence or distance information.

⌚ In the Time of day display the alarm is on.
Measure mode: beeps if you are exercising outside your target heart rate zone. Fitness Test mode: sounds an alarm at the end of the fitness test.

📊 Indicates the Interval Trainer.

📊 Indicates continuous interval (Cont).

▲ Exercise mode: indicates the heart rate above the target zone.
File mode: indicates the time spent above the target zone.

▼ Exercise mode: indicates the heart rate below the target zone.
File mode: indicates the time spent below the target zone.

M 100

Ma C.pm6

100-101



■ The graphic bar consists of five blocks. A flashing block indicates in which level you are in the Options settings or File recalling loops.
■ Continuously running bars indicate that the exercise is recorded.

⬡ Indicates low battery.

Display texts

ALARM: Indicates the alarm in watch settings.

AM or PM: Are used in 12h time mode. E.g. in 24h time mode 13:00 means 1:00 PM.

AVG: Together with a reading indicates average heart rate.

b0: Indicates that you have no bike settings on.

b1: Indicates bike 1 setting.

b2: Indicates bike 2 setting.

BasicUse: Exercising without settings.

BestLap: Indicates the shortest lap time information.

Cad*: Indicates pedalling speed measured in rounds per minute (RPM).

*Optional Polar Cadence Sensor required



CONNECT: Communication mode between wrist receiver and computer.

Cont: Up to 30 intervals succeed one another unless the Interval phase is manually stopped.

CoolDown: Cool-down phase at the end of an interval training exercise.

E0: BasicUse settings.

E1-E5: Indicates which exercise set you have used for the exercise.

ExeSet: Start setting your BasicSet (Int off) or Interval Training Set (Int on).

Exe. Time: Exercise duration.

FILE: Indicates the file mode.

FIT. TEST: Indicates fitness test mode.

M 101

8.3.2001, 12:44





FULL: After having stored 99 laps (the use of intervals reduces the amount). FULL appears in the display. You can continue taking lap times or intervals but they won't be recorded into the file.

HR_{max}-p: Predicted maximum heart rate value.

Interval, Int: Options mode: indicates Interval Training Set.

Exercise mode: Indicates interval exercise session including warm-up, interval and cool-down phases.

InZone/ Above/ Below: Indicate the time spent within, above and below the target zone.

KCal: Indicates the energy expenditure of your exercise.

Lap time: Lap time.

LAPS: Indicates how many lap times have been stored.

Lim High: The higher heart rate limit of the target zone.

Lim Low: The lower heart rate limit of the target zone.

Limits1, 2, 3: Heart rate limits for target zones 1, 2 and 3.

MAX: Indicates the highest heart rate.

MAX %: Indicates what percentage your current heart rate is of your maximum heart rate.

OPTIONS: Indicates the Options mode

Odometer: Measures cumulative total distance of several exercise sessions.

OwnCal: Calculates energy expenditure during exercise in kilocalories. 1 kilocalorie (kcal) = 1000 calories (cal). You can follow how much energy you lose by exercising in one exercise session or in a day, week or even a year. The OwnCal can be used as a dose measure of exercise e.g. in nutrition planning. OwnCal calorie calculation starts when your heart rate reaches 90 bpm or is above 60% of your maximum heart rate, whichever is smaller. These limits are set to count only exercise calories. The higher the heart rate, the faster the energy expenditure. OwnCal is individually calibrated by your preset

weight, maximal oxygen uptake (VO_{2max}) and maximum heart rate (HR_{max}). The most accurate OwnCal is received by entering your clinically measured (in maximal treadmill or bicycle stress test) VO_{2max} and HR_{max} into the wrist receiver. Energy expenditure measurement is most accurate in continuous activities such as cycling and running.

RecoDist, distance-based

recovery: You set the recovery distance in the Options mode. In the File mode you will see the drop in your heart rate and the recovery distance.

RecoHr, heart-rate-based

recovery: You set the heart rate, which will end your recovery calculation. In the File mode you will see the drop in your heart rate and the recovery duration.

RecoTime, time-based recovery:

You set the recovery time in the Options mode. In the File mode you will see the drop in your heart rate and the recovery duration.





Split Time: The elapsed time from the beginning of the exercise until storing the split time.

Sw: Indicates stopwatch.

Timer1, 2, 3: Interval Training mode: Countdown timers for the Interval Training set.

WarmUp: Warm-up phase in the beginning of an Interval Training exercise.






Index

12/ 24h time mode	41	Odometer	65
Activity/button sound On/OFF	38	OwnCal On/OFF	31
Alarm settings	40	OwnCal calorie expenditure	102
Autostart On/OFF	36	HR _{max} -p On/OFF	32
BasicSet exercise	24, 57	OwnIndex	73
Bike 1/2/OFF	33	Pause an exercise	49
Buttons	6	Predicted maximum heart rate	75
Cadence On/OFF	36	Precautions	84
Care and maintenance	81	Recall training information	60
Code search	43	Recovery during BasicSet	58, 63
Date settings	41	Recovery during Interval training ..	55, 66
Display configuration	50	Recovery settings	29
Download training data to a computer	69	Reset cumulative counts to zero	68
Easy start	8	Reset the stopwatch	51
Exercise set	23	Reset the trip distance	59
File	60	Return to the Time of day display	7
Fitness test	73	Selecting exercise type	23
Fitness test On/OFF	32	Setting tips	42
Frequently asked questions	88	Start an exercise set	52
Functions during the exercise	47	Start cycling measurement	45
Heart rate limits settings	26	Start measuring your heart rate	11, 43
Heart rate limits checking	59, 64	Stop an interval training session	57
Heart rate limits On/OFF	26	Stop measuring your heart rate	12, 58
Help On/OFF	39	Swap the exercise type	58
How to enter settings	18	Swap the heart rate limits	48
Illuminate the display	48, 58	Swap the time zones 1/ 2	42
Interval Training Set	24	Technical specifications	93
Interrupt an interval exercise phase	59	Time of day settings	41
Interrupt an interval or recovery calculation	59	Timer settings	26
Lap and split time storing	49, 67	Transmitter	5, 11
Measuring units settings	38	Update HR _{max} -p and OwnIndex to user information	78
Modes and their functions	13	Upload settings from computer	71
Naming bike 1 or 2	37	User information settings	20
Naming exercise sets	30	Warranty	96
		Wheel size	34
		Zone alarm On/OFF	48

M 104



Road Map



Dear Customer

Congratulations on purchasing a Polar Heart Rate Monitor! We are proud to assist you in achieving your personal fitness and performance goals. If you want to get even more out of your Polar S510 during training, check www.polar.fi for the best product and training tips in Polar Personal Trainer.



Manufactured by:
Polar Electro Oy
Professorintie 5
FIN-90440 KEMPELE

Tel. +358-8-520 2100
Fax +358-8-520 2300
www.polar.fi

POLAR