

## MasterScope 360 USB System

### System required:

CPU : 1GHz or Better

RAM : 512MB or Better

VGA : 32MB (Resolution 800x600 or 1024x786)

USB Port: 1.1 or 2.0

OS: Windows XP, Windows Vista, Windows 7



### Overview:



### System Specification

Power: USB Bus-Power

Interface: Mini usb 1.1/ 2.0

Video Out Format : NTSC & PAL

Recording Medium: PC Hard drive

Image Storage Format : JPEG

Video Recording Format: ASF

### Insertion Tube & Light Source

- Image Sensor : CMOS Image Sensor
- Size Tip (Insert Tube) Diameter:  
3.9/4.3/5.5/8/10mm
- Tube Length: 1 Meter (up to 30 Meter)
- Field of View (FOV) : 67°
- Depth of View (DOV) 1cm / 3-5cm / 8cm
- Light Source: 4-6 LED
- Probe Working Temperature: -20° to 70° C
- Ingress Protection: IP 57
- Mirror adapter: 35° ~70° / 4° 5-90° / 55° ~110°

Step 1. ----- Make sure the USB cable is not plugged into the Computer.

Step 2.----- Install software by following installation instructions.

Step 3.----- Connect USB cable to MasterScope 360 system and your PC



Step 4.----- Make sure Green Light LED is on.



Connection




Disconnect

Step 5.----- Double Click  icon from your Computer.

Step 6.----- MasterScope 360 Software should launch.

Step 7.----- Functionality description



- If you want to edit an image: Choose the image you want to edit, first. Then click the edit icon. You can rotate or enlarge the image.
- If you click the “2” icon: This option allows you the ability to compare the differences between two images.

