

This document provides additional assistance with wiring your Extron IP Link enabled product to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific Extron IP Link enabled product or the controlled device manufacturer supplied documentation.

Device Specifications:

Device Type: Video Projector
Manufacturer: Projectiondesign
Firmware Version: N/A
Model(s): F32 WUXGA

Minimum Software and Firmware Requirements:

IP Link Compiler	IP Link Firmware	GC Version
1.6.0	1.17	3.5.1

Version History:

Driver Version	Date	Notes
1	2/10/2014	Initial version.

Driver Notes:

IP Link® Device Interface Ethernet Communication Sheet

Control Commands & States:

Aspect Ratio	1:1 Fill All Letterbx st to 16:9	16:9 Fill Aspect Ratio	4:3 Letterbx to 16:9
Auto Image	Execute		
Freeze	On	Off	
Input	VGA Composite HDMI	S-Video Component BNC	DVI RGB XP2
Iris	Open	Close	
Iris Speed	1 to 3		
Lamp Mode	Normal	Eco	
Lamp Select	Lamp 1 Auto	Lamp 2	Dual Lamp
Menu Navigation	Up Right	Down Menu	Left Enter
On Screen Display	On	Off	Warning
Power Control	On	Off	
Video Mute	On	Off	

IP Link® Device Interface Ethernet Communication Sheet

Status Available:

Aspect Ratio	1:1 Fill All Letterbx st to 16:9	16:9 Fill Aspect Ratio	4:3 Letterbx to 16:9
Connection Status	Connected	Disconnected	
Freeze	On	Off	
Input	VGA Composite HDMI	S-Video Component BNC	DVI RGB XP2
Lamp 1 Status	Broken Off Status Unavailable	Warming Up Cooling Down	On Lamp is not present
Lamp 1 Usage	Hours		
Lamp 2 Status	Broken Off Status Unavailable	Warming Up Cooling Down	On Lamp is not present
Lamp 2 Usage	Hours		
Lamp Mode	Normal	Eco	
Lamp Select	Lamp 1 Auto	Lamp 2	Dual Lamp
On Screen Display	On	Off	Warning
Operation Hours	Hours		
Power Control	On	Off	
Power Status	On Warming Up	Off Status Unavailable	Cooling Down
Video Mute	On	Off	

Network communication:

When configuring the Ethernet driver, be sure device settings match that of the GC configuration.

Port Type:	Ethernet
Logon Credentials Supported:	Yes
Default User Name:	admin
Default Password:	admin
Default Port:	1025
Multi-Connection Capable:	Yes
Port Changeable:	Yes

Ethernet Driver Configuration Description:

Please refer to user manual for settings and changes to the network communication parameters such as: User Name, Passwords and Port Number.

Notes for the Device: