




American Weigh Scales, Inc.

AMW-13

Digital Tabletop Scale



AMW-13 *User Manual*

AMW-13 Manual

Thank you for purchasing the American Weigh AMW-13 digital tabletop scale. Please read all operating instructions carefully before use. This electronic scale is a precision instrument. With normal care and proper treatment, it will provide years of reliable service.

Never load the scale with more than the maximum capacity. Overloading will permanently damage it! Avoid any exposure to extreme heat or cold. Your scale works better when operated at normal room temperature. Always allow the scale to acclimate to normal room temperature for at least one hour before use. Give your scale sufficient warm up time. Usually 30-60 seconds before calibration to give the internal components a chance to stabilize.

Keep your scale in a clean environment. Dust, dirt, moisture, vibration, air currents and a close distance to other electronic equipment can all cause an adverse effect on the reliability and accuracy of your scale.

Handle with care. Gently apply all items to be weighed onto tray top. Although this scale is designed to be quite durable, try to avoid rough treatment as this may permanently damage the internal sensor.

Avoid shaking, dropping or otherwise shocking the scale. This is a precision instrument and must be handled with extreme care.

Only operate the scale on a stable, vibration free surface.

I. OPERATION

Place Scale on a horizontal flat surface.

1. Press [ON/OFF] key.
2. Wait until "0.0" is displayed.
3. Put the object(s) on the weighing platform.
4. Using the [MODE] key, you can switch between the weighing units.

II. TARE WEIGHING

1. Turn on scale as described above.
2. Place the "tare item" on the platform.
3. Press [TARE] and wait until "0.0" is displayed.
4. Add the "net-weight-item".

III. TROUBLESHOOTING

The primary reasons for inaccuracy or malfunction are low batteries, incorrect calibration, overload or operating on an unstable surface. Please keep this in mind and maintain and operate your scale properly.

This scale is a precise instrument and must be handled with the utmost care and caution.

Battery-Symbol, [lo]

Change the batteries.

[OUE2] Recalibrate the scale as shown above.

[EEEEEE] You are overloading the scale. Remove the excessive load immediately!

[UNST] Use the scale in a more stable position

Specifications

Model	AMW-13
Capacity	6000g / 13lb
Resolution	1g / 0.1oz
Weighing Units	grams (g), pounds / ounces (lb/oz)
Display	5 - Digit Backlit LCD
Platform Dimensions (Inches)	6 x 6 Stainless Steel
Scale Dimensions (Inches)	6.2 x 7.2 x 1.6
Power	one 9V Battery (included) or AC-Adapter (sold separate)
Gross Weight	1.69 lb