AUGUSt®

User Manual

Model No.: EP636



Bluetooth Wireless Stereo Headphones Casque Stéréo Sans-fil Bluetooth Kabellose Bluetooth Stereo Kopfhörer Cuffie Stereo Senza Fili Bluetooth Auriculares Estéreo Bluetooth Inalámbricos

August International Ltd United Kingdom Telephone: +44 (0)845 250 0586 www.augustint.com



User Manual

Thank you for purchasing the August EP636 Bluetooth Wireless Stereo Headphones. This user manual is designed to familiarise you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble the EP636, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

1. Safety Instructions

Storage and Use



Maintenance

Please unplug all leads before cleaning this device.



-2-

English

2. Main Features

- Wireless Headphones for Bluetooth Devices
- Micro USB Socket
- Hands-Free Calls with Integrated Microphone
- Built-in Rechargeable Battery
- Adjustable Headband
- Distance: up to 10m
- Bluetooth Version: Bluetooth V4.0

3. Accessories





USB charging cable

User manual

4. Part Names and Functions





- 1. Status LED
- 2. Previous Track

3. MFB - Multi Function Button (Turn on/off, Enter pairing mode, Play/Pause, Answer/End/Reject/Transfer call, Last number redial)

- 4. Volume Up
- 5. Next Track
- 6. Volume Down
- 7. Power Socket
- 8. Microphone
- 9. NFC

5. Operations

5.1 Switch On / Off

To switch on the device, press and hold the MFB button for 2 seconds until there is a warning beep. The status LED momentarily lights red after switching on.

To switch off the device, press and hold the MFB button for 3 seconds to switch off the device until there is a warning beep. The status LED will fade up then fade down.

5.2 Bluetooth Connections

Press and hold the MFB button for 5 seconds when the device is off to enter pairing mode. When the device enters pairing mode the LED flashes red and blue quickly and a two tone beep is heard.

- For mobile phones
- 1. Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed)
- 2. Select "EP636" from the available devices and confirm connection.

- 3. The status LED flashes blue to indicate a successful connection.
- 4. To enable multi-point which allows two phones to be paired at the same time, set the headphones to pairing mode and click the MFB button once to enable multi-point. Pair the headset to Phone A. Restart the headset to pairing mode and pair the headphones to Phone B, then use Phone A paired device list to reconnect to the headphones. When switching between phones, it may take about 10 seconds for the switchover to occur.
- 5. To disable multi-point, set the headphones to pairing mode and double click the MFB button.

Note: Accessing Bluetooth settings on mobile phones varies for each phone, to find the information for your phone, please refer to its user manual.

- For computers

- 1. Enable the Bluetooth function on your computer.
- 2. Select "Devices and Printers" from the Control Panel and click "Add a Device".
- 3. Select "EP636" from the available devices, the system will install the driver automatically.

Note: For Windows XP and Vista, a third-party Bluetooth driver is needed (not included).

- 4. The status LED flashes blue to indicate a successful connection.
- 5. If the EP636 is not automatically set as your output device, select "Sound" from the control panel then highlight the EP636 and select "Set Default".

Note: When switched on, the EP636 will automatically reconnect to the last paired Bluetooth device if it is in range.

- NFC

- 1) Enable Bluetooth and NFC functions on your source device.
- 2) Touch the NFC area of your source device against the NFC area on the left side of the EP636. They will automatically pair with each other.
- 3) Confirm Bluetooth pairing if prompted. "EP636" will now be listed in your source device's Bluetooth device list.

4) To disconnect your device, touch the NFC area of your device against the NFC area on the left side of the EP636.

Note: The first time you pair the EP636 through NFC, you will need to tap twice. Once to turn the headphones on and once to pair.

5.3 Remote Control

The EP636 is able to control the music playing on either a mobile phone or a computer with a Bluetooth connection. Click the MFB button to pause or resume playing music. Click "+" or "--" to increase or decrease the volume. Click "<" or " >" to select the previous or next track. Press and hold "<" or " >" to move fast backwards or forwards through the track.

Note: Music playing control is only compatible with devices that support A2DP, please refer to your devices user manual for its A2DP compatibility.

5.4 Hands-free Calling

- 1. Whilst connected to your mobile phone, the EP636 will act as a hands-free system for calls.
- 2. To pick up or hang up a call click the MFB button.
- 3. To reject an incoming call press and hold the MFB button for 2 seconds.
- 4. To transfer the call between the headphones and your mobile phone during a call, double click the MFB button.
- 5. For Last Number Redial double click the MFB button while the EP636 is connected to the mobile phone.

5.5 Factory Reset

When in pairing mode press and hold the MFB and "__" buttons at the same time for 5 seconds.

6. Charging

When the power is low, the status LED flashes red. To charge the EP636, connect the micro USB lead to the device's power socket, and the other end of the USB cable to a powered USB port.

The status LED constantly lights red whilst charging and lights blue once the battery is fully charged.

Note:

- 1) You must select a qualified charger from a regular manufacturer.
- 2) Make sure that the headphones are fully charged before using for the first time.
- 3) The headphone must be charged before use if it hasn't been used for more than 1 year.

7. Specification

Bluetooth Specification	Bluetooth V4.0
Bluetooth Profile	A2DP1.2 AVRCP1.4 HSP1.2 HFP1.6
DSP	CVC6.0 Noise and Echo reduction
Operating Range	10m
Frequency Response	80Hz-20KHz
Speaker Output	20mW
SNR	≥90dB
Distortion	≤1.0%
Battery	Li-ion 3.7V / 195mAh
Working Time	About 12.5 hours
Charging Time	About 3 hours
Weight	About 130g
Dimensions	165.7 x 161.5 x 50mm

8. Troubleshooting

Problem	Solution
Won't turn on.	Please charge the EP636.
Can't find the EP636.	Confirm the EP636 is in pairing mode and within 10 meters from the device.
Can't install the driver for EP636 on a computer.	Update the driver of the Bluetooth module on your computer.
The sound quality is intermittent in Bluetooth mode.	Disable the Wi-Fi on your source device.
No sound.	Check the volume on both the source device and the EP636.

9.Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone:	+44 (0) 845 250 0586
Email:	service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity

may be consulted at August International Ltd, Unit 5 Swains Mill, Crane Mead, Ware SG12 9PY, England.

CE

Industry Canada Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.



For details of further relevant technical standards, please contact us at the address above.