

# Display Merchandiser Instruction Manual



Model . GC872-A/GC873-A/GC874-A

## **Safety Tips**

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required.
- Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
  - o Health and Safety at Work Legislation
  - o BS EN Codes of Practice
  - Fire Precautions
  - o IEE Wiring Regulations
  - o Building Regulations
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT use the appliance outside.
- DO NOT use this appliance to store medical supplies.
- DO NOT use electrical appliances inside the appliance (e.g. heaters, ice-cream makers etc.).
- DO NOT allow oil or fat to come into contact with the plastic components or door seal. Clean immediately if contact occurs.
- Always carry, store and handle the appliance in a vertical position and move by holding the base
  of the appliance.
- Always switch off and disconnect the power supply to the unit before cleaning.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a POLAR agent or a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety

# **Product Description**

GC872-A Refrigerated Display Merchandiser 100 litres

GC873-A Refrigerated Display Merchandiser 120 litres

GC874-A Refrigerated Display Merchandiser 160 litres

#### **Pack Contents**


The following is included:

- GC872-A/GC873-A/GC874-A 2 adjustable shelves
- Instruction manual

POLAR prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damaged as a result of transit, please contact your dealer immediately

#### Installation



- 1. Remove the appliance from the packaging. Make sure that all protective plastic film and coatings are thoroughly removed from all surfaces.
- 2. Maintain a distance of 20cm (7 inches) between the unit and walls or other objects for ventilation. Increase this distance if the obstacle is a heat source.
- NOTE: Before using the appliance for the first time, clean the shelves and interior with soapy water and rinse thoroughly.

# **Operation**

The control panel is located below the doors on the rear of the appliance

#### Turn On

- 1. Close the doors of the appliance
- 2. Connect the appliance to a mains power supply
- 3. Press the Power switch (Green) to the On position.

## **Internal Light**

The light switch is located on the rear of the appliance next to the power switch.

# **Setting the Operating Temperature**

- 1. Press the set button. The display will flash
- 2. Press the ≜ or ₹ buttons to display the required temperature
- 3. Press the button to store the temperature



#### **Manual Defrost:**

Press and hold the button for 2 seconds to begin automatic defrost. The defrost light illuminates

#### Cleaning, Care & Maintenance

- 1. Switch off and disconnect from the power supply before cleaning
- 2. The doors can be removed for ease of cleaning
- 3. Clean the interior of the appliance as often as possible
- 4. Do not use abrasive cleaning agents. These can leave harmful residues
- 5. Clean the door seal with water only
- 6. Always wipe dry after cleaning
- 7. Do not allow water used in cleaning to run through the drain hole into the evaporation pan

A POLAR agent or a qualified technician must carry out repairs if required

#### **Replacing the Interior Lamp**

Call your dealer or a qualified electrician, the Lamp Assembly is available to purchase as a spare part.

# **Cleaning the Condenser**

Periodic cleaning of the Condenser can extend the life of the appliance. POLAR recommend that an agent or qualified technician cleans the condenser.

# **Troubleshooting**

If your appliance develops a fault, please check the following table before making a call to the helpline

Fault	Probable Cause	Action		
The appliance is not	The unit is not switched on	Check the unit is plugged in correctly and		
working		switched on		
	Plug and lead are damaged	Call POLAR agent or a qualified Technician		
	Fuse in the plug has blown	Replace the fuse		
	Power supply	Check power supply		
	Internal wiring fault	Call POLAR agent or qualified Technician		
The appliance turns on, but	Too much ice on the evaporator	Defrost the appliance		
the temperature is too	Condenser blocked with dust	Call POLAR agent or a qualified Technician		
high/low	D	Check doors are shut and seals are not		
	Doors are not shut properly	damaged		
	Appliance is located near a heat	Move the refrigerator to a more quitable		
	source or air flow to the condenser	Move the refrigerator to a more suitable		
	is being interrupted	location		
	Ambient temperature is too high	Increase ventilation or move appliance to a		
	Ambient temperature is too high	cooler position		
	Unsuitable foodstuffs are being	Remove any excessive hot foodstuffs or		
	stored in the appliance	blockages to the fan		
	Amalianas is arraula - Ja-J	Reduce the amount of food stored in the		
	Appliance is overloaded	appliance		
	Factory default parameters	Call DOL AP agent or a qualified technicism		
	adjusted	Call POLAR agent or a qualified technician		
The appliance is leaking	The appliance is not properly	Adjust the screw feet to level the appliance		
water	leveled	(if applicable)		
The appliance is unusually loud	Loose screw/nut	Check and tighten all nuts and screws		
	The appliance has not been	Check installation position and change if		
	installed in a level or stable position	necessary		
The display lamp does not illuminate	Lamp needs replacing	Call POLAR agent or a qualified technician		
	Light not turned On	Ensure Light button has been pressed		
mummac	Light not turned On	Properly		
Door does not shut	Dirt/obstacle in runners	Clean runners		

#### **Technical Specifications**

Model	Voltage	Power	Range	Capacity (litres)	Refrigerant	Dimensions H X W X D	Weight (Kg)
						(mm)	
GC872-A	220-240V 50Hz	160W	3 to 8°C	100	R134a 100g	663 x 705 x 452	39
GC873-A	220-240V 50Hz	160W	3 to 8°C	120	R134a 120g	663 x 705 x 570	64
GC874-A	220-240V 50Hz	200W	3 to 8°C	160	R134a 130g	663 x 883 x 570	71

#### **Electrical Wiring**

The plug is to be connected to a suitable mains socket.

POLAR appliances are wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E


All POLAR appliances must be earthed, using a dedicated earthing circuit.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

# **Compliance**

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.



POLAR products have been approved to carry the following symbol:





All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of POLAR.

Every effort is made to ensure all details are correct at the time of going to press, however, POLAR reserve the right to change specifications without notice.

# **DECLARATION OF CONFORMITY**

Equipment

**Refrigerated Merchandiser** 

Type

Model GC872-A/GC873-A/GC874-A

Legislation

AS/NZ 3820 Essential Safety Requirements for Low Voltage Electrical Equipment

Standards EN55014-1

EN55014-2 EN61000-3-2 EN61000-3-3 EN60335-2-89 EN60335-1 EN62233

AS-NZS 60335.2.89:2010

Producer

Name

**Polar** 

Producer Address 15 Badgally Road, Campbelltown, NSW 2560

Date 12/07/12

**Signature** 

N. J. honorell.

Full Name Richard Cromwell

Position Marketing Director

I, the undersigned, hereby declare that the equipment specified above conforms to the above Legislation and Standard(s).

