

# DMX512 Master CDW Wall Control Panel

SR-2201(US)



## Feature


- DMX512 Signal
- Glass Wall Touch Control
- CDW (all white color)
- White & black




## Parameter

Part No.	Input Voltage	Output	Size	Remarks
SR-2201(US)	12-24VDC	DMX512 Signal	120x75x29.1	Touch Sensor


## Product Size




## Installation



## Wiring diagram



## Description of buttons



## Operation

### 1. Set DMX Address


Set all DMX Decoder as DMX Address 001

### 2. Save color

1) Touch color wheel  to choose the color

2) Long press a target number over 3 seconds (light flashing means successfully saved, saving 1-6 colors will cover the original colors)

### 3. Default setting colors

Long press  to default settings as following colors.

① 100% Warm white

② 50% warm white +50% cool white

③ 100% Natural white

④ 50% Natural white +50% cool white

⑤ 100% Cool white

⑥ 50% Cool white +50% warm white

## Safety & Warnings

- 1) The product shall be installed and serviced by a qualified person.
- 2) IP20. Please avoid the sun and rain. When installed outdoors, please ensure it is mounted in a water proof enclosure.
- 3) Always be sure to mount this unit in an area with proper ventilation to avoid overheating.
- 4) Please check if the output voltage of any LED power supplies used comply with the working voltage of the product.
- 5) Never connect any cables while power is on and always assure correct connections to avoid short circuits before switching on.
- 6) Please ensure that the cable is secured tightly in the connector
- 7) For update information please consult your supplier.

## Warranty Agreement

- 1) We provide lifelong technical assistance with this product:
  - 5-year warranty. We print date on every products, for example :1125 means year 2011, week 25. The warranty is for free repair or replacement and covers manufacturing faults only.
  - For faults beyond the 3-year warranty we reserve the right to charge for time and parts.
- 2) Limited Warrenty
  - Any defects caused by wrong operation.
  - Any damages caused by unauthorized removal, maintenance, modifying, incorrect connection and replacement of chips.
  - Any damages due to transportation, vibration etc. after purchase.
  - Any damages caused by earthquake, fire, lightning, pollution and abnormal voltage.
  - Any damages caused by negligence, inappropriate storing at high temperatures and humidity or near harmful chemicals.
  - Product has been updated
- 3) Repair or replacement as provided under this warranty is the exclusive remedy to the customer.