

The TRUCKFONE device must purchased from TRUCKFONE Inc. Authorized dealer and installed by a TRUCKFONE Inc. approved professional installer

Truckfone Parts





TRUCKFONE

The TRUCKFONE device must purchased from TRUCKFONE Inc. Authorized dealer and installed by a TRUCKFONE Inc. approved professional installer

Table of contents

Phone Layout	3
Preplanned Accessory Positioning	4
Installing the Swivel mount and Phone	6
Installing the Microphone	8
Installing the Speaker	9
Installing the Electrical Connections	10
Installing the Cellular Antenna	12
Troubleshooting	14

Phone Layout





Preplanned Accessory Positioning

Positioning of all accessories must be planned in advance before installation begins.

- Ensure that no wire braids go through locations where Phone accessories are to be installed.
- Ensure that any parts of the Truckfone will not interfere with the vehicle or its accessories' operation.

Plan Phone and Swivel mount Positions



Note!

The best way to determine the Phone's position to the customer's full satisfaction is to locate it when the customer is beside you and obtain his/her approval.

Please ensure the Phone's location does not interfere with the vehicle or its
accessories operation: it should not interfere with opening the glove compartment
or ashtray, should not prevent access to the lighter, moving the gear stick,
operating the hand break etc.



Warning!

Do not install the Phone in front of the vehicle's air bag. This restriction must be adhered to, as in the case of an emergency the air bag blows up and can fail to work properly.

- Ensure the surface on which this Phone is installed is sufficiently strong to carry the weight and pressure which would be exerted on it.
- When selecting the Phone's location, please ensure the control cable connected to it does not interfere with the vehicle or its accessories' operation.
- Ensure it is safe and convenient to operate the Phone and read the display from the driver's seat.
- Ensure the Phone would be protected from direct sunlight and humidity (air conditioner openings).
- Ensure the Phone would be protected from mechanical damage by the car's accessories.

Plan the Microphone's Position

- Install the Truckfone's microphone 30-40 cm away from where the driver speaks when he/she is in their normal driving position.
- It is recommended to install the microphone on the right side of the sun visor, away from the vehicle's window and from external sources of noise.
- Install the microphone in a different direction than the speaker so as to avoid echo.

Plan the Speaker's Position



Note!

The speaker and microphone (installed on the sun visor above the driver) must face **different directions**.



Note!

Do not hide the speaker inside the dash board.

If you cover it, sound quality will be lowered.

 Locate the speaker at the right side of the main console, at the front of the console, in a location where it would not bother the driver or passengers but would sound best.

Installing the Swivel mount and Phone



Truckfone

Swivel mount



Where to Position (Reminder)



Note!

The best way to determine the Phone's position to the customer's full satisfaction is to locate it when the customer is beside you and obtain his/her agreement.

Please ensure the Phone's location does not interfere with the vehicle or its
accessories operation: it should not interfere with opening the glove compartment
or ashtray, should not prevent access to the lighter, moving the gear stick,
operating the hand break etc.



Warning!

Do not install the Phone in front of the vehicle's air bag. This restriction must be adhered to, as in the case of an emergency the air bag blows up and can fail to work properly.

- Ensure the surface on which this Phone is installed is sufficiently strong to carry the weight and pressure which would be exerted on it.
- When selecting the Phone's location, please ensure the control cable connected to it does not interfere with the vehicle or its accessories' operation.
- Ensure it is safe and convenient to operate the Phone and read the display **from** the driver's seat.

- Ensure the Phone would be protected from direct sunlight and humidity (air conditioner openings).
- Ensure the Phone would be protected from mechanical damage by the car's accessories.

Installing the Swivel mount and Phone

- 1. Disassemble the Swivel mount joint from its two base units.
- 2. Install one of the Swivel mount base units in the determined location in the car with 4 tin screws.
- 3. Install the second Swivel mount base unit on the Truckfone, using the 4 philips screws provided with this kit.



Note!

Only use the original screws provided with this kit.

 Connect the Swivel mount joint to the two base units. Adjust the angles. Use the screws to connect the Swivel mount joint to the base units and fix the Swivel mount joint screw.

Installing the Microphone



The microphone is provided with a clip which makes it possible to install it on the sun visor.

Where to Locate the Microphone (Reminder)

- Install the Truckfone's microphone 30-40 cm away from where the driver speaks when he/she is in their normal driving position.
- It is recommended to install the microphone on the right side of the sun visor, away from the vehicle's window and from external sources of noise.
- Install the microphone in a different direction than the speaker so as to avoid echo, and ensure there is a distance of at least 1.5 meters between them.

Installing the Microphone

- 1. Using the clip, install the microphone on the right side of the sun visor.
- 2. Direct the microphone cable along the sun visor, behind it, so as not to be seen.
- 3. Continue directing the microphone cable along the left beam on the driver side.
- 4. Direct the cable under the dash board to the connection point of the cable with the control cable connected to the Phone.



Ensure the microphone cable and antenna cable are kept away from each other.

Ensure the microphone cable is not in contact and does not interfere with the car pedals and steering wheel stick.

5. Connect the microphone cable plug to the correct port on the control cable.

Installing the Speaker



Where to Locate the Speaker (Reminder)



Note!

The speaker and microphone (installed on the sun visor above the driver) must face **different directions**.

If the speaker and microphone face each other, this will cause echo.



Do not hide the speaker inside the dash board.

Note!

If you cover it, sound quality will be lowered.

 Locate the speaker at the right side of the main console, at the front of the console, in a location where it would not bother the driver or passengers but would sound best.

Installing the Speaker



- 1. Install the speaker at the right side of the main console, at the front of the console.
- 2. Disassemble the screws connecting the speaker to the hanger.
- 3. Install the hanger using the 2 tin screws.
- 4. Direct the speaker cable behind the mat located at the bottom of the car.
- 5. Ensure the cable does not interfere with the vehicle or its accessories' operation.
- 6. Ensure the speaker cable is not exposed to damage by the passengers.

Installing the Electrical Connections

The electrical cable is provided separately from the control cable. Before installation begins, connect the four leads (which include the 3A fuses) using a red or blue crimp sleeve as appropriate.



Please note sharp edges or moving parts which may damage the wires.

The value for the fuses provided with the kits must not be changed.

The kit is appropriate only for a 12V vehicle.

In case of converting any other kit model into this kit, please change the power cable.

The electrical cables should be directed as follows:

- So as not to disturb the driver or passengers.
- So as not to pass near the car's sharp or moving parts.



Note!

The external voltage connection is located under the dash board or close to the fuse box (depending on the car model).

In new vehicles a cellular phone connection can be found near the fuse box. See the car's user's manual under Info.

Only use the kit's original fuses (250V / 3A).

Installing the Voltage Cable

The following chart covers the manner by which the voltage cable should be connected to the car's electrical system.

Wire Color	Function	Must be connected to	Ensure
Red	To provide the Truckfone with fixed voltage	12V fixed voltage Connect with red fuse case which provided to a fixed voltage source (+)	Ensure a 250V / 3A fuse is used
Black	To provide a fixed minus (-)	Car body (minus)	Ensure the connection point is on the car body only Use a cable shoe, tin screw and
Green	To turn on the cellular phone after switching the ignition on and turn it off after car ignition is switched off	IGN voltage Connect with green fuse case which provided	springy disc Determine the correct point with a voltmeter Ensure a 250V / 3A fuse is used
Orange	To mute the stereo system when accepting a call or dialing	Installation not required	Ensure the connection is made only by an authorized car stereo installation technician

Installing the Cellular Antenna



Where to Locate the Cellular Antenna

- The preferred location for the antenna is on the right side of the windshield.
- If a cell phone or other communication system is installed in the car, please locate the antenna as far away as possible from the other Phone's antenna.

Remember!

Some car models (such as Renault Megan and Renault Kangoo) feature a radiation filter on the windshield. Therefore it is necessary to install the antenna on a side or back window.



Note!

In vehicles with air bags on the beam where the antenna cable passes, the antenna cable should be directed behind or beside the airbag.

Installing the Cellular Antenna

Installing the External Adapter and Antenna Rod

- 1. Thoroughly clean the location intended for installation on both sides of window using a cloth and detergent. Allow the spot to dry before you continue.
- 2. Carefully remove the clear plastic cover protecting the external adapter (the antenna base).
- 3. Locate the adapter on the cleaned location. Ensure the adapter is stably placed in a horizontal position parallel to the window border.
- 4. Carefully press the antenna base toward the window. Ensure all corners of the adapter are attached to the window and the antenna rod is in a vertical position.

Installing the Internal Adapter and Coaxial Cable

- 1. Carefully remove the clear plastic cover protecting the internal adapter.
- 2. Move the adapter, on the inside of the window, toward the antenna base (the external adapter), and direct the adapter so as to fully overlap the base.
- 3. Carefully press the antenna adapter to the window. Ensure all adapter corners are attached to the window.
- Direct the antenna's coaxial cable along the car beam. Ensure the antenna cable does not get damaged.



Note!

Do not direct the microphone cable and antenna cable together on the same beam (lintel).

- 5. When completing the cable's installation and reaching close to the control cable connected to the Phone, please leave approximately 30 cm of additional wire and cut off the unnecessary extra cable.
- Press a UHF mini connector at the end of the cable. Use the original plug and pressers only.
- 7. Examine the antenna and cable's proper working order with an efficiency meter.

Trouble Shooting

Symptom	What to Check	What to Do	
No reception	Check whether connector is correctly	Replace connector	
-	connected to the cable – use an		
	efficiency meter		
	Check if internal and external antenna	Attach antenna base	
	base is correctly attached		
	Check proper working order of	Replace antenna cable	
	antenna cable		
Other party	Check speaker's proper working order	Replace speaker	
cannot be	A Phone problem may exist	Replace Phone	
properly heard	Check speaker location	Change location	
User is not heard	Check microphone and contacts	Tighten microphone connector to	
by the other		the Phone	
party	Check routing of microphone cable	Change routing of microphone	
		cable	
	Check microphone's proper working	Replace microphone	
	order		
	A Phone problem may exist	Replace Phone	
Noise is heard	Ask whether noise always occurs in	Explain that reception trouble	
	specific geographical areas	sometimes occurs in transition	
		between coverage areas	
	Ask whether noise occurs when	Explain that the Phone is an	
	window is open	amplifying system that receives all	
		environmental noise, and therefore	
		it is preferable to speak with a	
		closed window	
	Check whether microphone and	If they are, install microphone as	
	antenna are installed on the same side	per the instructions	
	Check whether eye contact exists	If it does, change location	
	between speaker and microphone	accordingly	
	Check for improper voltage	Change voltage source in	
	connection – check whether voltages	accordance with instructions	
Dhana awitahaa	are connected as per instructions	Disability of the second secon	
Phone switches	Check minus (-) connection	Black wire: connect minus to car	
on and off by	Chook voltage contacts	body Tighton loops contacts	
itself Phone does not	Check func. Check connection to	Tighten loose contacts	
	Check fuse. Check connection to	Replace fuse. Tighten connection	
switch on after	voltage source (green cable)	to voltage source. Ensure a 250V/3A fuse is used	
switching on car Phone does not	Chook connection to newer source		
switch off after	Check connection to power source (green cable)	Tighten connection to power source	
switching off car	(green cable)		
Phone does not	Check connection to power source.	Replace fuse. Tighten connection	
switch on	Check fuse (red cable)	to power source	
SWILCII OII	טוובטא ועסב (ובע במטופ)	l to bower source	