

pidion

www.mypidion.com



BI-300

Series Manual



Barcode Bluetooth PC-Sync

- Please read the following warnings before using the product.
- Shapes and colors of the images shown in this manual may differ from the actual products.
- Contents of the manuals may differ based on the software version of products or conditions of the wireless provider.

Thank you for purchasing BI-300 of Bluebird Soft.

BI-300 is the latest wireless barcode scanner in that it is not just a data collector, but it also has a Bluetooth function. We ensure that BI-300 can save high capacity of information with 1D, 2D (PDF417 only supported), and it is easy to carry and use because of its ultra light and hand-held simple design, which gives you the best satisfaction.

- This User's Manual is protected under copyright laws.
- This User's Manual is produced by Bluebird Soft Inc. We made every effort to avoid wrong editing and missing information. Some parts, however, may not completely reflect actual case. We ask for your positive understanding about this.
- The programs installed in this Product are protected under related laws and regulations; they cannot be copied, moved or deleted without notice.
- Depending on users' environments, used programs or peripherals, some parts of this Product may not work normally.
- This wireless device may cause propagation interference, and so, it cannot be involved with life-saving services.

Trade mark



PIDION aims for leading brand in the future mobile industry.

As a global brand representing the image of reliability, representativeness, and cutting-edge technologies, this mark has been registered by Bluebird Soft Inc. around the world to be protected under trademark-related laws.

- 2 Warnings and Cautions**
- 4 Checking components**
 - 1. Basic components
 - 2. Options
- 5 Name and function of each component**
- 6 About scan, memory lamp/ battery, communication lamp**
 - 1. Checking lamp
 - 2. Indication of lamp status
- 8 About signal tone**
- 9 Changing a battery**
 - 1. Removing a battery
 - 2. Inserting a battery
- 10 Charging a battery**
 - 1. Charging with a charging cable
 - 2. Charging with a charger (option)

- 11 Power On/Off**
 - 1. Power On
 - 2. Power Off
- 12 Scanning barcode**
- 13 Sending data to PC**
 - 1. Procedures for data transmission
 - 2. Installing Driver
 - Windows XP
 - 3. Installing Driver
 - Windows Vista
 - 4. Installing PidionScan Program
- 25 Sending data by PDA**
 - 1. Procedures for data transmission
 - 2. Installing ActiveSync
 - 3. Installing PidionScan Program
 - 4. Bluetooth Power On/Power Off
 - 5. Bluetooth setting
 - Windows Mobile
 - 6. Bluetooth Setting
 - Windows CE

- 37 Using PidionScan Program**
 - 1. Connect
 - 2. Download
 - 3. Setting
 - 4. Configure
 - 5. About
- 47 Product Specifications**
- 48 Q&A**
- 49 Customer Service**
- 50 Service Center Information**
- 52 Certificate of Guarantee**
- 53 MIC Certification**
- 53 CE Mark and EEA**
- 54 Laser device**

Warnings and Cautions

These instructions are to protect the user's safety and prevent property loss. Please, read the instructions and use the product properly.



WARNING

If you do not observe this sign, it may cause a physical damage or property loss.



CAUTION

If you do not observe this sign, it may cause property loss or product damage.



Warning

- Do not direct the scanner window toward eyes of a man • animal. (It may cause damage to the retina and eyesight damage.)
- For product operation, do not press the button with a pointed or sharp tool or do not touch metallic materials with the connector while the product is operating. (It may lead to electric shock or fire, or product damage or malfunction.)
- Do not give a strong shock on the product or battery, or do not drop the product. (It may cause an explosion or fire.)
- Do not pull the cord or touch the power cord with a wet hand. (It may cause electric shock or product damage.)
- To remove the product from the power cord, do not pull the power cable or do not touch the power cord with a wet hand. (It may cause an electric shock or product fault.)
- Do not use the product while charging. (It may cause an electric shock or fire.)
- Do not use the product at a place with much humidity (bathroom), or with the possibility of snow • rain. (It may cause a product malfunction or electric shock.)
- If there is strange sound, smell or smoke, unplug the power cord immediately and contact the Customer Service Center. (It may cause fire or electric shock.)
- Keep the terminal, battery, charger and other accessories out of reach of the animals or children. (It may cause product damage or physical injury.)
- This product conforms to Rules of Electromagnetic Wave Emission prescribed by the Government, but do not use the product for a long time since it may cause a physical damage due to electromagnetic waves. (Note that using the product for a long time may cause a physical pain or convulsions due to excessive motion.)
- Do not put the product in a heater, microwave oven, heating cooker and high-pressure vessels. (It may cause explosion or fire.)



Caution

- Do not explode • repair • remodel the product. If you suspect a fault, contact the Customer Service Center. (It may cause electric shock or malfunction.)
- Power on the product at a place where products are forbidden to use or at an explosion hazard area in terms of radio. (It may cause malfunction of other equipment or explosion.)
- Do not use a charger and other components together with electric appliances of other manufacturers, and be sure to use a qualifying product. (We are not responsible for any damage due to non-use of a qualifying product.)
- Do not bend or twist the power cable too much, and do not put the cable under heavy materials. (It may cause fire or product damage.)
- Keep the product off a place with strong vibration or magnetic field. (It may cause product damage or malfunction.)
- When clearing the product, do not use toxic chemicals or strong detergent, but clean with a soft dry cloth. (It may cause product damage.)
- Do not shake or turn the hand-held necklace. (If dropped, it may cause abrasion or product damage.)
- Do not keep the product at too high or too low temperature. (It may cause product damage or malfunction.)
- Prevent sand or foreign substance from entering into the product. (It may cause product damage or malfunction.)
- Do not paint the product. (It may cause appearance damage and product defect.)
- Do not use the product for purposes other than those specified in the manual. (It may cause product damage and physical injury.)




Battery Precaution

- Do not give shock (e.g., fall of a battery) to the product and do not explode the product without permission. (It may cause product defect or short lifetime, or overhead leading to danger.)
- Do not place the battery around fire, a heater or microwave oven. (It may cause an explosion.)
- Use a designated qualifying battery and charger only. (It may cause an explosion and fire, leading to short lifetime of a battery.)
- Note that do not connect (short) a necklace, coin and other conductors(metal) to the battery terminal. (Overheating of a battery and short object may cause fire.)
- Do not place the battery around the car window with direct sunrays and at a closed place with high temperature. Keep the battery indoor at the normal temperature. (It may cause explosion.)
- Keep the battery out of reach of the children or animals. (It may cause product damage and physical injury)
- Even if the battery is charged sufficiently, the lifetime of a battery may be shortened due to a low voltage of internal characteristics.


Checking components

Before use, check if the components match with the purchased product. (If you want to purchase more, please contact a nearby agency.)

1 Basic components




[Barcode scanner (terminal)]



[Battery]



[Portable necklace]




[USB cable]

2 Options



[Car charger]



[Charger]



[Case]


※ The above figure may be a little different from a real object.

※ Accessory components may differ from the above figure depending on purchase specifications.

Name and function of each component

BI-300


Be familiar with the name and function of each component before using the product.



About scan, memory lamp/battery, communication lamp

Changing the color of the scan • memory lamp and battery • communication lamp let the user know the operating information on the scanner.

1 Checking lamp



2 Indication of lamp status

Division	Status	Scan • Memory lamp	Battery • Communication lamp
Basic operation	Booting	Violet	Violet
	Power supply, scanner initialization complete, barcode scan enabled	Orange/blue/violet conversion	Orange/blue/violet conversion
	Lack of memory storage	Turn orange	-
	Default mode (Sleep mode×)	Violet lamp 1 time/flickering 5 seconds	-
Scanning	Barcode scan successful	Blue lamp is flickering once	-
	Input error occurs, wrong barcode scanning, invalid input item, incorrect barcode setup procedure, set mode maintained	Orange lamp is flickering twice	-
Cancel	Delete one successfully scanned barcode	Orange lamp is flickering once	-
	Clear all saved barcodes (memory clear)	Orange (while clearing)	-
Charging required	Battery level of a scanner is less than 20% (charging is required)	Violet lamp is flickering	Violet lamp is flickering
Charging	-	-	Orange lamp is flickering
Charging completed	-	-	Blue lamp is flickering
Radio communication	Connect Bluetooth	-	Blue lamp is flickering
Wire communication	Connect with USB or Serial	-	Blue lamp is flickering
	Rx error and reject to attempt connecting	-	Orange lamp is flickering twice
Others	Barcode scan is successful during wire • radio communication, but Rx error occurs	Blue lamp is flickering once	Orange lamp is flickering twice


About signal tone

Notifies the operating information of the scanner to the user by tone volume or sequence.

Division	Status	Signal tone
Basic operation	Power supply, scanner initialization complete, barcode scan enabled	Low/medium/high once
	Lack of memory storage	High 3 times
Scanning	Barcode scan successful	High once
	Input error occurs, wrong barcode scanning, invalid input item, incorrect barcode setup procedure, set mode maintained	Low twice
Cancel	Delete one successfully scanned barcode	Low /high/low once
	Clear all saved barcodes (memory clear)	Low /high/low/long once
Radio communication	Bluetooth is connected	High once
	Bluetooth is disconnected	High /low once
Wire communication	Connect with USB or Serial	High once
	Wire communication is disconnected	High/low once
	Rx error and reject to attempt connecting	Low twice
Others	Barcode scan is successful during wire•radio communication, but Rx error occurs	High once


1 Removing a battery

- ① Power the terminal off.
- ② Unscrew the screw of a battery cover counterclockwise.
- ③ Lift up the battery cover in the arrow direction and remove.
- ④ Separate the battery connection cable from the connection terminal.



2 Inserting a battery

- ① Connect the battery connection cable to the connection terminal.
- ② Insert the battery.
- ③ Fit the battery cover to the bottom groove and close.
- ④ Tighten the screw clockwise.


**CAUTION**

If the lifetime of a battery is reduced more than half of a finished product, replace by a new battery.

Charging a battery

1 Charging with a charging cable

Before charging, connect the charge-USB cable to the external connector at the bottom of the terminal.




TIP

- If two lamps are violet-flickering it means a lack of battery. Please charge the battery.
- You should purchase charge- USB cable separately.


2 Charging with a charger (option)

Before charging, connect the charger connector to the external connector at the bottom of the terminal.



1 Power On

Push down the Power button on the left side of the terminal as shown in the figure, and then power is on. When booting is started, the lamp will be turn on in purple. After completion of booting up, the lamp will be flashed with blue/orange/purple color and can be heard signal sound.




TIP

It takes about 10 seconds to boot the terminal.
Use the product in 10 seconds.


2 Power Off

Push down the Power button on the left side of the terminal as shown in the figure, and then power is off.




Scanning barcode

Face the scanner window toward the barcode at intervals of approximately 10 seconds, and press the Scan button to read the barcode.



WARNING

- When scanning barcode, do not direct the scanner window toward eyes of a man • an animal. It may cause damage to the retina and eyesight damage.
- If you use the product at a place with a big difference in ambient temperature, barcode can't be recognized temporarily due to moisture or frost in the barcode window.
- If the scanner window is perpendicular (0°) to the barcode, it is impossible to read barcode due to characteristics of the laser barcode engine. Thus, scan at a little inclined angle, not a right angle.



Cancel
button



Status	Cancel button
Clear scanned barcode	Press the Cancel button short while scanning barcode to be cleared
Clear all saved barcodes (Clear All)	Press the Cancel button for 6 seconds while scanning one unspecific barcode

You can exchange data by connecting the terminal to a PC with the USB cable.

1 Procedures for data transmission

- ① Copy the driver [gserial.inf] file of a PC in the provided CD, and install it in the PC. (See P-14)
- ② Power the terminal on and connect the PC to the terminal with the UBS data cable. (See P-14)
- ③ Copy [PidionScan] of the PC in the provided CD and install. (See P-22)
- ④ Set the [PidionScan] program of the PC (See P-37).
- ⑤ Scan barcode with the terminal (See P-12).
- ⑥ Scanned barcode information is displayed in the screen of the [PidionScan] program, or in the Word/Memo of the PC (See P-38).



TIP

- If the PC and Bluetooth are properly connected, the battery • communication lamp turns blue, and high signal tone is generated once.
- Even if the Bluetooth transmission fails after barcode scanning, the barcode data is automatically stored in the scanner.

Sending data to PC

2 Installing Driver- Windows XP




TIP

If Microsoft ActiveSync is installed in a PC, set [Microsoft ActiveSync] ► <File> ► <Connection Setup> ► <Permit USB Connection> as inactive. Driver is not installed if USB connection is permitted.

- ① Select the PC driver folder [BI300_PidionScan_Windows XP, Vista], and copy the driver file [gserial_XP.inf] in the PC.

You can download the driver at our homepage.
(<http://www.mypidion.com>)


- ② Power the terminal on and connect it to the PC using the USB cable.



- ③ The [Found New Hardware Wizard] program is automatically run, and select <No, not this time>, and select the <Next> button.




- ④ Select the <Install from a list or specific location [Advanced]> menu and select the <Next> button.



Sending data to PC

2 Installing Driver- Windows XP

- ⑤ Select the <Include this location in the search> menu and select the <Search> button, and select a folder in which the driver file [gserial_XP.inf] is saved, and then select the <Next> button.



- ⑥ After the <Install Hardware> window appears, press the <Continue> button.

- ⑦ If you check <Finish> in the [Found New Hardware Wizard], the program is successfully installed.

**TIP**

- If the window to search for [usbser.sys] file does not appear, or the device is not properly recognized even after the driver file [gserial_XP.inf] is normally installed, separate the terminal from the PC, ► copy the [usbser.sys] file of in the <C:\WINDOWS\system32\drivers> folder, ► connect the terminal to the PC again.
- You can download the driver at our homepage. (<http://www.mypidion.com>)

Sending data to PC

3 Installing Driver- Windows Vista




TIP

If Microsoft ActiveSync is installed in a PC, set [Microsoft ActiveSync] ► <File> ► <Connection Setup> ► <Permit USB Connection> as inactivate. Driver is not installed if USB connection is permitted.


- ① Select the PC driver folder [BI300_PidionScan_Windows XP, Vista], and copy the driver file [gserial_XP.inf] in the PC.

You can download the driver at our homepage.
(<http://www.mypidion.com>)

- ② Power the terminal on and connect it to the PC using the USB cable.



- ③ The [Found New Hardware] program is automatically run, and then selects the <Locate and install driver software>.



- ④ The screen <Installing Device Driver Software> is displayed.


- ⑤ In the <Insert the disc that came with your Gadget Serial>, select the <I don't have the disc Show me other options.> button.




Sending data to PC

3 Installing Driver- Windows Vista

- ⑥ In the <Windows couldn't find driver software for your device>, select the <Browse my computer for driver software> button.



- ⑦ Select the <Browse...> button, and select a folder in which the driver file [gserial_Vista.inf] is saved, and select the <Next> button.



⑧ Select the <This driver software will be installed.> button.

⑨ Driver software installation is completed.



TIP

- If the window to search for [usbser.sys] file does not appear, or the device is not properly recognized even after the driver file [gserial_Vista.inf] is normally installed, separate the terminal from the PC, ► copy the [usbser.sys] file of in the <C:\WINDOWS\system32\drivers> folder, ► connect the terminal to the PC again.
- You can download the driver at our homepage. (<http://www.mypidion.com>)

Sending data to PC

4 Installing PidionScan Program




WARNING


- The seen screen corresponds to the [Windows XP] version and it depends on the software version used.
- Image seen in the [Windows Vista] screen is different, but the function is the same as [Windows XP].

- ① Select the PC driver folder [BI300_PidionScan_Windows XP, Vista], and copy the [PidionScan_Winxp,Vista] folder in the PC, and select the [PidionScan_WinXp,Vista.exe] program.

You can download the driver at our homepage.
(<http://www.mypidion.com>)



- ② Set <COM Port> in the [Connect] tab and select the <Connect> button.




TIP


<COM Port> of <Gadget Serial> is changed at each PC, so that check the number to which the Gadget Serial COM port is set.

To check <COM Port> to be set,

- a. Right-click the mouse in [My Computer] of the PC, and select <Properties>.




- b. Select [System Restore] ► [Hardware] ► <Device Manager>.



Sending data to PC

4 Installing PidionScan Program

- c. If you select <PORT (COM and LPT)> in <Device Manager>, you can check <Gadget Serial>.



- ③ For how to use the [PidionScan] program, refer to <Use PidionScan Program> on page 37.



Image seen in the PC screen is different, but the function is quite similar to PDA.

TIP

You can exchange data by connecting the terminal to the PDA supporting Bluetooth, without the USB cable.

1 Procedures for data transmission

- ① Install [Microsoft ActiveSync] in a PC. (See P-26)
- ② Connect the PDA and PC with the USB cable and install [PidionScan] in PDA, and disconnect. (See P-28)
- ③ Power the terminal on. (See P-11)
- ④ Set <Bluetooth> of the PDA. (See P-31)
- ⑤ Set the [PidionScan] program of the PDA. (See P-37)
- ⑥ Scan barcode with the terminal. (See P-12)
- ⑦ Scanned barcode information is displayed in the screen of the [PidionScan] program or in the Word/Memo of the PDA. (See P-38)



TIP

- If the PDA and Bluetooth are properly connected, the battery • communication lamp turns blue, and high signal tone is generated once.
- Even if the Bluetooth transmission fails after barcode scanning, the barcode data is automatically stored in the scanner.
- Because the Bluetooth interworking is disconnected while PDA is in Power Save mode, do not use Power Save mode when interworking with Bluetooth.

Sending data by PDA

2 Installing ActiveSync



TIP


To install the [PidionScan] program in the PDA, install the [MicroSoft ActiveSync] program in a PC.
If the [ActiveSync] program is already installed in the PC, you need not install the program separately.




WARNING

The seen screen corresponds to the [Microsoft ActiveSync 4.5] version and it depends on the software version used.


- ① Access the Microsoft's Website, and download [Microsoft ActiveSync], and install.



- ② Select the <Accept> button in the [License Contract] window, and ► fill in the <User ID> <Organization> in the [Customer information] window, and ► set <Installation Location> in the [Target Folder] window.



- ③ If ready to install, [Microsoft ActiveSync] is installed.



- ④ [Microsoft ActiveSync] installation is completed.

Sending data by PDA


3 Installing PidionScan Program




WARNING

- The seen screen corresponds to the [Windows Mobile] version and it depends on the software version used.
- Image seen in the [Windows CE] screen is different, but the function is the same as [Windows Mobile].


① Connect the PDA and the PC using the USB cable.



② Execute [Microsoft ActiveSync], and select the <Browse> button.



- ③ Copy the [BI300_Pidion-Scan_Windows Mobile] folder in the provided CD in the [Mobile Device] folder.



WARNING

- Depending on software version used in PDA, install the [BI300_PidionScan_Windows CE] folder for Windows CE, and install the [BI300_PidionScan_Windows Mobile] folder for Windows Mobile.
- The <PidionScan_WinCE.exe, PidionScan_WinMobile.exe> file and the <BI300SdkDll.dll> file and the <BIDevSearch.dll> file are enabled only if they are installed in the same folder.

Sending data by PDA

4 Bluetooth Power On/Power Off

If you want to connect other equipment using the Bluetooth, execute the Bluetooth function first.

Bluetooth Power On/ Power Off - 1

- ① Select the [Start] ► [Set] ► [Connect], and ► [Wireless Administrator].
- ② Select <Bluetooth>.



: Bluetooth on (set)



: Bluetooth off (release)



Bluetooth Power On/ Power Off - 2

- ① Select  at the top of the screen and select [Wireless Administrator].
- ② Select <Bluetooth>.



TIP


Terminal equipped with Bluetooth can be connected without setting Bluetooth.

5 Bluetooth setting-Windows Mobile




WARNING

The seen screen corresponds to the [Windows Mobile 5.0] version and it depends on the software version used.



- ① Select the [Start] ► [Set] ► [Connections] and ► [Bluetooth].



- ② Select <Turn on Bluetooth> in [Mode] tab.



Sending data by PDA


5 Bluetooth setting-Windows Mobile

- ③ Select <Add New Device> in the [Device] tab.



- ④ Select <BI-300> among the searched Bluetooth devices, and select the <Next> button.

※ It is possible to search for <BI-300> only if the terminal power is on.



- ⑤ Enter password and select <Next> button.

※ If the PDA and the terminal are connected for the first time, enter password to register.
Default password is 1234, and the user can change the password.




- ⑥ Select <Serial Port> and select the <Finish> button.




- ⑦ Select <New Outgoing Port> in the [COM Port] tab.



- ⑧ Select <BI-300> and select the <Next> button.



- ⑨ Select an unused port address and select the <Finish> button.



TIP

Unavailable if a port in use is selected and available only if a port not in use is selected.


Sending data by PDA

6 Bluetooth Setting-Windows CE




WARNING

The seen screen corresponds to the [Windows CE 5.0] version and it depends on the software version used.




① Select [Start] ► [Set] ► [Bluetooth Device Attributes].



② <Bluetooth Administrator> and select the <Search Device> button.



- ③ Select the searched <BI-300>, and select <Trusted>.



- ④ If the Device Authentication window appears, press the <Yes> button.



- ⑤ If the PIN entry window appears, enter PIN, and select the <OK> button.

- ※ If the PDA and the terminal are connected for the first time, enter PIN to register. Default PIN is 1234, and the user can change the PIN.



- ⑥ If the device is set, the red <X> mark disappears.



Sending data by PDA

6 Bluetooth Setting-Windows CE

- ⑦ Select <BI-300>, and select <Activate>.



- ⑧ Red <✓> mark is displayed in the device list.



Using the program named PidionScan, you can perform data communication with the PDA/PC, and set the function of a terminal.


Image seen in the PC screen is different from that of PDA, but the function is quite similar each other.

**WARNING**

The seen screen depends on software version used.

Click [PidionScan] installed in PDA/PC to execute the program.

In case of PDA, go to [Start] ► [File Browser], and then search for the folder saving PidionScan. Select [PidionScan] in the folder.




1 Connect

You can connect/disconnect communication between the terminal and PC/PDA through Connect/Disconnect.

Connect : Connect to the ticked device in the list.

Disconnect : Disconnect to the ticked device in the list, among connected devices.



Device Name

It is possible to distinguish many devices by the terminal serial number.

Status

Display the progress status and results.

- **Connected** : Connected normally.
- **Connecting** : Attempting to connect.
- **Connect Fail** : Fail in connection.
- **Disconnected** : Disconnect.

Using PidionScan Program

2 Download

You can download data stored in the terminal.

Real-time data sync : If ticked off, barcode values read in all connected devices are displayed in data sheet in real time.

Reset

If you press Reset, barcode values read as Real-time data sync is cleared only from the screen.



TIP


If too many barcode values are displayed in a data sheet in Real-time data sync state, sometimes, there may be a problem with program performance.

Data sheet

- Possible to adjust the width of each row by drag.
- Scroll is automatically created if an item goes beyond the window.
- Unless otherwise, size only is left as blank.

Download data saved in the device

- ① If you press the <Start> button in the [Download] tab, the <Downloading> popup window appears (If the Popup window appears, the Download button is deactivated, and activated again after the completed Popup window disappears)



- ② Device IDs of all connected devices are displayed in the Popup window, and the download status per device is progressed by %.

IF download is completed, the <Done!> message is displayed, and the download of the next device gets started.




- ③ If download of all devices is completed, the <Download Completed!> message is displayed, and automatically disappears in one second.



- ④ File name of download location is saved as <Device name_scandata.extension>.

For PDA, downloaded files are saved in the <Device(my device)> folder, and for PC, downloaded files are in a folder where the EXE file of [PidionScan] exists.




Using PidionScan Program

3 Setting

Auto re-connect

- Automatically re-connect if Bluetooth connection is disconnected.
- You can set the maximum number of attempt.
 - Time interval default is 5 seconds, the maximum number of attempt is 0~10 (impossible to automatically re-connect if 0)
- Default : 3times



Auto Real-time mode

- If you select the checkbox, barcode values read by If you click the check box, the barcode data from the terminal will be indicated on the exe window of notepad or word at your PC or PDA in real time.
- If you do not select the checkbox, barcode values are not displayed in real time.

Time Stamp

Used to display date and time in the barcode information.

example) 2008/11/20 19:26:13 01223334
 date time Barcode information




TIP

If you select the <Auto Real-time mode> checkbox, the <Time Stamp> checkbox is activated.

4 Configure

You can configure the environment such as terminal volume, memory. For multiple accesses, you can select many terminals and apply set value at a time.

If you select the checkbox of a target terminal and click the <Configure Selected Setting> button, you can move to the submenu of Configure.



TIP


Change settings in each submenu, and check <Configure this tab>, and select the <OK> button at the right top, and then settings are applied.

General

Beep Volume : You can adjust the beep volume to level 4 (Off/Low/Medium/High). (Default : High)

Battery Level : Battery level is displayed as High/Medium/Low.

Data Store : Memory usage is displayed and available memory is indicated as %.




Using PidionScan Program

4 Configure

Symbology

You can set a barcode symbol. Select the checkbox of a barcode symbol.

Default : Default barcode is selected.



Among the barcode symbols, Supplement code, Interleaved 2 of 5 Length Min, Interleaved 2 of 5 Length Max, MSI check digit, MSI check digit algorithm are needed to put the default value of symbol.

If you click the check box of barcode symbol, Sub Option which you can input the default value will pop up. Then, input the default value as below and push Set button.

① Supplementcode

• Basic Set Point : 0

Number	Description
0	Disable : Will not recognize supplement code
1	Decode : Must recognize Supplementcode in order to be recognized as correct bar code.
2	Autodiscriminat : With or without the Supplementcode, will recognize bar code.



- Only the numbers 0~2 to be entered otherwise setting will be cancelled.

② Interleaved 2 of 5 Length Min : Set up minimum cognition length.

- Basic Set Point : 3
- Numbers 0~255 to be entered otherwise setting will be cancelled.



③ Interleaved 2 of 5 Length Max : Set up Maximum cognition length.


- Basic Set Point : 30
- Enter numbers 0~255 otherwise setting will be cancelled.



④ MSI check digit : Set up Check Digit. It is the method to inspect whether the barcode is correct.

- Basic Set Point : Check_1

Number	Check Digit
0	check_1
1	check_2



- Numbers 0~1 to be entered otherwise setting will be cancelled.

Using PidionScan Program

4 Configure

- ⑤ **MSI check digit algorithm**
: Modulo_10_10/ modulo_10_11 / modulo_10_12 can be set by check digit algorithm.

- Basic Set point : modulo_10_10

Number	Check digit algorithm
0	modulo_10_10
1	modulo_10_11
2	modulo_10_12

- Enter numbers 0~2 otherwise setting will be cancelled.




Prefix/Suffix

You can edit the function by allocating character to each barcode value.

Prefix, Suffix : You can use carriage return and linefeed by entering a value.

- **Default**
Prefix : Blank
Suffix : `␣`



Trigger


You can the Scan mode of the Scan button.

Single : Scans one barcode each time you press the Scan button once.

Continuous : If you press the Scan button once, the laser is continuously emitted, so that barcodes are read in a row.

If you press the Scan button once again, laser emission is stopped. If you scan the barcode, after a certain period of time, even if it is read once, additional data can be read. You can set a certain period of time, and the range is 0~9999, unit is ms(1/1,000 of 1 second), Default is 2222ms.

Multiple : If you press the Scan button once, laser is continuously emitted, so that barcodes can be read in a row, but a read barcode is not read again. If you press the Scan button one more time, laser emission is stopped.



System

You can change the Power Save mode and password of the terminal.

Power Save Mode : Set to the Power Save mode for saving power. If you do not use a terminal for a certain period of time (minute), the terminal is changed to the Power Save mode.

Security Setting : Set password.

- Password is up to 4 numeric characters.
- PIN Code : Set password.
- Confirm : Confirm password to be set.
- Press the Change button and turn off and on the terminal again, then, password is changed.

Default Setting : All settings for the terminal are initialized to default setting. If you execute this, the terminal reboots as initialization.

Erase all data : Clear all barcode values saved in the terminal.



Using PidionScan Program

4 Configure



TIP

PIN Code should be the same as a 4 digit password entered in Confirm.

5 About

Information on software version and copyright is displayed.



Classification		Specification
Physical	Size	36 x 85 x 19 mm
	Weight	Battery (included) : 54g Main body (battery excluded) : 38g
Functionality	CPU	Samsung
	OS	Linux
	RAM	16MB
	ROM	32MB
	Interface	24pin Connector used RS-232C, USB Client
	Wireless	Bluetooth Class 2, Max. distance 10m, Bluetooth 1.2
Electrical	Battery capacity	Built-in 720mAh Li-Ion Battery
	Charging time	Approx. 2 ~ 3 hours
	Battery lifetime after one-time charging	Continuous Barcode Scan 15,000 or more

Electrical	Bluetooth	Frequency : 2402MHz ~ 2480MHz Output : 20uW Emission type : F1D Modulation mode : GFSK method : Number of channels repeated : 79 Type of public line : Chip ANT Gain of public line : 1.1 dBi Active circuit is not added
Environmental	Temperature in operation	-5 ~ +40℃
	Temperature in storage	-20 ~ +60℃
	Humidity	0 ~ 95% (non-condensing)
	Protection	IP30
Optical	Decode Capability	1D : UPC-A, UPC-E, EAN-13, EAN-8, EAN-128, BookLand, Supplement Code, UCC Coupon Extended Code, Code 128, Code39, Code 93, Interleaved 2 of 5, CodeBar, MSI. 2D : MaxiCode, Data Matrix, Code 39, UPC, Postnet, QR Code, OCR-A, OCR-B
		Barcode recognition notice
		Notify by the change of scanning lamp color, tone volume or sequence

If the terminal does not operate normally, please refer to:

Q Water comes into the barcode scanner. What shall I do?

A First, remove the battery from the barcode scanner, and dry it up at the dry place for a certain period of time.

Q Power is not on.

A Check if the battery is inserted properly and use after charging the battery for a certain period of time.

Q A battery is not charged.

A Check if the barcode scanner is properly connected to the charger.

Q Barcode is not scanned.

A ① Angle of scan may be incorrect. Scan at a right angle.

② Barcode cannot be read if you scan barcode too far. Move close and scan barcode.

③ The barcode may be damaged. Scan other barcodes for check.

Q Barcode data scanned by PDA is not transmitted.

A ① When transmitting Bluetooth, check if PDA supports the Bluetooth function.

② Check if the Bluetooth of PDA is set properly.

③ When sending Bluetooth through data cable, check if cable is connected correctly.

Q Data is not sent from PC.

A ① Check if data cable is connected properly.

② Check if the connection program is correctly installed in a PC.

Q Heat is generated in the barcode scanner

A If you use the product for a long time, heat is generated sometimes. Use the product in relief because product performance is not affected.

Q Lifetime of a battery is reduced.

A Batteries are consumables. Lifetime may be reduced depending on period of use. Please, replace by a new battery.

※ If a problem still remains even if you check the above items, please contact a nearby Customer Service Center.

※ The warranty period (one year after the purchase date) for the product is one year.

For any enquires of problems or inconveniences while using the product please call +82-2-1588-1380.

[Before asking for after-sales service]

- Before requesting after-sales service, the user needs to back up data in the device in person.
- We do not backup products registered at the customers service center. Therefore, we are not responsible for any damage or loss of data.

[Customer care center of Bluebird Soft Inc.]

- Phone : +82-2-1588-1380
- Fax : +82-2-548-0870
- E-Mail : gcs@bluebird.co.kr
- Address : 1242, Gaepo-dong, Gangnam-gu, Seoul, Korea

[Work hours]

- Mon.-Fri. : 9 A.M. ~ 6 P.M. (GMT Time: +9 Hours)
- We do not work on Saturday, Sundays and National Holidays.

[How to ask for after-sales service]

- For after-sales service, please contact your local dealer or our customer care center.
- Do not remove the label of the product on purpose.
- Make sure to deliver the product in a safe way. Bluebird Soft is not liable for device loss during delivery.

Service Center Information

[Regulations on Free/Charging Repairs]

Type of Customer Damage		Contents of Compensation	
		Within the Term of Guarantee	After term of guarantee
When requesting important repairs within 10 days of purchase		Exchange or Repayment	
Requesting important repairs within 1 month since purchase date		Exchange or Repair Free of Charge	
An important repair is needed after 1 month of exchange		Exchange or Repair Free of Charge	
When it is impossible to exchange within 1 month		Repayment	
Possible Repairs	The same problem occurs 3 times	Repair Free of Charge	Charged Repair
	The same problem occurs 4 times	Exchange or Repayment	Charged Repair
	5 problems in all different parts		
Impossible Repairs	When the manufacturer has lost the product in which the customer has requested for a repair	Exchange or Repayment	Exchange after depreciation of the fixed price.
	When it is impossible to repair within 1 month.		
	Impossible to exchange.	Repayment	Exchange after adding 10% to the depreciated price of the fix price (the highest price-purchased price).

- Abiding to the Regulations of Customer Damage Repayment, Terms of Component Possession: 3 years
- Exchange will be made to the same product. If an exchange for the same product is impossible, then it will be exchanged for a similar product. However, there should be a repayment if the customer does not want an exchange for a similar product.
- Repayment amount should be the amount written in the receipt
- If the price on the receipt is higher than the price, than the usual price will be used as a standard, considering that other incidental expenses had been added to the higher price.

[Charged Service]

1. If it is not a default, it will be charged when requesting for after-sales service.

- Service request due to inappropriate use of the customer
- Loss of a PIN number
- Use of programs that might effect the program (over-clock, forceful changes in the input of the system, personal developments)

2. Default due to a mistake on the part of the customer

- Default due to inappropriate or careless use of the product (dropping, submersion under water, shock, damage, unreasonable operations, etc).
- Default due to a repair or unauthorized technician.
- Default caused intentionally or by carelessness of the customer.
- Default due to the use of fraudulent parts or components.

3. Other cases

- Default due to nature (fire, damage due to sea wind, flood damage, etc.).
- Expendable parts have exhausted there life (batteries, antenna, or other component parts).

4. Regulations of treatment after charged service

- If the same default occurs on the part that had been repaired within a 2 months(60 days) period, it will be provided with free of charge repair service.

There will be no returning of goods or repayment upon the following situation:

- Removal of the sealing of the product if it had been sealed.
- If the product has been damaged due to careless use by the customer or due to a natural disaster (floods, rain, fire, etc.).
- Loss of product or other components (CD, diskette, manual, connecting cables, etc).
- Damage to the product after 10 days of purchase, the product will either be exchanged or provided with after-sales service (note, returning of goods or repayment is not allowed).

Certificate of Guarantee

Thank you for purchasing a product from Bluebird Soft Inc.

- If a circumstance arises where you lose a receipt or the certificate of guarantee, then the term of guarantee will be calculated 3 months (certified by the number of the manufacture, a certificate of inspection) after the date of manufacture.
 - In case of accessories (such as batteries), only those that match the sales list managed by the service center will be eligible for customer service.
 - A repair or an exchange of batteries that does not match the sales list of the service center due to the carelessness of the customer will be fully charged.
2. If Bluebird had been notified of the defaults within the term of the guarantee and the extent of guarantee, Bluebird will repair or exchange those products according to the guarantee policies.
 3. If Bluebird cannot repair or exchange defaulted products that had been sent within the term of the guarantee, but falls within the coverage of the guarantee policies, Bluebird will compensate for the products.
 4. Bluebird does not have any responsibility to repair, exchange, or repay products until the customer returns the defaulted product. The exchanged product will be provided with one that has a quality equal to that of the brand new product.

Name of Product	Barcode scanner	Name of Model	BI-300
Date of Purchase		Manufacture Number	
Place of Purchase		Term of Guarantee	1 year from purchase

5. Bluebird will guarantee those products that are from countries in which Bluebird rightfully distributed the guaranteed products.
6. Bluebird products may include parts, composition, accessories, and materials that have the same capability as a brand new product.
7. If it is a software product, guaranteed service will be offered only in cases where the programming commands cannot be launched. Bluebird cannot guarantee that the product will never stop or there will never be an error when using the product.

[Guarantee of the Product]

1. Due to the regulations of the customer damage compensation, Bluebird Soft Inc. (hereafter Bluebird) will guarantee the products as follows.

The following information on this class B equipment is provided for the users:



This equipment is home appliances registered as EMI/EMS/EMC, and is available in all areas including residential district.

BBS-BI-300

BBS-BI-300A(B)



WARNING

You can use a life safety-related service because radio equipment corresponding to the following has a possibility of radio interference.

CE0678①


Laser device

Class 1 laser device is considered to be not dangerous if used for its intended purposes. The following description is a requirement required for compliance with U.S. and international rules.



If you use the control operation, coordination or procedures other than items specified herein, you may be exposed to dangerous laser beam.

Class 2 laser scan uses low-power visible light diode. Users should not directly look at light of quite bright light source such as sunlight. Instantaneous exposure to class 2 laser is considered to be not harmful.



The following information is provided for the users according to Article 5, IEC 825 and EN60825.

ENGLISH

CLASS 1
CLASS 2

CLASS 1 LASER PRODUCT
LASER LIGHT
DO NOT STARE IN TO BEAM
CLASS 2 LASER PRODUCT

DANISH/DANSK

KLASSE 1
KLASSE 2

KLASSE 1 LASERPRODUKT
LASERLYGT
SE IKKE IND I STRÅLEN
KLASSE 2 LASERPRODUKT

DUTCH/NEDERLANDS

KLASSE 1
KLASSE 2

KLASSE 1 LASERPRODUKT
LASERLICHT
NIET IN STRAAL STAREN
KLASSE 2 LASERPRODUKT

FINNISH/SUOMI

LUOKKA 1
LUOKKA 2

LUOKKA 1 LASERTUOTE
LASERVALO
ÄLÄ TUKUOTA SÄDETTÄ
LUOKKA 2 LASERTUOTE

FRENCH/FRANÇAIS

CLASSE 1
CLASSE 2

PRODUIT LASER DE CLASSE 1
LUMIÈRE LASER
NE PAS REGARDER LE RAYON FIXEMENT
PRODUIT LASER DE CLASSE 2

GERMAN/DEUTSCH

KLASSE 1
KLASSE 2

LASERPRODUKT DER KLASSE 1
LASERSTRAHLEN
NICHT DIREKT IN DEN LASERSTRAHL SCHAUEN
LASERPRODUKT DER KLASSE 2

CHINESE / 简体中文

1 类
2 类

1 类激光产品
激光
切勿直视光束
2 类激光产品

KOREAN / 한국어

1등급
2등급

1등급 레이저 제품
레이저 광선
이 광선을 투시하지 마십시오.
2등급 레이저 제품

HEBREW

מוצר לייזר רמה 1

רמה 1

אור לייזר

רמה 2

אל תחביט אל תוך חזרים
מוצר לייזר רמה 2

ITALIAN/ITALIANO

CLASSE 1
CLASSE 2

PRODOTTO AL LASER DI CLASSE 1
LUCE LASER
NON FISSARE IL RAGGIO
PRODOTTO AL LASER DI CLASSE 2

NORWEGIAN/NORSK

KLASSE 1
KLASSE 2

LASERPRODUKT, KLASSE 1
LASERLYS
IKKE STIRRE INN I LYSSTRØLEN
LASERPRODUKT, KLASSE 2

PORTUGUESE/PORTUGUÊS

CLASSE 1
CLASSE 2

PRODUTO LASER DA CLASSE 1
LUZ DE LASER
NÃO FIXAR O RAO LUMINOSO
PRODUTO LASER DA CLASSE 2

SPANISH/ESPAÑOL

CLASE 1
CLASE 2

PRODUCTO LASER DE LA CLASE 1
LUZ LASER
NO MIRAR FIJAMENTE EL RAY
PRODUCTO LASER DE CLASE 2

SWEDISH/SVENSKA

KLASS 1
KLASS 2

LASERPRODUKT KLASS 1
LASERLJUS
STIRRA INTE MOT STRÅLEN
LASERPRODUKT KLASS 2

JAPANESE / 日本語

クラス1
クラス2

クラス1 レーザ製品
レーザ光線
光線を直視しないでください
クラス2 レーザ製品



Customers Service Center

Hours

Mon.- Fri. : 9 A.M. ~ 6 P.M.
(GMT Time: +9 Hours)

We are not open on Saturday,
Sundays and National Holidays.

Address : 1242, Gaepo-dong,
Gangnam-gu, Seoul, Korea

Bluebird constantly strives to bring utmost satisfaction to all our customers.