

User Manual



PixBAND Quad 6

6 High Powered Quad-Colour LEDs

www.showtech.com.au

Table of Contents

1. Safety instructions.....3

1.1 Overhead rigging4

1.2 Power Connection6

1.3 Cleaning and Maintenance6

2. Menu Navigation7

3. DMX Allocation9

4. Technical Specifications10



PixBAND Quad 6

1. Safety Instructions

FOR SAFE AND EFFICIENT OPERATION

Be careful with heat and extreme temperature.

Avoid exposing it to direct rays of sun near a heating appliance.

Do not put it in a temperature below 41°F/5°C, or exceeding 95°F/35°C.

Keep away from humidity, water and dust.

Do not place the set in a location with a high humidity or lots of dust.

Containers with water should not be placed on the set.

Keep away from sources of hum and noise

Such as transformer motor, tuner, TV set and amplifier.

To avoid placing on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

NO USER SERVICABLE PARTS INSIDE.

If unit is out of service please contact your point of purchase.

If any troubles arise, remove the power plug and contact your Pro Shop representative for repair. Do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable. Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug.

When not using the unit for an extended period of time be sure to disconnect the plug from the receptacle.

1.1 Overhead Rigging

This item must be built in a way that it can hold 10 times more of its weight for 1 hour without causing any damages. The installation must be secured with a secondary safety attachment. The Safety attachment has to be constructed in a way that no part of the installation can fall down. When rigging, de-rigging or servicing the fixture staying in the area below the installation place, on bridges, under high working places and other endangered areas is forbidden. Before taking the device in operation, the installation must be approved by an expert. The operator has to make sure that safety-related and machine-technical installations are approved by a skilled person once a year.

IMPORTANT! OVERHEAD RIGGING REQUIRES EXTENSIVE EXPERIENCE.

Including (but not limited to) calculating working load limits, installation material being used, and periodic safety inspection of all installation material and the projector. If you lack these qualifications, do not attempt the installations yourself, but instead use a professional structural rigger. Improper installation can result in bodily injury and/or damage to property.

Use only professional trussing system if the item shall be lowered from the ceiling or high joists. Never let the device swing freely in a room.

CAUTION: Overhead Items may cause serious injuries when crashing down!! If there is concern about the safety then DO NOT INSTALL the device.

DANGER OF FIRE!

When installing the device, make sure there is no highly-flammable material (decoration articles, etc) within a distance of min. 0.5m.

PixBAND Quad 6

Mount the projector with the mounting bracket to your trussing system using an appropriate clamp.

For overhead use, always install a safety-rope that can hold at least 10 times the weight of the fixture. You must only use safety –ropes with quick links with screw cap. Pull the safety-rope through the hole in the mounting bracket and over the trussing system or a safe fixation spot. Insert the end in the quick link and tighten the safety screw. The maximum drop distance must never exceed 20cm

A safety rope which already held the strain of a crash or which is defective must not be used again.

DANGER TO LIFE!

Before taking into operation for the first time, the installation has to be approved by an expert.

1.2. Power Connection

!! CAUTION !!

Never leave this device running unattended!! Every person that is involved with this item has to be qualified!!

Connect item with main plug. The voltage and frequency must exactly be the same as stated on the device. The power plug must always be inserted without force.

1.3. Cleaning and Maintenance

Please make sure that safety-relating and machine-technical installations are inspected by a skilled person once a year.

1. Make sure before installing that all screws are tightly connected and not corroded.
2. There must be no deformations on the housings, fixations and installations spots
3. No damages must be showed on the power supply cables, material fatigue and sediments

If the exterior of the unit is going to be cleaned, please use moist, lint free cloths. Never use alcohol or solvents.

The Cooling fan must be cleaned monthly and check to ensure it is free of obstructions.

To clean the interior of the device please use a vacuum cleaner or an air jet, however we recommend cleaning the lenses weekly to ensure the best output from your unit.

2.0 Menu navigation

Menu Selection	Options	Extended Options
DMX Address Set the unit start address	DMX Address	001-512
DMX Channel Adjust the DMX mode on the unit	4 Channel Mode 8 Channel Mode 24 Channel Mode	RGB + dimmer, strobe RGB + macros + dimmer Individual Pixel Control
Master / Slave Allows the unit to be set in slave mode to copy other units on DMX chain	Master Slave	Master Mode Slave Mode
Auto Show Allows the user to select in built auto show	Auto Show 1 Auto Show 2 Auto Show 3 Auto Show 4 Auto Show 5 Auto Show 6 Auto Show 7 Auto Show 8 Auto Show 9 Auto Show 10	

PixBAND Quad 6

	Auto Show 11	Fade Speed 0-100%
	Auto Show 12	
	Fade	

Static	Fixture Color	Fixture Color
Allows the user to select non-changing output colours and shades, as well as setting the strobe function	Select R,G,B	select desired colour
	Select S	Select S for Strobe C1: Red C2: Green C3: Blue C4: White C5: Green + Blue C6: Red + Blue C7: Red + Green C8: Red + Green + Blue C9: Red + White C10: Green + White C11: Blue + White C12: Red + Green + White C13: Red + Blue + White C14: Green + Blue + White C15: Red + Green + Blue + White
	Select Mode C	

Dimmer Mode	Off	Dimmer Speed off
-------------	-----	------------------

PixBAND Quad 6

<p>Allows the user to select from 4 options of dimming speeds</p>	<p>Dimmer 1</p> <p>Dimmer 2</p> <p>Dimmer 3</p>	<p>Dimmer Speed Fast</p> <p>Dimmer Speed Medium</p> <p>Dimmer Speed Slow</p>
<p>Sound Mode</p>	<p>Sound activation</p>	<p>On</p> <p>Off</p>
<p>Standby</p>	<p>Standby</p>	<p>Off</p> <p>On</p>
<p>Back Lite</p> <p>Adjusts the setting of the LCD back light</p>	<p>On</p> <p>10s</p> <p>20s</p> <p>30s</p>	<p>LCD Backlight will remain on</p> <p>LCD off after 10 seconds</p> <p>LCD off after 20 seconds</p> <p>LCD off after 30 seconds</p>
<p>Back Dimmer</p>	<p>Back Dimmer</p>	<p>0-100</p>
<p>White Balance</p> <p>Adjustable level of RGB to allow fine tuning of colour output</p>	<p>Balance</p>	<p>Adjustable levels of red, green and blue</p>
<p>Auto</p>	<p>Auto</p>	<p>Test</p>

PixBAND Quad 6

--	--	--

Version	V1.0	
----------------	------	--

Factory settings	Factory	Yes No
-------------------------	---------	-----------

Reset	Reset	Yes No
--------------	-------	-----------

3.0 DMX Allocation

4ch	6ch	8ch	30ch		
1	1	1	1	Red	000-255
2	2	2	2	Green	000-255
3	3	3	3	Blue	000-255
4	4	4	4	White	000-255
	5	5		Strobe	000-255
	6	8	0	Dimmer	000-255
		6	0	Macros	000-255
		7	0	Speed	000-010 No Function 011-255 Strobe Slow to Fast
			21	Red	000-255
			22	Green	000-255
			23	Blue	000-255
			24	White	000-255

4.0 Technical Specifications

Power in: 100-240 VAC, 50/60Hz

Power consumption: 55 W

LED type: 8W RGBW 4 IN 1 LED

Number of LEDs: 6 pcs

Beam angle: 120°

Dimensions (L x W x H): 560 x 65 x 196 mm

Weight: 3.0 kg