Manual

2.4GHz Wireless Presenter

Table of Contents

| Safety Instructions | 1 |
|-----------------------|-------|
| Package Contents | 1 |
| Introduction | 1 |
| Features | 2 |
| System Requirement | 2 |
| Specification | 3 |
| Hardware Installation | 3 |
| Production Function | 8 |
| Certificate | 9 |
| Disclaimer | 9 |

Safety Instructions

Always read the safety instructions carefully

- Keep this User's Manual for future reference
- Keep this equipment away from humidity
- Lay this equipment on a reliable flat surface before setting it up
- If any of the following situation arises, get the equipment checked by a service technician:
 - The equipment has been exposed to moisture.
 - The equipment has been dropped and damaged.
 - The equipment has obvious sign of breakage.
 - The equipment has not working well or you cannot get it work according to User's Manual.

Package Contents

- Wireless Presenter X 1
- Receiver X 1
- Battery 1.5V AAA X 2
- Manual X 1

Introduction

Wireless Presenter is an ideal assistant to make your presentation successful. With the RF technology and a receiver compliant with USB1.1, it allows you to freely control your slides from distances up to 15 meters for more flexibility. The embedded laser pointer is also useful to highlight your key points. Besides, the function keys make you freely control the slides as page up/down, play/ESC, mode switch, blank on/off, laser light and etc. Keep the wireless presenter in hand, making a perfect presentation is just so easy.

Features

- 1. An ideal tool for a perfect presentation
- 2. 2.4GHz Radio Frequency (worldwide license free radio frequency)
- 3. Remote control slides from a distance up to 15 meters
- 4. Function keys could be switched under PowerPoint and Windows Media Player mode both
- 5. Laser point function (with lock design for children protection)
- 6. Receiver is compliant with USB 1.1 interface
- 7. Support plug-and play
- 8. Turn to sleeping mode while motionless over 10 minutes
- 9. Battery support AAAx2

System Requirements

IBM PC or compatible system with USB 2.0(USB 1.1 compatible supported) interface.

Intel Pentium 4 1G or higher, and compatible computer.

DDR 256M Memory RAM or more

OS: Win 98SE, Win ME, Win 2000-SP4 (up to Service Pack), Win XP-SP1 (up to Service Pack) and Win Server 2003.

Specification

| Model | | Wireless Presenter | | | | |
|-----------|------------------|--------------------|----------------|-----|------|-----|
| Indicator | RF Specification | 2.4GHz worldwid | frequency e | ISM | band | for |

| | Power | AAA X 2 |
|--------------------|-----------------------------------|--|
| | Power Consumption | 3V 1.2mA3V 27mA while Laser Pointer is on |
| Laser Pointer | Laser wavelength at peak emission | 650nm+-20nm (Red Light) |
| | Indicator | Max to 4 maters |
| | Power consumption | 1mW |
| Receiver | Interface | USB 1.1 on receiver |
| | Power consumption | 5V 30mA |
| Operation Distance | | 15 meters, from indicator to receiver |

Hardware Installation

- 1. Any OS in the systems, there are no driver support.
- 2. The Wireless Presenter is bundled the system for under OS Win 98SE, Win ME, Win 2000-SP4 or up, Win XP-SP1 or up and Win Server 2003.
- 3. The Wireless Presenter can be connected multiple functions such as **remote presenter and a laser point** under all the OS.
- 4. For the Wireless Presenter, any OS must be installed the office for PowerPoint.
- 5. Any the program of office system can be supported this product under PowerPoint such as office 97, 2000, XP or up.

Windows 98SE

1. Please plug-in the product of "receiver" to system. This system detects the new system for "USB Human Interface Device" and click the "NEXT".



2. After that, the system detects the new hardware for searching " Search for the best driver for you device {Recommended} " and clicks the " NEXT ".



 Windows will search for new system in its system database on your hard drive, and in any of the following selected location for the "specify a location: (option)
c:\Windows "in browse. Click "NEXT" to start the search.




4. Windows searches for the device for new system "USB Human Interface Device ". Windows is now ready to install the best system for this device click back to select a different driver for location of driver: (option) C:\\Windows\inf\\HIDDEV.INF" and click "NEXT" to continue.



5. Please insert the disk labeled Windows 98 Second Edition CD-ROM and then click "OK".




6. After that, please direct the location of driver to the "base5.cab" in Windows 98SE.




7. Windows has finished installing the software that your new hardware device requires for "USB Human Interface Device" and clicks the "FINISH".




Windows 98SE/ME/2000/XP/Server 2003





Product Function



| | T |
|--------|--------------------------------------|
| Key | Function |
| Key 1 | Laser Light |
| Karr O | Play PowerPoint (under Microsoft |
| | PowerPoint mode) |
| Key 2 | Play/Pause Windows Media Player |
| | (under Windows Media Player) |
| Key 3 | ESC PowerPoint (under PowerPoint |
| | mode) |
| | Stop Windows Media Player (under |
| | Windows Media Player mode) |
| | Blank On/Off (under PowerPoint mode, |
| Kov 1 | switch change) |
| Key 4 | Mute On/Off (under Windows Media |
| | Player mode, switch change) |
| Key 5 | Page Down (under PowerPoint mode) |
| | Volume - (under Windows Media Player |
| | mode) |
| | Page Up (under PowerPoint Mode) |
| Kay C | |
| Key 6 | Volume + (under Windows Media Player |
| | mode) |
| Key 7 | Mode Switch (PowerPoint/Windows |
| | Media Player Mode) |

Functional Setup

| Function | Usage Style |
|--------------------|---|
| Laser On/Off | Press Key 1 + Key 7 for 3 seconds (Confirm setup action already in Red |
| | LED flashlight) |
| Sleeping | System no action for over 10 minutes) |
| Mode Switch Change | Press Key 7 for 1.5 seconds (Confirm setup action already in Green LED |
| | flashlight) |
| ID Change | Press Mode key for 1.5 second. Press PAGE_DOWN key for 3 second. |
| | The mode system keeps the flashlight in Green LED until LED on when |
| | RD interference condition that ID change requirement. |

CE - Certificate

This equipment is in compliance with the requirements of the following regulations: EN 55 022: CLASS B



Disclaimer

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage. No part of this document may be reproduced or transmitted in any form by any means, electronic or mechanical, including photocopying, recording or information recording and retrieval systems without the express written permission of the manufacturer.