

User Manual

M3

Head-Mounted-Display (HMD), DVI



Subject to technical modifications

Copyright: Trivisio Prototyping GmbH, Karcherstrasse 10, D-67655 Kaiserslautern

WARNING

Before using the M3 HMD please read carefully these safety instructions.

Read this handbook and use the M3 HMD device in strict accordance in order to prevent any damage to your eye, other injury, loss of visual functions, property damage or death.

Children under the age of fifteen may not use this product.

We strongly advise you to get familiar with the M3 HMD device and its capabilities before you use it for the first time.

Table of Contents

Table of Contents.....3

1 Safety instructions.....4

1.1 Health concerns4

1.2 General safety hints5

1.3 Warning for electrical products.....5

2 Content of the M3 HMD Kit6

3 Description7

3.1 Head Mounted Display HMD7

3.2 Connectors8

4 General Operating Instructions9

4.1 Preparation9

4.2 Connecting to external video sources9

4.3 Adjusting the graphics driver10

4.4 Adjusting the image.....11

4.5 Adjusting the HMD.....12

4.6 Using the integrated microphone14

4.7 Using external earphones16

4.8 Firmware update17

5 Maintenance and Cleaning Instructions.....18

6 Troubleshooting19

7 Returning used electronic devices in EU countries20

8 Technical Data21

8.1 Head Mounted Display21

1 Safety instructions

1.1 Health concerns

➔ **WARNING:** Eye Disease, Eye Injury, and Glaucoma

If you have been diagnosed with or are susceptible to eye disease, eye injury, or glaucoma consult your doctor before use and do not use without your doctor's approval.

➔ **CAUTION:** Heart Disease, High Blood Pressure

If you have a history of heart disease or high blood pressure consult your doctor before use and do not use without his approval.

➔ **CAUTION:** Seizures

If you have a history of temporary spasm, unconsciousness, or epileptic seizures from light stimulation, consult your doctor before use and do not use without his approval.

If any of the following symptoms occur, if using M3 HMD, stop using immediately and rest:

- eye fatigue or irritation,
- headaches or dizziness,
- aches and pain in the neck or shoulders,
- double vision,
- nausea or motion sickness,
- inability to focus on the displays.

Misuse or overuse of this product may result in eye damage, or loss of visual functions.

1.2 General safety hints

- ➔ Avoid getting the cable entangled around your neck, body or arms. Wear the cable close to your body.
- ➔ To ensure that the device does not fall off during use, always have it tightened with an adequate tension.


1.3 Warning for electrical products

- ➔ To avoid any risk of electrocution, do not bring any part of the M3 HMD in contact with water when it is connected to an AC outlet or a PC.
- ➔ Avoid using and storing the M3 HMD at wet, humid, dusty and smoky surroundings and extreme temperatures.
- ➔ Do not use M3 HMD at temperatures below -10°C and above +40°C. Avoid dropping or mechanical shock, as frame and displays may be deformed.
- ➔ Always unplug the M3 HMD when it will not be used.
- ➔ In case of damage contact your retailer. There are no user serviceable parts. Only qualified service personnel should perform any service required on this product.

2 Content of the M3 HMD Kit

The M3 HMD kit contains the following elements. Please check that all of these are included. If any item is not supplied contact your M3 HMD dealer.

HMD (1), Driver-CD(2), Cleaning cloth (3)



3 Description

3.1 Head Mounted Display HMD


The HMD contains one **microdisplays** (1) to show the images. The **cable** (2) is permanently attached to the case. At the end of the cable there are several connectors (see 3.2 Connectors page 8). On the bottom side of the case is a 2.5mm audio connector for external earphones (3). The HMD is fixed to a flexible head-band (4).



3.2 Connectors

The cable of HMD contains the following connectors:

- (1) DVI-D (only digital signals !)
- (2) USB (power-supply, control and firmware updates)
- (3) 3.5mm pink jack for microphone
- (4) 3.5mm green jack for earphones



4 General Operating Instructions

4.1 Preparation

Unpacking the Device

- ➔ Please unpack the devices and compare with the list under paragraph 2 on page 6 to check that all parts are complete. Please contact your dealer if any parts are missing.

4.2 Connecting to external video sources

Connect the cables to PC


To prevent damage to the electronic, first connect the video cable with your PC before you power on the device by connecting the USB cable to the PC. Plug in all the other connectors (audio). For normal operation at least the DVI and USB plugs (see 3.2 Connectors page 8) are needed. If the DDC function of your graphics card is working correct the M3 HMD will be recognized automatically and you will see an image inside the HMD.

If the device is not recognized automatic reboot your PC.

- ➔ If you do not see an image after rebooting please refer to 4.3 Adjusting the graphics driver page 10.



4.3 Adjusting the graphics driver

If you have connected the HMD to secondary DVI output of your graphic card then adjust the driver settings: In MS-Windows® go to menue "Display Properties". You should see two monitors. Click on the appropriate symbol and activate "Extend my Windows desktop onto this monitor".




4.4 Adjusting the image

To adjust the image start the software "hmd_connection.exe" which can be downloaded from www.trivisio.com. After installation select the HMD (also serial number is shown here). Then you can go to menu "Picture" and adjust the brightness, contrast and gamma of the image.



4.5 Adjusting the HMD


To optimize the position of the display carefully move the ocular into the right position. You can slide and rotate the case relatively to the head-fixation and you can rotate the front side hinge in all directions.



Adjustment to the head with a single head band

The pressure of the head band on you head (called spring force and marked by the → red arrows) is set at the manufacturers premises, and is only adjustable there. Hence, it is needed to say which size of head will wear the monocular.

The → blue arrows show the possibility to adjust manually the size of this head band.



Adjust carefully the head band by pulling and pushing with your hands. Adjust both sides equally.





Minimal position





Maximal position

4.6 Using the integrated microphone

In MS-Windows® go to menue "Volume Control" and in "Properties" activate "Microphone".




If the microphone is not loud enough you can activate a booster: Click on menu "Volume Control" and select "Advanced Settings", then a button "Advanced" appear to reach next menu:




4.7 Using external earphones

Plug your external earphones to the connector on the bottom side of case (1) 2.5mm jack). If the 3.5mm jack is inserted into your PC soundcard the signal will be forwarded to the headset.



4.8 Firmware update

In the need of a firmware update select the menu of HMD-software "hmd_connection.exe" and choose new firmware file by clicking on "Browse". The firmware is provided as "name.hex" file. Then click "Program". During the update process never unplug the device and do not shut down the computer and do not turn off the power !



5 Maintenance and Cleaning Instructions

To clean the HMD use a damp cloth. A light rinsing agent may be added to the water. Do not use any detergents.

To clean the ocular of the HMD use a dry, clean cloth. A cleaning cloth for this purpose is provided with the M3 HMD-kit.

In case of damage contact your retailer. There are no user serviceable parts. Only qualified service personnel should perform any service required on this product.

6 Troubleshooting

Problem	Cause	Remedy
No image	DVI video cable or USB cable not connected or not plugged properly	Check cables connections
No image	Computer does not recognize the new hardware	Connect the HMD to the PC and reboot your computer
Only dark, or only white image	Incorrect brightness	Adjust brightness by using the supplied software
Flickering image	Wrong resolution or wrong frequency	Set the resolution of computer to 800x600 at 60Hz
Bad or colorized image quality	Fingerprints or dirt on ocular window	Clean ocular window

All other problems should be performed by a trained and authorised service provider !

7 Returning used electronic devices in EU countries

	<p>This HMD and accessories shall not be treated as household waste. The separate collection is a condition for reuse, recycling and utilisation of used electronic devices, which ensures the protection of resources. To comply with german ElektroG (Rücknahme und Entsorgung von Elektro- und Elektronikaltgeräten) and european WEEE (Waste Electrical and Electronic Equipment) electronic used devices from private households can be returned free of charge. For details please contact your local distributor or directly Trivisio Prototyping GmbH (www.trivisio.com).</p>
---	---

8 Technical Data

8.1 Head Mounted Display

Display	SVGA microdisplay 480,000 pixels colour equals 1,440,000 pixels
Field of view	approx. 30° diagonal
Eye relief.....	approx. 25mm
Camera.....	640x480 pixels color 8bit, 69 fps, USB 2.0 1/3"CMOS
Focus.....	manually adjustable
Iris.....	fixed
Camera lens.....	f=6.8mm, M9x0.5 52° (changeable)
Power consumption.....	1.8W (5V/360mA taken from USB port)
Operating temperature.....	-10°C to +40°C
Weight HMD	100g
Dimensions (W/H/D).....	200mm/50mm/250mm (including head fixation)