



www.prolight.co.uk



Spectra I.R Remote

(Order code: LEDJ90B)

USER MANUAL

WARNING

**FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY
BEFORE YOUR INITIAL START-UP!**

**CAUTION!**

**Keep this equipment away from rain,
moisture and liquids.**

**SAFETY INSTRUCTIONS**

Every person involved with the installation, operation & maintenance of this equipment should:

- Be competent
- Follow the instructions of this manual

Before your initial start-up, please make sure that there is no damage caused during transportation. Should there be any, consult your dealer and do not use the equipment.

To maintain the equipment in good working condition and to ensure safe operation, it is necessary for the user to follow the safety instructions and warning notes written in this manual.

Please note that damages caused by user modifications to this equipment are not subject to warranty.

IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorised modification to the equipment.

- Never remove warning or informative labels from the equipment.
- Do not open the equipment and do not modify the equipment.
- Do not expose to flammable sources, liquids or gases.
- If the equipment has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation might damage the equipment. Leave the equipment switched off until it has reached room temperature.
- If your product fails to function correctly, discontinue use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Prolight dealer for service.
- Repairs and servicing must only be carried out by a qualified technician.
THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.
- **WARRANTY;** One year from date of purchase.

OPERATING DETERMINATIONS

If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void.

Button functions:

The “**BLACKOUT**” button is used to set the LED’s into the power on or off modes.

The “**AR**” button is used to set the LED’s into the auto run mode.

The “**S PR**” button is used to set the LED’s to run the built-in programmes

Built-in programme selection: 7 colour selection, colour changing and colour fade.

Choose between the 9 built-in programmes by pressing the “+” and “-” buttons.

The “**FL**” button is used to set the LED’s to flash on and off, to change the flash frequency use the “+” and “-” buttons.

The “**SP**” button is used to set the run speed, this button is available only in the colour change or colour fade modes. To change the speed use the “+” and “-” buttons.

The “**D**” button is used to set the LED’s into DMX mode. (See DMX value table)

The “**SA**” button is used to set the LED’s into sound activated mode. This function is unavailable on the Exterior Spectra Series.

The “**SL**” button is used to set the LED’s into slave mode.

The “**S**”, “**0**”, “**1**”, “**2**”, “**3**”, “**4**”, “**5**”, “**6**”, “**7**”, “**8**” and “**9**” buttons are used to set the DMX address for the LED’s. (see example below)

The “**R**”, “**G**”, and “**B**” buttons are used to set the brightness for the LEDs, to change the brightness use the “+” and “-” buttons.

DMX Address Examples:

To set the DMX address “245”;

- 1) Press the “**S**” button, so the red LED’s come on, this means you can now start to set the DMX address.
- 2) Press the “**2**” button, so the green LED’s come on, this means the first digit “**2**” (the hundreds place) setting is successful.
- 3) Now Press the “**4**” button, and the blue LED’s will come on, this now means that the second digit “**4**” (tens place) setting is successful.
- 4) Now Press the “**5**” button, and all of the R/G/B LED’s will come on, this means that the final digit “**5**” (units place) setting is successful and the full DMX address setting has been changed.
- 5) Now press the “**DMX MODE**” button to save the new address into memory.

To set the DMX address “002”;

- 1) Press the “**S**” button, so the red LED’s come on, this means you can now start to set the DMX address.
- 2) Press the “**0**” button, so the green LED’s come on, this means the first digit “**0**” (the hundreds place) setting is successful.
- 3) Now Press the “**0**” button, and the blue LED’s will come on, this now means that the second digit “**0**” (tens place) setting is successful.
- 4) Now Press the “**2**” button, and all of the R/G/B LED’s will come on, this means that the final digit “**2**” (units place) setting is successful and the full DMX address setting has been changed.
- 5) Now press the “**DMX MODE**” button to save the new address into memory.

DMX Value/Function table:

CHANNEL	VALUE	FUNCTION
CH1	0-255	Master dimmer (0-100%)
CH2	0-255	Red dimmer
CH3	0-255	Green dimmer
CH4	0-255	Blue dimmer
CH5	0-10	No function
	11-255	Strobe (000 = slowest to 255 = fastest)

Please note: Set the DMX address on each fixture before plugging into the DMX controller.

Please note: The I.R Remote is not usable when the fixture(s) are being controlled by a DMX controller

Please note: The maximum transmitter distance is 10M. Please make sure that you have the I.R remote aimed directly at each fixture to be programmed.

Please note: If you do not press the “DMX MODE” button after you have changed the DMX address, when you power down the fixture it will lose the address you have set.

I.R Remote specifications:

Transmitting IR signal distance: 10M maximum.

Selectable functions including RGB dimming, Built-in programmes, Auto run, Flash, speed, Slave and DMX mode.

Power supply: DC 3V

Dimensions: 85 x 52 x 6mm (LxWxH)

Weight: 20g