



kitsound.co.uk

ksTM

KITSOUND

SOUL
WIRELESS
SPEAKER

USER MANUAL



Do not dispose of Lithium Polymer batteries with general waste. Please return it to battery recycling collection point



We are craftspeople. We are musicians. We are KitSound™
And we all commit ourselves to achieving one shared goal: Bringing
people closer to their music. By truly understanding music we stay true
to its craft. Pure, rich, incredible sound. We'll settle for nothing less.

At KS we believe your music deserves to be showcased on great quality products that don't cost the earth. We might not all share the same taste in music (the ferocious disputes on music forums prove that), but whether it's Irish folk, death metal or any number of obscure genres which seem to be multiplying by the minute, the artists responsible for connecting with you through their craft have bared their souls to do so. And we think that's worth celebrating.



Charging the battery

The unit has a built-in rechargeable lithium battery.

Connect one end of the USB power cable to the charging port of the main unit and connect the other end to your PC or USB output mains charger. The battery will start charging.

Note:

- It takes approx. 4 hours to fully charge the battery
- Whilst charging, the LED will turn orange
- When fully charged, the LED will turn off
- A fully charged unit has up to 10 hours* of playback time

*At medium volume. Actual playback time will vary depending on volume and type of music played.

Attaching the handle

There are 2 screws supplied with the handle to attach it to the Soul.

Please follow these instructions:

1. Line up the hole on one side of the handle with one of the screw holes on the Soul.
2. Using the supplied screwdriver, loosely tighten the screw.
3. Follow steps 1 and 2 for the other side.
4. Tighten up both screws until the handle does not rotate under mild force.

Bluetooth pairing

Press and hold down the volume dial until the green light starts to flash and a beep is heard.

When the green light is flashing, it means the Soul is in pairing mode. Go to the Bluetooth menu on your phone and make sure Bluetooth is switched on. Then search for new devices and 'Soul' should appear in the list. Select this and if asked for a passcode, enter '0000'. The Soul will then be paired to your device.

When turning the speaker back on again, it will automatically search for and connect to any paired devices within range. If no devices are found, the Soul will remain in pairing mode until a device is connected or the Soul is switched off.

Using the speaker

- | | |
|----------------|--|
| 1. Turn on | Press and hold down the volume dial until the green light comes on |
| 2. Turn off | Press and hold down the volume dial until the green light goes off |
| 3. Volume + | Twist the volume dial in a clockwise direction |
| 4. Volume - | Twist the volume dial in an anti-clockwise direction |
| 5. Play/Pause* | Press down (do not hold) the volume dial |

*This feature is only available if your phone supports Bluetooth profile AVRCP.
Check your handset/tablet manual if unsure.

Aux-in

Use a 3.5 mm aux-in cable to connect your Bluetooth speaker through the aux-in socket at the bottom of the unit.

Note:

When you plug the aux-in cable into the aux-in socket, the current Bluetooth connection will disconnect. When you unplug the aux-in cable, the Bluetooth connection will resume.

Hands-free

The Soul supports hands-free calling. When receiving a call, press the volume dial down (do not hold) to answer to call. To end a call, press the volume dial down again.

Care and maintenance

Wipe the unit with a soft dry cloth. Do not use any wax, polish sprays or abrasive cleaners.

Caution:

Never allow any water or other liquids to get on or inside the unit. The Soul is made from untreated wood so if it gets wet it will warp over time. Please do not store the Soul in a damp place as this will have the same effect as getting it wet.

Specifications

- Bluetooth v2.1
- Range: Up to 10 m
- Power input: USB DC 5 V
- Driver size: 50 mm
- RMS: 2 x 3 W
- Frequency Range: 90 Hz - 20 kHz
- Unit size: W225 x H115 x D53.5 (mm)
- Weight: 1.0 kg

Box contents

- Soul wooden Bluetooth speaker
- Leather handle
- Screwdriver
- 2 screws
- Instruction manual