

Kensington®

READ FIRST!

120 Watt Universal AC Power Adapter User Manual



Congratulations!

Your new Kensington 120 Watt Universal AC Power Adapter is a highly efficient, one-adapter power solution for your notebook and other digital devices. With the Adapter, you can power and charge your notebook and digital device from any standard home/office wall outlet.

The Adapter powers and charges the newest, high wattage notebooks as well as older legacy notebooks and digital devices such as cell phones, iPods, MP3 music players, DVD players, portable gaming devices, digital cameras, and camcorders.

The Adapter delivers the correct amount of power to each digital device through a patented, interchangeable tip called SmartTip.™ SmartTips are required and sold separately. See www.kensington.com for more information on which SmartTips are needed for your digital devices. Purchasing additional SmartTips allow you to power and charge your digital devices such as notebooks, cell phones, iPods, MP3 music players, DVD players, portable gaming devices, digital cameras, and camcorders, etc.

To simultaneously power and charge your notebook and other digital devices use our Dual Charging Cable for Kensington Power Adapters — sold separately.

Please read this short manual to learn valuable information about the proper use and installation of your Adapter. Register your new Adapter online at www.kensington.com/register.

Important: Safety Information



Warning: This manual contains important safety and operating instructions for your Adapter. Please carefully read this section to reduce the risk of injury, and pay attention to the following:

- Only use recommended SmartTips and contents of this package. Otherwise, there is a risk of fire, injury to persons, or damage to personal property.
- This Adapter is suitable only for mobile electronic digital devices. Otherwise, there is a risk of electrical shock or damage to this unit or related products.
- SmartTips are uniquely designed. If a tip does not fit in the appropriate socket, this indicates that a mismatch has occurred. Please refer to the SmartTip compatibility chart at www.kensington.com to select the correct tip for your digital device.



Do not force the SmartTip into your digital device, it can damage the Adapter and the digital device.

- Do not open the Adapter or make any attempt to disassemble or modify it. Doing so could result in risk of injury to persons, or damage to property.

General: Safety Information



Warning: Failure to read and follow the safety instructions in this User Manual before using and installing your Adapter could result in serious or fatal injury or property damage.

- Your Adapter is not a toy. Keep it away from children. Make sure that all persons who operate your Adapter read and follow this User Manual.
- Your Adapter should only be used with Kensington approved accessories. Using your Adapter with non-approved accessories may result in serious or fatal injury or property damage.
- Never attempt to use your Adapter to power any device that requires more than 120 Watts of peak input power.
- Your Adapter is suitable only for use with mobile electronic digital devices. Using your Adapter with other electronic devices may result in serious or fatal injury or property damage.
- To avoid potential property damage, disconnect input power to your Adapter when it is not in use. Do not leave your Adapter or any device operating unattended.
- Your Adapter may become hot during operation. To prevent serious or fatal injury or property damage provide adequate ventilation and refrain from placing items on or around your Adapter during operation.
- In order to disperse the heat generated while operating your Adapter, keep it well ventilated. While in use, maintain several inches around the top and sides of the Adapter.
- When operating your Adapter, regularly check that the input and output power cables are firmly connected. Loose power cables can generate harmful heat which can damage your Adapter or mobile electronic digital device.

- Avoid operating your Adapter near a heat source, heat vent, or in direct sunlight. Your Adapter should be used in temperatures between 50–80°F.
- Do not operate your Adapter near flammable materials or any locations which can accumulate flammable fumes.
- Keep your Adapter dry. Do not expose the Adapter to water, rain, or snow; if it gets wet or is exposed to moisture, wipe it dry immediately.
- If damage or wear to any component of your Adapter is observed, do not use your Adapter and never attempt to repair it yourself. Return it to the place of purchase or have it repaired by a qualified technician.
- Do not modify or tamper with your Adapter's external or internal components. Doing so could result in serious or fatal injury or property damage. It may also invalidate your Adapter's warranty.

Features

The Adapter offers many features:

1. One-adapter power solution for your digital needs
2. Compatible with most major notebooks and digital devices
3. Efficient power — providing up to 120W of peak power
4. Safety features include: over voltage, temperature and short circuit protection
5. Compact and lightweight — your mobile power needs in one slim package

Technical Specifications

Input voltage:	100–120/220–240 Volts 50/60Hz AC
Output voltage:	0 to 24 Volts DC
Output current:	6.5 Amps maximum
Output power:	Up to 120 Watts
Unit dimensions:	5.6" L x 3.1" W x 0.66" H
Weight:	6 Ounces
AC input cable:	18"
DC power output cable:	3'

Contents

- Adapter
- Adapter input and output cables
- User Manual
- Travel bag

This Adapter has a shorter input cable that connects to an AC outlet. The longer cable connects to your digital device.

Using your Adapter

Once connected, your battery will automatically charge regardless of whether your digital device is turned on or off.

NOTE: We recommend that you use the Adapter only with batteries (for your notebook and digital device) that meet or exceed the original manufacturer's specifications.



CAUTION: Like the power adapter that originally came with your digital device, the Adapter may get warm to the touch during use. This is normal. Avoid placing the Adapter in direct sunlight or next to heat sensitive materials.

Purchasing the Proper SmartTip for your Digital Device

Make sure you purchase the right SmartTip for your digital device by going to www.kensington.com or your closest retail store.



WARNING: Never use a SmartTip that is not compatible with the device you are powering. Adapter SmartTips are uniquely designed. If a SmartTip does not fit into your notebook or mobile electronic digital device, this indicates that you are using the wrong tip. Please refer to the SmartTips compatibility chart at www.kensington.com to select the correct tip for your notebook or mobile electronic digital device. Forcing a SmartTip into your notebook or mobile electronic digital device can result in property damage to your Adapter, notebook or mobile electronic digital device.

After you have purchased the SmartTip that matches your digital device you're ready to be connected.

Your SmartTips and Adapter power cords are color coded for your convenience. The following indicate the product category by color:

- Green = Notebooks (high-power)
- Yellow = Entertainment devices such as iPods, MP3 music players, and portable DVDs (mid-power)
- Blue = PDAs, portable gaming devices, cell phones, cameras, and camcorders (low-power)

SmartTip Label


C — Camera, Camcorder	J — MP3 music player	P — PDA
D — DVD player	M — Cell phone	
G — Portable gaming device	N — Notebook	



WARNING: Each AC plug only functions correctly with its designated power source. The US plug (110/120V) will work when connected to a 110/120V AC power source; the other plug styles are designed for use with particular 220/240V AC power sources. Using the wrong plug will cause the Adapter to malfunction and may render the plug unusable.

Getting Connected

1. Connect the correct SmartTip to the Adapter output cord.



2. Insert the Adapter output cord into the device's power socket.
3. Insert the AC plug into a standard wall outlet and you're ready to get started.

AC Wall Socket Connection

Use the AC wall socket connection anywhere a 100–120 Volt or 200–240 Volt AC power source is available.

1. Connect the SmartTip to the Adapter output cable and your digital device, if you haven't done so already.
2. Connect the AC wall socket input cable to the Adapter.
3. Plug the AC connector into a wall outlet or power strip.

When the Adapter has power, its status light glows green. Your devices' battery is now charging. You can now turn on and use your digital device.

Technical Support

Technical support is available to all registered users of Kensington products. There is no charge for technical support except long distance charges where applicable. Technical Support Contact information can be found on the last page of this manual.

Technical Support Tips

- You may find the answer to your problem in the Frequently Asked Questions (FAQ) section of the Support area on the Kensington Website: www.kensington.com.
- Call from a telephone where you have access to your notebook, or other digital device
- Be prepared to provide the following information:
 - Name, address, and telephone number
 - The name of the Kensington product
 - Make and model of your notebook, or other digital device
 - Your system software and version (where applicable)
 - Symptoms of the problem and what led to them

1-Year Limited Warranty

KENSINGTON TECHNOLOGY GROUP (“KENSINGTON”) warrants the PRODUCT 38004 AC Universal Power Adapter against defects in material and workmanship under normal use and service for one year from the original date of purchase. KENSINGTON, at its option, shall repair or replace the defective unit covered by this warranty. Please retain the dated sales receipt as evidence of the date of purchase. You will need it for any warranty service. In order to keep this warranty in effect, the product must have been handled and used as prescribed in the instructions accompanying this warranty. This warranty does not cover any damage due to accident, misuse, abuse, or negligence.

DISCLAIMER OF WARRANTY

The limited warranty described herein is your sole remedy. To the extent permitted by law, Kensington disclaims all other implied or express warranties of merchantability and/or fitness for a particular purpose.

LIMITATION OF LIABILITY

Except to the extent of repairing or replacing the Adapter as expressly stated in the limited warranty described herein, Kensington shall not be liable for any damages, whether direct, indirect, incidental, special, and consequential, exemplary, or otherwise, including lost revenues, lost profits, loss of use of software, loss recovery of data, rental of replacement equipment, downtime, damage to property, and third-party claims, arising out of any theory of recovery, including statutory, contract or tort. Notwithstanding the term of any limited or implied warranty, or in the event that any limited warranty fails of its essential purpose, in no event will Kensington’s entire liability exceed the purchase price of this product. Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province.

Federal Communications Commission Radio Frequency Interference Statement

Note: The Adapter has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that the interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MODIFICATIONS: Modifications not expressly approved by Kensington may void the user’s authority to operate the device under FCC regulations and must not be made.

SHIELDED CABLES: In order to meet FCC requirements, all connections to equipment using a Kensington input device should be made using only the shielded cable provided.

Declaration of Conformity Compliance Statement for the Adapter

The Adapter complies with Part 15 of the FCC Rules. Operation is subject to two conditions: (1) This device may not cause harmful interference, and, (2) this device must accept any interference received, including interference that may cause undesired operation. As defined in Section 2.909 of the FCC Rules, the responsible party for this device is Kensington Technology Group, 333 Twin Dolphin Drive, Sixth Floor, Redwood Shores, CA 94065, USA, (800) 535-4242.

Contacting Kensington

Troubleshooting information and answers to frequently asked questions are available 24 hours a day on the Kensington Website at www.support.kensington.com.

Support by Telephone

Technical Support is available by telephone. Please visit www.kensington.com for hours.

U.S. and Canada 800-535-4242
Mexico 52(55)5384-0620



Kensington Technology Group
333 Twin Dolphin Drive
Sixth Floor
Redwood Shores, CA 94065
USA

ACCO Europe PLC
Gatehouse Road
Aylesbury
Bucks, HP19 8DT
UNITED KINGDOM

ACCO Canada Inc.
5 Precidio Court
Brampton, Ontario L6S 6B7
CANADA

www.kensington.com

This manual is copyright © 2005 Kensington Technology Group, a division of ACCO Brands, Inc. Any unauthorized copying, duplicating, or other reproduction of the contents hereof is prohibited without written consent from Kensington Technology Group. All rights reserved. 5/05

Kensington is a registered US trademark of ACCO World Corporation with issued registrations and pending applications in other countries throughout the world. SmartTip is a trademark of Comarco Wireless Technologies Inc. Apple and iPod are registered trademarks of Apple Computer, Inc. All other registered and unregistered trademarks are the sole property of their respective owners. Protected under US Patent 5,838,554; 6,091,611; 6,172,884; 6,266,261; 6,693,413; 6,707,284; 6,831,848. Other US and Foreign Patents Pending



VCCI RTCA DO-160D

901-1706-00