ULTRA CHORUS UC200

Ultimate Stereo Chorus Effects Pedal

Thank you for showing your confidence in us by purchasing the BEHRINGER ULTRA CHORUS UC200. This ultimate effects pedal is designed to deliver super-thick chorus with unbelievable stereo effect. Thanks to its high-performance features you'll have full parameter control for absolute flexibility and limitless creative options.

The chorus effect slightly detunes the original signal. A very pleasant detune effect is created in connection with the pitch variation. The chorus effect is used often and quite extensively used for dispersing signals.

1. Controls



- 1 The **LEVEL** control adjusts the output level.
- 2 The **TONE** control allows you to adjust the overall effects sound and achieve a more defined and brilliant tone.
- 3 The **RATE** control determines the chorus effect speed.
- Turn up the **DEPTH** control to achieve a fuller, deeper effect sound.
- **S** The **ON/BATT** LED illuminates when the effect is activated. It also serves as a battery level indicator.
- **6** Use the footswitch to activate/deactivate the effect.
- **Output** Use this ¼" TS **IN** connector to plug in the instrument cable.
- The two ¼" TS connectors OUT A and OUT B send the signal to your amp. Use both connectors if you want to achieve full stereo chorus effect. For mono use just plug in OUT A.

Use the **DC IN** connection to plug in a 9 V power supply (not included).

The **BATTERY COMPARTMENT** is located underneath the pedal cover. To install or replace the 9 V battery, press the hinges with a ballpen and remove the pedal cover. Be careful not to scratch the unit.



The UC200 has no on/off switch. As soon as you insert the jack into the in connector, the UC200 begins running. When not using the UC200, remove the jack from the in connector. This extends the life of the battery.

The SERIAL NUMBER is located at the bottom.

2. Safety Instructions

Do not use near water, or install near heat sources. Use only authorized attachments/accessories. Do not service product yourself. Contact our qualified servicing personnel for servicing or repairs, especially when power supply cord or plug is damaged.

3. Warranty

Í

Í

Please register your new BEHRINGER equipment right after your purchase by visiting http://behringer.com and read the terms and conditions of our warranty carefully.

4. Specifications

1⁄4" TS
500 kΩ
1⁄4" TS
1 kΩ
1⁄4" TS
1 kΩ
9 V, 100 mA regulated
120 V~, 60 Hz
220 V~, 50 Hz
240 V~, 50 Hz
230 V~, 50 Hz
100 V~, 50 - 60 Hz

Power connector	2 mm DC jack, negative center
Battery	9 V type 6LR61
Power consumption	30 mA
Power consumption	<i>,</i> ,

Physical/Weight	
Dimensions (H x W x D)	approx. 2 ¼ x 2 ¾ x 4 ½" approx. 54 x 70 x 123 mm
Weight	approx. 0.73 lbs / 0.33 kg

BEHRINGER is constantly striving to maintain the highest professional standards. As a result of these efforts, modifications may be made from time to time to existing products without prior notice. Specifications and appearance may therefore differ from those listed or shown.



FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

BEHRINGER

ULTRA CHORUS UC200

Responsible Party Name:

Address:

MUSIC Group Services US Inc.

18912 North Creek Parkway, Suite 200 Bothell, WA 98011, USA

Phone Number:

Phone: +1 425 672 0816

ULTRA CHORUS UC200

complies with the FCC rules as mentioned in the following paragraph:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Important information:

Changes or modifications to the equipment not expressly approved by MUSIC Group can void the user's authority to use the equipment.

