

Unit 12 Barratt Trading Estate, Denmore Road, Bridge of Don, Aberdeen AB23 8JW

# **Riser User Manual**

This Manual Covers the Following Part Numbers:

110-5119-HV0

This is a certified safety critical product and modifications or changes not authorised by Phuel Oil Tools may compromise the Safety, Functionality and Certification of the assembly.

## Safety Considerations:


All pressure equipment has a particular pressure rating and care must be taken to ensure that no item is used in a situation that may cause its working pressure to be exceeded.

This equipment is heavy and should not be lifted without lifting aids

OPS-5119A



## **Recommended Operation and Maintenance for a Typical Riser**



### Pre Job

- Check that the certification and scheduled maintenance is up to date.
- Examine the assembly, to make sure that it is good operating order, and seal areas and threads are not damaged.

### Post Job

- After each job, the assembly should be thoroughly cleaned and redressed if required.
- The assembly should be protected against the effects of corrosion and damage.

#### Annually

- Inspect the condition of sealing surfaces and surface coatings, and threads, repair/replace as necessary.
- Re-coat threads and sealing surfaces if necessary. Contact Phuel if in doubt.
- Pressure Test to 300 to 500 psi and to maximum working pressure.
- Inspect paintwork and repair where necessary.

#### **Five Yearly**

• Recertification by Phuel Oil Tools in accordance with DNV-RP-E101


#### **Pressure Test**

- Fit the appropriate test caps and fill with test fluid, bleeding off any air in the system
- Apply pressure between 300 to 500 psi and hold for a minimum of 10 minutes
- Increase pressure to Maximum Working Pressure, allow to stabilise and hold for 15 minutes with no visible leaks.
- Bleed off pressure, drain test fluid, and remove test caps and dry
- Apply coating of de-watering solution to protect the bore and threads, and fit thread protectors



## Safe-Lok Operation


Where fitted, this is identified by an upset shoulder above the collar with slots and recesses.






## User Manual -Saver Sub Maintenance

Saver Sub Removal




## **Saver Sub Refitting**



### **Alternative Saver Subs**

Other saver subs are available, contact Phuel Oil Tools for details.





STAINLESS STEEL

N/A

STATUS Released SHEET 1 OF 1 CONTROLLED DOCUMENT - CHECK THAT YOU ARE USING THE CORRECT REVISION

SURFACE FINISH 250 RMa

DIMENSIONS IN INCHES

BY

REVISION HISTORY



## User Manual -Bill of Material and Spares

## Bill of Material – 110-5119-HV0

Item	Part Number	Description	Qty
1	110-5122-480	RISER TUBE 5-1/8", 2.0m 6.950 PHUEL THREAD	1
2	110-2051-480	TOP SUB (9-4)	1
3	110-2289-480	BOTTOM SUB (9-4)	1
4	110-2053-480	COLLAR 9-4 (SPLIT TYPE)	1
5	110-2054-480	SPLIT RING (9-4)	1
6	145-2176-480	SAVER SUB PORT	1
7	110-2329-3A4	STOP PIN FOR (9" & 8.375")	4
8	WNL-0580-316	WASHER NORDLOCK (M12)	6
9	SHC-0583-3A4	Soc Hd Cap 1/2 UNC Length 3/4 in	2
10	801-0119-V90	O-Ring - B.S Size 119	1
11	801-0361-V90	O-Ring - B.S Size 361	2
12	801-0438-V90	O-Ring - B.S Size 438	1
98	910-3369-N66	MALE PROTECTOR (DW) 9-4 ACME	1
99	910-3370-N66	FEMALE PROTECTOR (DW) 9-4 ACME	1

## Spares

Use only spares supplied or approved by Phuel Oil Tools Ltd. O-Rings conform to industry standards and may be substituted with those from other suppliers -- at the sole risk of the user.

Individual items may be ordered as required using the part number specified

Elastomeric spares are supplied in Viton and HNBR material as standard. Many other materials are available please specify when ordering.

It is recommended that sufficient quantities of the following spares be maintained to ensure that the equipment is always available when required.

#### Redress kit part number: RDK-5119-HV0

Item	Part Number	Description	Qty
10	801-0119-V90	O-Ring - B.S Size 119	1
11	801-0361-V90	O-Ring - B.S Size 361	2
12	801-0438-V90	O-Ring - B.S Size 438	1

## **Supporting Equipment**

The following is compatible with this assembly, contact Phuel Oil Tools for details:



Collar Lift / Assist Clamp Product code: 182



Lift Clamp Product code: 950



Manifold Block Product code: 111



Light Weight Dolly Product code: 112