ELECTRONIC CASH REGISTER TK-6000/6500



Introduction

Congratulations on your selection of a CASIO TK-6000/TK-6500 series electronic cash register. This ECR is the product of the world's most advanced electronic technology, for outstanding versatility and reliability. Simplified operation is made possible by a specially designed keyboard layout and a wide selection of automated, programmable functions.

A specially designed keyboard layout and a bright, easy-to-read display help to take the fatigue out of long hours operation.

Notes for TK-6000-1



Casio Electronics Co., Ltd. Unit 6, 1000 North Circular Road London NW2 7JD, U.K.

Please keep all information for future reference.

Notes for TK-6000/6500

GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. (Not applicable to other areas)

WARNING: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of Canadian Department of Communications.

The main plug on this equipment must be used to disconnect mains power. Please ensure that the socket outlet is installed near the equipment and shall be easily accessible.

Important!

Your new cash register has been carefully tested before shipment to ensure proper operation. Safety devices eliminate worries about breakdowns resulting from operator errors or improper handling. In order to ensure years of trouble-free operation, however, the following points should be noted when handling the cash register.

Do not locate the cash register where it will be subjected to direct sunlight, high humidity, splashing with water or other liquids, or high temperature (such as near a heater).



Never operate the cash register while your hands are wet.



Be sure to check the sticker on the side of the cash register to make sure that its voltage matches that of the power supply in the area.





Use a soft, dry cloth to clean the exterior of the cash register. Never use benzene, thinner, or any other volatile agent.

Never try to open the cash register or attempt your own repairs. Take the cash register to your authorized CASIO dealer for repairs.



Introduction & Contents	2
Getting Started	
Remove the cash register from its box	
Remove the tape holding parts of the cash register in place.	8
Remove the cash drawer from its box	8
Connect the drawer.	8
Mount the cash register	9
Plug the cash register into a wall outlet	
Insert the mode key marked "OW" into the mode switch.	
Install receipt/journal paper.	
Set the date.	
Set the time	
Introducing TK-6000/6500	
General guide	
Display (TK-6000/TK-6500)	
Keyboard (TK-6000)	
Keyboard (TK-6500)	
Allocatable functions	
How to remove/replace the sheet holder (TK-6000 only)	
How to install a menu sheet in the sheet holder (TK-6000 only)	27
Basic Operations and Setups	
How to read the printouts	
How to use your cash register	29
Assigning a clerk	
Clerk button	
Clerk lock/clerk key	
Clerk secret number key	
Displaying the time and date	
Preparing coins for change	
Preparing and using department/flat-PLU keys	
Registering department/flat-PLU keys	
Programming department/flat-PLU keys	
To program a unit price for each department/flat-PLU	
To program the tax calculation status for each department/flat-PLU	33
To program high amount limit for each department/flat-PLU	
Registering department/flat-PLU keys by programming data	
Preset price	
Preset tax status	
Locking out high amount limitation	
Preparing and using PLUs	
Programming PLUs	
To program a unit price for each PLU	
To program tax calculation status for each PLU	
Registering PLUs	
Shifting the taxable status of an item	
Calculation merchandise subtotal	
Preparing and using discounts	40
Programming discounts	
Registering discounts	
Discount for items and subtotals	40

Preparing and using reductions	41
Programming for reductions	41
To program preset reduction amount	
Registering reductions	
Reduction for items	
Reduction for subtotal Registering credit and check payments	
Check	
Credit	
Mixed tender (cash, credit and check)	
Preparing and registering the Euro	
Basic programming for the Euro and its exchange rate	
Registering the Euro	
Validation printing	
Total amount validation	
Validation sample	
Registering returned goods in the REG mode	
Registering returned goods in the RF mode	
Normal refund transaction	
Reduction of amounts paid on refund	
Registering money received on account	
Registering money paid out	
Registering loan amounts	
Registering pick up amounts	
Changing media in drawer	
Making corrections in a registration	50
To correct an item you input but not yet registered	50
To correct an item you input and registered	
To cancel all items in a transaction	
No sale registration	
Printing the daily sales reset report	
Advanced Operations	
Clerk interrupt function	
Single item cash sales	
Addition	
Addition (plus)	
Premium (%+)	
Tray total	
Tray total premium/discount	57
Multiple item totalling function	
Coupon transactions	
Coupon registration using <coupon> (coupon key)</coupon>	
Coupon registration using <coupon2> (coupon 2 key)</coupon2>	
Preset tender amount	
Bottle link operation	
Bottle returns Bottle return key	
Arrangement key registrations	
Set menu	

Currency exchange function		62
Registering foreign currency		
Full amount tender in foreign currency 6		
Partial tender in a foreign currency 6		
Food stamp function		64
Food stamp registration	64	
No change due6		
Mixed food stamp/cash change6		
Food stamp registration (Illinois rule)		
No change due		
Mixed food stamp/cash change 6		
Electronic benefits transfer		
About mixed EBT card tenders		
No change due		71
·		
Inputting the number of customers		75
Text recall		76
Temporarily releasing compulsion		76
Printing slip		
		"
Printing slips		
To perform auto batch printing 1		
To perform auto batch printing 2		
Check tracking systems		78
		10
Check tracking system		
Opening a check		
Issuing a guest receipt		
Closing a check memory		
New/old check key operation		
Add check		
Separate check		
Clerk transfer	34	
Table transfer		
VAT breakdown printing		85
Deposit registrations		85
Deposit from customer		
Deposit from customer during sales transaction		
Bill copy		86
Programming to clerk		
• •		07
Programming clerk number		
Programming trainee status		
Programming commission rate		00
Programming descriptors and messages		00
Programming receipt message and clerk name		
Machine number		
Programming department/transaction key descriptor Programming flat-PLU descriptor		
Entering characters		92
5		52
Entering characters by code		
Character code list		
Using character keyboard		

To print the individual department, PLU/flat-PLU read report 94 To print the financial read report 95 To print the individual clerk read/reset report 96 To print the PLU/flat-PLU read/reset report 98 To print the PLU/flat-PLU read/reset report 98 To print the PLU/flat-PLU read/reset report 99 To print the mouthy sales read/reset report 99 To print the group read/reset reports 100 To print unit price/rate program (except PLU/flat-PLU) 101 To print the PLU/flat-PLU program 103 Troubleshooting 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace the ink ribbon 107 To replace the ink ribbon 109 To replace receipt paper 109 To replenish the stamp ink 109 <th>Printing read/reset reports</th> <th></th>	Printing read/reset reports	
To print the individual clerk read/reset report		
To print the daily sales read/reset report 96 To print the PLU/flat-PLU read/reset report 98 To print the hourly sales read/reset report 98 To print the monthly sales read/reset report 99 To print the periodic 1/2 sales read/reset reports 100 To print the periodic 1/2 sales read/reset reports 101 Reading the cash register's program 101 To print the priodic normal except PLU/flat-PLU) 101 To print the PLU/flat-PLU program 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 To replenish the stamp ink 109 Options 109		
To print the PLÚ/flat-PLU read/reset report 98 To print the hourly sales read/reset report 98 To print the monthly sales read/reset report 99 To print the group read/reset report 99 To print the periodic 1/2 sales read/reset reports 100 To print the periodic 1/2 sales read/reset reports 101 Reading the cash register's program 101 To print unit price/rate program (except PLU/flat-PLU) 101 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 Options 109 Specifications 109		
To print the hourly sales read/reset report 98 To print the group read/reset report 99 To print the group read/reset report 99 To print the group read/reset report 100 To print other sales read/reset reports 101 Reading the cash register's program 101 To print unit price/rate program (except PLU/flat-PLU) 101 To print the PLU/flat-PLU program 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 Options 109 Options 109		
To print the monthly sales read/reset report 99 To print the group read/reset report 99 To print the periodic 1/2 sales read/reset reports 100 To print the periodic 1/2 sales read/reset reports 101 Reading the cash register's program 101 To print unit price/rate program (except PLU/flat-PLU) 101 To print the PLU/flat-PLU program 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 To replenish the stamp ink 109 Options 109		
To print the group read/reset report. 99 To print the periodic 1/2 sales read/reset reports 100 To print other sales read/reset reports 101 Reading the cash register's program 101 To print unit price/rate program (except PLU/flat-PLU) 101 To print the PLU/flat-PLU program 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 Options 109		
To print the periodic 1/2 sales read/reset reports 100 To print other sales read/reset reports 101 Reading the cash register's program 101 To print unit price/rate program (except PLU//flat-PLU) 101 To print key descriptor, name, message program (except PLU) 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 109 Options 109 Options 109		
To print other sales read/reset reports 101 Reading the cash register's program 101 To print unit price/rate program (except PLU/flat-PLU) 101 To print key descriptor, name, message program (except PLU) 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 109 To replenish the stamp ink 109 Options 109		
Reading the cash register's program 101 To print unit price/rate program (except PLU/flat-PLU) 101 To print key descriptor, name, message program (except PLU) 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 Options 109 Specifications 109		
To print key descriptor, name, message program (except PLU) 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 Options 109 Specifications 110		
To print key descriptor, name, message program (except PLU) 102 To print the PLU/flat-PLU program 103 Troubleshooting 104 When an error occurs 104 In case of power failure 105 Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace receipt paper 108 To replace receipt paper 109 Options 109 Specifications 110	To print unit price/rate program (except PLU/flat-PLU)	101
Troubleshooting104When an error occurs104In case of power failure105Clearing a machine lock up106When the register does not operate at all106User Maintenance and Options107To replace the ink ribbon107To replace the ink ribbon107To replace receipt paper108To replace receipt paper109To replenish the stamp ink109Specifications110	To print key descriptor, name, message program (except PLU)	102
When an error occurs104In case of power failure105Clearing a machine lock up106When the register does not operate at all106User Maintenance and OptionsTo replace the ink ribbon107To replace the ink ribbon107To replace journal paper108To replace receipt paper109To replenish the stamp ink109Options109Specifications110	To print the PLU/flat-PLU program	103
In case of power failure105Clearing a machine lock up106When the register does not operate at all106User Maintenance and OptionsTo replace the ink ribbon107To replace the ink ribbon107To replace journal paper108To replace receipt paper109To replenish the stamp ink109Options109Specifications	Troubleshooting	104
Clearing a machine lock up 106 When the register does not operate at all 106 User Maintenance and Options 107 To replace the ink ribbon 107 To replace journal paper 108 To replace receipt paper 109 To replenish the stamp ink 109 Options 109 To replace for sum of the stamp ink 109 To replenish the stamp ink 109 To replace for sum of the stamp ink 109 To replace for sum of the stamp ink 109 To replenish the stamp ink 109	When an error occurs	104
When the register does not operate at all106User Maintenance and Options107To replace the ink ribbon107To replace journal paper108To replace receipt paper109To replenish the stamp ink109Options109Specifications110	In case of power failure	105
User Maintenance and Options107To replace the ink ribbon107To replace journal paper108To replace receipt paper109To replenish the stamp ink109Options109Specifications110	Clearing a machine lock up	106
To replace the ink ribbon107To replace journal paper108To replace receipt paper109To replenish the stamp ink109Options109Specifications110	When the register does not operate at all	106
To replace journal paper108To replace receipt paper109To replenish the stamp ink109Options109Specifications110	User Maintenance and Options	
To replace receipt paper 109 To replenish the stamp ink 109 Options 109 Specifications 109	To replace the ink ribbon	107
To replenish the stamp ink	To replace journal paper	108
Options	To replace receipt paper	109
Specifications 110	To replenish the stamp ink	109
	Options	109
Index	Specifications	110
	Index	111

This section outlines how to unpack the cash register and get it ready to operate. You should read this part of the manual even if you have used a cash register before. The following is the basic set up procedure, along with page references where you should look for more details.



Mount the cash register.

- 1. Screw in 2 fixing screws bottom side of the register.
- 2. Mount the cash register on the top of the drawer, ensuring that the feet on the bottom of the cash register go into the holes on the drawer.







Plug the cash register into a wall outlet.

Be sure to check the sticker on the side of the cash register to make sure that its voltage matches that of the power supply in your area. The printer will operate for a few seconds. Please do not pass the power cable under the drawer.

7 Insert the mode key marked "OW" into the mode switch.
REG1
OFF
FEG2
FEG1
FEG2
FEG1
FEG1
FEG2
FEG1
FEG1
FEG2
FEG1
FEG2
FEG2
FEG1
FEG2
F





Never operate the cash register without paper. It can damage the printer.

Getting Started





Getting Started

General guide

This part of the manual introduces you to the cash register and provides a general explanation of its various parts.



Roll paper

You can use the roll paper to print receipts and a journal (pages $10 \sim 11$).

Printer ink ribbon

Provides ink for printing of registration details on the roll paper (page 107).

Receipt on/off switch / key

Use the receipt on/off switch/key in REG1, REG2 and RF modes to control issuance of receipts. In other modes, receipts or reports are printed regardless the receipt switch/key setting.

A post-finalization receipt can still be issued after finalization when the switch/key is set to off. The cash register can also be programmed to issue a post-finalization receipt even when the switch/key is set to on.

Receipt on/off switch



Receipt on/off key



When the register issues receipts, this indicator is lit.



Introducing TK-6000/6500

Mode key (for U.K., U.S. and Canada)

The following four types of mode keys are provided with the unit in the United Kingdom, the United States and Canada.



- a. OP (Operator) key Switches between OFF and REG1.
- b. M (Master) key Switches between OFF, REG1, REG2, X1 and RF.
- c. OW (Owner) key Switches between OFF, REG1, REG2, X1, Z1, X2/ Z2 and RF.
- d. PGM (Program) key Switches to any position.

Mode key (for other area)

The following three types of mode keys are provided with the unit in areas outside of the United Kingdom, the United States and Canada.



- a. OP (Operator) key Switches between OFF and REG1. b. M (Master) key
- Switches between OFF, REG1, REG2, X1 and RF. c. OW (Owner) key
- Switches to any position.

TK-6000/6500 User's Manual

Mode switch

Use the mode keys to change the position of the mode switch and select the mode you want to use.



Mode switch	Mode name	Description
OFF	Stand-by	Any of the mode control keys can be inserted and removed from the mode switch in this position.
REG1	Register 1	Used for normal sales transactions. Any of the mode control keys can be inserted and removed from the mode switch in this position.
REG2	Register 2	Used for special operations. Since switching to REG2 requires a special key, such functions as discounts, credit sales, charge sales, check payments, and paid outs can be controlled by programming them as prohibited in REG1 and allowed in REG2.
RF	Refund Reg minus	Used for processing refunds. When the mode switch of the register is in RF position, you can access either the refund mode or the register minus mode.
X1	Daily sales read	Used to obtain daily reports without resetting (clearing) all total data.
Z1	Daily sales reset	Used to obtain daily reports while resetting (clearing) all total data.
X2/Z2	Periodic sale read/reset	Used to obtain periodic sales reports without resetting total data or while resetting all total data.
PGM	Program	Used when programming functions and preset data such as unit prices and tax rates. Also used when reading program data.

Clerk key/button/lock

On models available in the United States and Canada, clerk or cashier assignment can be performed using clerk secret numbers only (clerk buttons are not equipped).

In Germany, you can assign clerks by using clerk key or by clerk secret number (clerk key is equipped). In other areas, you can assign clerks by using clerk button or by clerk secret number.

The method you are assigning clerk depends on the programming of your cash register.

Clerk secret number key

When the cash register is programmed to use clerk secret numbers for clerk or cashier assignment, the clerk buttons are not functional.



Clerk lock/key

You can assign the clerk or cashier inserting a clerk key into the clerk lock .



Clerk lock

Clerk button

You can assign the clerk or cashier using the four buttons located below the display panel.





Drawer

The drawer opens automatically whenever you finalize a registration and whenever you issue a read or reset report. The drawer will not open if it is locked with the drawer key.

Drawer lock

Use the drawer key to lock and unlock the drawer.

When the cash drawer does not open!

In case of power failure or the machine is in malfunction, the cash drawer does not open automatically. Even in these cases, you can open the cash drawer by pulling drawer release lever (see below).



Display (TK-6000/TK-6500)

Display panel

Main display for the U.S.



Main display for Canada and Germany



Main display for other area



Customer display for all area



Display example

Item registration



Menu shift



Repeat registration



Totalize operation



① Amount/Quantity

This part of the display shows monetary amounts. It also can be used to show the current date and time.

2 Department number

When you press a department key to register a unit price, the corresponding department number $(01 \sim 04, 08)$ appears here.

③ Taxable sales status indicators

When you register a taxable item, the corresponding indicator is lit.

④ PLU, flat-PLU number

When you register a PLU, flat-PLU item, the corresponding PLU, flat-PLU number appears here.

(5) Menu sheet number

When you press the **MENU** key to designate the 1st ~ 6th menu sheet, the corresponding number is displayed.

6 Number of repeats

Anytime you perform a repeat registration (pages 32, 37), the number of repeats appears here. Note that only one digit is displayed for the number of repeats. This means that a "5" could mean 5, 15 or even 25 repeats.

⑦ Total/Change indicators

When the TOTAL indicator is lit, the displayed value is monetary total or subtotal amount. When the CHANGE indicator is lit, the displayed value is the change due.

8 RCT, REG, X1, Z1 indicators

RCT: When the register issues receipts, this indicator is lit.

X1: Indicates daily sales read mode

Z1: Indicates daily sales reset mode

Keyboard (TK-6000)

THE FEED	JOURNAL FEED	8 CLK#	21 RC	PD
2 1 RECEPT	[%-]		24	8
RECEPT	T/S1	5 T/S2	3	7
5 RF		# _{NS}	2	6
		ERR CORR CANCEL		5
Z	8	9	25 CR1	CR2
4	5	6	26 [СН	Z Z Z Z Z Z Z
	2	3	28 USUBT	OTAL
0	00		29 CA/-	AMT TEND

)											
9	18	27	36	45	54	63	72	81	90	99	108
8	17	26	35	44	53	62	71	80	89	98	107
7	16	25	34	43	52	61	70	79	88	97	106
6	15	24	33	42	51	60	69	78	87	96	105
5	14	23	32	41	50	59	68	77	86	95	104
4	13	22	31	40	49	58	67	76	85	94	103
3	12	21	30	39	48	57	66	75	84	93	102
2	11	20	29	38	47	56	65	74	83	92	101
1	10	19	28	37	46	55	64	73	82	91	100

for the U.S. and Canada

• Register Mode

- (1) **Paper feed key** [FEED], [FEED] Hold this key down to feed paper from the printer.
- ② Post receipt key RECEIPT Use this key to produce a post-finalization receipt.
- ③ **Receipt on/off key** WONFF Use this key pressing two times to change the status "receipt issue" or "no receipt." In case of "receipt issue", the indicator is lit.
- (4) Open key OPEN

Use this key to temporarily release a limitation on the number of digits that can be input for a unit price.

(5) Refund key **RF**

Use this key to input refund amounts and void certain entries.

6 Clear key C

Use this key to clear an entry that has not yet been registered.

- (7) Ten key pad 0, 1 ~ 9, 00, ·
 Use these keys to input numbers.
- (8) Clerk number key CLK# Use this key to sign clerk on and off the register.
- ③ VAT key VAT Use this key to print a VAT breakdown.
- Discount key % Use this key to register discounts.
- (1) Minus key Use this key to input values for subtraction.

12 Loan key LOAN

This key is used to input the amount of money provided for making change. This operation affects media totals, rather than sales totals. Loans are made for all types of money which can be specified by the finalize key.

13 Pick up key

When the amount in drawer exceeds the limit value (sentinel function), the manager performs a pick up operation. This key is used for this function. This operation affects media totals, rather than sales totals. Pick ups are made for all types of money which can be specified by the finalize key.

14) Tax status shift 1 key T/S1

Use this key to change the Taxable 1 status of the next item.

15 Tax status shift 2 key T/S2

Use this key to change the Taxable 2 status of the next item.

(6) Validation key ULDUse this key to validate transaction amounts on slip.

Non-add/No sale key ** NS
 Non-add key: To print reference number (to identify a personal check, credit card, etc.) during a transaction, use this key after some numerical entries.
 No sale key: Use this key to open the drawer without registering anything.

RECEIPT	JOURNAL	9 VAT	21 23 RC EURO	30	
2	2	13	24		L
RECEIPT		UP			L
RECEIPT ONOFF	6		3		
RF		#/NS	2		
	9 Zate TME	ERR. CORR CANCEL			
7	8	9	25 CR1 CR2		
4	5	6	26 27 CH CHK/ TEND		L
	2	3	28 SUBTOTAL		
T		$\overline{}$	29 CA AMT TEND		

for German



for other area

(18) Multiplication/For/Date/Time key

Use this key to input a quantity for a multiplication operation and registration of split sales of packaged items. Between transactions, this key displays the current time and date.

(19) Multiplication/Date/Time key

Use this key to input a quantity for a multiplication operation. Between transactions, this key displays the current time and date.

20 Error correction/Cancellation key

Use this key to correct registration errors and to cancel registration of entire transactions.

- (21) Received on account key | RC | Use this key following a numeric entry to register money
- received for non-sale transactions. 2 Paid out key PD
 - Use this key following a numeric entry to register money paid out from the drawer.
- 23 Euro/Paid out key

Euro key: Use this key to convert the main currency to the sub currency (the euro/the local money), when registering a subtotal amount. This key is also used for specifying sub currency while entering an amount of payment or declaration in drawers.

Paid out key: Use this key following a numeric entry to register money paid out from the drawer.

24 Department keys | 1 |, | 2 |, | 3 | - | 4 |, |8

Use these keys to register items to departments.

- 25 Credit key [CR1], [CR2] Use this key to register a credit sale.
- (26) Charge key CH Use this key to register a charge sale.
- 27 Check key K Use this key to register a check tender.
- 28 Subtotal key SUB Use this key to display and print the current subtotal (includes add-on tax) amount.
- (29) Cash/Amount tendered key Use this key to register a cash tender.
- 30 Flat PLU key | 001|, | 002| ~ [108] Use these keys to register items to flat PLUs.

Keyboard (TK-6500)

(1		·	<u></u>												Ē		
) F	CEIPT EED	JOURNAL FEED	25	34	43	52	61	70	79	88	97	106	3) RECEIPT	Ý	CLK#	19 (RC	PD
	8	16	24	33	42	51	60	69	78	87	96	105	6 RECEIPT ON/OFF			4	8
	7	15	23	32	41	50	59	68	77	86	95	104	9)		RF	3	7
	6	14	22	31	40	49	58	67	76	85	94	103		3)	14) T/S2	2	6
	5	13	21	30	39	48	57	66	75	84	93	102.		6 X/FOR DATE TIME	# NS	1	5
	4	12	20	29	38	47	56	65	74	83	92	101	8 7	8	9	CR1	CR2
	3	11	19	28	37	46	55	64	73	82	91	100	4	5	6	CHK/	СН
	2	10	18	27	36	45	54	63	72	81	90	99	1	2	3	25 SUBT	OTAL
	1	9	17	26	35	44	53	62	71	80	89	98	0	00	•	CA	AMT TEND

• Register Mode

- (1) **Paper feed key** [RECEPT], [VURNAL Hold this key down to feed paper from the printer.
- (2) Flat PLU key $\begin{bmatrix} 001 \end{bmatrix}$, $\begin{bmatrix} 002 \end{bmatrix} \sim \begin{bmatrix} 106 \end{bmatrix}$ Use these keys to register items to flat PLUs.
- ③ **Post receipt key** RECEIPT Use this key to produce a post-finalization receipt .
- (4) Validation key VALD Use this key to validate transaction amounts on slip.
- (5) Clerk number key CLK# Use this key to sign clerk on and off the register.
- 6 Receipt on/off key RECEIPT

Use this key pressing two times to change the status "receipt issue" or "no receipt." In case of "receipt issue", the indicator is lit.

7 Loan key LOAN

This key is used to input the amount of money provided for making change. This operation affects media totals, rather than sales totals. Loans are made for all types of money which can be specified by the finalize key.

8 Pick up key

When the amount in drawer exceeds the limit value (sentinel function), the manager performs a pick up operation. This key is used for this function. This operation affects media totals, rather than sales totals. Pick ups are made for all types of money which can be specified by the finalize key.

9 Discount key %-

Use this key to register discounts.

- (1) Minus key Use this key to input values for subtraction.
- (1) **Refund key** [**F**] Use this key to input refund amounts and void certain entries.
- Error correction/Cancellation key
 Use this key to correct registration errors and to cancel registration of entire transactions.
- (3) Tax status shift 1 key T/S1 Use this key to change the Taxable 1 status of the next item.
- (14) Tax status shift 2 key [7/52] Use this key to change the Taxable 2 status of the next item.
- (5) Clear key C

Use this key to clear an entry that has not yet been registered.

(6) Multiplication/For/Date/Time key

Use this key to input a quantity for a multiplication operation and registration of split sales of packaged items. Between transactions, this key displays the current time and date.

17) Non-add/No sale key $\#_{NS}$

Non-add key: To print reference number (to identify a personal check, credit card, etc.) during a transaction, use this key after some numerical entries.

No sale key: Use this key to open the drawer without registering anything.

for the U.S.

- (B) Ten key pad 0, 1 ~ 9, 00, · Use these keys to input numbers.
- (19) Received on account key RC Use this key following a numeric entry to register money received for non-sale transactions.
- Paid out key PD Use this key following a numeric entry to register money paid out from the drawer.
- (2) Department keys 1, 2, 3 ~ 8 Use these keys to register items to departments.
- 2 Credit key CR1, CR2 Use this key to register a credit sale.
- Check key HKD Use this key to register a check tender.
- (2) Charge key CH Use this key to register a charge sale.
- Subtotal key TOTAL
 Use this key to display and print the current subtotal (includes add-on tax) amount.
- Cash/Amount tendered key Use this key to register a cash tender.

Allocatable functions

You can tailor a keyboard to suit your particular type of business.

Add check

Use this key in a check tracking system to combine the details of more than one check into a single check.

Arrangement

Use this key to activate an arrangement program programmed in the arrangement file. Any operation that can be performed from the keyboard, as well as mode, can be programmed in an arrangement program, and can be performed merely by pressing this key. In addition, one numeric entry can be included in an arrangement program. In this case, input the number and press this key. The mode control function of this key can be programmed for all modes except for the OFF and PGM mode.

Bill copy

Use this key to issue bill copy.

Bottle return

Use this key to specify next item as bottle return.

Cancel

Invalidates all preceding data registered for departments, PLUs and set menus within a transaction. This key must be pressed before the transaction involving the data to be invalidated is finalized. It is also effective even after calculation of subtotal amount.

Check endorsement

Use this key to print a preset check endorsement message using the slip printer.

Check print

Use this key to print the check on the slip printer.

Clerk transfer

Use this key to transfer opened checks to another clerk.

Coupon

Use this key for registering coupons.

Coupon 2

Use this key to declare the next item registration as coupon.

Cube

This key provides the same functions as the Square key. In addition, this key also has a cube multiplication function.

Currency exchange

Use this key to convert foreign currency to local currency or vice versa using the exchange rate preset for the key and displays the result.

Use this key for conversions of a home currency subtotal or merchandise subtotal to equivalent of another country's currency.

Use this key for conversions of another country's currency to the equivalent of the home currency.

Customer number

Use this key to register the number of customers.

Declaration

Use this key to declare in drawer amount for money declaration.

Deposit

Use this key to register deposits.

Eat-in

Use this key to specify if the customer eats in the restaurant. Before closing a transaction press this key.

EBT (electronic benefit transfer)

Use this key to register an EBT amount with a tender amount input.

Food stamp shift

Use this key to change food stamp status.

Food stamp subtotal

Use this key to obtain the food stamp applicable amount.

Food stamp tender

Use this key to register a food stamp payment amount with a tender amount input.

Ketten Bon

Use this key to enter quantities for multiplication. Multiplication by this key issues singular order prints.

Manual tax

Use this key to register a tax amount.

Menu shift

Use this key to shift key to the 1st ~ 6th menu.

Merchandise subtotal

Use this key to obtain subtotal excluding the add-on tax amount and the previous balance.

New balance

Use this key for adding the latest registered total amount to the previous balance to obtain a new balance.

New check

Use this key in a check tracking system to input a new check number in order to open a new check under that number.

New/Old check

Use this key in a check tracking system to input check numbers in order to open new checks and to reopen existing checks. When the clerk inputs a check number, the register checks to see if that number already exists in the check tracking memory. If there is no matching number in the memory, a new check is opened under the input number. If the check number input matches a number already stored in the memory, that check is reopened for further registration or finalization.

No sale

Use this key to open the drawer between transaction.

Non add

Use this key to print reference numbers (personal check number, card number, etc.)

Normal receipt

Use this key to change the order status from Bon to normal.

Old check

Use this key in a check tracking system to input the number of an existing check (previously created by the New check key) whose details are stored in the check tracking memory. Existing checks are reopened to perform further registration or to finalize them.

Open 2

Use this key to suspend the compulsory specifications.

Open check

Use this key to issue an open check report of an assigned clerk.

Operator number

Use this key to enter a clerk number during clerk transfer.

Operator X/Z

Use this key to issue a clerk's individual X/Z report.

Plus

Use this key for registering surcharge.

Premium

Use this key to apply a preset % or manual input % to obtain the premium amount for the last registered item or subtotal.

Previous balance

Use this key to register the previous negative/positive balance at the beginning of or during a transaction.

Previous balance subtotal

Use this key to obtain subtotal excluding the add-on tax amount and current balance.

Price

Use this key to register an open PLU.

Price inquiry

Use this key to confirm the price and descriptors of PLU without registering.

Rate tax

Use this key to activate the preset tax rate or manually input rate to obtain the tax for the preceding taxable status 1 amount.

Recall

Use this key for recalling the transferred check number by the store key. When this key is pressed, the check number will appear in order of the oldest record.

Review

Use this key to examine the current transaction by displaying item descriptor and registered amount. This key is also used for void operation.

Separate check

Use this key in a check tracking system to separate selected items from one check to another check.

Slip feed/release

Use this key to feed slips inserted into the slip printer. This is done by specifying the number of feed lines. This key is also used to release the slip paper holder if numbers are not entered.

Slip back feed/release

Use this key to back feed slips inserted into the slip printer. This is done by specifying the number of feed lines. This key is also used to release the slip paper holder if numbers are not entered.

Slip print

Use this key to execute a slip batch printing on the slip printer. Pressing this key prints the sales details. Actual printing is performed following receipt issuance.

Square

This key provides the same functions as the Multiplication key. In addition, this key also has a square multiplication function.

Store

Use this key for storing the check number of the registered items. When this key is pressed, registered item data will be stored, and then these data will transfer to the youngest check number.

Table number

Use this key to input table numbers.

Table transfer

Use this key to transfer the contents of a check to another check.

Takeout

Use this key to specify if the customer takes out items. Before total a transaction. Press this key for the tax exemption.

Tax exempt

Use this key to change taxable amounts to nontaxable amounts.

Taxable amount subtotal

Use this key to obtain taxable amount subtotal.

Text print

Use this key to enter characters to print.

Text recall

Use this key to print preset characters.

Tip

Use this key to register tips.

Tray total

Use this key to display the total amount for all registrations from the last registration until this key is pressed or registrations between presses of this key.

Void

Use this key to invalidate preceding item data registered.

How to remove/replace the sheet holder (TK-6000 only)

Remove the sheet holder

Follow steps $1 \sim 2$.



Replace the sheet holder

Follow steps 3 ~ 4.



How to install a menu sheet in the sheet holder (TK-6000 only)

Open the sheet holder

Follow the steps $1 \sim 3$.





Set a menu sheet in the sheet holder

Follow the steps $4 \sim 6$.





How to read the printouts

- The journal and receipts are records of all transactions and operations.
- The contents printed on receipts and journal are almost identical.
- You can choose the journal skip function. If the journal skip function is selected, the cash register will print the total amount of each transaction, and the details of premium, discount and reduction operations only, without printing department and PLU item registrations on the journal.
- The following items can be skipped on receipts and journal.
 - Consecutive number
 - Taxable status
 - Taxable amount
 - Item counter

Receipt Sample	Journal Sample (Item lines Included)	Journal Sample (Item lines Skipped)
********************** * THANK YOU * ** CALL AGAIN ** ****************	REC DZ 04-2000 11:58 1 DEPT01 T1 •1.00 1 DEPT02 T1 •2.00 5 DEPT03 •5.00	REC 07 04-2000 11:57 CO1 MCHO: 7 No TA1 -3.00 TX1 -0.15
* COMMERCIAL MESSAGE * * COMMERCIAL MESSAGE * * COMMERCIAL MESSAGE * * COMMERCIAL MESSAGE *	e TA1 •3.00 TA1 •0.15 TL •8.15 CASH •10.00	TL •8.15 CASH •10.00 CG •1.85 REG 03-04-2000 11:57 C02 MC#01 000124
REG 03-04-2000 11:58 — Mode/Date/Time C01 MC#01 000123 — Clerk/Machine No. Consecutive No.	CG -1.85 REG 03-04-2000 11:59 €C02 MC#01 000124	TA1 -10.00 TX1 -0.50
1 DEPT01 T1 •1.00+ Q'ty/Item 1 DEPT02 T1 •2.00 5 DEPT03 •5.00+ Item counter 7 No TA1 •3.00 TX1 •0.15 TU 0 15	1 DEPT01 T1 -1.00 1 DEPT03 T1 -3.00 1 DEPT02 T1 -2.00 1 DEPT04 T1 -4.00 5 DEPT05 -5.00 9 No 10 00	TL •15.50 CASH ·20.00 CG ·4.50 REG 03-04-2000 11:58 CO1 MC#01 000125 7 No
TL • 8.15 CASH •10.00 CG •1.85 **** BOTTOM MESSAGE ***	TA1 ·10.00 TX1 ·0.50 TL •15.50 CASH ·20.00 -4.50	TA1 -3.00 TX1 -0.15 TL -9.35 CASH -10.00
*** BOTTOM MESSAGE *** *** BOTTOM MESSAGE *** *** BOTTOM MESSAGE ***		REG 03-04-2000 11:59

In the operation examples contained in this manual, the print samples are what would be produced if the roll paper is being used for receipts. They are not actual size. Actual receipts are 45 mm wide. Also, all sample receipts and journals are printout images.

How to use your cash register

The following describes the general procedure you should use in order to get the most out of your cash register.

BEFORE business hours...



Check to make sure that the cash register is plugged in securely. Page 9
Check to make sure there is enough paper left on the roll. Pages 10, 11
Read the financial totals to confirm that they are all zero. Page 95
Check the date and time. Page 31

DURING business hours...

- Register transactions.
- Periodically read totals.

Page 32 Page 94



AFTER business hours...

•



- Reset the daily totals. Page 53
 - Remove the journal.
- Empty the cash drawer and leave it open.
- Take the cash and journal to the office.

Page 108

Page 17

Assigning a clerk



On models available in the United States and Canada, clerk or cashier assignment can be performed using clerk secret numbers only (clerk buttons are not equipped). In Germany, you can assign clerks by using clerk key or by clerk secret number (clerk key is equipped).

In other areas, you can assign clerks by using clerk button or by clerk secret number. The method you of assigning clerk depends on the programming of your cash register.

Clerk button

You can assign the clerk or cashier using the four buttons located below the display panel.

Clerk lock/clerk key

You can assign the clerk or cashier inserting a clerk key into the clerk lock .

Clerk secret number key

When the cash register is programmed to use clerk secret numbers for clerk or cashier assignment, the clerk buttons are not functional.

Clerk sign on



• If you do not want the clerk secret number to be shown on the display, press (ak#) before entering the number.

Clerk sign off





OPERATION

• The current clerk is also signed off whenever you set the mode switch to OFF position.

Important!

- The error code "E008" appears on the display whenever you try to perform a registration, a read/ reset operation without signing on.
- A clerk cannot sign on unless other clerk is signed off.
- The signed on clerk is also identified on the receipt/journal.

Displaying the time and date



You can show the time or date on the display of the cash register whenever there is no registration being made.

To display and clear the time



Preparing coins for change



You can use the following procedure to open the drawer without registering an item. This operation must be performed out of a sale.

(You can use the \mathbb{RC} key instead of the $\#_{NS}$ key. See page 52.)

Opening the drawer without a sale



Preparing and using department/flat-PLU keys

Registering department/flat-PLU keys



The following examples show how you can use the department/flat-PLU keys in various types of registrations.

Single item sale

Example 1

	Unit price	\$1.00
Item	Quantity	1
	Dept.	1
Payment	Cash	\$1.00



Example 2 (Subtotal registration and change computation)

			OPERATION	RECEIPT
	Unit price	\$12.34	1234	REG 03-04-2000 09:10
Item	Quantity	1	Unit price	C01 MC#01 000003
	Flat-PLU	1	001 Flat-PLU	1 PLU001 12.34
Payment	Cash	\$20.00	SUB TOTAL	TL •12.34+ Total amount CASH ·20.00+ Amount tendered
				CG •7.66 ⁺ Change
			Amount tendered	

Repeat

	Unit price	\$1.50
Item	Quantity	3
	Dept.	1
Payment	Cash	\$10.00

OPERATION

RECEIPT



Multiplication



Split sales of packaged items



Programming department/flat-PLU keys

To program a unit price for each department/flat-PLU



To program the tax calculation status for each department/flat-PLU

Tax calculation status

This specification defines which tax table should be used for automatic tax calculation.



Programming procedure

To program high amount limit for each department/flat-PLU



Γ	Description	Choice	Program code
	High amount limit for entering unit price manually.	Significant numbers	$D_6 D_5 \sim D_2 D_1$

Registering department/flat-PLU keys by programming data



Preset price

	Unit price	(\$1.00) _{preset}
Item	Quantity	1
	Dept.	2
Payment	Cash	\$1.00

OPERATION	RECEIPT
	REG 03-04-2000 09:30 C01 MC#01 000007 1 DEPT02 •1.00 Department No./unit price TL •1.00 Department No./unit price CASH •1.00

RECEIPT

Preset tax status

Item 1	Unit price	(\$2.00) _{preset}	5 × DATE		34-2000		
	Quantity	5	3	C 01	MC#01	000008	– Tax status
	Dept.	3	4	5 DEPTO		·10.00	
	Taxable	(1) _{preset}	SUB TOTAL	1 DEPTO4 TA1	4 T2	•2.00 •10.00	- Taxable Amount 1
Item 2	Unit price	(\$2.00) _{preset}	2 0 00 CA/AMT	TX1 TA2		•0.40- •2.00-	– Tax 1 – Taxable Amount 2
	Quantity	1		TX2	-1 -	·0.20-	– Tax 2
	Dept.	4		tl Cash	" L .	2 .60 •20.00	
	Taxable	(2) _{preset}		CG		•7.40	
Payment	Cash	\$20.00					

Locking out high amount limitation

OPERATION

OPERATION



Item	Unit price	\$1.05	1 0 5 0 3 ERROR ALARM (E037)	REG 03-04-2000 C01 MC#01) 09 : 40 0000(
	Quantity	1	(Exceeding high amount)		
	Dept.	3	C	1 DEPTO3	1.0، 1 .05 ، 1
	Max.amount	(\$10.00) _{preset}	105	Cash	·2.0
Payment	Cash	\$2.00	SUB	CG	-0.9

Preparing and using PLUs

This section describes how to prepare and use PLUs.

CAUTION:

Before you use PLUs, you must first program the unit price and tax status.

Programming PLUs

To program a unit price for each PLU


Registering PLUs



The following examples show how you can use PLUs in various types of registrations.

PLU single item sale





• The model for the U.S./Canada, use $\left[\begin{array}{c} X/FOR\\ yourge \\ Temperature \end{array}\right]$ instead of $\left[\begin{array}{c} X/FOR\\ yourge \\ Temperature \\$

Quantity

PLU

Cash

Item

Payment

Split sales of packaged item



Open PLU

			OPERATION	RECEIPT
Item 1	Unit price Quantity PLU	\$32.80 1 30	3 0 PLU 3 2 8 0 PRICE Unit price	REG 03-04-2000 10:05 C01 MC#01 000014 1 PLU0030 -32.80 1 NU0031 17.99
Item 2	Unit price Quantity	\$13.00 2	3 1 PLU 1 3 00 PRICE	1 PLU0031 •13.00 1 PLU0031 •13.00 TL • 58.80 CASH •60.00
Payment	PLU Cash	31 \$60.00	Repeat PRICE	CG •1.20
	1		SUB TOTAL 6 0 00 CA/AMT /TEND	

• Before registering an open PLU, it is necessary to preset it as an open PLU.

Shifting the taxable status of an item

By pressing "Tax Shift" key, you can shift the taxable status of an item.

DECEIDT



Calculation merchandise subtotal

			OPERATION	RECEIPT
Item 1	Dept. 1	\$4.00	4 00 1	REG 03-04-2000 10:10
	Quantity	1	T/S1	C01 MC#01 000015
	Taxable	(2) _{preset}	Pressing Trst changes the tax status	1 DEPT01 T2 -4.00 1 DEPT02 T1 -2.00
	Dept. 2	\$2.00	from Nontaxable to Taxable 1	1 DEPT03 T12 •6.00
Item 2	Quantity	1	T/S2	1 DEPT04 •7.00 TA1 •8.00
	Taxable	(No)→1	6 00 3	TX1 •0.32 TA2 •10.00
	Dept. 3	\$6.00	Pressing Ts2 changes the tax status from Taxable 1 to Taxable 1, 2	TX2 -0.50
Item 3	Quantity	1	Т/52	TL •19.82 CASH ·20.00
	Taxable	(1)→1, 2		CG •0.18
Item 4	Dept. 4	\$7.00	Pressing [752] changes the tax status from Taxable 2 to Nontaxable	
	Quantity	1	SUB	
	Taxable	(2)→No		
Payment	Cash	\$20.00]	

Important!

To change the tax status of the next item to be registered, be sure to press T/S1, T/S2.
 If the last item registered is programmed as nontaxable, a discount (%- key) operation on this item is always nontaxable.

In this case, you cannot manually change the tax status to Taxable 1 or 2 by pressing the T/S1, T/S2 keys.

Preparing and using discounts

This section describes how to prepare and register discounts.

Programming discounts

To program a rate to the %- key



Registering discounts

REG

Mode switch

The following example shows how you can use the [%]- key in various types of registration.

Discount for items and subtotals

			OPERATION	RECEIPT
Item 1	Dept. 1 Quantity	\$5.00	5 00 1 1 6 PLU	REG 03-04-2000 10:15 C01 MC#01 000016
	Taxable	(1) _{preset}	Applies the preset discount	1 DEPTO1 T1 -5.00 1 PLU016 T2 -10.00
Item 2	PLU 16 Quantity	(\$10.00) _{preset}	rate to the last item registered.	5% %- T2 -0.50 ST -14.50
	Taxable	(2) _{preset}	3 • 5 % - The input value takes priority	3.5% %0.51
Discount	Rate	$(5\%)_{\text{preset}}$	of the preset value.	TA1 •5.00
Subtotal discount		3.5%	SUB	TX1 •0.20 TA2 •9.50
	Taxable	Nontaxable	1 5 00 ^{CA} /TEND	TX2 •0.48
Payment	Cash	\$15.00		TL •14.67 CASH •15.00 CG •0.33

• You can manually input rates up to 4 digits long (0.01% to 99.99%).

Taxable status of the %- key

- Whenever you perform a discount operation on the last item registered, the tax calculation for discount amount is performed in accordance with the tax status programmed for that item.
- Whenever you perform a discount operation on a subtotal amount, the tax calculation for the subtotal amount is performed in accordance with the tax status programmed for the ^{%-} key.

Preparing and using reductions

This section describes how to prepare and register reductions.

Programming for reductions

You can use the - key to reduce single item or subtotal amounts.

To program preset reduction amount



Registering reductions

The following examples show how you can use the [-] key in various types of registration.

RECEIPT

Reduction for items

REG

Mode switch

	Dept. 1	\$5.00	5 00 1		2000 10:	
Item 1	Quantity	1	2 5 🗕	CO1 MC	‡01 O	00017
	Taxable	(1) _{preset}	Reduces the last amount registered by the value input.	1 DEPTO1		•5.00 -0.25
Reduction	Amount	\$0.25	4 5 PLU	1 PLU0045	T1	•6.00
	PLU 45	(\$6.00) _{preset}	—	- TA1		-0.50
Item 2	Quantity	1	SUB	TX1	4.0	•0.41
	Taxable	(1) _{preset}	1 1 00 CA/AMT TEND	TL Cash		11.00
Reduction	Amount	(\$0.50) _{preset}		CG		•0.34
Payment	Cash	\$11.00		<u>.</u>		

OPERATION

- You can manually input reduction values up to 7 digits long.
- If you want to subtract the reduction amount from the department or PLU totalizer, program "Net totaling."

Reduction for subtotal

Payment	Taxable Cash	(No) _{preset} \$7.00
Subtotal Reduction	Amount	\$0.75
	Taxable	(2) _{preset}
Item 2	Quantity	1
	Dept. 2	\$4.00
	Taxable	(1) _{preset}
Item 1	Quantity	1
	Dept. 1	\$3.00

OPERATION

RECEIPT

3 00 1	REG 03-04-1	2000 10:25
4 00 2	CO1 MC	#01 000018
SUB	1 DEPT01 1 DEPT02	T1 •3.00 T2 •4.00
7 5 -	-	-0.75
Reduces the subtotal by the	TA1	-3.00
value input here.	TX1	·0.12
SUB TOTAL	TA2	-4.00
7 00 CA/AMT	TX2	·0.20
	TL	-6.57
	Cash	•7.00
	CG	•0.43

Registering credit and check payments



Check

REG



Mixed tender (cash, credit and check)

Item	Dept. 4	\$55.00
Item	Quantity	1
	Check	\$30.00
Payment	Cash	\$5.00
	Credit	\$20.00

OPERATION

3

5 5 00

5 00

0 00

RECEIPT

C01 MC#01	000021
1 DEPTO4	•55.00 55.00
	•30.00
CASH CREDIT1	•5.00 •20.00
	CO1 MC#01 1 DEPT04 TL - CHECK CASH

Preparing and registering the Euro

Basic programming for the Euro and its exchange rate

Before registering the Euro, you must define the main currency, and its exchange rate. If you need to select cash drawer or some rounding specification, please ask your dealer.

Description	Choice	Program code
Define the euro as the main currency.	Yes = 0 No = 1	D ₁₀
Select rounding option: Round off = 0, Cut off = 1, Round up = 2	Significant number (0 ~ 2)	
Exchange rate (within 6-digits)	Significant numbers	$D_8 D_7 D_6 D_5 D_4 D_3$
Decimal point position of exchange rate: Integer only = 0 1st decimal place = 1, 2nd decimal place = 2, 3rd decimal place = 3, 4th decimal place = 4, 5th decimal place = 5, 6th decimal place = 6 Example: $(D_8 \sim D_2)$ 1Euro = 1.977DM; Set "001977" 1Euro = 1957.77319 Lit; Set "1957772"	Significant number (0 ~ 6)	
Always "0"		0 D ₁
GM → 3 TUB → 2 8 2 2 TUB ■		
le switch	D ₁₀ D ₁	

Registering the Euro



The following example shows the basic operation using the currency exchange function.

(1) Case A

Main currency	Local	
Payment	Euro	
Change	Local	
Rate	1 Euro = 0.5 FFr	

(2) Case B

Main currency	Euro
Payment	Local
Change	Euro
Rate	1 Euro = 0.5 FFr

Case A

OPERATION		DISPLAY
600 ₁		
ELRO PD	Press the Rep key, which converts the subtotal amount into the sub currency by applying the preset exchange	0.00E
SUB TOTAL	rate. After you press the $\begin{bmatrix} SUB \\ TOTAL \end{bmatrix}$ key, the result is shown on the display.	12.005
	Press the $[m_{p}]$ key if you enter the payment in the sub currency.	0.0 0 E
	\checkmark Press the (M/M) key to finalize the transaction. The change amount is shown in the programmed	15.00E 15.0
	currency.	

Case B

OPERATION		DISPLAY
1 2 00 1		
Euro PD	\square Press the $\square P_{PD}$ key, which converts the subtotal amount	0.00L
SUB TOTAL	into the sub currency by applying the preset exchange rate. After you press the $\begin{bmatrix} SUB \\ TOTAL \end{bmatrix}$ key, the result is shown on the display.	5.0 <u>0</u> L
ELRO. PD	\bigcirc Press the $\overset{\square B \square 0}{\frown}$ key if you enter the payment in the sub	0.0 0 L
6 00	currency.	5.00L
CA/AMT /TEND	Press the HAND key to finalize the transaction. The change amount is shown in the programmed currency.	0.0 0

Printouts

000022

€15.00 •7.50 •1.50

.6.00 -6.00 €12.00

REG 03-04-2000 10:45 C01 MC#01 0000

1 DEPTO1

TL

EURO money CASH

Cash CG



REG 03-04-20 C01 MC#0	
1 DEPTO1 TL =	€12.00 €12.00 -6.00
LOCAL money	
Cash	•6.00
Cash	€12.00
CG	€0.00

Validation printing



You can perform total amount validation following finalization using \mathbb{R} , \mathbb{CH} , \mathbb{R} ,

Total amount validation



Registering returned goods in the REG mode

REG

Mode switch

The following example shows how to use the \mathbb{RF} key in the REG mode to register goods returned by customers.

Item 1	Dept. 1	\$2.35
	Quantity	1
Item 2	Dept. 2	\$2.00
	Quantity	1
Item 3	PLU 1	(\$1.20) _{preset}
	Quantity	1
Returned	Dept. 1	\$2.35
Item 1	Quantity	1
Returned	PLU 1	(\$1.20) _{preset}
Item 3	Quantity	1
	Quantity	▲
Payment	Cash	\$2.00





Registering returned goods in the RF mode



The following examples show how to use the RF mode to register goods returned by customers.

Normal refund transaction

Returned	Dept. 1	\$1.50
Item 1	Quantity	2
Returned	PLU 2	(\$1.20) _{preset}
Item 2	Quantity	6
Payment	Cash	\$10.20



5	0	
		1
	6	
	2	PLU
	CA /	/ AMT TEND

RECEIPT



• The model for the U.S./Canada, use $\begin{bmatrix} X/FOR \\ /OHE \end{bmatrix}$ instead of $\begin{bmatrix} X/FOR \\ /OHE \end{bmatrix}$

Reduction of amounts paid on refund

Returned	Dept. 3	\$4.00
Item 1	Quantity	1
Reduction	Amount	\$0.15
Returned	PLU 2	(\$1.20) _{preset}
Item 2	Quantity	1
Discount	Rate	$(5\%)_{\text{preset}}$
Payment	Cash	\$5.20

4 00 <u>3</u>	RF 03-04-	2000 1	1:10
I 5 —	C01 MC	#01	000027
2 PLU %- SUB TOTAL CA/AWT TEND	1 DEPT03 – 1 PLU0002 5% %– TA1 TA1 TA2 TX2 TL CASH	T1 T1 T2 T2	-4.00 -0.15 -1.20 -0.06 -3.85 -0.15 -1.14 -0.06 5.20 -5.20

RECEIPT

Important!

REG

Mode switch

• To avoid miss registrations in the RF mode, return the mode switch to the former position immediately.

Registering money received on account

OPERATION



Registering money paid out

The following example shows how to register money paid out from the register. This registration must be performed out of a sale.

OPERATION

RECEIPT







REG

Mode switch

Making corrections in a registration

There are three techniques you can use to make corrections in a registration.

- To correct an item that you input but not yet registered.
- To correct the last item you input and registered.
- To cancel all items in a transaction.

To correct an item you input but not yet registered



• The model for the U.S./Canada, use $\left[\frac{X/FOR}{2}\right]$ instead of $\left[\frac{X/FOR}{THE}\right]$.

To correct an item you input and registered



• The model for the U.S./Canada, use $\boxed{X/FOR}_{V \to TE}$ instead of $\boxed{X/TEE}_{TEE}$.

To cancel all items in a transaction



No sale registration



You can use the following procedure to open the drawer without registering a sale. This operation must be performed out of a sale.

OPERATION

RECEIPT

#_{NS}



Printing the daily sales reset report

This report shows daily sales totals.

OPERATION

REPORT

Z1 Mode switch ↓ CA/AMT CA/AMT TEND Z 03-04-2000 17:40 C01 MC#01 000174	— Date/time — Clerk name/mc No./consecutive No.	CH RC PD CORR VLD RCT	No 56 •1,174.85 No 4 •810.00 No 5 •520.00 ·J.00 No 14 •39.55 No 19 No 7	
Z BATCHO1	— Report title	NS	No 3 No 5	
Z FIX 0001 0001011	 Fixed total report title/reset counter Report code 	Z DEPT	 0001 - 0001015 -	 Department report title/reset counter Report code
GROSS 981.25 -6,574.40 NET No 111	 Gross total *2 Net total *2 	DEPT01 DEPT02	203.25 -1,108.54 183	 Department count/amount *1
-7,057.14 CAID -1,919.04 CHID -139.04 CKID -859.85 CRID(1) -709.85	 Cash in drawer *² Charge in drawer *² Check in drawer *² Credit in drawer *² 	DEPTO4 TL	-1,362.26 -17.22 	 Department total count/total amount
RF No 3 -10.22 CUST CT 111 AVRG -63.57	 Refund mode *2 Number of customer *2 Average sales per customer *2 	Z CASH	-2,872.28 IER 0001- 0001017-	 Clerk report title/reset counter Report code
DC -1.22 REF -2.42 CLEAR № 85 ROUND -0.00	 Discount total *2 Refund key *2 Clear key count *2 Rounding total *2 	C01 GROSS NET	1- 421.25 •2,872.28 № 111	 Clerk name/drawer No. *1 Gross total *1 Net total *1
CANCEL № 2 -12.97	 Cancellation *2 Taxable 1 amount *2 	CAID CHID	•1,845.35 •1,057.14 •139.04	– Net total ·
TA1 -2,369.69 TX1 -128.86 TA2 -2,172.96 TX2 -217.33	 Taxable 1 amount *2 Tax 1 amount *2 Taxable 2 amount *2 Tax 2 amount *2 	rf Clear	No 1 -1.00 No 5 -4.43	 Refund mode *1 Clear key count *1
GT1 •00000000125478.96 GT2 •0000000346284.23 GT3 •0000000123212.75	 Grand total 1 *2 Grand total 2 *2 Grand total 3 *2 	C02	-4.43	– Clerk name/drawer No.
Z TRANS 0001 0001012 CASH No 362 •1,638.04	– Function key count/amount *1 p	rogrammin	-	ctions/clerks are not printed by y programming.

This chapter describes more sophisticated operations that you can use to suit the needs of your retail environment.

Clerk interrupt function

There are two types of clerk interrupt function, illustrated by PROCEDURE 1 and PROCEDURE 2 below.

• In PROCEDURE 1, each clerk possesses a unique clerk interrupt buffer, and so the clerk interrupt function gives each individual clerk the ability to perform an independent registration operation. In this case, each clerk is individually linked to a unique clerk interrupt buffer.

• In PROCEDURE 2, multiple clerks use the same clerk interrupt buffer, and so a single clerk interrupt operation (clerk change during registration) can be performed any registration is in progress.

In this case, multiple clerks are linked to a single clerk interrupt buffer.

Note the following important points concerning the clerk interrupt function.

• The register must be programmed to allow the clerk interrupt function.

• To use the clerk interrupt function, a clerk interrupt buffer must be allocated with the memory allocation operation. Next the manager control operation (X1 mode) should be used to perform clerk assignment for the clerk interrupt function. The clerk interrupt operation cannot be performed by clerks who are not linked to a clerk interrupt buffer.

• You cannot use the clerk interrupt function on a register set up to function as part of a check tracking system. In the REG1, REG2, and RF modes, clerks can be changed while a transaction is in progress, making it possible for multiple clerks to simultaneously perform registrations in the same mode using a single register. For example, if clerk 1 is interrupted while registering a transaction, clerk 2 can use the same machine to register a different transaction. Then clerk 1 can continue the original registration from the point where it was interrupted.

PROCEDURE 1



NOTES

- A guest receipt can be issued following clerk change, and receipts can be issued separately for each clerk.
- A cancel operation can be performed during registration by either of the clerks. When clerk 1 signs back on (after being interrupted by clerk 2), the cancel operation cancels only the items registered after signing back on (only this receipt) or from the top of the transaction. This is selectable by the key program.

Single item cash sales

A department key or PLU programmed with single item sale status finalizes the transaction as soon as it is registered.

The single item sales function cannot work properly if the keyboard does not include <CASH> (the cash key). The single item sales function can only be used for cash sales.

Example 1





Addition (plus)

Example

\$1.00 Dept. 1 Item 1 Quantity 1 Addition \$0.10 Dept. 1 \$2.00 Item 2 3 Quantity Addition $3 \times (\$0.20)$ \$7.70 Payment Cash

 $\begin{array}{c}
1 & 00 & 1 \\
1 & 0 & + \\
3 & \swarrow_{\text{DATE}} \\
2 & 00 & 1 \\
3 & \swarrow_{\text{DATE}} \\
+ \\
\hline
CA/AMT \\
TEND
\end{array}$

OPERATION

REG 03-04-2000 13:15 C01 MC#01 0001

RECEIPT

C ()1	MC#01		000104
1	DEPTO1 + DEPTO1 + TL CASH		-7	·1.00 ·0.10 ·6.00 ·0.60 70 ·7.70

• The model for the U.S./Canada, use $\left[\frac{X/FOR}{2/2\pi E}\right]$ instead of $\left[\frac{X/FOR}{2}\right]$

Premium (%+)

Example

OPERATION RECEIPT 00 Dept. 1 \$1.00 1 1 REG 03-04-2000 13:20 **C**01 MC#01 000105 %+ Item 1 1 0 Quantity 1 DEPT01 -1.00 Premium 10% 10% 2 00 \$2.00 Dept. 1 1 **%**+ -0.10 Item 2 •6.00 •7.10 3 DEPT01 SUB TOTAL 3 Quantity ST 15% Subtotal Premium %+ 15% ·1.07 **%**+ CA/ AMT TEND Cash \$8.17 Payment TL Cash **•8.17**

• The model for the U.S./Canada, use $[X_{\text{Jean}}^{X/\text{FOR}}]$ instead of $[X_{\text{Tean}}^{X}]$

Advanced Operations

Tray total

Tray total premium/discount

The buffer memory stores all items that fall into the prescribed range, starting from the first item registered for a transaction up to the point that <TRAY TOTAL> (the tray total key) is pressed to perform a tray total premium/discount operation. Following a premium/discount operation, the buffer is cleared and storage of new data starts from registration of the next item following the first premium/discount operation. The following operations clear the buffer memory.

- Press <TRAY TOTAL> twice.
- Press <TRAY TOTAL> and then perform a premium/discount operation. The contents of the buffer memory are
 restored if an error correction operation is performed to delete the premium/discount operation.
 Example

Dept. 1 Dept. 3	\$1.00 \$2.00
Dept. 3	\$2.00
	φ2.00
iscount	(5%) _{preset}
Dept. 3	\$3.00
Dept. 4	\$4.00
iscount	10%
Cash	\$9.15
	iscount Dept. 3 Dept. 4 iscount Cash



Multiple item totalling function

This function accumulates all items registered from the first item registered up to point that <TRAY TOTAL> is pressed, or all items between two presses of <TRAY TOTAL>. Pressing <TRAY TOTAL> displays the total amount with the tax included and prints it on the receipt and journal (printing on receipt and journal is programmable.)

Example

			OPERATION	RECEIPT
Customer A	Dept. 1 Dept. 3	\$1.00 \$2.00	1 00 1 2 00 3	REG 03-04-2000 13:30 CO1 MC#01 000107
Customer B	Dept. 3 Dept. 4	\$3.00 \$4.00	TRAY TOTAL 3 00 3	1 DEPTO1 -1.00 1 DEPTO3 -2.00 TRAY TL -3.00
Payment	Cash	\$10.00	4 00 4	1 DEPTO3 -3.00 1 DEPTO4 -4.00
. <u> </u>			TRAY TOTAL CA/AMT CA/AMT	TRAY TL -7.00 TL -10.00 CASH -10.00

Coupon transactions

Note that errors result when the result of a calculation is negative if the cash register is programmed to prohibit credit balances.

000108

-6.00 -1.00

-4.00 -1.00

-8.00

-8.00

Coupon registration using <COUPON> (coupon key)

Example

	Dept. 1	\$3.00
Item 1	Quantity	2
	Coupon	\$0.50 × 2
	Dept. 3	\$4.00
Item 2	Quantity	1
	Coupon	(\$1.00)
Payment	Cash	\$8.00

OPERATION	RECEIPT
2 × me 3 00 1 2 × me 5 0 CPN 4 00 3 CPN CA/AMT CA/AMT	REG 03-04-2000 13:35 CO1 MC#01 0001 2 DEPT01 -6. CPN -1. 1 DEPT03 -4. CPN -1. TL -8. O CASH -8.

• The model for the U.S./Canada, use $\begin{bmatrix} X/FOR \\ / DTE \end{bmatrix}$ instead of $\begin{bmatrix} X/DTE \\ / DTE \end{bmatrix}$

Coupon registration using <COUPON2> (coupon 2 key)

Example

OPERATION RECEIPT Dept. 1 \$15.00 5 00 03-04-2000 13:40 REG 1 **C**01 MC#01 000109 CPN2 1 Quantity 1 Item 1 1 DEPT01 -15.00 PLU Coupon 2 n \$1.50 Dept.1 CPN2 CPN2 PLU n 1 DEPT01 -1.50**PLU 10** \$5.00 1 PLU0010 -5.00 CPN2 Quantity 1 CA/AMT TEND 1 PLU0050 -0.50Item 2 TL -18.00 Coupon 2 (\$0.50) **PLU 50** CASH -18.00Payment Cash \$18.00

Preset tender amount

An amount up to six digits long can be programmed to <CASH> (cash/amount tendered key). Then, when <CASH> is pressed without inputting a value, the programmed value is automatically registered and the transaction is finalized. When an amount is programmed to <CASH>, attempting to manually input an amount results in an error.

Example 1

Payment	Cash	(\$10.00)
Item	Quantity	1
Itom	Dept. 1	\$8.00



OPERATION

RECEIPT

RECEIPT

8 00 1		03-04-2000	
CA/ANT TEND	C 01	MC#01	000110
The preset amount is tendered.	1 DE	PT01	-8.00
	TL		8.00
	CA	SH	·10.00
	CG		•2.00

Example 2

Item	Dept. 1	\$15.00	1 5 00 1	REG 03-04-2000 13:50
Itelli	Quantity	1		C01 MC#01 000111
Derverent	Cash	(\$10.00)	An error occurs by manual input	1 DEPT01 -15.00
Payment	Check	\$5.00	С	TL •15.00 CHECK •5.00
				CASH -10.00 CG -0.00

Bottle link operation

You can link PLU or subdepartment to a PLU. **Example**

OPERATION RECEIPT PLU 1 PLU (\$8.00) REG 03-04-2000 13:55 **C**01 MC#01 000112 Item 1 (\$0.80)PLU 11_{linked} PLU Quantity 1 1 PLU0001 **-8.**00 1 PLU0011 •0.80 0 00 CA/AMT TEND PLU 2 (\$5.00) 3 PLU0002 15.00 3 PLU0012 -1.50 Item 2 PLU 12_{linked} (\$0.50) -25.30 TL Quantity 3 .30.00 Cash

• The model for the U.S./Canada, use $\boxed{X_{\text{core}}^{X/\text{FOR}}}$ instead of $\boxed{X_{\text{core}}}$.

\$30.00

Bottle returns

Payment

Cash

Bottle return key

You can use the linked bottle return key to register a bottle return. A PLU whose programmed unit price represents the contents of the bottle, can be linked with PLU whose programmed unit price represents the deposit on the bottle. In the following example, the bottle return key has been programmed to operate as a linked bottle return key.

CG

-4.70

The bottle return key must be pressed before input of each new linked bottle return.

Example

			OPERATION	RECEIPT
Return Item 1	PLU 1 PLU 11 _{linked} Quantity	(\$8.00) (\$0.80) 1	BR 1 PLU 3 Mare BR 2 PLU	REG 03-04-2000 14:00 CO1 MC#01 000113 BR
	PLU 2	(\$5.00)	CA/AMT TEND	1 PLU0011 -0.80
Return Item 2	PLU 12 _{linked}	(\$0.50)	_	3 PLU0012 -1.50 TL -2.30
	Quantity	3	-	CASH -2.30
Payment	Cash	\$2.30		

• The model for the U.S./Canada, use $\frac{X/FOR}{\sqrt{2\pi E}}$ instead of $\frac{X}{THE}$.

Arrangement key registrations

Key operations can be assigned to an <ARRANGE> (arrangement key). Then, simply pressing <ARRANGE> performs all of the key functions assigned to it.

Key operations can also be assigned to an address code. Then, when you input the address code using <ARRANGE>, all of the key functions assigned to the address code are performed.

Example 1

Arrangement 1				
Item 1	PLU 1	(\$8.00)		
	Quantity	1		
Item 2	PLU 2	(\$5.00)		
Item 2	Quantity	1		
Payment	Cash	\$13.00		

OPERATION	RECEIPT
ARF	REG 03-04-2000 14:05 C01 MC#01 000114
	1 PLU0001 -8.00 1 PLU0002 -5.00
	L -13.00
	CASH •13.00

Example 2

			OPERATION	RECEIPT
	Arrangeme	ent 5	5 ARR	REG 03-04-2000 14:10
Itam 1	Dept. 1	\$1.00	-	C01 MC#01 000115
Item 1	Quantity	1		1 DEPT01 -1.00
Itom 2	Dept. 2	\$2.00		1 DEPT02 ·2.00 TL •3.00
Item 2	Quantity	1		CASH •3.00
Payment	Cash	\$3.00		

Set menu

When you register a set menu, its total amount is added to the PLU totalizer and counter. The price of each set menu item is also added to each respective PLU totalizer and counter.

OPERATION

Example

Set menu	PLU 35	\$5.00
Item 1	PLU 1	
Item 2	PLU 2	
Item 3	PLU 3	
Item 4	PLU 4	
Payment	Cash	\$5.00

3 5 PLU	REG	03-04-2000	14:15
CA/AMT TEND	C 01	MC#01	000116
	1 PL	U0035	•5.00
	р	LU0001	
	р	LU0002	
		LU0003	
	р	LU0004	
	TL		5.00
	CA	SH	•5.00

RECEIPT

_____I

Currency exchange function

When <CE> (currency exchange key) is pressed, a current subtotal including tax is converted directly into foreign currency and the result is displayed, and the subsequent finalization is handled using the foreign currency. The currency exchange function is released by finalizing a transaction, partial tender operation, receipt issuance, or by pressing <SUBTOTAL>.

Before using the currency exchange function, it is necessary to program the conversion rate.

Registering foreign currency

Full amount tender in foreign currency

* Pre-programmed exchange rate: \$ 100 = \$0.9524

Important!

Tenders in a foreign currency can be registered using and and only. Other finalize keys cannot be used.

OPERATION DISPLAY RECEIPT **FI I** 03-04-2000 14:20 REG Enter the unit price and press the 0 00 **C**01 MC#01 000117 (Displays in \$) applicable department key. 56 1 DEPTO1 2000 -10.000 00 Enter the next unit price and press 2 **DEPT02** ·20.00 (Displays in \$) the applicable department key. TL -30.00 CE ← Press **CE** and **SUB** without en-CASH ¥5,000 (Displays in ¥: 3,150) tering a numeric value. This op-CASH •47.62 eration converts the subtotal (in-CG 17.62 cluding tax) dollar value into yen by applying a pre-programmed exchange rate. The result is shown on the display and printed on the receipt/journal by programming. 588 • Enter the amount tendered in yen CE 0 0 0 and press | CE |. This operation (5,000) converts the entered yen amount into dollars by applying a pre-programmed exchange rate. The result is shown on the display. Press to finalize the transaction. (Displays in \$) Note that you do not need to reenter the dollar amount. The register automatically calculates the change amount due in dollars and shows it on the display, receipts and journal.

Partial tender in a foreign currency

* Pre-programmed exchange rate: \$ 100 = \$0.9524

Important!

Partial tender in a foreign currency can be registered using [1][] and [1][] only. Other finalization keys cannot be used, but the remaining tender can be finalized using any finalize key.



Food stamp function

Food stamp registration

No change due



Item 1	Dept. 1	\$1.00
	Taxable	1, F/S
Item 2	Dept. 2	\$2.00
	Taxable	2
Item 3	Dept. 3	\$3.00
	Taxable	$No \rightarrow F/S$
Payment	Food stamp	\$2.00
	Cash	\$4.14

OPERATION RECEIPT 1 00 REG 03-04-2000 14:30 1 **C**01 MC#01 000119 00 2 1 DEPT01 T1 F \$1.00 F/S 00 3 3 1 DEPTO2 T2 \$2.00 Shifting food stamp 1 DEPTO3 F \$3.00 status, press **F/S** key. \$1.00 TA1 FS/ST \$0.04 TX1 Press **FS/ST**, at the top of TA2 \$2.00 the food stamp tender. TX2 \$0.10 2 00 **FS/TD** Subtotal TL \$6.14 FSST \$4.04 Food stamp subtotal CA/AMT /TEND FSTD \$2.00 Food stamp tendered CASH \$4.14

Mixed food stamp/cash change

Example 1

			OPERATION
τ. 1	Dept. 1	\$1.00	1 00
Item 1	Taxable	1, F/S	F/S 2 00
Item 2	Dept. 2	\$2.00	F/S 3 00
nem 2	Taxable	2, F/S	
Item 3	Dept. 3	\$3.00	7 00
nem 5	Taxable	F/S	
Payment	Food stamp	\$7.00	1

ATION	R	ECEIPT	
1 00 1 2 00 2 3 00 3 FS/ST 7 00 FS/TD		2000 14:35 #01 000120 T1 F \$1.00 T2 F \$2.00 F \$3.00 \$1.00 \$0.04 \$2.00 \$0.10 \$6.14 \$6.14 \$7.00 \$0.86	 Subtotal Food stamp subtotal Food stamp tendered Cash change

The change in food stamp transactions is automatically calculated as cash for amounts of \$1.00 or less, and as food stamps for amounts greater than \$1.00.

Example 2



In the above example, the total amount of change due is \$2.92; \$2.00 in food stamps and \$0.96 in cash.

Example 3

Item 1	Dept. 1	\$2.00
	Taxable	1, F/S
Item 2	Dept. 4	\$0.50
	Taxable	No
Payment	Food stamp	\$5.00

OPERATION	RECEIPT
2 00 1 5 0 4 FS/ST 5 00 F8/TD	REG 03-04-2000 14:45 C01 MC#01 000122 1 DEPT01 T1 F 1.00 1 DEPT04 \$0.50 TA1 \$2.00 TX1 \$0.08 TL \$2.08 FSST \$2.08 FSTD \$5.00 FSCG \$2.00 CG \$0.42

When food stamp items are included in a transaction, the amount of change due in cash is applied as a cash amount tendered for cash (nonfood stamp) items. In this example, the \$0.50 purchased (department 4) is automatically deducted from the \$0.92 cash due in change from the food stamp purchase (department 4).

Example 4

		OPERATION	RECEIPT
Item 1Dept. 1Item 1TaxableItem 2Dept. 2TaxableTaxableItem 3Dept. 3Taxable	\$1.00 1, F/S \$2.00 2 \$3.00 No	1 00 1 2 00 2 3 00 3 FSST 5 00 FSTD	REG 03-04-2000 14:50 CO1 MC#01 000123 1 DEPT01 T1 F \$1.00 1 DEPT02 T2 \$2.00 1 DEPT03 \$3.00 TA1 \$1.00 TX1 \$0.04 TA2 \$2.00
Payment Food stamp Cash	\$5.00 \$4.14		TX2 \$0.10 TL \$6.14 FSST \$1.04 FSTD \$5.00 FSCG \$3.00 CASH \$4.14

The following calculation is performed internally to apply the cash change due on the food stamp transaction to the balance due of the cash transaction.

	Food stamp transaction	Cash transaction
Price items:	\$1.00	\$5.00
Tax:	\$0.04	\$0.10
Total due:	\$1.04	\$5.10
Amount tendered:	\$5.00 (food stamp)	\$4.14 (cash), \$0.96 (change from food stamp)
Amount due:	\$1.04	
Change amount due:	\$3.00 (food stamp), \$0.96 (cash)	
Total:		\$5.10

Food stamp registration (Illinois rule)

No change due

Example 1

Item 1	Dept. 1	\$1.00
	Taxable	1, F/S
Item 2	Dept. 1	\$2.00
nem 2	Taxable	1, F/S
Item 3	Dept. 4	\$3.00
	Taxable	F/S
Payment	Food stamp	\$6.00

OPERATION

RECEIPT

1 00 1 2 00 1	REG 03-04-2 C01 MC#	000 14:55 01 000124
3 00 4 FS/ST	1 DEPTO1 1 DEPTO1 DEPTO4	T1 F \$1.00 T1 F \$2.00 F \$3.00
6 00 FS/TD	TL FSST FSTD	\$6.00 \$6.00 \$6.00

Example 2

Item 1	Dept. 1	\$2.00
	Taxable	1, F/S
Item 2	Dept. 1	\$3.00
nem 2	Taxable	1, F/S
Item 3	Dept. 4	\$4.00
	Taxable	1, F/S
Payment	Food stamp	\$5.00
	Cash	\$4.16

OPERATION

RECEIPT

2 00 1 3 00 1	REG 03-04-20 C01 MC#0	
4 00 4	1 DEPTO1 1 DEPTO1	T1 F \$2.00 T1 F \$3.00
FS/ST	1 DEPT04 FSST FSTD	F \$4.00 \$9.00 \$5.00
5 00 F8/TD	TA1 TX1 CASH	\$4.00 \$0.16 \$4.16

No change due (continued...)

Example 3

Item 1	Dept. 1	\$2.00
	Taxable	1, F/S
Item 2	Dept. 2	\$3.00
	Taxable	2, F/S
	Food stamp	\$1.00
Payment	Cash	\$4.14

OPERATION	RECEIPT
2 00 1 3 00 2 FS/ST 1 00 FS/TD CA/AMT	REG 03-04-2000 15:05 CO1 MC#01 000126 1 DEPT01 T1 F \$2.00 1 DEPT02 T2 F \$3.00 FSST \$5.00 \$5.00 FSTD \$1.00 TA1 \$1.00 TX1 \$0.04 TA2 \$2.00 TX2 \$0.10 CASH \$4.14

If the total of the food stamps tendered is less than the food stamp total, the food stamp tendered amount is deducted from the taxable 1 and 2 amount.

Example 4

			OPERATION	RECEIPT
Item 1	Dept. 1 Taxable	\$1.00 1, F/S	1 00 1 5 00 2	REG 03-04-2000 15:10 CO1 MC#01 000127
Item 2	Dept. 2 Taxable	\$5.00 2, F/S	FS/ST 4 00 FS/TD	1 DEPTO1 T1 F \$1.00 1 DEPTO2 T2 F \$5.00 FSST \$6.00
Payment	Food stamp Cash	\$4.00 \$2.05		FSTD \$4.00 TA2 \$1.00 TX2 \$0.05 CASH \$2.05
			-	

In this example, the result of the taxable 1 amount is "0".

Mixed food stamp/cash change

Example 1

			OPERATION	RECEIPT
Item 1	Dept. 1	\$1.50	1501	REG 03-04-2000 15:15
Item I	Taxable	1, F/S	2 00 1	C01 MC#01 000128
Item 2	Dept. 1	\$2.00	3 00 4	1 DEPT01 T1 F \$1.50 1 DEPT01 T1 F \$2.00
	Taxable	1, F/S	FS/ST	1 DEPT04 F \$3.00
Item 3	Dept. 4	\$3.00		TL \$6.50 FSST \$6.50
	Taxable	F/S		FSTD \$10.00
Payment	Food stamp	\$10.00		FSCG \$3.00 CG \$0.50

The change in food stamp transactions is automatically calculated as cash for amount of \$1.00 or less, and as food stamps for amounts greater than \$1.00. In the above example, the total amount of change due is \$3.50 (\$3.00 in food stamps and \$0.50 in cash).

Example 2

			OPERATION	RECEIPT	
Item	Dept. 1	\$2.00	2 00 1	REG 03-04-2000 15:20	
	Taxable	1, F/S	FS/ST	C01 MC#01 000129	
Payment	Food stamp	\$5.00		1 DEPTO1 T1 F \$2.00	
			5 00 877	TL \$2.00 FSST \$2.00 FSTD \$5.00 FSCG \$3.00	

Example 3



OPERATION

When food stamp items are included in a transaction, the amount of change due in cash is applied as a cash amount tendered for cash (nonfood stamp) items. In this example, the \$0.30 purchase is automatically deducted from the \$0.80 cash due in change from the food stamp purchase.

Example 4

Item 1	Dept. 1	\$1.00
	Taxable	1, F/S
Item 2	Dept. 1	\$2.50
	Taxable	1, F/S
Item 3	Dept. 3	\$5.00
item 5	Taxable	No
Payment	Food stamp	\$5.00
	Cash	\$4.50

00 1 1 REG 03-04-2000 15:30 **C**01 MC#01 000131 5 0 2 1 1 DEPTO1 T1 F \$1.00 5 00 3 1 DEPT01 T1 F \$2.50 FS/ST 1 DEPTO3 \$5.00 FSST \$3.50 FSTD \$5.00 5 00 FSCG \$1.00 FS/TD Cash \$4.50 CA/AMT /TEND

RECEIPT

The following calculation is performed internally to apply the cash change due on the food stamp transaction to the balance due of the cash transaction.

	Food stamp transaction	Cash transaction
Price items:	\$3.50	\$5.00
Tax:	\$0.00	\$0.00
Total due:	\$3.50	\$5.00
Amount tendered:	\$5.00 (food stamp)	\$4.50 (cash), \$0.50 (change from food stamp)
Amount due:	\$3.50	
Change amount due:	\$1.00 (food stamp), \$0.50 (cash)	
Total:		\$5.00

Food stamp + Taxable 1 + Taxable 2

When food stamps are received as partial tender for items preset with the status "food stamp", "taxable 1", and "taxable 2", the calculation are performed using one of the two cases described in this section. The case used depends on the food stamp amount received as partial tender.

Case 1

Example 5

This case is used when the total amount of the items preset with the status "food stamp", "taxable 1", and "taxable 2" is greater than or equal to the food stamp amount received as partial tender. Case 1 subtracts the food stamp amount tendered from both the taxable 1 amount and taxable 2 amount.

			OPERATION	RECEIPT
Item 1	Dept. 1 Taxable	\$2.00 1, F/S	2 00 1 3 00 2	REG 03-04-2000 15:35 C01 MC#01 000132
Item 2	Dept. 2 Taxable	\$3.00 2, F/S	T/S2 2 00 1 FS/ST	1 DEPT01 T1 F \$2.00 1 DEPT02 T2 F \$3.00 1 DEPT01 T12F \$2.00 FSST \$7.00
Item 3	Dept. 1 Taxable	\$2.00 1/2, F/S		FSTD \$2.00 TA1 \$2.00 TX1 \$0.08
Payment	Food stamp Cash	\$2.00 \$5.23	CA/AMT	TA2 \$3.00 TX2 \$0.15 CASH \$5.23

In this example, the food stamp received as partial tender is \$2.00, so that amount is deducted from both the taxable 1 amount and taxable 2 amount. This means that the remaining taxable 1 amount is \$2.00, while the remaining taxable 2 amount is \$3.00.

Case 2

This case is used when the total amount of the items preset with the status "food stamp", "taxable 1", and "taxable 2" is less than or equal to the food stamp amount received as partial tender.

Example 6

Item 1	Dept. 1	\$2.00
	Taxable	1, F/S
Item 2	Dept. 2	\$3.00
	Taxable	2, F/S
Item 3	Dept. 1	\$2.00
nem 5	Taxable	1/2, F/S
Payment	Food stamp	\$4.00
	Cash	\$3.05

OPERATION RECEIPT 00 2 1 REG 03-04-2000 15:40 **C**01 MC#01 000133 00 3 2 T1 F \$2.00 T2 F \$3.00 T/S2 1 DEPT01 2 00 1 1 DEPTO2 FS/ST T12F \$2.00 1 DEPTO1 FSST \$7.00 FSTD \$4.00 TA2 \$1.00 4 00 FS/TD TX2 \$0.05 Cash \$3.05
Electronic benefits transfer

In addition to standard food stamp tender finalizations, this model also allows finalization for tenders electronic benefits transfer (EBT) card.

EBT tenders can be accepted for New Jersey rule or Illinois rule food stamp tenders, as well as for food stamp tenders that do not follow these rules.

About mixed EBT card tenders

When the register is programmed to prohibit an EBT amount tendered that exceeds the food stamp subtotal, nonfood stamp items cannot be paid for using an EBT card. In this case, the following applies:

- ST (EBT/TEND FS/ST) = Balance due (the remaining balance due must be finalized using another finalize key.)When the register is programmed to allow an EBT amount tendered that exceeds the food stamp subtotal, nonfood stamp items can be paid for using an EBT card. In this case, there are two possible situations:
- ST > EBT/TEND ٠
- ST (EBT/TEND FS/ST) = Balance due (the remaining balance due must be finalized using another finalize key.)EBT/TEND > or = ST
 - EBT/TEND ST = cash change

No change due

Example 1

Payment	EBT	\$6.00
Item 3	Taxable	F/S
	Dept. 3	\$3.00
Item 2	Taxable	2, F/S
	Dept. 2	\$2.00
Item 1	Taxable	1, F/S
	Dept. 1	\$1.00

OPERATION RECEIPT 00 REG 03-04-2000 15:45 **C**01 MC#01 00 1 DEPT01 T1 F \$1.00 00 3 **1 DEPT02** T2 F \$2.00 FS/ST 1 DEPT03 TL \$6.00 FSST 6 00 ЕВТ EBTTD

000134

F \$2.00

\$6.00

\$6.00

Example 2

Dept. 1	\$1.00
Taxable	1, F/S
Dept. 2	\$2.00
Taxable	1, F/S
Dept. 3	\$3.00
Taxable	1
EBT	\$5.00
Cash	\$1.12
	Taxable Dept. 2 Taxable Dept. 3 Taxable EBT

OPERATION

RECEIPT

RECEIPT

1 00 1		000 15:50
2 00 2	CO1 MC#	01 000135
3 00 3 FS/ST	1 DEPTO1 1 DEPTO2 1 DEPTO3 FSST	T1 F \$1.00 T1 F \$2.00 T1 \$3.00 \$3.00
5 00 EBT	EBTTD TA1 TX1 CASH	\$5.00 \$3.00 \$0.12 \$1.12

Change due

Payment	EBT	\$5.00
nem 5	Taxable	1
Item 3	Dept. 3	\$0.30
Item 2	Taxable	1, F/S
	Dept. 2	\$1.20
Item 1	Taxable	1, F/S
	Dept. 1	\$1.00

OPERATION

1 00 1 REG 03-04-2000 15:55 CO1 MC#01 0001 000136 2 0 2 0 1 DEPTO1 T1 F \$1.00 3 3 T1 F \$1.20 1 DEPTO2 FS/ST 1 DEPT03 \$0.30 T1 TA1 \$0.30 \$0.01 \$2.51 TX1 5 00 евт TL \$2.20 \$5.00 \$2.49 FSST EBTTD CG



Example

Item 1	Unit price	\$3.00
	Dept.	1
Item 2	Unit price	\$5.00
	Dept.	2
Tip	Amount	\$0.80
Payment	Cash	\$10.00
	•	



1

RECEIPT

3 00 1	REG 03-04-20	
5 00 2	CO1 MC#O	1 000137
SUB TOTAL 8 0 TIP	1 DEPTO1 1 DEPTO2 TIP	·3.00 ·5.00 ·0.80 \$8.80
0 00 CA/AMT	CASH CG	\$10.00 \$1.20

Inputting the number of customers

Example 1

Item 1	Unit price	\$15.00
	Dept.	1
Item 2	Unit price	\$5.00
	Dept.	2
Customer Number		2
Payment	Cash	\$20.00



Example 2

You can only use the following operation to re-input the number of customers when <CUSTOMER> (customer number key) is preset to allow re-input. When programming prohibits re-input of the number of customers, this operation causes an error.



You can re-input the number of customers either immediately after the initial input or during later registration.

Example 3

You can use the following operation to add customers to an original number of customers input (when addition to the number of the customer is allowed).

OPERATION	RECEIPT
3 CST 1 5 00 1 5 00 2 2 CST SUB TOTAL 2 0 00 CA/AMT	REG 03-04-2000 16:15 C01 MC#01 000140 CT 3 1 DEPT01 •15.00 1 DEPT02 •5.00 CT 5 5 TL •20.00 CASH •20.00

Text recall

This procedure is used to recall text by inputting the address where the text is stored. The recalled text is printed on the receipt and journal.

Example

Item 1	Unit price	\$46.00	
	Dept.	1	
Item 2	Unit price	\$10.00	
nem 2	Dept.	2	
Payment	Cash	\$56.00	
Text 1	MEDIUM SIZE		
Text 2	SMALL SIZE		

OPERATION RECEIPT 4 6 00 1 REG 03-04-2000 16:20 **C**01 MC#01 000141 TEXT 3 0 CT 00 1 DEPTO1 -46.00 TEXT 2 MEDIUM SIZE 1 DEPTO2 -10.00 SUB SMALL SIZE -56.00 TL Cash -56.00

Temporarily releasing compulsion

<OPEN 2> (open 2 key) can be programmed to release specific compulsion. **Example 1**

			OPERATION	RECEIPT
Item	Unit price Dept.	\$10.00	1 0 00 1 1 0 00 1	REG 03-04-2000 16:25 CO1 MC#01 000142
Payment	Check	\$10.00		1 DEPT01 ·10.00
Validation compulsory		pulsory	Validation compulsory (E041)	TL -10.00 CHECK -10.00
			OPEN 2	Validation compulsory is temporarily released.

Example 2

OPERATION

RECEIPT

AFIDT



Printing slip

To perform batch printing on the slip printer, you must first use the memory allocation operation (see program 5 mode in the dealer's manual) to reserve slip buffer memory. The capacity of the slip buffer memory is determined by the number of units of slip buffer memory reserved by the memory allocation operation. The register can be programmed to check the status of the registration buffer memory whenever slip batch printing is performed, and sound an alarm when the buffer memory is almost full. The alarm sounds when there are 12 lines or less remaining, and once it starts to sound, the only operation you can perform is the cancel operation or operations using one of the following keys.

- <CA/AMT TEND> (cash/amount tendered key) operation
- <CH> (charge key) operation
- <CHK/TEND> (check tendered key) operation
- <DEPOSIT> (deposit key) operation
- <NEW BALANCE> (new balance key) operation
- <SUBTOTAL> (subtotal key) operation

You must perform one of above operations when the registration buffer alarm sounds. Any other operations results in an error.

Printing slips

The cash register can be connected to the optional SP-1300 slip printer, which features an automatic feed function and automatic back feed function.

Automatic feed function

This function makes it possible to program the number of line feeds that should be inserted from the normal print start position before starting slip printing of a new slip. Even if line feeds are programmed for this function, they are not inserted for validation printing, check endorsement printing, and check printing performed using the slip printer. Note also that line feeds are not inserted automatically at the beginning of a second slip when the transaction requires printing that extends from one slip to another.

Automatic back feed function

This function performs automatic back feed following slip printing, validation printing, and endorsement printing on the slip printer. The slip paper is released once the back feed operation is complete.

Manual feed function

<SLIP FEED/RELEASE> (slip feed/release key: assigned to the register's keyboard using the program 4 mode) can be used for manual feed of the slip paper. You perform manual feed by inputting a value for the number of lines (up to two digits in the range of 1 to 99) and then press <SLIP FEED/RELEASE>.

Manual back feed function

<SLIP BACK FEED/RELEASE> (slip back feed/release key: assigned to the register's keyboard using the program 4 mode) can be used for manual back feed of the slip paper. Manual back feed can be performed by inputting a value for the number of lines (up to two digits in the range of 1 to 99) and then press <SLIP BACK FEED/RELEASE>.

You can print slips using automatic or manual batch printing. The slip print operation can be performed in REG1, REG2, and RF modes only.

Finalizing a registration without inserting a slip paper into the slip printer when the register is programmed as "slip paper insertion into slip printer compulsory before finalizing registration" produces an error.

To perform auto batch printing 1



About the maximum number of slip lines

You can program the maximum number of lines that can be printed on a slip. Once you do, any attempt to exceed the preset maximum results in an error. When such an error occurs, press <C>, change slip paper and press <SLIP PRINT> to restart printing.

Check tracking systems

Check tracking system

With the check tracking system, the amount, check number, number of slip print lines, store number, date/time and registration detail data are stored in two files (check tracking index file and check tracking detail file).

- Check tracking detail file and index file are cleared by the following timing:
 - 1. The check is cleared after printing finalized data on slip or guest check receipts, or the check is also cleared when the new or old check operation is made.
 - 2. The check is cleared after printing finalized data on slip or guest check receipt, or check is also cleared when the same finalized check number is assigned in new check operation.
 - You can select one of these options by programming.

• Auto new balance function The register can be programmed so that whenever a clerk (by clerk key) signs off while a check is open, a <NEW BALANCE> operation is automatically performed to temporarily finalize the open check.

- You can specify a range of checks that can be opened by each clerk. Once you do, any attempt by a clerk to open a check using a number that is not within his specified range results in an error.
- Either of the following two operations can be used to correct input of a wrong check number. <NEW CHECK>

Re-input the correct check number, or cancel the original check number, issue a receipt, and then re-input the correct check number.

<OLD CHECK>, <NEW/OLD>

Temporary finalize the original check number, issue a receipt, and then re-input the correct check number.

Opening a check

Example



Remove slip

Press <NEW BALANCE> to temporarily close the transaction. If you want to finalize a check immediately, use <CASH>, <CHARGE>, <CREDIT> or <CHECK>.

Adding to a check

Example

			OPERATION	RECEIPT
Check# Table#		1234 33	1 2 3 4 OLD 3 0 00 1	REG 03-04-2000 16:40 CO1 MC#01 000145 TABLE No.000033 CT 1
T. 1	Dept. 1	\$30.00	1 0 00 2	CHECK No.1234
Item 1	Quantity	1	Insert slip	ST •90.50
Item 2	Dept. 2	\$10.00	NB	1 DEPT01 •30.00 1 DEPT02 •10.00
	Quantity	1	Remove slip	+ •0.50 SRVC TL
			-	-131.00

- The table number is stored in the check tracking index memory so its input is not required in this operation even if table number input is preset as compulsory. Table number input after inputting the check number may be performed, however, without generating an error.
- Once a check is opened under a number in a certain mode (REG1 or REG2), the same mode must be used to make additions to the check.

Issuing a guest receipt

The following operation can be used to print out the balance of a temporarily finalized check. Example

OPERATION	RECEIPT	
1 2 3 4 GUEST Input the number of check you want.	REG 03-04-2000 16:45 CO1 MC#01 000146 TABLE No.000033 CT 1 CHECK No. 1 2:334 1 DEPT01 -10.00 1 DEPT01 -10.00 1 DEPT02 -20.00 1 DEPT02 -20.00 1 DEPT03 -30.00 + -0.50 1 1 DEPT02 -10.00 + -0.50 1 DEPT02 -10.00 + + -0.50 SRVC TL - 1.31.00 -	

Closing a check memory

Example



	03-0 No.000033 No. 1234	4-2000 MC#01	16:50 0001 CT	
#13	1 DEPTO1 1 DEPTO1 1 DEPTO2 1 DEPTO2 1 DEPTO3 + SRVC TL	. or	·10.00 ·10.00 ·20.00 ·20.00 ·30.00 ·0.50	
#17	1 DEPTO1 1 DEPTO2 +	- 70	-30.00 -10.00 -0.50	
#17	SRVC TL TL CASH CG	•131 •131		

New/old check key operation

Example 1

When a check number is input and <NEW/OLD> is pressed, the key works as a new check key function if there is no matching check number in the check tracking memory.



Example 2

When a check number is input and <NEW/OLD> is pressed, the key works as an old check key if there is matching check number in the check tracking memory.

OPERATION

3 4 5 6 NEW/ 3 1 00 CA/AMT TEND	REG 03-04-2000 17:00 CO1 MC#01 000149 CT 1 CHECK No. 3456
	ST •30.50 TL • 30.50 CASH •31.00 CG •0.50

RECEIPT

Add check

This operation lets you combine the amounts of more than one check into a single check.

Example

Registration for check number 1234

Original check					
Check# 1234					
Item 1	Dept. 1	\$10.00			
	Quantity	1			
Item 2	Dept. 2	\$20.00			
	Quantity	1			

OPERATION	RECEIPT			
2 3 4 CHEW 3 3 ^{TABLE} 1 0 00 1 2 0 00 2 NB	REG 03-04-2000 17:05 C01 MC#01 000150 CHECk No. 1234 TBL-# 000033 1 DEPT01 •10.00 1 DEPT02 •20.00 + •0.50 SRVC TL •30.50			

Registration for check number 3456

			OPERATION	RECEIPT
	Added che	eck	3 4 5 6	REG 03-04-2000 17:10
Check#		3456	3 0 00 1	C01 MC#01 000151 CHECK No.3456
Itana	Dept. 1	\$30.00		
Item	Quantity	1		1 DEPTO1 •30.00 + •0.50
			-	SRVC TL - 30.50

Registration for check number 1234

OPERATION RECEIPT OLD 3 2 REG 03-04-2000 17:15 Check No. : **C**01 MC#01 000152 Check No. : ADD CHECK 1234 3 4 5 6 3456 TABLE No.000033 CT 1 NB CHECK No. 1234 ST -30.50 ADD CHK 3456 •30.50 ST •0.50 ł SRVC TL -61.50

Separate check

This operation makes it possible to split a single check into separate checks.

Example



Clerk transfer

This operation lets you change the clerk who is in charge of a specific open check number.

Example

To change the clerk for check number 1234 from clerk 1 to clerk number 4.



Table transfer

With this operation, you can change the number of a check.

Example 1

To change the check number 1234 to 1111 (which is newly opened).



Example 2

To change the check number 3456 to 2222 (which has already been opened).



VAT breakdown printing

You can force printing of the VAT breakdown at the finalize stage, regardless of whether the cash register is programmed to print or skip printing of the VAT breakdown. Every time you want to have VAT breakdown, press <VAT>.

OPERATION

Example

Item 1	Dept. 1	\$1.00
	Taxable	1
Item 2	PLU 1	(\$2.00)
	Taxable	2
Payment	Cash	\$3.00

1 00 1	REG
2 PLU	C01
VAT CA/AMT TEND	1 DI 1 PI T(T) T

RECEIPT

REG	 2000 17:	:40
C01	‡01 ()00156
1 PI Ti Ti Ti Ti	 T1 T2	•1.00 •2.00 •0.90 •0.10 •1.90 •0.10 •0.10

Deposit registrations

Use the following procedures to register deposits.

Deposit from customer

OPERATION RECEIPT \$50.00 5 0 Deposit Cash REG 03-04-2000 17:45 **C**01 MC#01 000157 DEPO-.50.00 -50.00 TL CASH .50.00

Deposit from customer during sales transaction

		OPERATION RECEIPT			
Items	Dept. 1 Dept. 2	\$10.00 \$20.00	1 0 00 1 2 0 00 2	REG 03-04-2000 17:50 C01 MC#01 000158	
Deposit		\$20.00		1 DEPT01 •10.00 1 DEPT02 •20.00	
Payment	Cash	\$10.00	CA/AMT /TEND	DEPO+ -20.00 TL -10.00	
				CASH •10.00	

Bill copy

Example 1

To issue a copy of a bill dated February 1, 2000 in the amount of \$35.00 cash.



Note that you can finalize this operation using the cash amount tendered key.

Example 2

To issue a copy of a bill dated February 1, 2000 in the amount of Euro 30.00 cash (sub-currency).



Programming to clerk

You can program up to 4-digit assigning number (clerk number), trainee status of clerk (i.e. training cashier) and commission rate for each clerk.

Programming clerk number



Programming trainee status



Programming commission rate



				Trainee				Commission rate						
Record	Clerk number		status				ion rate			Commission rate 2				
No.					50	status	Inte	eger	Dec	imal	Integer		Decimal	
	D4	D3	D2	D1	D6	00000	D8	D7	D6	D5	D4	D3	D2	D1
1						00000								
2						00000								
3						00000								
4						00000								
5						00000								
6						00000								
7						00000								
8						00000								
9						00000								
10						00000								

Character programming can be performed in two ways:

- Character keyboard programming (see page 93), or
- Entering characters by code (see page 92).

Programming descriptors and messages

The following descriptors and messages can be programmed;

- Messages (Logo, commercial and bottom message)
- Clerk name
- PLU item descriptor
- Department key descriptor
- Machine number

Programming receipt message and clerk name



C10

Machine number

1007

Up to 8 characters can be set.

Clerk 10

Address code	Contents	Initial character				
Machine n	Machine number					
0191 Machine number		MC#01				

Address code	Contents	Initial character	Yours	
0132	1st line of logo message	YOUR RECEIPT		
0232	2nd line of logo message	THANK YOU		
0332	3rd line of logo message	CALL AGAIN		
0432	4th line of logo message			
0532	1st line of commercial message			
0632	2nd line of commercial message			
0732	3rd line of commercial message			
0832	4th line of commercial message			
0932	1st line of bottom message			
1032	2nd line of bottom message			
1132	3rd line of bottom message			
1232	4th line of bottom message			
1332	1st line of bill top message			
1432	2nd line of bill top message			
1532	3rd line of bill top message			
1632	4th line of bill top message			
1732	1st line of bill copy message			
1832	2nd line of bill copy message			
1932	3rd line of bill copy message			
2032	4th line of bill copy message			
2132	1st line of bill bottom message			
2232	2nd line of bill bottom message			
2332	3rd line of bill bottom message			
2432	4th line of bill bottom message			
2532	Post receipt message			
2632	1st line of guest intermediate msg.			
2732	2nd line of guest intermediate msg.			
2832	3rd line of guest intermediate msg.			
2932	4th line of guest intermediate msg.			
3032	1st line of guest bottom msg.			
3132	2nd line of guest bottom msg.			
3232	3rd line of guest bottom msg.			
3332	4th line of guest bottom msg.			
3432	5th line of guest bottom msg.			
3532	6th line of guest bottom msg.			
3632	7th line of guest bottom msg.			
3732	8th line of guest bottom msg.			
3832	9th line of guest bottom msg.			
3932	10th line of guest bottom msg.			

Programming department/transaction key descriptor

	To anothe	a uc	arti		1 41154	Cuo		y		٦		
	Characters	o" cc	→ tio	,	Depai Frans				\leq	 ➡	SUB TOTA]
de switch —	See "Entering character	s ^r se		ı. —								
Contents	Initial character						You	1400				
							100	IIS				
Department 01	DEPT01					_						
Department 02 Department 03	DEPT02					+		-+	\rightarrow			_
Department 03 Department 04	DEPT03							-+				-
Department 04 Department 05	DEPT04 DEPT05					+		-+				
				_								
Department 06 Department 07	DEPT06 DEPT07											_
Department 07	DEPTOR					-		_				_
	DEF100											
Contents	Initial character				Y	ours						
Cash/Amount tendered	CASH											
Charge	CHARGE											
Check	CHECK											
Credit 1	CREDIT1											
Credit 2	CREDIT2											
Loan	LOAN											
Received on account	RC											
Paid out	PD											
Pick up	P.UP											
Minus	****											
Discount	%-											
Refund	RF											
Correction	CORR											
Validation	VLD											
Receipt	RCT											
Non add/No sale	#/NS					_						
VAT	VAT							-+				
Tax shift 1	T/S1					_						
Tax shift 2	T/S2											
Open	OPEN	+++				_						
Clerk number	CLK#	++				_		_				
Subtotal	SUBTOTAL	++		_		_						
Receipt on/off	RCT ON/OFF	+++		_		-		_	_			
Multiplication/Date time	X	++				_						
Multiplication/for/Date time	QT	++				_						
Two zero	00	++		_		_						
Decimal point							1					
Media change	MEDIA CHG											

Programming flat-PLU descriptor



PLU No.	Contents	Initial character			Yours		 	
001	PLU 001	PLU0001						
002	PLU 002	PLU0002						
003	PLU 003	PLU0003						
004	PLU 004	PLU0004						
005	PLU 005	PLU0005						
006	PLU 006	PLU0006						
007	PLU 007	PLU0007						
008	PLU 008	PLU0008						
009	PLU 009	PLU0009						
010	PLU 010	PLU0010						
011	PLU 011	PLU0011						
012	PLU 012	PLU0012						
013	PLU 013	PLU0013						
014	PLU 014	PLU0014						
015	PLU 015	PLU0015						
016	PLU 016	PLU0016						
017	PLU 017	PLU0017						
018	PLU 018	PLU0018						
019	PLU 019	PLU0019						
020	PLU 020	PLU0020						
021	PLU 021	PLU0021						
022	PLU 022	PLU0022						
023	PLU 023	PLU0023						
024	PLU 024	PLU0024						
025	PLU 025	PLU0025						
026	PLU 026	PLU0026						
027	PLU 027	PLU0027						
028	PLU 028	PLU0028						
029	PLU 029	PLU0029						
100	PLU 106	PLUUIUo						_
107	PLU 107	PLU0107						
108	PLU 108	PLU0108						

Entering characters

In this section, the method to enter descriptors or messages (characters) to the cash register during programming is described.

Characters are specified by character keyboard or by codes. In the first half of this section, inputting method by character code is described. In the latter half, the usage of character keyboard is described.

Entering characters by code

Every time you enter a character, choose character codes by the character code list (below) and press the key to settle it. After you complete entering characters, press the **00** key to fix them.

Example:

Input "	A	Р	P	1	e		J	u	i	C	е		",
enter "	255 • 65 •	112 •	112	108 ·	101	32	74 ·	117 ·	105 ·	99 ·	101	00	,,

Character code list

Chara	Code	Chara	Code	Chara	Code	Chara	Code	Chara	Code	Chara	Code	Chara	Code
Space	32	0	48	â	64	р	80	``	96	Р	112	Ç	128
ļ	33	1	49	A	65	Q	81	a	97	q	113	ü	129
	34	2	50	В	66	R	82	Ь	98	r	114	é	130
#	35	3	51	С	67	S	83	С	99	s	115	â	131
\$	36	4	52	D	68	T	84	d	100	t	116	ä	132
%	37	5	53	E	69	U	85	е	101	u	117	à	133
å	38	6	54	F	70	V	86	f	102	v	118	a.	134
7	39	7	55	G	71	M	87	g	103	W	119	ç	135
(40	8	56	Н	72	X	88	h	104	X	120	ê	136
)	41	9	57	Ι	73	Y	89	i	105	y	121	ë	137
*	42		58	J	74	Ζ	90	j	106	z	122	·e	138
ł	43	;	59	К	75	Ľ	91	k	107	{	123	ï	139
7	44	<	60	L	76	١	92	1	108		124	î	140
	45	=	61	M	77]	93	m	109	}	125	'n	141
	46	\rangle	62	N	78	^	94	n	110	*	126	Ä	142
1 /	47	?	63	0	79		95		111		127	Å	143
1	47	!	05	U	19		95	0	111		127	н	145
7 Chara	47 Code	! Chara	Code	U Chara	Code	 Chara	Code	Chara	Code	Chara	Code	н Chara	Code
			1	I		 Chara L		· · · · ·	1	Chara Ó			
Chara	Code	Chara	Code	Chara	Code		Code	Chara	Code		Code	Chara	Code
Chara É	Code 144	Chara á	Code 160	Chara 	Code 176	L.	Code 192	Chara ð Ð	Code 208	Ó	Code 224	Chara 	Code 240
Chara É ₽	Code 144 145	Chara á i	Code 160 161	Chara ∷	Code 176 177	L L	Code 192 193	Chara 3 }	Code 208 209	Ó β	Code 224 225	Chara 	Code 240 241
Chara Ė ₽	Code 144 145 146	Chara á í	Code 160 161 162	Chara ∷	Code 176 177 178	L L T	Code 192 193 194	Chara ð Ð	Code 208 209 210	ό β ô	Code 224 225 226	Chara ±	Code 240 241 242
Chara É ∰ Ĝ Ö ò	Code 144 145 146 147	Chara á í ó ú	Code 160 161 162 163	Chara :: : : : : : : : : : : : :	Code 176 177 178 179	L L T	Code 192 193 194 195	Chara ð Ð Ê Ë È	Code 208 209 210 211	Ó β Ô	Code 224 225 226 227	Chara ± 	Code 240 241 242 243
Chara É ∰ Îft ô ö ù	Code 144 145 146 147 148	Chara á í ó ú ñ	Code 160 161 162 163 164	Chara	Code 176 177 178 179 180	L. 	Code 192 193 194 195 196	Chara ð Ĵ) Ê Ë È Í	Code 208 209 210 211 212	ό β ô ò ō	Code 224 225 226 227 228	Chara ± \}	Code 240 241 242 243 244
Chara É ∰ ft ô ô û û û	Code 144 145 146 147 148 149	Chara á í ó ú ñ	Code 160 161 162 163 164 165	Chara	Code 176 177 178 179 180 181	L 	Code 192 193 194 195 196 197	Chara ð Ð Ê Ë È Ê Î	Code 208 209 210 211 212 213	ό β ô ò ō ū μ	Code 224 225 226 227 228 229	Chara	Code 240 241 242 243 244 245
Chara É ∰ Îft ô ö ù	Code 144 145 146 147 148 149 150	Chara á í í ú í u ī N ª	Code 160 161 162 163 164 165 166	Chara	Code 176 177 178 179 180 181 182	L T T 	Code 192 193 194 195 196 197 198	Chara ð Đ Ê Ë Ê Î Î Î Î	Code 208 209 210 211 212 213 214	ό β ô ō ū μ	Code 224 225 226 227 228 229 230	Chara ± -	Code 240 241 242 243 244 245 246
Chara É ∰ ft ô ô û û û	Code 144 145 146 147 148 149 150 151	Chara á í ó ú ī ī N ª *	Code 160 161 162 163 164 165 166 167	Chara 	Code 176 177 178 179 180 181 182 183	L T 	Code 192 193 194 195 196 197 198 199	Chara ð Ð Ê Ë È Ê Î	Code 208 209 210 211 212 213 214 215	ό β ô ò ō ū μ	Code 224 225 226 227 228 229 230 231	Chara	Code 240 241 242 243 244 245 246 247
Chara É ft ô ô ù ù ù ÿ	Code 144 145 146 147 148 149 150 151 152	Chara á í ú ú ī ň	Code 160 161 162 163 164 165 166 166 167 168	Chara :: : : : : : : : : : : : :	Code 176 177 178 179 180 181 182 183 184	L 	Code 192 193 194 195 196 197 198 199 200	Chara ð Ĵ Ê Ë Ê Î Î Ĵ I J	Code 208 209 210 211 212 213 214 215 216	ό β ô ō ū μ Þ	Code 224 225 226 227 228 229 230 231 232	Chara	Code 240 241 242 243 244 245 246 247 248
Chara É e ft ô ô û û û û û û û û û û û û û û û û û	Code 144 145 146 147 148 149 150 151 152 153	Chara á í ú ū ⊼	Code 160 161 162 163 164 165 166 167 168 169	Chara :: : : : : : : : : : : : :	Code 176 177 178 179 180 181 182 183 184		Code 192 193 194 195 196 197 198 199 200 201	Chara ð Ĵ Ê Ë Ê Ê Î Î Ĵ J	Code 208 209 210 211 212 213 214 215 216 217	ό β ο ο ο ο ο ο μ Ϸ Φ Ο Ο Ο Ο	Code 224 225 226 227 228 229 230 231 232 233	Chara	Code 240 241 242 243 244 245 246 247 248 249
Chara É ₽ Îf Ô Ô Û Û Ŭ Ø f	Code 144 145 146 147 148 149 150 151 152 153 154	Chara á í ú ú ī ň	Code 160 161 162 163 164 165 166 167 168 169 170	Chara :: : : : : : : : : : : : :	Code 176 177 178 179 180 181 182 183 184 185 186		Code 192 193 194 195 196 197 198 199 200 201 202	Chara 3 D Ê Ë É Í Î I I I I I I I I I I I I I	Code 208 209 210 211 212 213 214 215 216 217 218	ό β ô ō ū μ Þ ¢	Code 224 225 226 227 228 229 230 231 232 233 234	Chara ± 	Code 240 241 242 243 244 245 246 247 248 249 250
Chara É ft ô ô ù ù ù ÿ Ü	Code 144 145 146 147 148 149 150 151 152 153 154 155	Chara á í ú ū ⊼	Code 160 161 162 163 164 165 166 167 168 169 170 170	Chara	Code 176 177 178 179 180 181 182 183 184 185 186 187		Code 192 193 194 195 196 197 198 199 200 201 202 202 203	Chara ð Ĵ Ê E E Î Î Î I I I I I I I I I I I I I	Code 208 209 210 211 212 213 214 215 216 217 218 219	ό β ο ο ο ο φ ν Ο ν ν γ	Code 224 225 226 227 228 229 230 231 232 233 234 235	Chara	Code 240 241 242 243 244 245 246 247 248 249 250 251
Chara É ₽ Îf Ô Ô Û Û Ŭ Ø f	Code 144 145 146 147 148 149 150 151 152 153 154 155 156	Chara á í ú í í í í í í í í í í í í í í í í í	Code 160 161 162 163 164 165 166 167 168 169 170 171 172	Chara	Code 176 177 178 179 180 181 182 183 184 185 186 187 188		Code 192 193 194 195 196 197 198 199 200 201 202 203 204	Chara 3 D Ê Ë É Í Î I I I I I I I I I I I I I	Code 208 209 210 211 212 213 214 215 216 217 218 219 220	ό β ô ō ū μ Þ ¢	Code 224 225 226 227 228 229 230 231 232 233 234 235 236	Chara ± 	Code 240 241 242 243 244 245 246 247 248 249 250 251 252

Using character keyboard

Example:

Input " 🏫 p p l e J u i c e enter "DBL""A" "SHIFT""p" "p" "l" "e" "SPACE" "CAP""J" "SHIFT""u" "i" "c" "e" 00

TK-6000



TK-6500

	-7													ā	3)
RECEIPT JOURN FEED FEED	u Û ĵ	Î 034	Ê 043	ç	Р 061р	Ø ‴	£ 079	× 088	Â 097	Ô 106 Ô				<	>
Á Ó 006 016	Ú	Í 033	Éé	Å ő	Ã 060	ÿ 069	a 078	0 087	096	i 105					
À ^à ^ò	Û ∞ů	Ì ⁰³²	È 041	Ææ	Ý 059 ý	068	ð 077	Ð 086 ^{1/2}	ß 1/4 095	± 104					
Ä 006 Ö 014	j Ü ∞2	Ї ₀₃₁	Ë 40	Ñ ⁰⁴⁹	Õ 058	≪¢ 067	≫ ¤ 076	€,	f - 094	ė 103					
1 2 005 013	2 3 ₀₂₁ #	4 030	5 %	6 ^ 048	7 057	8 066	9 (0)		= +	С				
Q W W	v E e ∞∞	R ⁰²⁹	T t	Y y	U u	I i	0 074	P 083 p	[092] 101	7	8	9		
	D d	F 128	G ⁰³⁷ g	H 046	J 055 j	К 064		; :	" " 091	` 100	4	5	6		
	018	V v	B ₀₃₆ b	N 045	M 054	, < 063	072	/ ?	1	• • ¥	1	2	3	#-	2
6 1 CAP SHIF 001 009	S)	026	035	044	053	062	071	080	_089	DBL 098	0	9) 00	0 (#-	1

1 Shift key

Pressing this key shifts the character from the uppercase letter to lower case letter and returns to the uppercase letter in sequence.

2 Left cursor key

This key is not used for this model.

③ Right cursor key

This key is not used for this model.

④ Double size letter key

Specifies that the next character you input to a double size character.

You must press this key before each double size character.

(5) Space key

Sets a space by depression.

6 CAP key

Shifts the character to the upper case letter.

(7) Alphabet keys

Used input to characters.

(8) Numeric keys

Used to enter program codes, memory number and character codes.

(9) Character fixed key

Enters when the alphabetic entry for a descriptor, name or message has been completed.

10 Backspace/Character code fixed key

Registers one character with code (2 or 3 digit). Clears the last input character, much like a back space key. (Does not clear the double size letter key entry.)

(1) Program end key

Terminates the character programming.

12 Character enter key

Registers the programmed characters.

Printing read/reset reports

• Daily sales read report ("X1" mode)

You can print read reports at any time during the business day without affecting the data stored in the cash register's memory.

• Daily sales reset report ("Z1" mode)

You should print reset reports at the end of the business day.

Important!

- The reset operation issues a report and also clears all sales data from the cash register's memory.
- Be sure to perform the reset operations at the end of each business day. Otherwise, you will not be able to distinguish between the sales data for different dates.

To print the individual department, PLU/flat-PLU read report

This report shows sales for specific departments or PLUs/flat-PLUs.



After you finish to select items, press sub to terminate.

To print the financial read report

This report shows gross sales, net sales, cash in drawer and check in drawer.



To print the individual clerk read/reset report

This report shows individual clerk totals.



*1 Money declaration:

Count how much cash is in the drawer and input this amount (up to 10 digits).

The cash register will automatically compare the input with the cash in drawer in the memory and print the difference between these two amounts.

Note that if money declaration is required by programming, you cannot skip this procedure.

TK-6000/6500 User's Manual

95

To print the daily sales read/reset report

This report shows sales except for PLUs.

OPERATION

REPORT



Ζ	BATCHO	1		— Report title
Z	FIX	(Fixed total report title/reset counter *4 Report code
DECLA EURO 1			∙0.00 €187.67	 Declared cash in drawer of main currency * Difference (= declared - accumulated) * Declared cash in drawer of sub currency *1 Difference (= declared - accumulated) *1
gross Net		-6	981.25 574.40	— Gross total *3
CAID CHID CKID CRID(-7 -6	,057.14 ,919.04 •139.04 •859.85	 Net total *3 Cash in drawer *3 Charge in drawer *3 Check in drawer *3 Credit in drawer *3
RF		٧o	 3 ∙10.22	— Refund mode *3
CUST AVRG DC REF CLEAR ROUND CANCEI		CT : Yo Yo	111 -63.57 -1.22 -2.42 85	 Customer number *3 Average sales per customer *3 Discount total *3 Refund key *3 Clear key count *3 Rounding total *3 Cancellation *3
TA1 TX1 TA2 TX2		•2	,369.69 •128.86 ,172.96 •217.33	 Tax 1 amount *3 Taxable 2 amount *3
GT1 GT2 GT3	-00000	00034	5478.96 6284.23 3212.75	 Grand total 1 *3 Grand total 2 *3 Grand total 3 *3
Z	trans		0001	- Function key report title/reset counter

	0001012-	 Report code
CASH	No 362	 Function key count/amount *2
	·1,638.04	- Function key count/amount
CH	No 56	
50	. •1,174.85	
RC	No 4	
PD	-810.00 No 5	
	-520-00	
	•5.00	
CORR	No 14	
VLD	No 19	
RCT NS	No 3 No 5	
Z DEPT	0001-	- Department report title/reset counter
	0001015-	– Report code
DEPTO1	38 -	 Department name/No. of items *2 Sales ratio/amount *2
8.13%	-257.53- 183	
	1.742 04	
TL	88.61 -	– Total No. of items
	-1,916.10-	 Total amount
Z CASHI	 rp	 Clerk report title/reset counter
Z CASHI	-ER 0001 0001017	 Report code
	0001011	Tupott Code
C 01		 Clerk name/drawer No.
GROSS	421.25	– Gross total
	·2,872.28	
NET		– Net total
CAID	•1,845.35 •1,057 14-	 Cash in drawer
CHID	-139.04	
RF	No 1	 Refund mode
	-1.00	- Keruna mode
CLEAR	No 5	 Clear key count
	-4.43	-
C 02	1	 Clerk name/drawer No.
		Clork hume/drawer 140.
Í		
1		

*1 Money declaration:

Count how much cash is in the drawer and input this amount (up to 10 digits).

The cash register will automatically compare the input with the cash in drawer in the memory and print the difference between these two amounts.

Note that if money declaration is required by programming, you cannot skip this procedure.

- ^{*2} Zero totalled departments/functions (the amount and item numbers are both zero) are not printed.
- ^{*3} These items can be skipped by programming.
- *4 The "*" symbol is printed on the reset report, memory overflow occurred in the counter/totalizer.

TK-6000/6500 User's Manual

To print the PLU/flat-PLU read/reset report

This report shows sales for PLUs.



To print the hourly sales read/reset report

This report shows hourly breakdowns of sales.



To print the monthly sales read/reset report

This report shows monthly breakdowns of sales.

OPERATION REPORT Х Read symbol/report title MONTHLY X1/Z1 0001020 Report code (read/reset) Mode switch Date of a month 1.. Gross symbol/No. of items GROSS 1236.76 .12,202.57 Gross sales amount Π NET 214 Net symbol/No. of customers No ·12,202.57 Net sales amount 31 GROSS 2132 14,187.57 NET No 205 .13,398.76 TL Total symbol 9746.63 GROSS Gross symbol/No. of items 161,022.49 Gross sales amount -16.52 Average daily gross sales

NET

No 2351

161,022.49

·68.49

To print the group read/reset report

This report shows PLU/subdepartment/department group totals.



Net symbol/No. of customers

Net sales amount

Average daily net sales

• Periodic sales read report ("X2" mode)

You can print read reports at any time during the business day without affecting the data stored in the cash register's memory.

• Periodic sales reset report ("Z2" mode)

You should print reset reports at the end of the business day.

To print the periodic 1/2 sales read/reset reports

These reports show sales breakdowns of sales by any two kinds of period you want.

OPERATION	REPORT
X2/Z2 (read/reset) Mode switch	CASH No 362 *1*638.04 CH No 56 *1*174.85 VLD 19 RCT No 3 NS No 5
ZZ1 BATCH02 — Report title	ZZ1 DEPT 0001 — Department report title/reset counter 00011115 — Report code
ZZ1 FIX 0001 - Fixed total ro 00011111 - Report code GR0SS 981.25 -67574.40 - Gross total *2	8.13% *257.53 + Sales ratio/amount * DEPT <u>02</u> 183
NET No 111 - 7,057.14 Net total *2 CAID •6,919.04 - Cash in draw CHID •139.04 - Charge in draw CHID •139.04 - Charge in draw Charge in draw CHID •09.85 - Credit in draw	awer $*^{2}$ wer $*^{2}$ $ZZ1 CASHIER 0001 - Clerk report title/reset counter 00011117 - Report code$
RF No 3 •10.22 CUST CT 111 - Customer nu	umber *2
AVRG •63.57 + Average sale DC •1.22 + Discount tota REF •2.42 + Refund key* CLEAR No ROUND •0.00 + Rounding tota	$\begin{array}{c c} \bullet 1,845.35 \\ \bullet 1,057.14 \\ \bullet 2 \\ \bullet 3 \\ \bullet 2 \\ \bullet 3 \\ \bullet$
CANCEL No 2 -12.97	•1.00 •1.00 CLEAR No 5 •4.43 Clear key count
TA1 •2,369.69 — Taxable 1 an TX1 •128.86 — Tax 1 amoun	nount *2
ZZ1 TRANS 0001 - Function key 00011112 - Report code	y report title/reset counter

^{*1} Zero totalled departments/functions (the amount and item numbers are both zero) are not printed.

^{*2} These items can be skipped by programming.

To print other sales read/reset reports

The following reports can be issued.

Procedure



Report/command code list

Report name	Command code	Report name	Command code
Fix totalizer *2	11	Department	15
Transaction key	12	best 50 (amount order)	60015
Subdepartment *1	13	best 50 (quantity order)	70015
PLU by record number (all)	14	Group	16
best 50 (amount order)	60014	Clerk *2	17
best 50 (quantity order)	70014	Hourly sales	19
menu (1st)	81	Monthly sales	20
menu (2nd) *1	82	Open check	25
menu (3rd) *1	83	Table analysis	28
menu (4th) ^{*1}	84	^{*1} Memory allocation is necessary.	
menu (5th) ^{*1}	85	*2 Input money in drawer, if the money dec	alration
menu (6th) *1	86	is compulsory.	

Reading the cash register's program

To print unit price/rate program (except PLU)



To print key descriptor, name, message program (except PLU)

OPERATION		REPO	RT
PGM Mode switch			
2 SUB TOTAL		FIX 0001-24 TRANS 0002-24 PLII 0003-24 0004-24	 Report header character
P02	– Program read symbol	BATCH 01 0001-29 BATCH 02 0002-29 BATCH 03 0003-29 0004-79	– Batch X/Z character
GROSS 0001-01 NET 0002-01 CAID 0003-01- CAIL 0004-01	– Fix total character	0001-32 YOUR RECEIPT 0002-32 THANK YOU	 Receipt message
CASH 0001-02 CHARGE 0002-02- CHECK 0003-02 0004-02	 Transaction key character 	0001-33 ***ENDORSE MESSAGE***** *******************************	 Check endorsement message
SUBDEPT01 UUUT-U3 SUBDEPT02 0002-03- SUBDEPT03 0003-03 0004-07 0001-05	– Subdepartment character	0001-34 ***SLIP MESSAGE******* *****************************	 Slip/external printer message
DEPT01 0001-05 DEPT02 0002-05- DEPT03 0003-05 0004-05 GROUP01 0001-06	– Department character	0001-39 CHARACTER RECALL***********************************	– Recall character
GROUPO2 0002-06- GROUPO3 0003-06 0004-04 C01 0001-07	— Group character	0002-39 ORDER01 0001-65 ORDER02 0002-65- ORDEP03 0003-65	– Order character
C02 0002-07- C03 0003-07 TBL01 0001-18 TBL02 0002-18-	 Clerk character Table character 	ORDEPOIS 0003-65 MC#01 0001-91 MC#02 0002-91- MC#03 0003-91	 Terminal connection table character
TBL 03 0003-18 0004-10 0001-20 GT1 0001-20 GT2 0002-20 GT3 0003-20		0001–96 AT COMMAND***********************************	– AT command
• @No⁄ ** € 0001-23 NoCT@ LB *QT 0002-23- X BUSY 0003-23	– Special character	0002-96 ATA ATI4 - PASSWORD 0001-97	– Online password

To print the PLU/flat-PLU program



This section describes what to do when you have problems with operation.

When an error occurs

Errors are indicated by an error codes. When this happens, you can usually find out what the problem is as shown below.

Press **C** and check the appropriate section of this manual for the operation you want to perform.

Error code	Meaning	Action
E001	Mode switch position changed before finalization.	Return the mode switch to its original setting and finalize the operation
E003	Clerk button pressed before finalization of a registration being performed under another clerk button.	Press the original clerk button and finalize the transaction before pressing another clerk button.
	check registration.	Input correct check number or assign the proper clerk number.
E004	Initialization or unit lock clear operation in progress.	Complete operation.
E005	Memory allocation exceeds total memory capacity.	Reallocate memory or expand memory (if possible).
E008	Registration without entering a clerk number.	Enter a clerk number.
E009	Operation without entering the password.	Enter password.
E010	The drawer is left open longer than the program time (drawer open alarm).	Close the drawer.
E011	Attempt to register while the cash drawer is open.	Shut the cash drawer.
E013	Journal paper near end. (option)	Replace the journal paper.
E015	Printer error	
E016	Two consecutive transactions attempted in the refund mode.	Switch to another mode and then back to the RF mode for the next transaction.
E017	Attempt made to register an item without inputting a check number.	Input a check number.
E018		Input a table number.
E019	Finalize operation attemped without entering the number of customer.	Enter the number of customer.
E021	No department linked PLU is registered.	Correct the program.
E023	Actual stock quantity becomes less than the minimum stock quantity.	Perform stock maintenance.
E024	Actual stock quantity becomes/is negative.	Perform stock maintenance.
E026	No condiment/preparation PLU is registered.	Register condiment/preparation PLU.
E029	Item registration is prohibited, while partial tender.	Finalize the transaction.
E030	Finalization of a transaction attempted without registering rate-tax.	Register <rate tax="">.</rate>
E031	Finalization of a transaction attempted without confirming the subtotal.	Press <subtotal>.</subtotal>
E032	Finalization of a transaction attmempted without confirming of the food stamp subtotal.	Press <fs st="">.</fs>
E033	Finalize operation attempted without entering amount tender.	Enter the amount tendered.
E035	Change amount exceeds preset limit.	Input amount tendered again.
E036	Contents of the drawer exceed programmed limit.	Perform pick up operation.
E037	High amount lock out/low digit lock out error	Enter correct amount.
E038	Read/reset operation without declaring cash in drawer. This error appears only when this function is activated.	Perform money declaration.
E040	Attempt to register a new transaction without issuing a guest receipt.	Issue a guest receipt.
E041	Attempt to register a new transaction without validation.	Perform validation operation.
E044	Attempt to register a new transaction without printing check.	Perform check print.
E045	Attempt to register a new transaction without printing check endorsement.	Perform check endorsement.
E046	Registration buffer full.	Finalize the transaction.
E047	Separate check buffer full. Attempt to register a new transaction without printing slip.	Allocate sufficient separate check buffer.
E047 E048		Perform slip printing operation. Insert new slip paper.
		Finalize and close the check number currently used.
E049	6 7	5
E050 E051	Check tracking detail memory full. Attempt to made use <new check=""> to open a new check using a number that is already used for an existing check in check</new>	Finalize and close the check number currently used. Finalize and close the check that is currently under the number that yo want to use or use a different check number.
	tracking memory. Attempt made to use <old check=""> reopen a new check using a</old>	Use the correct check number (if you want to reopen a check that already exi
E053	number that is not used for an existing check in check tracking memory.	in check tracking memory) or use <new check=""> to open a new check.</new>

Error code	Meaning	Action
E055	Normal registration is prohibited during separate check operation.	Terminate separate check operation.
E059	Attempt to finalize a transaction without specifying <eat-in> or <takeout>.</takeout></eat-in>	Press <eat-in> or <takeout>.</takeout></eat-in>
E060	External printer offline	
E061	External printer went down.	
E062	External printer paper end	Replace new paper.
E063	External printer is now printing.	
E064	Printing buffer full	
E066	Attept to print the last separated transaction on slip.	Print from the beginning of the transaction.
E075	Attempt to finalize a transaction when balance is less than or equal to zero.	Register item(s) until the balance becomes positive amount.
E085	Data exists in the consolidation file.	Clear the data.
E100	Prohibit master operation.	Perform it at master terminal.
E121	Network startup error.	
E139	Attempt to register <-> or <cpn> when the balance becomes negative.</cpn>	Enter proper minus/coupon amount.
E146	Arrangement file is full.	Set the arrangement properly.
E200	No memory cassette is set.	Set memory cassette.
E202	Can not read, because no designated file is in the memory cassette or nternal flash memory.	Check the operation and retry.
E203	Insufficient memory in the memory cassette or internal flash memory.	Use a vacant (formatted) memory cassette.
E204	Write protect switch of the memory cassette is on.	Check the write protect switch.
E205	Can not write, because designated file has already been in the memory cassette or internal flash memory.	Ceheck the operation and retry.

In case of power failure

If the power supply to the cash register is cut by a power failure or any other reason, simply wait for power to be restored. The details of any on-going transaction as well as all sales data in memory are protected by the memory backup batteries.

- Power failure during a registration The subtotal for items registered up to the power failure is retained in memory. You will be able to continue with the registration when power is restored.
- Power failure during printing a read/reset report The data already printed before the power failure is retained in memory. You will be able to issue a report when power is restored.
- Power failure during printing of a receipt and the journal Printing will resume after power is restored. A line that was being printed when the power failure occurred is printed in full.
- Other

The power failure symbol is printed and any item that was being printed when the power failure occurred is reprinted in full.

The memory protection battery is constantly charging and discharging as you switch the cash register on and off during normal operations. This causes the capacity of the battery to decrease after approximately five years of use.

Important !

- Remember ... a weak battery has the potential of losing valuable transaction data.
- A label on the back of the cash register shows the normal service period of the battery installed in your cash register.
- Have the battery replaced by your dealer within the period noted on this label.

Clearing a machine lock up

If you make a mistake in operation, the cash register may lock up to avoid damage to programs and preset data. Should it happens, you can use the following procedure to clear the lock up without losing any data.

- 1 Power off the register.
- 2 Insert the PGM key in the mode switch.
- 3 Press down FEED, and turn the mode switch to PGM mode.
- 4 The display shows ten Fs, then release **FEED**.
- 5 Press ^{SUB}. The display shows ten Fs and issue a receipt.

Important!

• If the register does not show ten Fs, never press with and call service representative.

When the register does not operate at all

Perform the following check whenever the cash register enter an error condition as soon as you switch it on. The results of this check are required by service personnel, so be sure to perform this check before you contact a CASIO representative for servicing.



To replace the ink ribbon



Open the printer cover.



4

Load a new ink ribbon cassette into the unit.



Turn the knob on the right side of the cassette to take up any slack in the ribbon.

Knob



Pull up the knob of the ribbon cassette.

Remove the printer sub

cover.

Replace the printer cover and printer sub cover.

Important!

Use only the ERC-32(P) ribbon (purple). Other types of ink ribbons can damage the printer. Never try to extend the life of an ink ribbon by replenishing the ink. Once an ink ribbon is in place, press <#/NS> or <NS> to test for correct operation.

To replace journal paper

REG2 X1 REG1 -↓ ∠Z1 X2/Z2 OFF RF PGM



Set the mode switch to the REG1 position and remove the printer cover.



Press WURNAL to feed about 20 cm of paper.



Cut the journal paper as shown in the photograph.



Cut the journal paper at the point where nothing is printed.



Press **JOURNAL** to feed the remaining paper from the printer.



Remove the journal take-up reel from its holder.









Do not pull the paper out of the printer by hand. It can damage the printer.



Remove the old paper roll from the cash register.



Load new paper as described on page 10 of this manual.









To replace receipt paper

Follow step

under "To replace journal paper" on the previous page.





Cut the receipt paper as shown in the photograph.



Press **TEEP** to feed the remaining paper from the printer.





Do not pull the paper out of the printer by hand. It can damage the printer.



Remove the old paper roll from the cash register.



Load new paper as described on page 11 of this manual.

To replenish the stamp ink



under "To replace journal paper" on the previous page.





Remove the stamp pad from its holder by lifting the knob.



Squirt one or two drops of ink into the holes on the back of the stamp pad.



Replace the stamp pad on its holder.

Options

Wetproof cover:

Memory chip: Memory cassette: C-NET card: WT-78, WT-79 (For TK-6000) RAM-610-10LL RAC-9 I/O-PB-14 Slip printer: Cable: External printer: Cable: Power supply: SP-1300 PRT-CB-8C UP-350, UP-250 PRT-CB-8A or PRT-CB-8B PS-170 and AC-170

Consult with your CASIO dealer for details.

Input method						
Entry:	10-key system, buffer memory 8 keys (2-key roll over)					
Department:	Full key system					
Display						
	Amount 10 digits (zero suppression); department No., PLU No., No. of repeats, total, change,					
	receipt on/off, transaction indicator					
Printer						
Receipt:	Dot matrix alpha-numeric system 24 digits, receipt on/off switch (key)					
_	Store name or slogan is printed automatically					
Logo stamp:	$20 (H) \times 30 (W) mm$					
Journal:	Dot matrix alpha-numeric system 24 digits					
	Automatic take up roll winding					
X7-1 , 1-4,	Journal paper near end sensor (option)					
Validation:	55 digits, one line, for 135 mm (minimum) wide slip					
Paper roll:	$45 (W) \times 83 (D) mm$					
Paper feed:	Separate for receipt and journal 3.0 l/s					
Print speed:	5.0 1/8					
Listing capacity	0000000					
Amount:	99999999					
Quantity: Tendered amount:	9999.999 9999999999					
Percent:	9999999999					
Tax rate:	9999.9999					
Numbers:	9999999999999999999					
Chronological data	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
Date print:	Automatic date printout on receipt or journal, automatic calendar					
Time print:	Automatic time printout on receipt or journal, 24-hour system/12-hour system					
Alarm	Futomatic time printout on receipt of journal, 2 + nour of scene 12 nour of steen					
	Key catch tone, error alarm, sentinel alarm					
Memory protection batt						
V L	48-hour full charge protects memories for approximately 90 days.					
	Battery should be replaced every five years.					
Power supply/power con						
	See the rating plate.					
Operation temperature						
	$0^{\circ}C \sim 40^{\circ}C (32^{\circ}F \sim 104^{\circ}F)$					
Humiditiy						
	10 ~ 90%					
Demensions and weight						
	454mm (H) × 345 mm (W) × 218 mm (D) /6.5kg					
	$17_{7/8.}$ " (H) × $13_{9/16}$ " (W) × $8_{9/16}$ " (D)/14lbs. 5oz. without drawer					

Totalizers		Contents				
Category	No. of totalizers	Amount (10 digits)	No. of items (6 integer/ 3 decimal)	Count (4 digits)	No. of customers (6 digits)	Periodic totalizers
Department	Up to 10	~	 ✓ 			~
PLU	Up to 108	~	 ✓ 			
Clerk	10	~	 ✓ 	~		~
Hourly sales	24	~			 ✓ 	
Monthly sales	31	~	 ✓ 		 ✓ 	
Transaction	Variable with program		v			
Non ressettable grand total	3	(16 digits)				
Reset counter	12			~		
Consecutive No.	1			(6 digits)		

* Specifications and design are subject to change without notice.

Α

add check 24, 82 adding to a check 79 addition (+) 56 alphabet key 93 arrangement 24, 61 assigning a clerk 30

В

backspace key 93 bill copy 24, 86 bottle link 60 bottle return 24, 60 bottom message 28, 88

С

cancel 21, 22, 24, 52 cash/amount tendered 21, 43 change 32 character code 92 character code fixed key 93 character enter key 93 character fixed key 93 character keyboard 93 charge 21, 23 check 21, 43 check endorsement 24 check print 24 check tracking 78 clearing a machine lock up 106 clerk button 17, 30 clerk interrupt 54 clerk key/button/lock 16, 30 clerk lock 17, 30 clerk name 30, 88 clerk number 20, 22, 87 clerk read/reset report 95 clerk secret number key 17, 30 clerk transfer 24, 84 closing a check 80 commercial message 28, 88 commission rate 87 consecutive No. 28 correction 50 coupon 24, 58 coupon II (2) 24, 58 credit 21, 23, 43 cube 24 currency exchange 24, 62 customer display 18 customer number 24

D

daily sales read/reset report 96 daily sales reset report 53 date display 31 date set 12 declaration 24 department 21, 23, 32 deposit 24, 85 descriptor 88 discount 20, 22, 40 display 18 double size letter key 93 drawer 17

E

eat-in 24 EBT (electronic benefits transfer) 24, 73 entering character 92 error code 104 error correction 21, 22, 51 Euro 21, 44

F

financial read report 95 flat PLU 21, 22, 32 food stamp 64 food stamp shift 24, 64 food stamp subtotal 24, 64 food stamp tender 24, 64

G

group read/reset report 99 guest receipt 80

Н

high amount limitation 34 hourly sales read/reset report 98

I

Illinois rule 67 indicator 19 individual clerk read/reset report 95 individual department, PLU/flat-PLU read report 94 ink ribbon 14, 107 item counter 28

J

journal 10, 28, 108 journal skip 28

Κ

Ketten Bon 24 keyboard (TK-6000) 20 keyboard (TK-6500) 22

L

left cursor key 93 loan 20, 22, 49 logo message 28, 88

Μ

machine No. 28 main display 18 manual tax 24 media change 49 menu shift 24 merchandise subtotal 24, 39 message 28, 88 minus 20, 22, 41 mixed tender 43 mode key 15 mode switch 16 money declaration 95, 97 monthly sales read/reset report 99 multiplication 21, 33, 37 multiplication/for 21, 23, 33

Ν

new balance 24, 79 new check 24, 79 new/old check 24, 81 no sale 20, 22, 24, 52 non add 20, 23, 24 normal receipt 25 number of customers 75

0

old check 25, 79 open 20 open check 25 open II (2) 25, 76 open PLU 38 opening a check 79 operator number 25, 84 operator X/Z 25 option 109

Ρ

paid out 21, 23, 48 paper feed 20, 22 periodic sales 100 pick up 20, 22, 49 PLU 36 PLU/flat-PLU read/reset report 98 plus 25 post receipt 20, 22 power failure 105 premium (%+) 25, 56 preset price 35 preset tax status 35 preset tender 59 previous balance 25 previous balance subtotal 25 price 25, 38 price inquiry 25 printing slip 77 program end key 93

R

rate tax 25 read report 94 recall 25 receipt 11, 28, 109 receipt on/off 20, 22 receipt on/off switch / key 14 received on account 21, 23, 48 reduction (-) 41 refund 20, 22, 47 repeat 19, 32, 37 reset report 53, 94 return 47 review 25, 83 RF mode 47 right cursor key 93 roll paper 14

S

separate check 25, 83 set menu 61 shift key 93 sign off 30 sign on 30 single item 32, 37, 55 slip 77 slip back feed/release 25, 77 slip feed/release 25, 77 slip print 25, 77 space key 93 split sales of packaged item 33, 38 square 25 stamp ink 109 store 25 subtotal 21

Index

Т

table number 25, 82 table transfer 25, 84 takeout 25 tax exempt 25 tax shift 20, 22, 39 taxable amount subtotal 25 text print 25 text recall 25, 76 time display 31 time set 12 tip 25, 74 trainee status 87 tray total 25, 57

V

validation 20, 22, 46 VAT 20, 85 void 25

W

wetproof cover 15, 109

CASIO.

CASIO COMPUTER CO., LTD. 6-2, Hon-machi 1-chome Shibuya-ku, Tokyo 151-8543, Japan

SA0002-A

TK-6000*E