



hp LaserJet 4345mfp



service



HP LaserJet 4345mfp Series

Service Manual



Copyright and License

© 2004 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained in this document is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number Q3942-90950

Edition 1, 11/2004

Trademark Credits

Java™ is a US trademark of Sun Microsystems, Inc.

Linux is a U.S. registered trademark of Linus Torvalds.

Microsoft®, Windows®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

PostScript® is a trademark of Adobe Systems Incorporated.

ENERGY STAR® and the ENERGY STAR logo® are U.S. registered marks of the United States Environmental Protection Agency.



Table of contents

1 Product information

HP LaserJet 4345mfp configurations.....	2
HP LaserJet 4345mfp (Q3942A—base model).....	2
HP LaserJet 4345x mfp (Q3943A).....	2
HP LaserJet 4345xs mfp (Q3944A).....	3
HP LaserJet 4345xm mfp (Q3945A).....	3
Features and benefits of the MFP.....	4
Functions.....	4
Speed and throughput.....	4
Resolution.....	4
Memory.....	4
User interface.....	5
Language and fonts	5
Copying and sending.....	5
Print cartridge.....	5
Paper-handling	6
Connectivity.....	6
Environmental features.....	6
Security features.....	7
Minimum system requirements for e-mail functionality.....	7
MFP parts and accessories.....	8
MFP parts.....	8
Interface ports.....	10
Model and serial numbers.....	10
Accessories and supplies.....	11
Parts compatibility with other HP LaserJet products.....	12
Moving the MFP.....	14
Locking and unlocking optional accessories.....	14
Site requirements.....	15
Physical specifications.....	15
Environmental specifications.....	16
MFP specifications.....	17
Electrical specifications.....	17
Acoustic specifications.....	18
Image area.....	18
Skew specifications.....	18
Media specifications.....	19
Printing and paper-storage environment.....	19
Envelopes.....	20
Envelopes that have double side seams.....	21

Envelopes that have adhesive strips or flaps.....	21
Envelope margins.....	21
Envelope storage.....	21
Labels.....	22
Label construction.....	22
Transparencies.....	22
Supported types and sizes of print media.....	23
Regulatory information.....	28
FCC and Telecom regulations.....	28
FCC regulations.....	28
Telecom.....	28
Environmental Product Stewardship program.....	29
Protecting the environment.....	29
Ozone production.....	29
Energy consumption.....	29
HP LaserJet printing supplies.....	29
Material safety data sheet.....	30
For more information.....	31
Country-/region-specific safety statements.....	32
Laser safety statement.....	32
Canadian DOC statement.....	32
Japanese VCCI statement.....	32
Korean EMI statement.....	32
Finnish laser statement.....	33
Australia.....	33
Declaration of conformity (HP LaserJet 4345mfp).....	34
Declaration of conformity (HP LaserJet 4345x mfp, 4345xs mfp, and 4345xm mfp).....	35

2 Service approach

Service approach.....	38
Ordering parts, accessories, and supplies.....	39
Ordering directly from HP.....	39
Ordering directly through the embedded Web server (for MFPs that are connected to a network).....	39
To order directly through the embedded Web server.....	39
Ordering directly through the HP Toolbox software (for MFPs that are directly connected to a computer).....	39
Hewlett-Packard Limited Warranty Statement.....	40
Print Cartridge Limited Warranty Statement.....	41
Availability of support and service.....	42
HP maintenance agreements.....	42
Priority Onsite Service.....	42
Next business day.....	42
Installation and maintenance-kit replacement.....	42

3 Installation and configuration

Installation checklist.....	44
Connecting to a computer or network.....	46
Network connection.....	46
Parallel connection.....	46

Fax connection.....	47
Analog faxing.....	47
Connecting the fax accessory to a phone line.....	47
Configuring and using the fax features.....	47
Digital faxing.....	48
Optional output and input devices.....	49
Security features.....	50
Securing the embedded Web server.....	50
To secure the embedded Web server.....	50
Foreign Interface Harness (FIH).....	50
Requirements.....	50
Using the FIH.....	50
To enable the FIH portal.....	50
To disable the FIH portal	51
Secure Disk Erase.....	51
Data affected.....	52
Gaining access to Secure Disk Erase.....	52
Additional Information.....	52
Job-storage features.....	52
HP DSS authentication.....	52
Locking the control-panel menus.....	52
Locking the formatter cage.....	53

4 Maintenance

Cleaning the MFP.....	56
Cleaning the outside of the MFP.....	56
Cleaning the touchscreen.....	56
Cleaning the scanner glass.....	56
Cleaning the fuser	56
Running the cleaning page	57
To run the cleaning page.....	57
Cleaning the ADF delivery system.....	58
To clean the ADF delivery system.....	58
To clean the ADF rollers.....	59
Calibrating the scanner.....	62
To print the calibration target.....	62
Performing preventive maintenance.....	63
Printer preventive maintenance	63
To reset the maintenance-kit counter.....	63
The ADF maintenance kit.....	64
Managing the print cartridge.....	65
HP print cartridges.....	65
Non-HP print cartridges.....	65
Print-cartridge authentication.....	65
Print-cartridge storage.....	65
Print-cartridge life expectancy.....	65
Checking the supply level.....	66
To check the supply level by using the control panel.....	66
To check the supply level by using the embedded Web server.....	66
To check the supply level by using the HP Toolbox software.....	66

To check the supply levels by using HP Web Jetadmin.....	66
Cartridge-low and cartridge-out conditions.....	66
When the cartridge is low on toner or drum life.....	66
When the cartridge is out of toner or drum life.....	67
Setting the real-time clock.....	68
Setting the date and time.....	68
To set the date format.....	68
To set the date.....	68
To set the time format.....	68
To set the time.....	69
Setting the wake time.....	69
To set the wake time.....	69
Setting the sleep delay.....	70
To set the sleep delay.....	70
Configuring and verifying an IP address.....	71
TCP/IP assignment.....	71
Automatic discovery.....	71
Dynamic host configuration protocol (DHCP).....	71
Verifying the TCP/IP configuration.....	71
Changing an IP address.....	71
To change an IP address by using HP Web Jetadmin.....	71
To change an IP address by using the embedded Web server.....	72
To change an IP address by using the control panel.....	72
Upgrading the firmware.....	73
Determining the current level of firmware.....	73
Downloading the new firmware from the HP Web site.....	73
Transferring the new firmware to the MFP.....	73
Using FTP to upgrade the firmware on a network connection.....	73
To upgrade the firmware on a network connection by using FTP.....	74
Using HP Web Jetadmin to upgrade the firmware.....	75
Using MS-DOS commands to upgrade the firmware.....	75
Upgrading the HP Jetdirect firmware.....	76

5 Theory of operation

Basic operation.....	78
Sequence of operation (printer).....	78
Sequence of operation (scanner).....	79
Formatter system.....	80
Sleep mode.....	80
Resolution Enhancement technology (REt).....	80
EconoMode.....	81
Input/output.....	81
CPU.....	81
Memory.....	81
Hard disk.....	81
Random-access memory.....	81
DIMM slots.....	81
Flash memory.....	82
Firmware flash memory card.....	82
Nonvolatile memory.....	82

HP Memory Enhancement technology.....	82
PJL overview.....	82
PML.....	82
Control panel.....	82
Scanner interface.....	83
Engine-control system.....	84
DC controller PCA.....	84
Motors and fans.....	86
Motor and fan functions.....	86
Ambient-temperature detection.....	87
Engine power supply circuit.....	87
Fuser control.....	88
Fuser over-temperature protection.....	89
High-voltage power supply.....	91
Low-voltage power supply	92
Overcurrent/overvoltage protection.....	94
Toner detection.....	94
Cartridge detection.....	94
Laser/scanner system.....	95
Laser/scanner control.....	96
Image-formation system.....	98
Print cartridge.....	99
Cartridge memory.....	99
Image-formation process.....	100
Pickup, feed, and delivery system.....	102
Pickup-and-feed block.....	105
Printing from tray 1.....	106
Printing from tray 2.....	107
Media-size detection.....	108
Cassette media-size detection.....	108
Media-length detection.....	108
Media-width detection.....	108
Cassette pickup operation.....	108
Lifter-driver operation.....	110
Multifeed prevention.....	110
Distance-between-pages adjustment.....	111
Media-skew prevention.....	112
Feed-speed control.....	114
Fusing and reversing/delivery block.....	115
Fusing.....	115
Face-down delivery.....	115
Face-up delivery.....	116
Jam detection.....	118
Pickup delay jam from tray 1.....	118
Pickup delay jam from tray 2.....	118
Pickup stationary jam.....	118
Fuser-delivery delay jam.....	119
Fuser wrapping jam.....	119
Fuser-delivery stationary jam when feeding regular-size media.....	119
Fuser-delivery stationary jam when feeding custom-size media.....	119

Reversing delay jam (face-down delivery only).....	119
Reversing stationary jam (face-down delivery only).....	120
Delivery delay jam during face-down delivery.....	120
Delivery delay jam during face-up delivery.....	120
Delivery stationary jam during face-down delivery.....	120
Delivery stationary jam during face-up delivery.....	120
Door-open jam.....	120
Residual-media jam.....	121
Printing from the 500-sheet feeder.....	122
500-sheet feeder pickup and feeding.....	123
Duplex-printing unit.....	125
Reversing/duplexing pickup.....	125
Duplex printing jam detection.....	126
Duplex-unit-pickup delay jam.....	127
Duplex-unit stationary jam.....	127
Duplex-unit delay jam.....	127
3-bin mailbox feed and delivery system.....	128
Stacker mode.....	130
Mailbox mode.....	130
Function-separator mode.....	130
Jam detection.....	130
Feed-delay jam.....	130
Feed-stationary jam.....	131
Residual-media jam.....	131
Stapler/stacker feed and delivery system.....	132
Staple mode.....	134
Stacker mode.....	134
Staple-jam detection.....	134
Feed-delay jam.....	134
Feed-stationary jam.....	135
Delivery-stationary jam.....	135
Residual-media jam.....	135
Stapler unit.....	135
Scanner system.....	137
Electrical system.....	137
Motors and fans.....	139
Optical assembly.....	139
ADF feed system.....	141
Jam detection.....	141
Residual-media jam.....	141
ADF pickup jam.....	142
ADF jam.....	142
Registration sensor jam.....	142
Read sensor jam.....	142
Exit sensor jam.....	142
ADF cover open jam.....	142
ADF open jam.....	142
6 Removal and replacement	
Removal and replacement strategy.....	144

Required tools.....	144
Before performing service.....	145
After completing service.....	145
Screws that are used in the MFP.....	146
User-replaceable parts.....	147
Print cartridge.....	148
Control-panel overlays.....	148
Control panel.....	149
Transfer roller.....	150
ADF input tray.....	151
ADF pickup and feed rollers.....	153
ADF separation pad.....	154
ADF delivery guide (clear mylar sheet).....	155
Output-bin assembly.....	157
Duplex-printing unit.....	158
Fuser-entrance guide.....	159
Fuser.....	160
Tray 2, 3, 4, or 5 pickup and feed rollers.....	161
Tray 1 pickup roller.....	162
Scanner filter cover and scanner filter.....	163
ADF-hinge flap.....	164
Formatter cover and formatter.....	166
Hard drive.....	168
DIMMs.....	170
Flash memory card (firmware).....	171
Fax accessory.....	172
Covers, doors, and external panels.....	173
Top-cover flatbed flange.....	174
Front cover.....	175
Back cover.....	179
Internal assemblies.....	181
Reversing-separation-guide assembly	182
Reversing assembly.....	183
Main fan (FN101) and reversing-unit fan (FN103).....	188
Thermistor (TH3).....	193
Tray 2 jam-access-cover switch (SW105).....	195
Tray 1 assembly.....	197
Front-cover support.....	200
Tray 1 feed-assembly.....	201
Feed-roller assembly.....	208
DC controller.....	211
Main motor (M101).....	214
DC controller fan (FN104).....	215
Print-cartridge fan (FN102).....	217
Print-cartridge motor (M102).....	219
Top-cover switch (SW101).....	221
Registration assembly.....	223
Paper-pickup-drive assembly	227
Lifter-drive assembly.....	231
Power-factor-correction (PFC) power supply.....	234

Engine power supply.....	239
Paper-feed assembly.....	245
Tray 2 detection switch.....	247
Paper-size-detection switch (SW102).....	248
Tray 2 paper-present sensor (PS101).....	249
Laser/scanner.....	250
Output-bin-full sensor.....	252
ADF and scanner components.....	254
ADF assembly.....	254
Scanner assembly.....	256
Scanner glass.....	261
Optical unit.....	264
Scanner bulb.....	268
Inverter PCA.....	270
Scanner fan.....	271
Scanner home-position sensor.....	272
Scanner-controller PCA.....	274
ADF components.....	275
ADF output-bin extension.....	276
ADF white mylar-backing.....	278
ADF front cover.....	280
ADF rear cover	281
ADF left-side cover.....	282
ADF jam-access cover and latch.....	284
ADF leading-edge and paper-present sensors.....	286
ADF hinges.....	287
500-sheet feeder components.....	289
500-sheet-feeder pickup and feed rollers.....	289
500-sheet-feeder rear cover.....	290
500-sheet-feeder right cover.....	291
500-sheet-feeder front cover.....	292
500-sheet-feeder upper-left cover.....	294
500-sheet-feeder left-side cover.....	295
500-sheet-feeder number-plate assembly.....	296
500-sheet-cassette front cover.....	297
500-sheet-feeder PCA.....	298
500-sheet-feeder lifter-drive assembly.....	299
500-sheet-feeder paper-size switch.....	300
500-sheet-feeder jam-access-cover-open switch.....	302

7 Troubleshooting

Troubleshooting process.....	304
Initial troubleshooting checklist.....	304
Troubleshooting checklist.....	304
Troubleshooting flowchart.....	306
Power-on checks.....	308
Power-on troubleshooting overview.....	308
Control-panel messages.....	310
Using the MFP help system.....	310
Resolving control-panel messages.....	310

Accessory lights for the 3-bin mailbox and stapler/stacker.....	332
Accessory lights	332
Formatter lights.....	333
Copy-board LED.....	333
HP Jetdirect LEDs.....	333
Heartbeat LED.....	334
Fax LED.....	334
Jams.....	335
Clearing jams from the top-cover and print-cartridge areas.....	337
Clearing jams from the optional envelope-feeder area.....	339
Clearing jams from the tray 1 area.....	341
Clearing jams from the tray 2, 3, 4, or 5 areas.....	343
Clearing jams from the optional duplexer.....	345
Clearing jams from the output areas.....	347
Clearing jams from the fuser.....	349
To clear jams from the fuser.....	349
Clearing jams from the ADF.....	353
Clearing staple jams.....	354
Solving repeated jams.....	356
Causes of persistent jams.....	357
Jams in the top-cover and print-cartridge area.....	357
Jams in the envelope-feeder area and the tray 1 area.....	358
Jams in the tray 2 area and the optional 500-sheet feeder areas.....	358
Jams in the duplexing area.....	359
Jams in the output area.....	359
Jams in the fuser.....	361
Jams in the ADF.....	361
Using the paper-path test.....	362
Using the scanner tests.....	362
Image-formation troubleshooting.....	363
Media-related print-quality problems.....	363
Overhead transparency defects.....	364
Print-quality problems that are related to the environment.....	364
Print-quality problems that are related to jams.....	364
Image-defect examples.....	365
Light print (partial page)	367
Light print (entire page)	368
Specks or dots	369
Dropouts	370
Lines	372
Horizontal lines.....	373
Gray background	374
Loose toner or toner smear	375
Repeating defects and repeating images	376
Misformed characters	377
Page skew.....	378
Curl or wave	379
Wrinkles or creases	380
Vertical white lines	381
Horizontal white lines.....	382

Tire tracks	383
White spots on black	384
Scattered lines	385
Blurred print	386
Random image repetition	387
Blank page (ADF).....	388
Page skew (ADF).....	389
Vertical lines (ADF).....	390
Image shifted (ADF).....	391
Unexpected image (ADF).....	391
Repetitive defect ruler.....	392
Media-transport problems.....	394
E-mail problems.....	396
To validate the SMTP gateway address.....	396
To validate the LDAP gateway address.....	396
Fax problems.....	397
Network connectivity problems.....	397
Troubleshooting network printing problems	397
Loopback test.....	397
Ping test.....	398
Functional checks.....	399
Engine test.....	399
Formatter test.....	399
Half self-test.....	400
Drum-rotation test.....	400
MFP resets.....	401
Cold reset.....	401
NVRAM initialization.....	401
Hard-disk initialization.....	402
Tools for troubleshooting.....	403
Using the embedded Web server.....	403
Opening the embedded Web server.....	403
Information tab.....	404
Settings tab.....	404
Digital Sending tab.....	405
Networking tab	405
Other links.....	405
Using the HP Toolbox.....	407
Supported operating systems.....	407
Supported browsers.....	407
Opening the HP Toolbox.....	408
Status tab.....	408
Alerts tab.....	408
Set up Status Alerts page.....	409
Administrative settings page.....	409
Device Settings window.....	409
Toolbox links.....	409
Other links.....	409
Using HP Web Jetadmin software.....	410
Information pages.....	411

To print an information page.....	411
Menu map.....	411
Configuration pages.....	412
Configuration page.....	412
HP Jetdirect page.....	414
Finding important information on the configuration pages.....	415
Supplies status page.....	417
Usage page.....	418
PCL or PS font list.....	419
Diagnostics menu.....	420
Individual component diagnostics.....	423
Paper-path-sensor test.....	423
Manual sensor test.....	424
Scanner tests.....	425
Component test.....	425
Service menu.....	426
Service ID.....	428
Restoring the Service ID.....	428
Converting the service ID to an actual date.....	428
Troubleshooting the embedded HP Jetdirect print server.....	429
Firmware-stack trace.....	429
Diagrams for troubleshooting.....	430
DC controller connections.....	430
Scanner-controller PCA connections.....	432
Locations of major components.....	433
Sensors and switches.....	435
Cassette sensors.....	435
Sensors in the print-cartridge area.....	436
Sensors on the reversing unit (top side).....	437
Sensors in the interior of the MFP.....	438
Output-bin detection switch, SW103.....	439
Tray 1 paper-present sensor, PS105.....	439
Top-cover switch, SW101.....	440
Tray 2 jam-access-cover switch, SW105.....	440
Motors, fans, solenoids, and clutch.....	441
Front-side fans.....	441
Rear-side fans.....	442
Rear-side motors (1 of 2).....	443
Rear-side motors (2 of 2).....	444
Rear-side solenoid.....	444
Reversing-unit motors and solenoids.....	445
Right, rear corner components (1 of 2).....	446
Right, rear corner components (2 of 2).....	447
Scanner and ADF components.....	448
ADF output-bin-full sensor.....	448
ADF pickup assembly sensors.....	449
ADF motors, solenoid, and sensors.....	450
General timing chart.....	451
General circuit diagrams.....	453

8 Parts and diagrams

How to order parts, supplies, and accessories.....	458
How to use the parts lists and diagrams.....	458
Screws that are used in the MFP.....	459
Customer-replaceable parts and accessories.....	460
Accessories.....	460
Customer-replaceable components (print engine).....	462
Customer-replaceable components (ADF and scanner).....	464
Cables and interfaces.....	466
Control panel and control-panel overlays.....	468
Memory.....	470
Print cartridge and maintenance kits.....	472
Documentation, software, and training material.....	474
Assembly locations.....	476
External components.....	480
Print-engine internal components.....	482
Upper-plate assembly.....	482
Internal components (1 of 5).....	484
Internal components (2 of 5).....	486
Internal components (3 of 5).....	488
Internal components (4 of 5).....	490
Internal components (5 of 5).....	492
Electrical/forward assembly.....	494
Main drive assembly.....	496
Paper-pickup-drive assembly.....	498
Lifter-drive assembly.....	500
Cassette.....	502
Paper-feed roller assembly.....	504
Registration assembly.....	506
Multipurpose assembly.....	508
Reverse assembly.....	510
Reverse-separation-guide assembly.....	512
Delivery assembly.....	514
Fuser.....	516
ADF components.....	518
ADF assembly.....	518
ADF internal components (1 of 3).....	520
ADF internal components (2 of 3).....	522
ADF internal components (3 of 3).....	524
ADF input tray.....	526
ADF separation pad.....	528
ADF separation-pad case.....	530
ADF pickup-roller assembly.....	532
ADF pickup-roller cover.....	534
ADF mylar-holder assembly.....	536
ADF mylar replacement kit.....	538
Scanner components.....	540
Scanner glass and cover.....	540
Scanner-base components.....	542
Scanner flatbed-unit assembly.....	544

Scanner covers.....	546
Scanner-carriage-lock assembly.....	548
Scanner-open-sensor assembly.....	550
Scanner-motor fan.....	552
Scanner motor.....	554
Scanner-belt assembly.....	556
Scanner slide-rail.....	558
Scanner optical assembly.....	560
500-sheet feeder components.....	562
Assembly locations.....	562
External components.....	564
500-sheet feeder main body (1 of 2).....	566
500-sheet feeder main body (2 of 2).....	568
500-sheet feeder lifter-drive assembly.....	570
500-sheet feeder cassette.....	572
Optional devices.....	574
Duplex-printing accessory.....	574
Stapler/stacker.....	576
3-bin mailbox.....	578
Alphabetical parts list.....	580
Numerical parts list.....	593
Index.....	607