ALTO-SHAAM. Food Holding Cabinet Electric





Model: 750-CTUS

• INSTALLATION• OPERATION• MAINTENANCE





W164 N9221 Water Street • P.O. Box 450 • Menomonee Falls, Wisconsin 53052-0450 USA
PHONE: 262.251.3800 • 800.558.8744 USA/CANADA FAX: 262.251.7067 • 800.329.8744 U.S.A. ONLY
www.alto-shaam.com

PRINTED IN U.S.A. MN-28871 (Rev. 1) ◆ 12/14



Delivery	Sanitation Sanitation/Food Safety11 Internal Food Product Temperatures11
Installation	Service
Installation Requirements	Thermostat Indicator
Clearance Requirements	Thermostat Calibration
Dimension Drawings, weights & capacities	Cable Heating Kits
Options and Accessories	Service view and Parts List
Electrical Specifications	Wire Diagrams
Before Initial Use	Always refer to the wire diagram(s) included with the un
Heating Characteristics	for most current version.
Operating Instructions	Warranty
Operating Instructions	Transportation Damage and Claims Back Cover
General Holding Guidelines	Limited Warranty Back Cover
Care and Cleaning	
Cleaning and Preventative Maintenance	
Protecting Stainless Steel Surfaces	
Cleaning Agents9	
Cleaning Materials	
Clean Daily10	



DELIVERY

This Alto-Shaam appliance has been thoroughly tested and inspected to ensure only the highest quality unit is provided. Upon receipt, check for any possible shipping damage and report it at once to the delivering carrier. See Transportation Damage and Claims section located in this manual.

This appliance, complete with unattached items and accessories, may have been delivered in one or more packages. Check to ensure that all standard items and options have been received with each model as ordered.

Save all the information and instructions packed with the appliance. Complete and return the warranty card to the factory as soon as possible to ensure prompt service in the event of a warranty parts and labor claim.


This manual must be read and understood by all people using or installing the equipment model. Contact the Alto-Shaam Tech Team Service Department if you have any questions concerning installation, operation, or maintenance.

NOTE: All claims for warranty must include the full model number and serial number of the unit.

UNPACKING

 Carefully remove the appliance from the carton or crate.

NOTE: Do not discard the carton and other packaging material until you have inspected the unit for hidden damage and tested it for proper operation.



2. Read all instructions in this manual carefully before initiating the installation of this appliance.

DO NOT DISCARD THIS MANUAL.

This manual is considered to be part of the appliance and is to be provided to the owner or manager of the business or to the person responsible for training operators. *Additional manuals are available from the Alto-Shaam Tech Team Service Department*.

3. Remove all protective plastic film, packaging materials, and accessories from the appliance before connecting electrical power. Store any accessories in a convenient place for future use.

SAFETY PROCEDURES AND PRECAUTIONS

Knowledge of proper procedures is essential to the safe operation of electrically and/or gas energized equipment. In accordance with generally accepted product safety labeling guidelines for potential hazards, the following signal words and symbols may be used throughout this manual.

DANGER



Used to indicate the presence of a hazard that WILL cause severe personal injury, death, or substantial property damage if the warning included with this symbol is ignored.

WARNING



Used to indicate the presence of a hazard that CAN cause personal injury, possible death, or major property damage if the warning included with this symbol is ignored.

CAUTION



Used to indicate the presence of a hazard that can or will cause minor or moderate personal injury or property damage if the warning included with this symbol is ignored.

CAUTION

Used to indicate the presence of a hazard that can or will cause minor personal injury, property damage, or a potential unsafe practice if the warning included with this symbol is ignored.

NOTE: Used to notify personnel of installation, operation, or maintenance information that is important but not hazard related.

- This appliance is intended to hold foods for the purpose of human consumption.
 No other use for this appliance is authorized or recommended.
- 2. This appliance is intended for use in commercial establishments where all operators are familiar with the purpose, limitations, and associated hazards of this appliance. Operating instructions and warnings must be read and understood by all operators and users.
- 3. Any troubleshooting guides, component views, and parts lists included in this manual are for general reference only and are intended for use by qualified technical personnel.
- 4. This manual should be considered a permanent part of this appliance. This manual and all supplied instructions, diagrams, schematics, parts lists, notices, and labels must remain with the appliance if the item is sold or moved to another location.

NOTE



For equipment delivered for use in any location regulated by the following directive:

DO NOT DISPOSE OF ELECTRICAL OR ELECTRONIC EQUIPMENT WITH OTHER MUNICIPAL WASTE.



Used to indicate that referral to operating instructions is a mandatory action. If not followed the operator or patient could suffer personal injury.



Used to indicate that referral to operating instructions is recommended to understand operation of equipment.

INSTALLATION

DANGER



IMPROPER INSTALLATION,
ALTERATION, ADJUSTMENT,
SERVICE, OR MAINTENANCE COULD
RESULT IN SEVERE INJURY, DEATH,
OR CAUSE PROPERTY DAMAGE.

READ THE INSTALLATION,
OPERATING AND MAINTENANCE
INSTRUCTIONS THOROUGHLY
BEFORE INSTALLING OR SERVICING
THIS EQUIPMENT.

CAUTION



TO PREVENT PERSONAL INJURY, USE CAUTION WHEN MOVING OR LEVELING THIS APPLIANCE.

CAUTION



METAL PARTS OF THIS EQUIPMENT BECOME EXTREMELY HOT WHEN IN OPERATION. TO AVOID BURNS, ALWAYS USE HAND PROTECTION WHEN OPERATING THIS APPLIANCE.


ADANGER



DO NOT store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.

SITE INSTALLATION

The Alto-Shaam
Holding Cabinet must
be installed in a location
that will permit the
oven to function for
its intended purpose
and to allow adequate
clearance for ventilation,
proper cleaning, and
maintenance access.



- 1. The oven must be installed on a stable and level surface.
- 2. DO NOT install this appliance in any area where it may be affected by any adverse conditions such as steam, grease, dripping water, high temperatures, or any other severely adverse conditions.
- **3. DO NOT** store or use any flammable liquids or allow flammable vapors in the vicinity of this oven or any other appliance.
- **4.** This appliance must be kept free and clear of any combustible materials.
- **5.** This appliance must be kept free and clear of any obstructions blocking access for maintenance or service.


Emissions testing conducted by Underwriters Laboratories, Inc.® was found to be in compliance with the applicable requirements of NFPA96: 2004 Edition, Par. 4.1.1.2. U.L emissions sampling of grease laden vapor resulted in a total of 0.55 milligrams per cubic meter with no visible smoke and is considered representative of all oven models in the line. Based on these results, hood installation and/or outside venting should not be a requirement in most areas. Verify local codes for locations where more restrictive codes are applicable.

CLEARANCE REQUIREMENTS

3" (76mm) top, bottom, right and left

INSTALLATION

SITE INSTALLATION



OPTIONS & ACCESSORIES				
Casters, 3" (76mm)	14227			
Casters, 5" (127mm) 400				
Legs, 6" (152mm) 52				
Pan Grid, Stainless Steel, Wire PN-211				
Shelf, Chrome plated, Wire SH-28				

WEIGHT		
NET	141 lb (64 kg)	
SHIP	190 lb (86 kg)	

CARTON DIMENSIONS: L X W X H

35" x 35" x 41" (889mm x 889mm x 1041mm)

PRODUCT\PAN CAPACITY
48 lb (22 kg) maximum
volume maximum: 51 qts. (57 liters)
FULL-SIZE SHEET PANS:
Six (6) 18" x 26" x 1" (457mm x 660mm x 25mm)
HALF-SIZE SHEET PANS:
*Twelve (12) 18" x 13" x 1" (457mm x 330mm x 25mm)
*WITH ADDITIONAL SHELVES
FULL-SIZE PANS:

— Includes two (2) side racks spaced at 3" (76mm) centers

*WITH ADDITIONAL SHELVES

*Six (6) 12" x 20" x 2-1/2" (530 x 325 x 65 mm) GN 1/1

INSTALLATION

ELECTRICAL INSTALLATION

- **1.** An identification tag is permanently mounted on the cabinet.
- **2.** Plug cabinet into a properly grounded receptacle ONLY, positioning the unit so the power supply cord is easily accessible in case of an emergency.
 - Arcing will occur when connecting or disconnecting the unit unless all controls are in the "OFF" position.
- **3.** If necessary, a proper receptacle or outlet configuration as required for this unit, must be installed by a licensed electrician in accordance with applicable, local electrical codes.

For CE approved units:

To prevent an electrical shock hazard between the appliance and other appliances or metal parts in close vicinity, an equalization-bonding stud is provided. An equalization bonding lead must be connected to this stud and the other appliances / metal parts to provide sufficient protection against potential difference. The terminal is marked with the following symbol.

NOTE: CE approved appliance must be connected to an electrical circuit that is protected by an external GFCI outlet.

Hard wired models:

Hard wired models must be equipped with a country certified external allpole disconnection switch with sufficient contact separation.

If a power cord is used for the connection of the product an oil resistant cord like H05RN or H07RN or equivalent must be used.

CAUTION

THIS SECTION IS PROVIDED FOR THE ASSISTANCE OF QUALIFIED SERVICE TECHNICIANS ONLY AND IS NOT INTENDED FOR USE BY UNTRAINED OR UNAUTHORIZED SERVICE PERSONNEL.

$oldsymbol{\Lambda}$ danger



ENSURE POWER SOURCE
MATCHES VOLTAGE IDENTIFIED
ON APPLIANCE RATING TAG.

DANGER





To avoid electrical shock, this appliance MUST be adequately grounded in accordance with local electrical codes or, in the absence of local codes, with the current edition of the National Electrical Code ANSI/NFPA No. 70. In Canada, all electrical connections are to be made in accordance with CSA C22.1, Canadian Electrical Code Part 1 or local codes.

ELECTRIC	ELECTRICAL						
VOLTAGE	PHASE	CYCLE/HZ	AMPS	kW	CORD & PLUG		
120V	1	50/60	18.8	2.25	NEMA L5-30P 30A, 125V PLUG		
208-240V	1	50/60	9.4	2.25	NEMA 6-15P		
at 208	1	50/60	8.5	1.77	5A, 250V PLUG		
at 240	1	50/60	9.8	2.36			
230V	1	50/60	9.4	2.17	CEE 7/7		
					16A, 25V PLUG		

WIRE DIAGRAMS ARE LOCATED INSIDE THE TOP OF THE UNIT.

OPERATION

USER INFORMATION

USER SAFETY INFORMATION

This appliance is intended for use in commercial establishments where all operators are familiar with the purpose, limitations, and associated hazards of this appliance. Operating instructions and warnings must be read and understood by all operators and users.

- **1.** Unit must be connected to the appropriate power source.
- **2.** Use hand protection when handling hot items.
- **3.** Preheat the unit for 30 minutes before use.
- **4.** Be certain only hot foods are placed into the unit.

CAUTION



METAL PARTS OF THIS EQUIPMENT BECOME EXTREMELY HOT WHEN IN OPERATION. TO AVOID BURNS, ALWAYS USE HAND PROTECTION WHEN OPERATING THIS APPLIANCE.

BEFORE INITIAL USE:

- **1.** Clean both the interior and exterior of the unit with a damp, clean cloth and mild soap solution. Rinse carefully.
- **2.** Clean and install the cabinet side racks. Shelves should be positioned with the curved end up and toward the back of the unit (reach-in models).

HEATING CHARACTERISTICS

The cabinet is equipped with a special heating cable. Through this Halo Heat concept, the heating cable is mounted against the walls of the unit to provide an evenly applied heat source controlled by a thermostat. The design and operational characteristics of the unit eliminate the need for a moisture pan or a heat circulating fan. Through even heat application, the quality of food products is maintained up to several hours or more.

OPERATION

OPERATING INSTRUCTIONS

Before Initial Use:

Clean appliance with a clean, damp cloth and mild soap solution. Clean and install pans, shelves or side racks.

1. Turn thermostat to 200°F (93°C) and preheat for 30 minutes.

When the thermostat is turned clockwise to an "ON" position, the indicator light will illuminate and will remain lit as long as the unit is calling for heat. Close the ventilation openings inside the door to accelerate heating.

The indicator light will go OUT when the air temperature inside the unit reaches the temperature set by the operator. It will then cycle "ON/OFF" at this holding point. Verify the full preheated temperature with the holding temperature gauge located on the control panel of the cabinet.

2. Load the cabinet with hot food only.

The purpose of the holding cabinet is to maintain hot food at proper serving temperature. Before loading the cabinet with food, use a food thermometer to make certain all products are at an internal temperature range of 140° to 160°F (60° to 71°C). Any food product not within the proper temperature range should be heated before loading into the holding cabinet.

3. Reset the thermostat to 160°F (71°C).

Check to make certain the cabinet door is securely closed, and reset the thermostat to 160°F (71°C). THIS WILL NOT NECESSARILY BE THE FINAL SETTING. The proper temperature range for the products being held will depend on the type and quantity of product. When holding food for prolonged periods, it is advisable to periodically check the internal temperature of each item with a food thermometer to assure maintenance of the proper temperature range of 140° to 160°F (60° to 71°C).

OPERATION

GENERAL HOLDING GUIDELINES

Chefs, cooks and other specialized food service personnel employ varied methods of cooking. Proper holding temperatures for a specific food product must be based on the moisture content of the product, product density, volume, and proper serving temperatures. Safe holding temperatures must also be correlated with palatability in determining the length of holding time for a specific product.

Halo Heat maintains the maximum amount of product moisture content without the addition of water, water vapor, or steam. Maintaining maximum natural product moisture preserves the natural flavor of the product and provides a more genuine taste. In addition to product moisture retention, the gentle properties of Halo Heat maintain a consistent temperature throughout the cabinet without the necessity of a heat distribution fan, thereby preventing further moisture loss due to evaporation or dehydration.

When product is removed from a high temperature cooking environment for immediate transfer into equipment with the lower temperature required for hot food holding, condensation can form on the outside of the product and on the inside of plastic containers used in self-service applications. Allowing the product to release the initial steam and heat produced by high temperature cooking can alleviate this condition. To preserve the safety and quality of freshly cooked foods however, a maximum of 1 to 2 minutes must be the only time period allowed for the initial heat to be released from the product.

This unit is equipped with a thermostat control between 60° and 200°F (16° and 93°C). If the unit is equipped with vents, close the vents for moist holding and open the vents for crisp holding. Use a metal-stemmed thermometer to measure the internal temperature of the product being held. Adjust the thermostat setting to achieve the best overall setting based on internal product temperature.

HOLDING TEMPERATURE RANGE			
MEAT	FAHRENHEIT	CELSIUS	
BEEF ROAST — Rare	130°F	54°C	
BEEF ROAST — Med/Well Done	155°F	68°C	
BEEF BRISKET	160° — 175°F	71° — 79°C	
CORN BEEF	160° — 175°F	71° — 79°C	
PASTRAMI	160° — 175°F	71° — 79°C	
PRIME RIB — Rare	130°F	54°C	
STEAKS — Broiled/Fried	140° — 160°F	60° — 71°C	
RIBS — Beef or Pork	160°F	71°C	
VEAL	160° — 175°F	71° — 79°C	
НАМ	160° — 175°F	71° — 79°C	
PORK	160° — 175°F	71° — 79°C	
LAMB	160° — 175°F	71° — 79°C	
POULTRY			
CHICKEN — Fried/Baked	160° — 175°F	71° — 79°C	
DUCK	160° — 175°F	71° — 79°C	
TURKEY	160° — 175°F	71° — 79°C	
GENERAL	160° — 175°F	71° — 79°C	
FISH/SEAFOOD			
FISH — Baked/Fried	160° — 175°F	71° — 79°C	
LOBSTER	160° — 175°F	71° — 79°C	
SHRIMP — Fried	160° — 175°F	71° — 79°C	
BAKED GOODS			
BREADS/ROLLS	120° — 140°F	49° — 60°C	
MISCELLANEOUS			
CASSEROLES	160° — 175°F	71° — 79°C	
DOUGH — Proofing	80° — 100°F	27° — 38°C	
EGGS —Fried	150° — 160°F	66° — 71°C	
FROZEN ENTREES	160° — 175°F	71° — 79°C	
HORS D'OEUVRES	160° — 180°F	71° — 82°C	
PASTA	160° — 180°F	71° — 82°C	
PIZZA	160° — 180°F	71° — 82°C	
POTATOES	180°F	82°C	
PLATED MEALS	140° — 165°F	60°— 74°C	
SAUCES	140° — 200°F	60° — 93°C	
SOUP	140° — 200°F	60° — 93°C	
VEGETABLES	160° — 175°F	71° — 79°C	

THE HOLDING TEMPERATURES LISTED ARE SUGGESTED GUIDELINES ONLY. ALL FOOD HOLDING SHOULD BE BASED ON INTERNAL PRODUCT TEMPERATURES. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.

CLEANING AND PREVENTATIVE MAINTENANCE

PROTECTING STAINLESS STEEL SURFACES

It is important to guard against corrosion in the care of stainless steel surfaces. Harsh, corrosive, or inappropriate chemicals can completely destroy the protective surface layer

pads, steel wool, or metal implements will abrade surfaces causing damage to this protective coating and will eventually result in areas of corrosion. Even water, particularly hard water that contains high to moderate concentrations of chloride, will cause oxidation and pitting that result in rust and corrosion. In addition, many acidic foods spilled and left to remain on metal surfaces are contributing factors that will corrode surfaces.

of stainless steel. Abrasive

Proper cleaning agents, materials, and methods are vital to maintaining the appearance and life of this appliance. Spilled foods should be removed and the area wiped as soon as possible but at the very least, a minimum of once a day. Always thoroughly rinse surfaces after using a cleaning agent and wipe standing water as quickly as possible after rinsing.

CLEANING AGENTS

Use non-abrasive cleaning products designed for use on stainless steel surfaces. Cleaning agents must be chloride-free compounds and must not contain quaternary salts. Never use hydrochloric acid (muriatic acid) on stainless steel surfaces. Always use the proper cleaning agent at the manufacturer's recommended strength. Contact your local cleaning supplier for product recommendations.

CLEANING MATERIALS

The cleaning function can usually be accomplished with the proper cleaning agent and a soft, clean cloth. When more aggressive methods must be employed, use a non-abrasive scouring pad on difficult areas and make certain to scrub with the visible grain of surface metal to avoid surface scratches. Never use wire brushes, metal scouring pads, or scrapers to remove food residue.




CARE AND CLEANING

The cleanliness and appearance of this unit will contribute considerably to operating efficiency and savory, appetizing food. Good equipment that is kept clean works better and lasts longer.



CLEAN THE UNIT THOROUGHLY AFTER EACH USE


- **1.** Disconnect unit from power source, and let cool.
- **2.** Remove, cover or wrap, and store unused products under refrigeration.



- **4.** Clean interior with a damp cloth or sponge and any good commercial detergent at the recommended strength.
- **5.** Spray heavily soiled areas with a water soluble degreaser and let stand for 10 minutes, then remove soil with a plastic scouring pad.

NOTE: Avoid the use of abrasive cleaning compounds, chloride based cleaners, or cleaners containing quaternary salts. *Never* use hydrochloric acid (muriatic acid) on stainless steel.





- **7.** Rinse surfaces by wiping with sponge and clean warm water.
- **8.** Remove excess water with sponge and wipe dry with a clean cloth or air dry. Leave door open until interior is completely dry. Replace shelves.
- **9.** Interior can be wiped with a sanitizing solution after cleaning and rinsing. This solution must be approved for use on stainless steel food contact surfaces.
- **10.** To help maintain the protective film coating on polished stainless steel, clean the exterior of the cabinet with a cleaner recommended for stainless steel surfaces. Spray the cleaning agent on a clean cloth and wipe with the grain of the stainless steel.
- **11.** Clean any glass with a window cleaner.

Always follow appropriate state or local health (hygiene) regulations regarding all applicable cleaning and sanitation requirements for foodservice equipment.

DANGER



AT NO TIME SHOULD THE INTERIOR OR EXTERIOR BE STEAM CLEANED, HOSED DOWN, OR FLOODED WITH WATER OR LIQUID SOLUTION OF ANY KIND. DO NOT USE WATER JET TO CLEAN.



SEVERE DAMAGE OR ELECTRICAL HAZARD COULD RESULT.

WARRANTY BECOMES VOID IF APPLIANCE IS FLOODED

SANITATION

Food flavor and aroma are usually so closely related that it is difficult, if not impossible, to separate them. There is also an important, inseparable relationship between cleanliness and food flavor. Cleanliness, top operating efficiency, and appearance of equipment contribute considerably to savory, appetizing foods. Good equipment that is kept clean, works better and lasts longer.

Most food imparts its own particular aroma and many foods also absorb existing odors. Unfortunately, during this absorption there is not distinction between GOOD and BAD odors. The majority of objectionable flavors and odors troubling food service operations are caused by bacteria growth. Sourness, rancidity, mustiness, stale or other OFF flavors are usually the result of germ activity.

The easiest way to insure full, natural food flavor is through comprehensive cleanliness. This means good control of both visible soil (dirt) and invisible soil (germs). A through approach to sanitation will provide essential cleanliness. It will assure an attractive appearance of equipment, along with maximum efficiency and utility. More importantly, a good sanitation program provides one of the key elements in the prevention of food-borne illnesses.

A controlled holding environment for prepared foods is just one of the important factors involved in the prevention of food-borne illnesses. Temperature monitoring and control during receiving, storage, preparation, and the service of foods are of equal importance.

The most accurate method of measuring safe temperatures of both hot and cold foods is by internal product temperature. A quality thermometer is an effective tool for this purpose, and should be routinely used on all products that require holding at a specific temperature.

A comprehensive sanitation program should focus on the training of staff in basic sanitation procedures. This includes personal hygiene, proper handling of raw foods, cooking to a safe internal product temperature, and the routine monitoring of internal temperatures from receiving through service.

Most food-borne illnesses can be prevented through proper temperature control and a comprehensive program of sanitation. Both these factors are important to build quality service as the foundation of customer satisfaction. Safe food handling practices to prevent foodborne illness is of critical importance to the health and safety of your customers.

HACCP, an acronym for Hazard Analysis (at) Critical Control Points, is a quality control program of operating procedures to assure food integrity, quality, and safety. Taking steps necessary to augment food safety practices is both cost effective and relatively simple. While HACCP guidelines go far beyond the scope of this manual, additional information is available by contacting:

CENTER FOR FOOD SAFETY AND APPLIED NUTRITION FOOD AND DRUG ADMINISTRATION 1-888-SAFEFOOD

INTERNAL FOOD PRODUCT TEMPERATURES					
	HOT FOODS				
DANGER ZONE	40° TO 140°F	(4° TO 60°C)			
CRITICAL ZONE	70° TO 120°F	(21° TO 49°C)			
SAFE ZONE	140° TO 165°F	(60° TO 74°C)			
	COLD FOODS				
DANGER ZONE	ABOVE 40°F	(ABOVE 4°C)			
SAFE ZONE	36° TO 40°F	(2° TO 4°C)			
FROZEN FOODS					
DANGER ZONE	ABOVE 32°F	(ABOVE 0°C)			
CRITICAL ZONE	0° TO 32°F	(-18° TO 0°C)			
SAFE ZONE	0°F or below	(-18°C or below)			

SERVICE

THERMOSTAT & INDICATOR LIGHT

Whenever the thermostat is turned "ON," the indicator light will indicate the power ON/OFF condition of the heating cable, and consequently, the cycling of the cabinet as it maintains the dialed cavity temperature. If this light does not illuminate after normal start-up, the main power source, thermostat, and/or indicator light must be checked.

If the warming cabinet does not hold the temperature as dialed, the calibration of the thermostat must be checked. If the warming cabinet fails to heat or heats continuously with the thermostat "OFF," the thermostat must be initially checked for proper operation. If these items are checked and found to be in order, a continuity and resistance check of the heating cable should be made. SEE CIRCUIT DIAGRAM.

CAUTION

THIS SECTION IS PROVIDED FOR THE ASSISTANCE
OF QUALIFIED SERVICE TECHNICIANS ONLY AND
IS NOT INTENDED FOR USE BY UNTRAINED OR
UNAUTHORIZED SERVICE PERSONNEL.



THERMOSTAT CALIBRATION

The thermostat is precision calibrated at the factory. Normally, no adjustment or recalibration is necessary unless the thermostat has been mishandled in transit, changed or abused while in service. A thermostat with a sensing bulb operates on hydraulic pressure, consequently, any bending of the bulb results in a change in its volume, and alters the accuracy of the thermostat calibration.


A thermostat should be checked or recalibrated by placing a quality, thermal indicator at the center of an empty holding cavity. DO NOT CALIBRATE WITH ANY FOOD PRODUCT IN THE CABINET. The thermostat should be set, and should be allowed to stabilize at that setting for a minimum of one hour. The center of the thermal swing of the air temperature within the cabinet should approximately coincide with the thermostat setting.

If calibration is necessary, the calibration screw should be adjusted with great care. The calibration screw of the thermostat is located in the thermostat dial shaft. With the shaft held stationary, a minute, clockwise motion of the calibration screw appreciably lowers the thermostat setting. A reverse, or counter-clockwise motion appreciably raises the thermostat setting. After achieving the desired cycling of the thermostat, the calibration screw must be sealed. Place a few drops of enamel sealant directly on the calibration screw.

(Red nail polish or equivalent is acceptable.)

CABLE HEATING SERVICE KIT NO. 4881					
Kit includes:		BU-3106	Cup Bushing	12	
CB-3045	Cable Heating Element 210 feet		ST-2439	Stud	12
CR-3226	Ring Connector	12	NU-2215	Hex Nut	24
IN-3488	Insulation Corner	1 foot	SL-3063	Insulating Sleeve	12
BU-3105	Shoulder Bushing	12	TA-3540	Electrical Tape	1 roll


SERVICE




Part numbers and drawings are subject to change without notice.

ITEM	DESCRIPTION	PART NO.	QTY	ITEM	DESCRIPTION	PART NO.	QTY
1	TOP ASSEMBLY	4445	1	13	THERMOSTAT	TT-3057	1
2	TOP ASSEMBLY MOUNTING SCREWS	SC-2425	6		THERMOSTAT KNOB	KN-3469	1
3	CORDSET (120V)	CD-33366	1	14	INDICATOR LIGHT (120V)	LI-3493	1
	CORDSET (120V) - prior to 5/1/13	CD-33367	1		INDICATOR LIGHT (208-240V, 230V)	LI-3516	1
	CORDSET (208-240V)	CD-3551	1	15	DOOR ASSEMBLY, RIGHT-HAND	5978	1
	CORDSET (230V)	CD-3922	1	16	DOOR ASSEMBLY, LEFT-HAND	5977	1
4	CORD STRAIN RELIEF BUSHING	BU-3964	1	17	HINGE SET (1 pair of 2 hinges)	HG-2015	2
5	CASING	1009	1		HINGE MOUNTING SCREWS	SC-2072	24
6	CASING MOUNTING SCREWS	SC-2425	2	18	DOOR HANDLE	HD-2007	2
7	CASING MOUNTING RIVETS	RI-2100	10		DOOR HANDLE MTG. SCREWS	SC-2073	6
8	BOTTOM ASSEMBLY	4499	1		DOOR HANDLE CATCH MTG. SCREWS	SC-2071	6
9	BOTTOM ASSEMBLY MTG. RIVETS	RI-2100	15	19	DOOR GASKET — Length per door: 7'	GS-2398	2
10	INSULATION	IN-22364	1	20	SIDE RACK	SR-2848	2
11	CABLE CONNECTION HARDWARE	N/A	1	21	CONTROL PANEL OVERLAY	PE-2703	1
12	HEATING CABLE, 144' (43891mm)	CB-3045	1	22*	TEMPERATURE GAUGE	GU-3273	1


^{*}NOT SHOWN



750-CTUS (Rev. 1) • INSTALLATION/OPERATION/SERVICE MANUAL - PG. 14



750-CTUS (Rev. 1) • INSTALLATION/OPERATION/SERVICE MANUAL - PG. 15



TRANSPORTATION DAMAGE and CLAIMS



All Alto-Shaam equipment is sold F.O.B. shipping point, and when accepted by the carrier, such shipments become the property of the consignee.

Should damage occur in shipment, it is a matter between the carrier and the consignee. In such cases, the carrier is assumed to be responsible for the safe delivery of the merchandise, unless negligence can be established on the part of the shipper.

- 1. Make an immediate inspection while the equipment is still in the truck or immediately after it is moved to the receiving area. Do not wait until after the material is moved to a storage area.
- 2. Do not sign a delivery receipt or a freight bill until you have made a proper count and inspection of all merchandise received.
- 3. Note all damage to packages directly on the carrier's delivery receipt.
- 4. Make certain the driver signs this receipt. If he refuses to sign, make a notation of this refusal on the receipt.
- 5. If the driver refuses to allow inspection, write the following on the delivery receipt: *Driver refuses to allow inspection of containers for visible damage.*
- 6. Telephone the carrier's office immediately upon finding damage, and request an inspection. Mail a written confirmation of the time, date, and the person called.
- 7. Save any packages and packing material for further inspection by the carrier.
- 8. Promptly file a written claim with the carrier and attach copies of all supporting paperwork.

We will continue our policy of assisting our customers in collecting claims which have been properly filed and actively pursued. We cannot, however, file any damage claims for you, assume the responsibility of any claims, or accept deductions in payment for such claims.

LIMITED WARRANTY

Alto-Shaam, Inc. warrants to the original purchaser only that any original part that is found to be defective in material or workmanship will, at Alto-Shaam's option, subject to provisions hereinafter stated, be replaced with a new or rebuilt part.

The original parts warranty period is as follows:

For the refrigeration compressor on Alto-Shaam Quickchillers[™], five (5) years from the date of installation of appliance.

For the heating element on Halo Heat® cooking and holding ovens, as long as the original purchaser owns the oven. This excludes holding only equipment.

For all other original parts, one (1) year from the date of installation of appliance or fifteen (15) months from the shipping date, whichever occurs first

The labor warranty period is one (1) year from the date of installation or fifteen (15) months from the shipping date, whichever occurs first. Alto-Shaam will bear normal labor charges performed during standard business hours, excluding overtime, holiday rates or any additional fees.

To be valid, a warranty claim must be asserted during the applicable warranty period. This warranty is not transferable.

THIS WARRANTY DOES NOT APPLY TO:

- 1. Calibration.
- 2. Replacement of light bulbs, door gaskets, and/or the replacement of glass due to damage of any kind.
- 3. Equipment damage caused by accident, shipping, improper installation or alteration.
- 4. Equipment used under conditions of abuse, misuse, carelessness or abnormal conditions, including but not limited to, equipment subjected to harsh or inappropriate chemicals, including but not limited to, compounds containing chloride or quaternary salts, poor water quality, or equipment with missing or altered serial numbers.
- 5. Damage incurred as a direct result of poor water quality, inadequate maintenance of steam generators and/or surfaces affected by water quality. Water quality and required maintenance of steam generating equipment is the responsibility of the owner/operator.
- 6. Damage caused by use of any cleaning agent other than Alto-Shaam's Combitherm® Cleaner, including but not limited to damage due to chlorine or other harmful chemicals. Use of Alto-Shaam's Combitherm® Cleaner on Combitherm® ovens is highly recommended.
- 7. Any losses or damage resulting from malfunction, including loss of product, food product, revenue, or consequential or incidental damages of any kind.
- 8. Equipment modified in any manner from original model, substitution of parts other than factory authorized parts, removal of any parts including legs, or addition of any parts.

This warranty is exclusive and is in lieu of all other warranties, express or implied, including the implied warranties of merchantability and fitness for a particular purpose. In no event shall Alto-Shaam be liable for loss of use, loss of revenue or profit, or loss of product, or for any indirect, special, incidental, or consequential damages. No person except an officer of Alto-Shaam, Inc. is authorized to modify this warranty or to incur on behalf of Alto-Shaam any other obligation or liability in connection with Alto-Shaam equipment.



Effective November 1, 2012

RECORD THE MODEL AND SERIAL NUMBER OF THE APPLIANCE FOR EASY REFERENCE.			
ALWAYS REFER TO BOTH MODEL AND SERIAL NUMBER IN ANY CONTACT WITH ALTO-SHAAM REGARDING THIS APPLIANCE.			
Model:	Date Installed:		
Voltage:	Purchased From:		
Serial Number:			

W164 N9221 Water Street · P.O. Box 450 · Menomonee Falls, Wisconsin 53052-0450 · U.S.A.