



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11330199
63-72 C-10 Level 1 Air Suspension System

Front Components:

- | | | |
|---|----------|---|
| 1 | 11331099 | Front CoolRide Kit for Stock Lower Arms |
| 1 | 11330500 | Black Series Front Shock Kit w/ Mounts |

Rear Components:

- | | | |
|---|----------|--------------------------|
| 1 | 11334099 | Rear CoolRide Kit |
| 1 | 11330700 | Black Series Rear Shocks |

Compressor System:

- | | | |
|---|----------|---|
| 1 | 30154000 | 3 gallon RidePro Compressor Kit (Analog Gauges) |
|---|----------|---|



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11331099
63-87 Chevy C10 Front CoolRide Kit
For Use w/ Stock Lower Arms

Components:

2	90006873	Front air springs – 224C
2	90000060	Upper air spring plate
2	90000057	Lower air spring cup bracket
2	90001083	Medium bump stops – 1.5" tall
1	90000293	Driver side steering stop
1	90000294	Passenger side steering stop

Hardware Kit:


16	99372002	3/8" USS Nylok nut	Air spring mounts
2	99371001	3/8" x 3/4" USS bolt	Air spring to lower cup bracket
2	99373005	3/8" lock washer	Air spring to lower cup bracket
4	99371003	3/8" x 1" USS bolt	Steering stop to lower arm
8	99371004	3/8" x 1 1/4" USS bolt	Upper mount to frame
30	99373003	3/8" SAE flat washer	

COOLRiDE[®]

by Air Ride Technologies

Installation Instructions

1. Raise and support truck at a safe, comfortable working height. Let the front suspension hang freely.
2. Remove coil spring, shock absorber and bump stop. Refer to factory service manual for proper disassembly procedure.



3. Hold the upper plate to the cross member as shown in the picture to the left and clamp to frame. Using the plate as a template drill 4 holes in the cross member.

4. Apply thread sealant to the air fitting and thread into the air spring. Remove the upper plate from the frame and place onto the studs on the top of the air spring. The holes are lettered; slide the plate to position B moving the air spring to the rear of the vehicle. Secure with flat washers and nyloc nuts. Route airline.



5. Bolt the lower bracket to the air spring using a 3/8" x 3/4" bolt, lock washer and flat washer.

6. Attach the air spring assembly to the frame using 3/8" x 1 1/4" bolts, Nylok nuts and flat washers supplied. The lower mount will simply sit in the coil spring pocket. It does not need to be attached.

7. Replace the factory shock, with the new ones supplied.

8. Bolt the steering stop to the lower arm. Check air spring clearance with the caliper at full lock. The air spring should be about 5" tall at ride height.

DO NOT ALLOW THE AIR SPRING TO RUB. THIS WILL DAMAGE THE AIR SPRING AND IS NOT A WARRANTABLE SITUATION.



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

Part # 11330500
63-72 C-10 Black Series Front Shock Kit
For Use w/ Stock Lower Arms

Components:

- | | | |
|---|----------|---------------------------|
| 2 | 20000009 | Shock absorbers – Eye/Eye |
| 2 | 90001617 | Upper shock studs |



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

Part # 11330700
63-72 C-10 Rear Black Series Shock Kit
For Use w/ Stock Suspension

Components:

- | | | |
|---|----------|------------------------------|
| 2 | 20000012 | Black Series shock – eye/eye |
|---|----------|------------------------------|



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11334099
63-72 Chevy C-10 Rear CoolRide Kit
For Use w/ Factory Trailing Arms

Components:

2	90006781	Front air spring – 267c
2	90000056	Upper air spring cup bracket
2	90000070	Lower air spring plate
2	90001082	Short bump stop

Hardware Kit:

4	99372002	3/8" USS Nylok nut	Air spring to upper mount
4	99373003	3/8" SAE washer	Air spring to upper mount
2	99435003	7/16" x 2" stud	Upper mount to frame
2	99432001	7/16" Nylok nut	Upper mount to frame
2	99433002	7/16" SAE washer	Upper mount to frame
2	99371009	3/8" x 4" bolt	Air spring to trailing arm
2	99373001	3/8" fender washer	Air spring to trailing arm
2	99373005	3/8" lock washer	Air spring to trailing arm

COOL RiDE[®]

by Air Ride Technologies

Installation Instructions

1. Raise the vehicle to a safe and comfortable working height with the suspension hanging freely.
2. Remove the coil spring and shock absorbers.



3. Apply thread sealant to a 90 degree air fitting and screw it into the top of the air spring.

Note: When using larger fittings you may need to trim the bracket and/or frame rail.

4. Place the upper mount over the studs on the air spring. Secure with two 3/8" Nylok nuts and flat washers.

5. Screw the 7/16 x 2" stud into the nut in the bottom of the bracket.

7. Bolt the assembly to the upper coil spring pocket with the stud sticking through the frame. Use a 7/16" nut and flat washer to fasten the assembly.

8. Bolt the bottom of the air spring to the trailing arm using a 3/8" x 4" bolt, fender washer and lock washer. The lower air spring plate must be installed between the air spring and the trailing arm.

9. Double check air spring clearance though full suspension travel.

10. Ride height on this air spring is approximately 5".

DO NOT ALLOW THE AIR SPRING TO RUB. THIS WILL DAMAGE THE AIR SPRING AND IS NOT A WARRANTABLE SITUATION.



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 30154000
4000 Series RidePro 4 Way Compressor System
3 Gallon Tank – Analog Gauges

Components:

- 1 31920002 Thomas 327 Compressor
- 1 31194000 RidePro 4 Way analog control panel with rocker switches (Black Face)
- 1 31913100 3 gallon aluminum tank
- 1 31934001 RidePro 4 Way valve block
- 1 31980005 Pressure switch – 135 On / 150 Off

Wiring:

- 1 90001924 Fuse holder
- 1 90001922 20 Amp fuse
- 2 31900036 Wiring harness - Control panel to valve

Airline & Fittings:

- 2 31940002 1/4" DOT airline - 30 ft. roll - valve block to gauges
- 2 31940000 1/8" DOT airline - 25 ft. roll - valve block to gauges
- 1 31952150 1/8"npt x 1/4" tube female straight - compressor
- 1 31957003 2" Brass Nipple - compressor
- 6 31954201 1/4" npt x 1/4" tube Elbow airline fitting
- 7 31954000 1/4" npt x 1/4" tube Straight airline fitting
- 4 31952000 1/8" npt x 1/8" tube Straight fitting - manifold to gauge fitting
- 1 31957004 1/4" npt plug - plug unused supply port



350 S. St. Charles St. Jasper, In. 47546

Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

ARC4000 Compressor System Instructions

These are some general guidelines to follow when installing your new RidePro air control system. Depending on the vehicle there are many different ways to plumb the system. Start out by planning a lay out of where you want everything to be mounted. Typically we try to keep the compressor, solenoids, tank, and sending units in a central location, but they can be separated to suit your needs.

Mounting the Compressor/ Pressure Switch

- **Remove the negative battery cable before beginning installation.**
- All of our compressors are sealed for moisture and dust resistance so they can be mounted anywhere on the vehicle. Although it is best to mount it in a place out of direct contact with rain and snow. It is OK to mount it underneath the vehicle but keep it inside the frame rails away from water and debris thrown off the tire.
- This is a dry compressor; therefore it is maintenance free and can be mounted in any position.
- It is best if mounted to something solid to reduce vibration and noise. If mounting it to sheet metal or the bed of a truck, use sound deadening material between the compressor and the mounting surface.
- Use the rubber grommets supplied on the feet of the compressor to reduce vibration.
- A template is supplied to aid in drilling the holes. Check template with compressor before drilling the holes.
- Apply thread sealant to the pressure switch and compressor T and screw into the tank.
- One spade of the pressure switch will connect to power the other to the red wire on the compressor.

Mounting the Air Tank

- The air tank can be mounted anywhere on the vehicle in any position.
- A template is supplied to aid in drilling the holes. Check the template with the tank before drilling the holes.
- If your air system is used frequently you may want to remove the tank once a season to drain any excessive accumulation of water.

Mounting the RidePro Air Valves

- The valves, like the compressor, are sealed and can be mounted in the same locations. Although if the vehicle will be exposed to freezing temperatures it is a good idea to mount them in the engine bay if possible to reduce the possibility of freezing.
- They can be mounted in any position.
- Mount the valves higher than the tank to avoid moisture build up. This could cause the air pressure sensors to give a faulty reading.
- Attach the ground strap to a good, clean ground (preferably the frame).
- The exhaust port will be left open.
- The valve is held closed with the pressure in the tank. If tank pressure drops below air spring pressure they will equalize deflating all 4 air springs.


Wiring Harness

- The red wire on the harness will connect to 12 v.
- The gray wire will then supply the gauge light 12v. Or the gauge light can be powered with illumination.

Routing the Airline and Fittings

- Make all airline cuts with a razor or tubing cutter. It must be clean and straight or it will not seal.
- All fittings are DOT approved push-to-connect style. They are very simple to use and are reusable. Firmly push the airline into the fitting to attach. To release the airline pull the collar on the fitting back towards the fitting and pull the airline out.
- Use thread sealant on all fittings.
- Do not over tighten the fittings. This could result in breaking the fitting or damaging the air spring.
- All of our airlines are DOT approved so they are very strong. But keep them away from any sharp edges. Also when passing through a hole in the frame use a grommet.
- Keep away from intense heat including mufflers and exhaust manifolds.
- Use zip ties or other fasteners to secure the airline.

ARC4000



Wiring at control panel:

Gray connects to gauge light

Red connects to "key on" power at fuse box