

PEAVEY T-15[®] OPERATING GUIDE

CAUTION
TO PREVENT ELECTRICAL SHOCK OR FIRE HAZARD, DO NOT EXPOSE THIS INSTRUMENT TO RAIN OR MOISTURE. BEFORE USING THIS INSTRUMENT, READ BACK COVER FOR FURTHER WARNINGS.

Neck:

The select rock maple neck is of a unique bi-laminated construction (U.S. Patent #4,237,944) to provide unmatched rigidity and freedom from warpage. Additional reinforcement is provided with a steel torsion rod. This neck adjusting rod features **rolled** threads for improved strength and freedom from breakage.

A special 23½" scale length provides a better reach for younger and beginning guitarists, and easier, faster fretting for the more experienced player. The arch of the fingerboard is on a 12" radius to allow excellent string bending characteristics without the buzzing and "frettingout" problems associated with the smaller 10" radius used by many other manufacturers. Frets are 18% nickel-silver, wide, and high crowned for a more secure grip when bending strings.

Body:

The T-15[®] body is made from the finest hand selected hardwood, and is relatively compact in keeping with the slightly shorter scale length. A double cutaway design with special forearm and rib-cage relief contouring, rests comfortably and with good balance against the player's body.

Pickups:

Two single-coil high performance pickups provide both high power and full-range operation. They may be used singly or in unison, and are controlled by master volume and tone controls. Exposed blade polepieces give much better performance than the more common individual magnet designs, especially when string bending on the upper frets.

Circuitry:

The circuitry of the T-15[®] is conventional, with the exception of a tone-compensating volume control, which minimizes high frequency losses when operated at reduced volume settings. However, full volume settings will maximize the tonal capabilities. The volume level should therefore be controlled at the amplifier whenever possible.

Bridge:

The massive die cast alloy bridge is triple chrome plated for durability and resistance to corrosion. Support is provided at **three** points for stability and maximum adjustment of height and tilt. A single, intonation-compensating bridge saddle is adjustable at both the treble and bass sides.

Hardware:

- Top quality covered tuning machines with ivory colored knobs
- Metal die cast top nut
- Massive control knobs
- Sturdy pickup selector switch with comfortable bat handle
- Output jack on face of guitar
- Cream and black, laminated pickguard
- Top quality rock and roll gauge strings for light action and good sustain


T-15[®] Controls:

1. Volume Control:

The volume control acts as a master volume in that it controls the total signal level delivered from both pickups to the output jack. Rotating the control knob **clockwise** will **increase** volume; rotating **counterclockwise** will **reduce** volume.

2. Tone Control:

The tone control, like the volume control, operates as a master control. Rotating **clockwise** will result in more treble (high frequencies) and a brighter tonality. Rotating **counterclockwise** will result in less treble and a "bassier" type sound.



3. Pickup Selector Switch:

This three-position switch determines which pickup is operational. With the guitar suspended in normal playing position, moving the switch handle upward activates the rhythm (neck) pickup; the extreme downward position activates the lead (bridge) pickup; the middle position activates both pickups simultaneously.

Output Jack:

The output jack is a conventional ¼" phone jack which accepts standard guitar patch cords.

Pickups:

The volume level between pickups can be adjusted by raising or lowering each pickup with its height adjusting screws. Raising the pickups closer to the strings will increase the output and volume. Lowering the pickups away from the strings will decrease output and volume.

NOTE
CARE MUST BE TAKEN TO MAINTAIN ADEQUATE CLEARANCE BETWEEN THE PICKUPS AND STRINGS. INADEQUATE CLEARANCE WILL RESULT IN LOSS OF SUSTAIN AND POSSIBLE STRING BUZZING WHEN PLAYING ON THE UPPER FRETS.

Adjustments:

Your T-15[®] guitar has been carefully adjusted for accurate intonation and playing ease at the Peavey factory. However, your playing style or playing requirements may necessitate additional adjustments at some time in the future. These adjustments should be made by your Peavey Dealer. However, with a little care and by adhering closely to the following instructions, you may attempt these adjustments yourself.

CAUTION
PLEASE READ AND UNDERSTAND INSTRUCTIONS THOROUGHLY BEFORE ATTEMPTING ANY ADJUSTMENTS.

Adjusting Torsion Rod:

All guitar necks must have a slight amount of bow to keep the strings from buzzing on the frets. To set the "straightness" of the neck, a Peavey torsion rod wrench No. 75031001 must be used (available from a Peavey Accessory Center).

1. Tune the instrument to standard (A-440) pitch.
2. Fret the sixth string (BIG E) at the first and last frets.
3. Check for clearance between the string and the eighth fret.
4. Clearance should be no less than .012" and no more than .025".
5. To increase clearance, loosen (counterclockwise) the torsion rod nut. Less clearance (straightening of the neck) is accomplished by tightening the nut.

CAUTION
IT IS NOT USUALLY NECESSARY TO ROTATE THE TORSION ROD NUT MORE THAN ONE FULL TURN IN EITHER DIRECTION. ONE-QUARTER TO ONE-HALF TURN IS NORMALLY SUFFICIENT TO MAKE MOST ADJUSTMENTS. EXCESSIVE ROTATION MAY CAUSE DAMAGE TO NECK AND TORSION ROD. IF EXCESSIVE FORCE IS NECESSARY TO ROTATE TORSION ROD NUT, YOU SHOULD CONSULT YOUR PEAVEY DEALER OR THE FACTORY BEFORE ANY FURTHER ADJUSTMENT IS MADE.

6. Repeat steps 1 through 5 until proper clearance has been reached.

Neck Tilt:

The neck tilt adjustment works in conjunction with the bridge height adjustment to set the overall string playing height. This adjustment should be used whenever possible to set string height rather than the bridge height adjustment.

1. Relieve string tension slightly by detuning guitar (approximately 1 to 2 full steps).
2. Loosen two neck screws (closest to headstock of guitar) approximately 1 turn.
3. Loosen remaining two neck screws (closest to bridge) approximately 2 turns.
4. String height may now be adjusted with the neck tilt screw which is located inside the fifth hole in the neck plate. A 1/8" allen wrench is used to make this adjustment. Turning the screw clockwise lowers the strings closer to the fingerboard.

NOTE
STRING HEIGHT SHOULD BE ADJUSTED TO FIT YOUR OWN PARTICULAR PLAYING STYLE. IT SHOULD BE NOTED THAT SETTING THE STRING HEIGHT TOO LOW WILL RESULT IN EXCESSIVE STRING BUZZ AND RATTLE — ESPECIALLY WITH A "HEAVY" PLAYING TECHNIQUE. EXCESSIVELY HIGH ACTION WILL

RESULT IN INTONATION PROBLEMS AND DECREASED PLAYABILITY.

5. After adjustment, securely tighten all four neck attaching screws.
6. Tune guitar to standard pitch. Check strings for correct height and playability. If necessary, repeat steps 1 through 5 until action is correct.

Bridge Height Adjustment:

The bridge height adjustment works in conjunction with the neck tilt adjustment to determine the overall string playing height. Ordinarily, the neck tilt adjustment should be used to set the string height.

The bridge height may be adjusted, if necessary, with the two forward bridge mounting screws. Rotating the screws clockwise will lower the bridge. Rotating counterclockwise will raise the bridge.

String Intonation:

Accurate string intonation settings insure that your instrument will play in tune at any point on the neck, although "perfect intonation" is a physical impossibility with a fretted instrument, the correct settings will maximize the accuracy of individual notes up and down the neck.

Intonation is set by comparing the pitch of an open string to the pitch of the same string when it is played one octave higher at the 12th fret. The actual "vibrating length" of that string is varied until the notes are both at the right pitch. The "vibrating length" of the string is altered by adjusting the bridge saddle either forward or backward, depending on whether the fretted note is sharper or flatter in pitch than the open note. If the fretted note is sharper than the open note, the vibrating length of the string must be increased — move the bridge saddle to the rear, away from the pickups. If the fretted note is flat, the vibrating length must be shortened — move the bridge saddle forward, toward the pickups, to shorten the length.

The T-15® features a specially compensated bridge which requires setting the intonation only on the 1st and 6th strings. All other strings will then be reasonably accurate.


NOTE
IT IS OFTEN DIFFICULT FOR THE UNTRAINED EAR TO DETERMINE WHEN THE OPEN NOTE AND THE FRETTED NOTE ARE AT PRECISELY THE SAME PITCH. SOME PLAYERS FIND THAT COMPARING THE 12TH FRET HARMONIC OF THE STRING (RATHER THAN THE OPEN NOTE) TO THE FRETTED NOTE IS MUCH EASIER. A HARMONIC IS PLAYED BY PLUCKING THE STRING WITH THE RIGHT HAND WHILE TOUCHING THE STRING WITH THE LEFT INDEX FINGER (AS LIGHTLY AS POSSIBLE) DIRECTLY ABOVE THE TWELFTH FRET. THE LEFT INDEX FINGER IS DRAWN AWAY AS QUICKLY AS POSSIBLE AFTER THE STRING IS PLUCKED, PRODUCING A "CHIME" EFFECT. THIS CHIMED NOTE IS THEN COMPARED TO THE FRETTED NOTE.

FOR EVEN GREATER EASE AND A HIGH DEGREE OF ACCURACY, WE RECOMMEND ONE OF THE MANY TYPES OF ELECTRONIC GUITAR TUNERS THAT ARE AVAILABLE FROM MOST MUSIC STORES. THE TUNERS WHICH USE EITHER A METER OR A MOVING LED DISPLAY ARE USUALLY EASIER TO USE THAN THE TYPE WITH A NUMERICAL FREQUENCY READOUT.


Setting Intonation:

NOTE
BOTH TORSION ROD AND STRING HEIGHT SETTINGS INTERACT CLOSELY WITH STRING INTONATION. THESE ADJUSTMENTS MUST BE COMPLETED BEFORE ANY ATTEMPT IS MADE TO SET STRING INTONATION AT THE BRIDGE.

1. Insure that torsion rod and string height settings are accurate.
2. Tune guitar to standard A-440 pitch.



3. Place the guitar on a clean flat surface, so that **only the body** is in contact with the work surface. Any pressure on the neck will affect intonation settings.
4. Play the 1st string open (small E) and compare it to the pitch of the same string when it is played at the 12th fret. The notes should be the same pitch.
5. Using an allen wrench, adjust the treble side of the bridge so that the pitch of the open note and the fretted note are the same. NOTE: It will often be necessary to re-tune the open string to standard pitch after bridge position is altered.
6. Repeat step 5 for the 6th string (Big E).
7. Repeat steps 1 through 6 as necessary until intonation of the 1st and 6th strings are accurately adjusted. The specially compensated T-15® bridge will insure that the remaining strings are reasonably accurate.



Care For The T-15®.

The T-15® is a high quality musical instrument constructed from the finest materials and with the most up-to-date production methods available. With reasonable care, it should provide many, many years of service and outstanding playability.

Temperature and Humidity:

It is important that your T-15® be protected from any extremes or sudden changes in either temperature or humidity. The instrument should be stored in its case whenever it is not in use.

Strings:

String life may be greatly extended by frequent cleaning and wiping after use. Dirt and perspiration tend to build up on the underside of the strings, so it is often necessary to slide a rag between the strings and the fingerboard. Dirt-laden strings cause tuning and intonation problems, as well as rust and corrosion.

For best performance, strings should be changed approximately once a month or every twenty-four playing hours. Some players may find that they prefer to change strings more often.

NOTE

YOUR T-15® IS EQUIPPED WITH PEAVEY VELVET GLIDERS® — OUR NEW STAINLESS STEEL GUITAR STRINGS. THE INTONATION AND ACTION OF YOUR INSTRUMENT HAS BEEN CAREFULLY ADJUSTED FOR MAXIMUM PLAYABILITY WITH THESE STRINGS. WHEN STRING REPLACEMENT BECOMES NECESSARY, WE RECOMMEND OUR HIGH QUALITY AND LONG LASTING PEAVEY GLIDERS® STAINLESS STEEL STRINGS.

Finish:

Your T-15® has a polyurethane finish which is both durable and weather-resistant, but nevertheless, needs care. Automotive-grade waxes will protect, clean, and shine it. Between waxing, the instrument should be wiped with a dry, soft cloth.

Case:

A unique molded plastic case (Patent applied for) provides maximum protection and road durability. The T-15® case features large storage areas and a padlock tab to facilitate locking for air shipment.

The case may be cleaned with a damp cloth, with or without soap. Care should be taken to avoid wetting the foam interior.

The Electric Case™


The following are some general guidelines if you have purchased the Peavey T-15® guitar with our optional Electric Case™. The Electric Case™ is our rugged, double walled and molded case which contains an extremely sensitive 10 watt preamp, power amp and special combination.

The preamp section contains two inputs for the guitar, labeled A and B. Input A is the most sensitive input and will provide the highest amount of gain (volume). The B input exhibits somewhat **less** gain than input A and should be used with guitars which have very high output ("hot") pickups.

Next are the pre gain, equalizer and post gain controls. These controls can be adjusted in a variety of ways to obtain many different tonalities and textures. For example: If you desire a **very** clean tonality, rotate the **post gain** control between "8" and "10" and then adjust the **pre gain** control to the desired volume level.

NOTE

WE DO NOT RECOMMEND THAT THE PRE GAIN CONTROL, FOR THIS APPLICATION, BE SET HIGHER THAN ITS NUMBER "5" POSITION. PLACING THE PRE GAIN CONTROL ABOVE THIS SETTING COULD RESULT IN POWER AMP CLIPPING AND POSSIBLE SPEAKER DAMAGE/FAILURE.



The equalizer control can now be adjusted to provide a "bassier" type of sound ("0" - "5") or a brighter tonality ("5" - "10").

If you desire a distorted sound for rock-type textures, rotate the **pre gain** control between its number "5" to "10" position and then adjust the **post gain** control between its number "1" to "5" position. The equalizer control can be adjusted for "silkier" distortion sounds ("0" - "5") or for a greater amount of "bite" ("5" - "10").

NOTE

AS WITH THE SETTINGS FOR OBTAINING A "CLEAN" SOUND, IT IS NOT RECOMMENDED TO ROTATE THE POST GAIN CONTROL HIGHER THAN ITS NUMBER "5" POSITION. SETTINGS HIGHER THAN "5" COULD RESULT IN A POWER AMP OVERLOAD AND POSSIBLE SPEAKER DAMAGE AND/OR FAILURE COULD RESULT.

CAUTION

FOR YOUR SAFETY, WE HAVE INCORPORATED A THREE-WIRE LINE (MAINS) CABLE WITH PROPER GROUNDING FACILITIES. IT IS NOT ADVISABLE TO REMOVE THE GROUND PIN UNDER ANY CIRCUMSTANCES. IF IT IS NECESSARY TO USE THE AMP WITHOUT PROPER GROUNDING FACILITIES, SUITABLE GROUNDING ADAPTORS SHOULD BE USED. MUCH LESS NOISE AND GREATLY REDUCED SHOCK HAZARD EXIST WHEN THE UNIT IS OPERATED WITH THE PROPER GROUNDED RECEPTACLES.

**PEAVEY GUITAR ONE-YEAR
LIMITED WARRANTY/REMEDY**

PEAVEY ELECTRONICS CORPORATION ("Peavey") warrants this Guitar to be free from defects in material and workmanship for a period of one year from date of purchase; PROVIDED, however, that this limited warranty is extended only to the original retail purchaser and is subject to the conditions, exclusions and limitations hereinafter set forth.

**CONDITIONS, EXCLUSIONS AND
LIMITATIONS OF LIMITED WARRANTY**

This limited warranty shall be VOID and of NO EFFECT if:

1. The first purchase of the product is for the purpose of resale; or
2. The original retail purchase is not made from an AUTHORIZED PEAVEY DEALER; or
3. The product has been damaged by accident or unreasonable use, neglect, improper service or maintenance, or other causes not arising out of defects in material or workmanship.

This limited warranty shall not extend to or cover guitar strings. Replacement of guitar strings is deemed to be reasonable and necessary maintenance.

Purchaser's exclusive remedy for breach of this limited warranty is repair of the defect or replacement of the Guitar, at Peavey's option, after the Guitar is returned, postage prepaid and insured, along with a description of the problem, proof of purchase and a complete return address to:

PEAVEY ELECTRONICS CORPORATION
711 A Street
Meridian, Mississippi 39301

If the defect is remedial under this limited warranty, and the other terms and conditions expressed herein have been complied with, Peavey will repair or replace the product and will return it, freight collect, to the purchaser. Other than the postage and insurance requirement, no charge will be made for such repair or replacement.

Peavey's liability to the purchaser for any cost whatsoever, and regardless of the form of action, whether in contract or in tort, including negligence, shall be limited to actual damages up to an amount equal to the greater of the purchase price of the product causing the damage or \$500.00. UNDER NO CIRCUMSTANCES WILL PEAVEY BE LIABLE FOR ANY LOST PROFITS, ANY INCIDENTAL DAMAGES OR ANY CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF OR INABILITY TO USE THE GUITAR, EVEN IF PEAVEY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

The foregoing limitation of remedy will not apply to the payment of cost and damage awards for personal injury or damage to real property or tangible personal property caused by negligence on Peavey's part.

THIS LIMITED WARRANTY IS IN LIEU OF ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT

LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE; PROVIDED, HOWEVER, THAT IF THE OTHER TERMS AND CONDITIONS NECESSARY TO THE EXISTENCE OF THE EXPRESS, LIMITED WARRANTY, AS HEREIN ABOVE STATED, HAVE BEEN COMPLIED WITH, IMPLIED WARRANTIES ARE NOT DISCLAIMED DURING THE ONE-YEAR PERIOD FROM DATE OF PURCHASE OF THIS GUITAR.

SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

THIS LIMITED WARRANTY IS THE ONLY EXPRESS WARRANTY ON THIS GUITAR, AND NO OTHER STATEMENT, REPRESENTATION, WARRANTY OR AGREEMENT BY ANY PERSON SHALL BE VALID AS TO OR BINDING UPON PEAVEY.

THE WARRANTY REGISTRATION CARD AND A LEGIBLE COPY OF THE PROOF OF PURCHASE SUPPLIED TO YOU BY THE AUTHORIZED PEAVEY DEALER IN CONNECTION WITH YOUR PURCHASE FROM HIM OF THIS GUITAR SHOULD BE ACCURATELY COMPLETED, MAILED TO AND RECEIVED BY PEAVEY WITHIN FOURTEEN (14) DAYS FROM THE DATE OF YOUR PURCHASE.

Should notification become necessary for any condition that would require correction, the registration card will help insure that you are contacted and properly notified.

If you move from the address shown on the WARRANTY REGISTRATION CARD, you should notify Peavey of the change of address so as to facilitate your receipt of any bulletins or other forms of notification which may become necessary in connection with any condition that may require dissemination of information or correction.

The WARRANTY REGISTRATION CARD and subsequent notices of change of address should be mailed to:

PEAVEY ELECTRONICS CORPORATION
P.O. Box 2898
Meridian, Mississippi 39301

In the event any modification or disclaimer of express or implied warranties, or any limitation of remedies, contained herein conflicts with applicable law, then such modification, disclaimer or limitation, as the case may be, shall be deemed to be modified to the extent necessary to comply with such law.

The limited warranty is given by Peavey Electronics Corporation with respect to equipment purchased in the United States of America.

WARNING

DO NOT USE IMPROPER OR POORLY DESIGNED GUITAR STRAPS OR OTHER MEANS OF SUPPORT. POSSIBLE INJURY COULD RESULT IF IMPROPER, INFERIOR, ILL FITTING OR WORN OUT STRAPS ARE USED. THE INSTRUMENT COULD POSSIBLY FALL, CAUSING BODILY INJURY OR DAMAGE TO THE INSTRUMENT OR ASSOCIATED EQUIPMENT IF THE HOLDING DEVICES FAIL FOR ANY REASON.

DANGER

GUITAR STRINGS ARE MADE FROM VERY STRONG STEEL ALLOYS. THEY ARE DESIGNED TO BE USED UNDER TENSION AND, UNDER CERTAIN CONDITIONS, THEY MAY BREAK AND SPRING AWAY FROM THE GUITAR. DO NOT TUNE OR PLAY THIS INSTRUMENT WITH YOUR FACE IN CLOSE PROXIMITY TO THE STRINGS, AS SERIOUS INJURY COULD RESULT IF A STRING SHOULD BREAK.

CAUTION

THE PEAVEY ELECTRIC CASE™ HAS BEEN DESIGNED AND CONSTRUCTED TO PROVIDE ADEQUATE POWER RESERVE FOR PLAYING MODERN MUSIC WHICH MAY REQUIRE OCCASIONAL PEAK POWER. TO HANDLE OCCASIONAL PEAK POWER, ADEQUATE POWER "HEADROOM" HAS BEEN DESIGNED INTO THIS SYSTEM. EXTENDED OPERATION AT ABSOLUTE MAXIMUM POWER LEVELS IS NOT RECOMMENDED SINCE THIS COULD DAMAGE THE ASSOCIATED LOUDSPEAKER SYSTEM. PLEASE BE AWARE THAT MAXIMUM POWER CAN BE OBTAINED WITH VERY LOW SETTINGS OF THE GAIN CONTROLS IF THE INPUT SIGNAL IS VERY STRONG.

DANGER

ALL AMPLIFICATION ACCESSORIES, MICRO-PHONES, MIXERS, ETC., MUST BE PROPERLY GROUNDED AND SHOULD BE UTILIZED WITH A 3-WIRE MAINS SYSTEM IN ORDER TO AVOID ELECTRICAL SHOCK.

DANGER

DO NOT COME INTO CONTACT WITH OTHER ELECTRICAL APPARATUS WHEN PLAYING (OR TOUCHING) YOUR INSTRUMENT. THE METAL PARTS OF THIS INSTRUMENT ARE GROUNDED ACCORDING TO PROPER AND ACCEPTED INDUSTRY PRACTICE, BUT IT IS POSSIBLE TO ENCOUNTER AN ELECTRICAL SHOCK WHEN COMING INTO CONTACT WITH ANOTHER ELECTRICAL APPARATUS IF IT HAS IMPROPER GROUNDING FACILITIES.



PEAVEY ELECTRONICS CORPORATION
711 A Street / Meridian, MS 39301 / U.S.A.

Due to our efforts for constant improvement, features and specifications are subject to change without notice.

© 1982
Printed in U.S.A.

80370018 5/82