

## IMPORTANT NOTES

There is a risk assumed by individuals who use this type of equipment. To minimize risk, please follow these rules:

- 1. Consult your physician before beginning any exercise program.
- 2. Inspect equipment daily. Tighten all loose connections and replace worn parts immediately. Failure to do so may result in serious injury.
- 3. Do not allow minors or children to play on or around this equipment.
- 4. Exercise with care to avoid injury.
- 5. If unsure of proper use of equipment, call your local Parabody distributor or call the Parabody customer service department at (800) 328-9714.

**Please note:** 

- \* Thank you for purchasing the Parabody 916101 ST Dumbbell. Please read these instructions thoroughly and keep them for future reference. This product must be assembled on a flat, level surface to assure its proper function.
- \* We recommend cleaning your product (pads and frame) on a regular basis, using warm soapy water. Touch-up paint can be purchased from your Parabody customer service representative at (800) 328-9714.

## Tools Required for Assembly

- \* 3/4" wrench
- \* Ratchet with 3/4" socket
- \* Tape measure
  - Bolt Length Ruler

## NOTE: BOLT LENGTH IS MEASURED FROM THE UNDERSIDE OF THE HEAD OF THE BOLT.



## PARTS LIST

1

ę

KEY	PART #	DESCRIPTION	QTY
1	6688301	UPRIGHT FRAME	2
2	6688701	TOP TIER	1
3	6689001	BOTTOM TIER	1
4	3202103	1/2-13 X 4" BOLT	8
5	3102502	1/2" WASHER	8
6	3102801	1/2" LOCKNUT	8

STEP 1: Loosely attach BOTTOM TIER (3) between the UPRIGHT FRAMES (1) using four 1/2 X 4" BOLTS (4) four 1/2" WASHERS (5), and four 1/2" LOCKNUTS (6) as shown in figure 1. (NOTE: BOTTOM TIER (3) is wider than TOP TIER (2).



3



STEP 3: SECURELY TIGHTEN ALL BOLT CONNECTIONS.

ŝ

ŧ٣

