

OPERATING GUIDE

Mark III™ Bass Bass Amp Head



FENDER
®



Intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



Intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

CAUTION Risks of electrical shock — DO NOT OPEN

CAUTION To reduce the risk of electric shock, do not remove cover. No user serviceable parts inside. Refer Servicing to qualified service personnel.

WARNING To prevent electrical shock or fire hazard, do not expose this appliance to rain or moisture. Before using this appliance, read the operating guide for further warnings.



Este símbolo tiene el propósito de alertar al usuario de la presencia de instrucciones importantes sobre la operación y mantenimiento en la literatura que viene con el producto.



Este símbolo tiene el propósito de alertar al usuario de la presencia de “(voltaje) peligroso” que no tiene aislamiento dentro de la caja del producto que puede tener una magnitud suficiente como para constituir riesgo de corrientazo.

PRECAUCION Riesgo de corrientazo - No abra.

PRECAUCION Para disminuir el riesgo de corrientazo, no abra la cubierta. No hay piezas adentro que el usuario pueda reparar. Deje todo mantenimiento a los técnicos calificados.

ADVERTENCIA Para evitar corrientazos o peligro de incendio, no deje expuesto a la lluvia o humedad este aparato. Antes de usar este aparato, lea más advertencias en la guía de operación.



Ce symbole est utilisé pour indiquer à l’utilisateur qu’il ou qu’elle trouvera d’importantes instructions sur l’utilisation et l’entretien (service) de l’appareil dans la littérature accompagnant le produit.



Ce symbole est utilisé pour indiquer à l’utilisateur la présence à l’intérieur de ce produit de tension non-isolée dangereuse pouvant être d’intensité suffisante pour constituer un risque de choc électrique.

ATTENTION Risques de choc électrique — NE PAS OUVRIR!

ATTENTION Afin de réduire le risque de choc électrique, ne pas enlever le couvercle. Il ne se trouve à l’intérieur aucune pièce pouvant être réparée par l’utilisateur. Confier l’entretien à un personnel qualifié.

AVERTISSEMENT Afin de prévenir les risques de décharge électrique ou de feu, n’exposez pas cet appareil à la pluie ou à l’humidité. Avant d’utiliser cet appareil, lisez les avertissements supplémentaires situés dans le guide d’utilisation.



Dieses Symbol soll den Benutzer auf wichtige Instruktionen in der Bedienungsanleitung aufmerksam machen, die Handhabung und Wartung des Produkts betreffen.



Dieses Symbol soll den Anwender vor unisolierten gefährlichen Spannungen innerhalb des Gehäuses warnen, die von Ausreichender Stärke sind, um einen elektrischen Schlag verursachen zu können.

VORSICHT Risiko - Elektrischer Schlag! Nicht öffnen!

VORSICHT Um das Risiko eines elektrischen Schlages zu vermeiden, nicht die Abdeckung entfernen. Es befinden sich keine Teile darin, die vom Anwender repariert werden könnten. Reparaturen nur von qualifiziertem Fachpersonal durchführen lassen.


ACHTUNG Um einen elektrischen Schlag oder Feuergefahr zu vermeiden, sollte dieses Gerät nicht dem Regen oder Feuchtigkeit ausgesetzt werden. Vor Inbetriebnahme unbedingt die Bedienungsanleitung lesen.

E N G L I S H

1 3 4 5 6

11

12



2

7

8

9

10

HIGH GAIN INPUT (1)

Used for most electric guitars. It is 6 dB louder than the Low Gain input.

LOW GAIN INPUT (2)

Provided for instruments that have extremely high outputs, which can result in overdriving (distorting) the High Gain input. If both inputs are used simultaneously, the output levels are the same (both are Low Gain).

PRE GAIN (3)

Controls the input volume level of the amplifier.

BRIGHT SWITCH (4)

Provides a preset boost (± 8 dB) to treble frequencies. To activate, depress the switch to its "in" position.

PUNCH SWITCH (5)

Provides a preset boost (± 8 dB) to midbass frequencies. To activate, depress the switch to its "in" position.

POST GAIN (6)

Controls the overall volume level of the amplifier. The final level adjustment should be made after the desired sound has been achieved.

LINE PATCH (7)

Provided for connecting external effects devices into the signal path. To patch an effects device, connect the send jack to the input of the device. Connect the output of the device to the return jack. High quality shielded cable should be used for these connections.

LOW (8)

An active tone control (shelving type, ± 15 dB) that varies the low frequency boost or cut.

OPERATION NOTE: Excessive EQ boost, especially of the low frequencies, increases the possibility of speaker damage, and sacrifices valuable headroom.

GRAPHIC EQUALIZER (9)

This seven-band, one octave equalizer provides 15 dB of boost or cut at each center frequency.

HIGH (10)

An active tone control (shelving type, ± 15 dB) that varies the high frequency boost or cut.


COMPRESSION LED (11)

The amplifier is equipped with the patented DDT compression circuit (US Patent 4,318,053). The compression circuit eliminates audible power amp clipping, reduces distortion, and protects the loudspeaker. In use the compression LED may occasionally illuminate, indicating that the compressor is engaging to prevent distortion. If the LED is continuously illuminated, Gain control or Low EQ control settings should be reduced to prevent possible loudspeaker damage.

PILOT LED (12)

Illuminates when AC power is being supplied to the amp.

13 14



15 16

LINE CORD (120V PRODUCTS ONLY) (13)

For your safety, we have incorporated a 3-wire line (mains) cable with proper grounding facilities. It is not advisable to remove the ground pin under any circumstances. If it is necessary to use the equipment without proper grounding facilities, suitable grounding adaptors should be used. Less noise and greatly reduced shock hazard exists when the unit is operated with the proper grounded receptacles.

FUSE (14)

The fuse is located within the cap of the fuseholder. If the fuse should fail, IT MUST BE REPLACED WITH THE SAME TYPE AND VALUE IN ORDER TO AVOID DAMAGE TO THE EQUIPMENT AND TO PREVENT VOIDING THE WARRANTY. If the amp repeatedly blows fuses, it should be taken to a qualified service center for repair.

WARNING: THE FUSE SHOULD ONLY BE REPLACED WHEN THE POWER CORD HAS BEEN DISCONNECTED FROM ITS POWER SOURCE.

POWER SWITCH (15)

Center position is OFF. Two ON positions are provided, one of which will properly ground the amplifier. Switch to the ON side that yields the lowest amount of residual hum or popping noise when the instrument is touched. 220 and 240 volt models utilize a two way On/Off switch only.

SPEAKER OUTPUT JACKS (16)

Provided for connection of external speaker(s). Minimum total impedance is 4 ohms.

SPECIFICATIONS

POWER AMP SECTION

Rated Power & Load:

150 W into 4 ohms with DDT™ compression

Power @ Clipping: (Typically)

(1 kHz, 120 V AC line)
155 W RMS into 4 ohms
@ 10% THD
165 W RMS into 4 ohms
@ 5% THD

Frequency Response:

+0, -2 dB, 20 Hz to 30 kHz
@ 140 W RMS into 4 ohms

Total Harmonic Distortion:

Less than 0.2%, 100 mW to 140 W RMS, 20 Hz to 10 kHz, 4 ohms, typically below 0.1%




DDT™ Dynamic Range:

Greater than 20 dB

DDT™ Maximum THD:

Below 0.6% THD for 6 dB overload
Below 1% THD for 16 dB overload

TONE SETTING CHART



Hum & Noise:

Greater than 90 dB below rated power

Power Consumption:

(Domestic)

500 W @ 120 V AC, 50/60 Hz

PREAMP SECTION

The following specs are measured @ 1 kHz with the low, high, graphic EQ @ 0 dB; Push Bright & Push Punch out (off); Post Gain @ 10. Nominal levels are with Pre Gain @ 5; Minimum levels are with Pre Gain @ 10

Preamp High Gain Output:

Impedance: High Z, 220 K ohms
Nominal Input Level: -20 dBV,
100 mV RMS
Minimum Input Level: -40 dBV,
10 mV RMS
Maximum Input Level: +10 dBV,
3 V RMS

Preamp Low Gain Input:

Impedance: High Z, 44K ohms
Nominal Input Level: -14 dBV,
200 mV RMS
Minimum Input Level: -34 dBV,
20 mV RMS
Maximum Input Level: +16 dBV,
6 V RMS

Preamp Output:

Load Impedance: 1 K ohms or greater

Nominal Output Level: 0 dBV,
1.0 V RMS
(At the DDT™ limit of
150 W RMS Output)

Power Amp Input:

Impedance: High Z, 22 K ohms
Designed Input Level: 0 dBV,
1 V RMS
(Switching jack providing
preamp output to power amp
input connection when not used)

System Hum & Noise

@ Nominal Input Level:

(20 Hz to 20 kHz unweighted)
Greater than 86 dB below
weighted power

Equalization:

Low & High: ±15 dB @ 80 Hz
& 8 kHz, Shelving
7 Band Graphic: ±15 dB @ 120,
180, 340, 660, 1.3 K, 2.6 K,
5 K; Peak/Notch
Push Bright: +8 dB @ 2 kHz
Push Punch: Special EQ

E S P A Ñ O L

Consulte los diagramas del panel delantero en la sección de inglés de este manual.

HIGH GAIN INPUT (Entrada de ganancia alta) (1)

Se usa para la mayoría de las guitarras eléctricas. Tiene 6 dB más volumen que la entrada de baja ganancia.

LOW GAIN INPUT (Entrada de baja ganancia) (2)

Se suministra para instrumentos que tienen una salida extremadamente alta, la cual puede causar la sobrecarga (distorsión) de la entrada de alta ganancia. Si se usan ambas entradas simultáneamente, el nivel de salida es el mismo (ambos son de baja ganancia).

PRE GAIN (Control del preamplificador) (3)

Controla el nivel de volumen a la entrada del amplificador.

BRIGHT SWITCH (Interruptor de brillo) (4)

Proporciona un impulso de +8 dB a las frecuencias agudas. Para activar empuje el interruptor hacia dentro.

PUNCH SWITCH (Interruptor para obtener más impulso) (5)

Provee un aumento de ±8 dB a las frecuencias medias graves. Para activar este control empuje hacia dentro.

POST GAIN (Control de ganancia posterior al preamplificador) (6)

Controla el nivel global de volumen del amplificador. El ajuste final de nivel debe hacerse una vez que se haya conseguido el sonido deseado.

LINE PATCH (Puenteo de cable) (7)

Se proporcionan enchufes hembras para conectar aparatos de efectos externos a la trayectoria de la señal. Para hacer puenteo con un aparato de efectos, conecte el enchufe hembra a la entrada del aparato. Conecte la salida del aparato al enchufe hembra de retorno. Se deben usar cables blindados de alta calidad para estas conexiones.

LOW (Bajo) (8)

Un control de tono activo (tipo "repisa" ±15 dB) que varía la baja frecuencia, la aumenta o la disminuye.

NOTA DE OPERACION: El exceso de ecualización, especialmente en las frecuencias graves, aumenta la posibilidad de dañar los altavoces y también desperdicia valiosa gama dinámica.

GRAPHIC EQUALIZER (Ecualizador gráfico) (9)

Este ecualizador de 7 bandas y una octava proporciona 15 dB de impulso o reducción a cada frecuencia media.

HIGH (Control de frecuencias agudas) (10)


Un control de tono activo (tipo "repisa" ±15 dB) que varía el impulso o la reducción de las frecuencias agudas.

COMPRESSION LED (LED que indica compresión) (11)

El amplificador está provisto del circuito de compresión patentado "DDT". El circuito de compresión elimina el recorte de señales audibles del amplificador de potencia, reduce la distorsión y protege el altavoz. El LED que indica compresión puede iluminarse ocasionalmente durante la operación indicando que el compresor está activado para evitar distorsión. Si el LED está constantemente iluminado, se deben disminuir los valores del control de ganancia o del control del ecualizador de frecuencias graves para evitar posible daño al altavoz.

PILOT LIGHT LED (LED indicadora de lámpara piloto) (12)

Se ilumina cuando el amplificador recibe corriente alterna.



LINE CORD (120 V PRODUCTS ONLY) (Cable de corriente para 120 v solamente) (13)

Para su protección hemos incorporado un cable de 3 polos con polo a tierra. No es recomendable remover la pata del polo a tierra bajo ninguna circunstancia, se recomienda un adaptador en caso necesario. Esto reducirá ruidos y peligrosos corrientazos.

FUSE (Fusible) (14)

El fusible se encuentra localizado dentro de la cápsula del portafusible. Si el fusible se quema o falla, SE DEBERÁ REEMPLAZAR CON UNO DEL MISMO TIPO Y VALOR, PARA EVITAR DAÑO AL APARATO Y EL ANULAMIENTO DE LA GARANTIA. Si el aparato quema los fusibles repetidamente, cerciórese de que está conectado a un tomacorriente con el voltaje adecuado, si esto es correcto, entonces desconéctelo y llévelo a revisión por un técnico autorizado.

ATENCION: Antes de reemplazar el fusible quemado, cerciórese de que el aparato está completamente desconectado del tomacorriente.

POWER SWITCH (Interruptor de corriente) (15)

La posición del centro es "OFF" (Apagado). Tiene dos posiciones "ON" (Encendido), una de las cuales conectarán el amplificador correctamente a tierra. Elija el lado "ON" que produce menos zumbido residual o ruido al tocar el instrumento. Los modelos para 220 y 240 voltios utilizan un interruptor de dos posiciones solamente: "ON/OFF".

SPEAKER OUTPUTS (Salidas de altavoces) (16)

Se suministra para la conexión de altavoz(ces) externo(s). El mínimo total de impedancia es de 4 ohms.

F R A N C A I S

Veuillez vous référer au “front panel line art”
situé dans la section en langue anglaise de ce manuel.

HIGH GAIN INPUT (Entrée haut gain) (1)

Cette prise s'utilise avec la plupart des guitares électriques. Elle donne un gain supérieur de 6dB à l'entrée “Low Gain”.

LOW GAIN INPUT (Entrée faible Gain) (2)

Cette prise accepte les instruments à très haut niveau de sortie qui causeraient de la saturation (distorsion) sur l'entrée “High Gain”. Si les deux entrées sont utilisées simultanément, les niveaux sont alors équivalents (“Low Gain”).

PRE GAIN (3)

Contrôle le niveau de volume à l'entrée de l'amplificateur.

BRIGHT SWITCH (Interrupteur “Bright”) (4)

Accentue (de ±8 dB) les fréquences aiguës. Enfoncer l'interrupteur à la position “In” pour mettre en service.

PUNCH SWITCH (Sélecteur “Punch”) (5)

Accentue (préréglé à ±8 dB) les fréquences moyennes graves. Activer en abaissant l'interrupteur à la position “In”.

POST GAIN (6)

Commande le volume global de l'amplificateur. Le réglage final de niveau doit être effectué après avoir obtenu la sonorité désirée à l'aide des autres réglages.

LINE PATCH (Branchement de ligne) (7)

Sert à introduire des appareils d'effets externes dans le cheminement du signal. Pour brancher un appareils d'effets, branchez la prise d'envoi à l'entrée de l'appareil. Branchez la sortie de l'appareil à la prise de retour. Utilisez des câbles blindés de haute qualité pour ces connexions.

LOW (Graves) (8)

Réglage de tonalité actif (type passe-bas, ±15 dB), faisant varier l'atténuation ou l'accentuation des fréquences graves.

NOTE: Une accentuation excessive par égalisation (“EQ”), surtout dans les fréquences graves, augmente les risques de dommages aux haut-parleurs et diminue la réserve de puissance disponible.

GRAPHIC EQUALIZER (Égalisateur graphique) (9)

Cet égalisateur graphique à 7 bandes/une octave coupe ou renforce de 15dB à chaque fréquence centrale.

HIGH (Aiguës) (10)


Réglage de tonalité actif (type passe-haut, ±15 dB) contrôlant l'atténuation ou l'amplification des fréquences aiguës.

COMPRESSION LED (DEL témoin de compression) (11)

Cet amplificateur est équipé d'un circuit de compression DDT (brevet U.S. 4,318,053). Ce circuit élimine l'écrêttement audible, réduit la distorsion et protège le haut-parleur. Au cours du fonctionnement, la diode témoin de compression peut clignoter, indiquant alors la mise en service du compresseur afin d'éviter la distorsion. Si la diode reste allumée continuellement, il faut réduire les réglages “Gain” ou “Low EQ” pour éviter d'endommager les haut-parleurs.

PILOT LIGHT LED (DEL témoin) (12)

S'allume lorsque l'ampli reçoit l'alimentation CA.



LINE CORD (120V products only) (Cordon d'alimentation pour appareils 120V seulement) (13)

Pour votre sécurité, nous avons incorporé un câble d'alimentation secteur à 3 fils avec mise-à-terre appropriée. Il n'est pas recommandé d'enlever la broche de mise-à-terre en aucune circonstance. S'il est nécessaire d'utiliser l'équipement sans mise-à-terre appropriée, utilisez des adaptateurs de mise-à-terre convenables. Une bonne mise-à-terre amoindrit le bruit de fond et réduit grandement les risques de choc.

FUSE (Fusible) (14)

Le fusible se trouve à l'intérieur de son support. Si le fusible grille, IL DOIT ÊTRE REMPLACÉ PAR UN FUSIBLE DE MÉME TYPE ET MÉME VALEUR POUR ÉVITER TOUT DOMMAGE À L'APPAREIL ET ÉVITER D'ANNULER LA GARANTIE. Si le fusible grille de façon répétée, apportez l'appareil à un centre de service qualifié pour réparation. AVERTISSEMENT: LE FUSIBLE NE DOIT ÊTRE REMPLACÉ QUE LORSQUE LE CORDON D'ALIMENTATION EST DÉ BRANCHÉ DE LA SOURCE D'ALIMENTATION.

POWER SWITCH (Interrupteur d'alimentation) (15)

La position "Off" (hors service) est située au centre. Deux positions "On" (en service) sont disponibles, assurant ainsi une mise à terre appropriée. Sélectionnez le côté "On" sous lequel il y a le moins de bourdonnement ("hum"), de bruits et de craquements quand l'instrument est touché. Les modèles 220 et 240 volts sont équipés d'un interrupteur ne comportant que deux positions ("On/Off").

SPEAKER OUTPUTS (Sorties haut-parleur) (16)

Prises de sortie pour haut-parleur(s) externes(s). L'impédance totale résultante doit être au minimum de 4 ohms.

D E U T S C H

Siehe diagramm der frontplatte im englischen teil des handbuchs.

HIGH GAIN INPUT (1)

Dieser Eingang kann für die meisten elektrischen Gitarren verwendet werden. Er ist 6 dB empfindlicher als der Low Gain Input.

LOW GAIN INPUT (2)

Dieser Eingang ist für die Instrumente vorgesehen, die ein besonders hohes Ausgangssignal erzeugen. Falls beide Eingänge gleichzeitig benutzt werden, sind die Ausgangssignale gleich (beide sind dann Low Gain).

PRE GAIN (3)

Regelt die Eingangsempfindlichkeit des Verstärkers.

BRIGHT SWITCH (Bright-Schalter) (4)

Bewirkt eine voreingestellte Anhebung der hohen Frequenzen um 8 dB. Die Bright-Einstellung wird bei eingedrücktem Schalter (“In”) aktiviert.

PUNCH SWITCH (Punch-Schalter) (5)

Bewirkt eine voreingestellte Anhebung um 8 dB im Bassbereich. Wird bei eingedrücktem Schalter (“In”) aktiviert.

POST GAIN (6)

Kontrolliert die Gesamtlautstärke des Verstärkers. Die engültige Lautstärke sollte erst eingestellt werden, wenn der gewünschte Sound erreicht ist.

LINE PATCH (7)

Dient zum Anschluß externer Effektgeräte in den Signalweg. Die “Send”-Buchse muß mit dem Input des Effektgeräts verbunden werden, der Output des Geräts mit der “Return”-Buchse. Für diese Verbindungen hochwertige abgeschirmte Kabel verwenden.

LOW (8)

Eine aktive Klangregelung (± 15 dB) zur Anhebung oder Absenkung der tiefen Frequenzen.

BEDIENUNGSHINWEIS: Eine extreme Anhebung der Klangregelung insbesondere in den tiefen Frequenzen vergrößert die Gefahr von Lautsprecherschäden und beschneidet den verfügbaren Dynamikbereich (Headroom).

GRAPHIC EQUALIZER (Graphic Equalizer) (9)

Dieser Sieben-Band-Equalizer ermöglicht eine Anhebung oder Absenkung von 15 dB der Eckfrequenzen.

HIGH (10)


Eine aktive Klangregelung (± 15 dB) zur Anhebung oder Absenkung der hohen Frequenzen.

COMPRESSION LED (11)

Der Verstärker ist mit dem patentierten DDT Compression System ausgestattet. Das Compression System eliminiert hörbares “Clippen” der Endstufe, reduziert Verzerrung und schützt den Lautsprecher. Im Betrieb kann das Compression-LED gelegentlich aufleuchten, um anzudeuten, daß der Compressor arbeitet, um Verzerrungen zu unterdrücken. Wenn das LED ununterbrochen aufleuchtet, müssen die Gain- oder Low EQ-Reglerstellungen reduziert werden, um einem möglichen Lautsprecher-schaden vorzubeugen.

PILOT LIGHT (12)

Leuchtet auf, wenn das Gerät eingeschaltet ist.



LINE CORD (120V products only) (Nur bei 120 Volt-Geräten) (13)

Zu Ihrer Sicherheit haben wir das Gerät mit einem dreiadriegen geerdeten Netzkabel versehen. Es ist unter keinen Umständen empfehlenswert den Erdungskontakt des Anschlußkabels zu lösen. Falls es notwendig sein sollte, das Equipment ohne die vorgesehene Erdung zu betreiben empfiehlt sich die Verwendung eines Grounding Adaptors. Die geringsten Störgeräusche und die höchste Sicherheit vor elektrischen Schlägen wird jedoch durch die Benutzung der vorgesehenen Erdungsmöglichkeiten erreicht.

FUSE (14)

Die Sicherung befindet sich innerhalb der Kappe des Sicherungshalters. Wenn die Sicherung durchbrennt, MUSS SIE DURCH EINE DES GLEICHEN TYPS UND MIT DEM GLEICHEN WERT ERSETZT WERDEN, UM DAS GERÄT ZU SCHÜTZEN UND DIE GARANTIELEISTUNGEN ZU ERHALTEN. Wenn am Verstärker wiederholt die Sicherung durchbrennt, muß das Gerät in eine qualifizierte Fachwerkstatt.

WARNUNG: SICHERUNGSWECHSEL NUR BEI ABGEZOGENEM NETZKABEL VORNEHMEN!

POWER SWITCH (Netzschalter) (15)

Die Exportgeräte mit 220/240 Volt Netzspannung sind mit einem On/Off-Schalter versehen.

SPEAKER OUTPUTS (Speaker Outputs) (16)

Vorgesehen für den Anschluß externer Lautsprecher. Die Gesamtimpedanz von 4 Ohm darf nicht unterschritten werden.

THIS LIMITED WARRANTY VALID ONLY WHEN PURCHASED AND REGISTERED IN THE UNITED STATES OR CANADA. ALL EXPORTED PRODUCTS ARE SUBJECT TO WARRANTY AND SERVICES TO BE SPECIFIED AND PROVIDED BY THE AUTHORIZED DISTRIBUTOR FOR EACH COUNTRY.
Ces clauses de garantie ne sont valables qu'aux Etats-Unis et au Canada. Dans tous les autres pays, les clauses de garantie et de maintenance sont fixées par le distributeur national et assurée par lui selon la législation en vigueur.
Diese Garantie ist nur in den USA und Kanada gültig. Alle Export-Produkte sind der Garantie und dem Service des Importeurs des jeweiligen Landes unterworfen.
Esta garantía es válida solamente cuando el producto es comprado en E.U. continentales o en Canadá. Todos los productos que sean comprados en el extranjero, están sujetos a las garantías y servicio que cada distribuidor autorizado determine y ofrezca en los diferentes países.

**PEAVEY ONE-YEAR LIMITED
WARRANTY/REMEDY**

PEAVEY ELECTRONICS CORPORATION ("PEAVEY") warrants this product, EXCEPT for covers, footswitches, patchcords, tubes and meters, to be free from defects in material and workmanship for a period of one (1) year from date of purchase, PROVIDED, however, that this limited warranty is extended only to the original retail purchaser and is subject to the conditions, exclusions, and limitations hereinafter set forth:

PEAVEY 90-DAY LIMITED WARRANTY ON TUBES AND METERS

If this product contains tubes or meters, Peavey warrants the tubes or meters contained in the product to be free from defects in material and workmanship for a period of ninety (90) days from date of purchase; PROVIDED, however, that this limited warranty is extended only to the original retail purchaser and is also subject to the conditions, exclusions, and limitations hereinafter set forth.

CONDITIONS, EXCLUSIONS, AND LIMITATIONS OF LIMITED WARRANTIES

These limited warranties shall be void and of no effect, if:

- a. The first purchase of the product is for the purpose of resale; or
 - b. The original retail purchase is not made from an AUTHORIZED PEAVEY DEALER; or
 - c. The product has been damaged by accident or unreasonable use, neglect, improper service or maintenance, or other causes not arising out of defects in material or workmanship; or
 - d. The serial number affixed to the product is altered, defaced, or removed.
- In the event of a defect in material and/or workmanship covered by this limited warranty, Peavey will:
- a. In the case of tubes or meters, replace the defective component without charge.
 - b. In other covered cases (i.e., cases involving anything other than covers, footswitches, patchcords, tubes or meters), repair the defect in material or workmanship or replace the product, at Peavey's option; and provided, however, that, in any case, all costs of shipping, if necessary, are paid by you, the purchaser.

THE WARRANTY REGISTRATION CARD SHOULD BE ACCURATELY COMPLETED AND MAILED TO AND RECEIVED BY PEAVEY WITHIN FOURTEEN (14) DAYS FROM THE DATE OF YOUR PURCHASE.

In order to obtain service under these warranties, you must:

- a. Bring the defective item to any PEAVEY AUTHORIZED DEALER or AUTHORIZED PEAVEY SERVICE CENTER and present therewith the ORIGINAL PROOF OF PURCHASE supplied to you by the AUTHORIZED PEAVEY DEALER in connection with your purchase from him of this product.
- If the DEALER or SERVICE CENTER is unable to provide the necessary warranty service you will be directed to the nearest other PEAVEY AUTHORIZED DEALER or AUTHORIZED PEAVEY SERVICE CENTER which can provide such service.

OR

- b. Ship the defective item, prepaid, to:

PEAVEY ELECTRONICS CORPORATION
International Service Center
Highway 80 East
MERIDIAN, MS 39301

including therewith a complete, detailed description of the problem, together with a legible copy of the original PROOF OF PURCHASE and a complete return address. Upon Peavey's receipt of these items:

If the defect is remedial under these limited warranties and the other terms and conditions expressed herein have been complied with, Peavey will provide the necessary warranty service to repair or replace the product and will return it, FREIGHT COLLECT, to you, the purchaser.

Peavey's liability to the purchaser for damages from any cause whatsoever and regardless of the form of action, including negligence, is limited to the actual damages up to the greater of \$500.00 or an amount equal to the purchase price of the product that caused the damage or that is the subject of or is directly related to the cause of action. Such purchase price will be that in effect for the specific product when the cause of action arose. This limitation of liability will not apply to claims for personal injury or damage to real property or tangible personal property allegedly caused by Peavey's negligence. Peavey does not assume liability for personal injury or property damage arising out of or caused by a non-Peavey alteration or attachment, nor does Peavey assume any responsibility for damage to interconnected non-Peavey equipment that may result from the normal functioning and maintenance of the Peavey equipment.

UNDER NO CIRCUMSTANCES WILL PEAVEY BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, ANY INCIDENTAL DAMAGES, OR ANY CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT, EVEN IF PEAVEY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

THESE LIMITED WARRANTIES ARE IN LIEU OF ANY AND ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE; PROVIDED, HOWEVER, THAT IF THE OTHER TERMS AND CONDITIONS NECESSARY TO THE EXISTENCE OF THE EXPRESSED, LIMITED WARRANTIES, AS HEREINABOVE STATED, HAVE BEEN COMPLIED WITH, IMPLIED WARRANTIES ARE NOT DISCLAIMED DURING THE APPLICABLE ONE-YEAR OR NINETY-DAY PERIOD FROM DATE OF PURCHASE OF THIS PRODUCT.

SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THESE LIMITED WARRANTIES GIVE YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

THESE LIMITED WARRANTIES ARE THE ONLY EXPRESSED WARRANTIES ON THIS PRODUCT, AND NO OTHER STATEMENT, REPRESENTATION, WARRANTY, OR AGREEMENT BY ANY PERSON SHALL BE VALID OR BINDING UPON PEAVEY.

In the event of any modification or disclaimer of expressed or implied warranties, or any limitation of remedies, contained herein conflicts with applicable law, then such modification, disclaimer or limitation, as the case may be, shall be deemed to be modified to the extent necessary to comply with such law.

Your remedies for breach of these warranties are limited to those remedies provided herein and Peavey Electronics Corporation gives this limited warranty only with respect to equipment purchased in the United States of America.

INSTRUCTIONS — WARRANTY REGISTRATION CARD

1. Mail the completed WARRANTY REGISTRATION CARD to:

PEAVEY ELECTRONICS CORPORATION
POST OFFICE BOX 2898
MERIDIAN, MISSISSIPPI 39302-2898

- a. Keep the PROOF OF PURCHASE. In the event warranty service is required during the warranty period, you will need this document. There will be no identification card issued by Peavey Electronics Corporation.
2. IMPORTANCE OF WARRANTY REGISTRATION CARDS AND NOTIFICATION OF CHANGES OF ADDRESSES:
 - a. Completion and mailing of WARRANTY REGISTRATION CARDS — Should notification become necessary for any condition that may require correction, the REGISTRATION CARD will help ensure that you are contacted and properly notified.
 - b. Notice of address changes — If you move from the address shown on the WARRANTY REGISTRATION CARD, you should notify Peavey of the change of address so as to facilitate your receipt of any bulletins or other forms of notification which may become necessary in connection with any condition that may require dissemination of information or correction.
3. You may contact Peavey directly by telephoning (601) 483-5365.

IMPORTANT SAFETY INSTRUCTIONS

WARNING When using electric products, basic cautions should always be followed, including the following.

1. Read all safety and operating instructions before using this product.
2. All safety and operating instructions should be retained for future reference.
3. Obey all cautions in the operating instructions and on the back of the unit.
4. All operating instructions should be followed.
5. This product should not be used near water, i.e., a bathtub, sink, swimming pool, wet basement, etc.
6. This product should be located so that its position does no interfere with its proper ventilation. It should not be placed flat against a wall or placed in a built-in enclosure that will impede the flow of cooling air.
7. This product should not be placed near a source of heat such as a stove, radiator, or another heat producing amplifier.
8. Connect only to a power supply of the type marked on the unit adjacent to the power supply cord.
9. Never break off the ground pin on the power supply cord. For more information on grounding, write for our free booklet "Shock Hazard and Grounding."
10. Power supply cords should always be handled carefully. Never walk or place equipment on power supply cords. Periodically check cords for cuts or signs of stress, especially at the plug and the point where the cord exits the unit.
11. The power supply cord should be unplugged when the unit is to be unused for long periods of time.
12. If this product is to be mounted in an equipment rack, rear support should be provided.
13. Metal parts can be cleaned with a damp rag. The vinyl covering used on some units can be cleaned with a damp rag, or an ammonia-based household cleaner if necessary. Disconnect unit from power supply before cleaning.
14. Care should be taken so that objects do not fall and liquids are not spilled into the unit through the ventilation holes or any other openings.
15. This unit should be checked by a qualified service technician if
 - a. The power supply cord or plug has been damaged.
 - b. Anything has fallen or been spilled into the unit.
 - c. The unit does not operate correctly.
 - d. The unit has been dropped or the enclosure damaged.
16. The user should not attempt to service this equipment. All service work should be done by a qualified service technician.
17. This product should be used only with a cart or stand that is recommended by Peavey Electronics.
18. Exposure to extremely high noise levels may cause a permanent hearing loss. Individuals vary considerably in susceptibility to noise induced hearing loss, but nearly everyone will lose some hearing if exposed to sufficiently intense noise for a sufficient time.

The U.S. Government's Occupational Safety and Health Administration (OSHA) has specified the following permissible noise level exposures.

Duration Per Day In Hours	Sound Level dBA, Slow Response
8	90
6	92
4	95
3	97
2	100
1½	102
1	105
½	110
¼ or less	115

According to OSHA, any exposure in excess of the above permissible limits could result in some hearing loss.

Ear plugs or protectors in the ear canals or over the ears must be worn when operating this amplification system in order to prevent a permanent hearing loss if exposure is in excess of the limits as set forth above. To ensure against potentially dangerous exposure to high sound pressure levels, it is recommended that all persons exposed to equipment capable of producing high sound pressure levels such as this amplification system be protected by hearing protectors while this unit is in operation.

SAVE THESE INSTRUCTIONS



Features and specifications subject to change without notice.

Peavey Electronics Corporation 711 A Street / Meridian, MS 39302-2898 / U.S.A. / (601) 483-5365 / Telex 504115 / Fax 484-4278
©1992 #80300959

Printed in U.S.A. 8/92