


HARDWARE INCLUDED

it all starts with a vision




500 South CP Avenue • P.O. Box 280 • Lake Mills, WI 53551
 toll free 800.335.4348 • phone 920.648.4090 • fax 920.648.3373
 www.visionfitness.com

©2006 Vision Fitness. All Rights Reserved. 6.06
 A616.43PRD
 REV1



TOOLS & PARTS INCLUDED



Assembly Guide

R2050 AND R2150

STEP-THRU SEMI-RECUMBENT FITNESS BIKES

To avoid possible damage to this Fitness Bike, please follow these assembly steps in the correct order. Before proceeding, find your new Fitness Bike's serial number located on the front axle tube, and enter here:


Refer to this number when calling for service, and enter this serial number on your Warranty Card and in your own records. Be sure to read your Owner's Guide before using your new Fitness Bike. **If any parts, hardware or tools are missing, please call 1.800.335.4348, Extension 12.**

NOTE: It is recommended that you apply grease to the threads of each bolt and screw as you assemble your Fitness Bike to prevent loosening and noise. Also, during each assembly step, ensure that ALL bolts and screws are in place and partially threaded in before completely tightening any ONE bolt or screw.

STEP 1

ORANGE BAG

- Slide the Rear Foot into place on the back end of the frame. Secure the foot bolt (M8x20) to the frame with two lock washers (SW8) to the inside holes and two lock washers (SW8) to the inside holes. Tighten with the 5mm T-Handle Wrench.
- Attach each half of the rear foot joint cover with the M4x10 L screw. Tighten with the screwdriver.




STEP 1

STEP 2

BLUE BAG

- Rotate the handle on the seat frame to the forward position. Tighten the adjustment bolt on the seat frame bracket with the 5mm T-Stopper wrench.
- Slide the seat frame onto the seat rail. Attach the seat rail stopper onto the seat rail with two M8x25 L bolts and two lock washers (SW8). Tighten with the 5mm T-Handle wrench.
- Connect the heart rate wires in the seat handlebar to the heart rate wires coming up from the seat frame.
- Mount the seat handlebars to the seat frame with four bolts (M8x1.5) and four lock washers (SW8). Tighten with the 5mm T-Handle wrench.
- Mount the seat bottom cushion to the seat frame with four bolts (M6x3.5) and four arc washers (AW). Tighten with the 4mm T-shaped wrench.
- Mount the seatback cushion to the seat frame with four bolts (M6x3.5) and four arc washers (AW). Tighten with the 4mm T-shaped wrench.




STEP 2

STEP 3

PINK BAG

- Slide the console mast cover onto the console mast.
- Take the wire tie that exits the bottom of the console mast and wrap it around the wire harness and heart rate wires that are sitting in the console mast bracket on the frame. Pull the wire tie up through the top of the console mast so that the wire harness and heart rate wires exit the top of the mast.
- Slide the bottom of the console mast over the frame bracket being careful not to pinch the heart rate wires or wire harness. Assume the mast is positioned correctly by inserting the Set Screw (M8x10) through the front edge of the mast. Tighten with the 5mm T-Handle wrench. Secure the mast to the frame with four bolts (M8x1.5) and four lock washers (SW8). Tighten with the 5mm T-Handle wrench.
- Slide the console mast cover down so it sits on the frame covers.
- Mount the console mast handlebar to the console mast with two bolts (M8x20) and two lock washers (SW8). Tighten with the 5mm T-Handle wrench.
- With the screwdriver, remove the four bolts on the back side of the console. Plug in the wire harness and heart rate wires to the back side of the console. Mount the console to the console mast with the four bolts and screwdriver.
- Remove the water bottle cage bolts from the backside of the console mast. Mount the water bottle cage to the mast with these two bolts and the screwdriver.




STEP 4

STEP 4

PEDALS

- Attach the left and right pedals to the left and right crank arms. **NOTE:** The left and right crank arms should be labeled left or right. Tighten with the included pedal wrench.
- Plug in the power supply to the power socket on the front side of the bike.



STEP 3