



Power Master

User Manual



Dear User,
Thank you for purchasing BRIK **Power Master**.
Please read this User Manual before operating the machine to ensure its best performance and your safety.

Instructions:

Connecting BRIK

- Use 2.1mm diameter cables (thinner ones) to connect BRIK **12V In** items to **Power Master's DC12V** sockets.
- Use the 2.5mm diameter cable (thicker one) to connect BRIK **Integrated Amplifier 20V In** to **Power Master's DC20V** socket.

Connecting Mains

- This unit is supplied with a power supply suitable for your country's mains supply. Before connecting, check the label to ensure the local power supply is compliant.

CAUTION: Connect the power cable to the **Power Master's AC 115V / AC 230V** socket before connecting to the mains. Once this has been done, press the **Power** button on the front panel to turn on the machine.

Switching On/Off

- Press **Power** button on the front panel of **Power Master** to turn on/off all machines connected.
- Use the switch on an individual item's rear panel or press **Power** button on its front panel to turn on/off the individual item.

-- **Power Master** is designed for BRIK **Integrated Amplifier** with additional BRIK items. Do NOT use **Power Master** as the power supply to other machines.

BRIK[®]

Power Master




Power

Specifications:

POWER SUPPLY - A
POWER SUPPLY - B
POWER INPUT

POWER CONSUMPTION
DIMENSION

DC 12V x 4
DC 20V x 1
AC 230V 50HZ (Europe)
AC 115V 60HZ (US)
18W
W 140 x H 48 x D160 mm





CE ~~RoHS~~

The information was correct at the time of going to press. The manufacturer reserves the rights to make changes to the technical specification without prior notice.

The manufacturer accepts no responsibility for damage caused by not adhering to these instructions for use. Modification or change to any part of the product by unauthorized persons releases the manufacturer from any liability over and above the lawful rights of the customer.