

WARNING: SOME DUST CREATED BY POWER SANDING, SAWING, GRINDING, DRILLING, AND OTHER CONSTRUCTION ACTIVITIES contains chemicals known to cause cancer, birth defects or other

reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
 arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

GENERAL SAFETY RULES

WARNING: READ AND UNDERSTAND ALL INSTRUCTIONS. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

SAVE THESE INSTRUCTIONS.

WORK AREA

1. Keep your work area clean and well lit. Cluttered benches and dark areas invite accidents.

2. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.

3. Keep bystanders, children, and visitors away while operating a power tool. Distractions can cause you to lose control.

ELECTRICAL SAFETY

1. Double insulated tools are equipped with a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Do not change the plug in any way. Double Insulation is eliminates the need for the three wire grounded power cord and grounded power supply system.

2. Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is grounded.

3. Don't expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

4. Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock.

5. When operating a power tool outside, use an outdoor extension cord marked "W-A" or "W". These cords are rated for outdoor use and reduce the risk of electric shock.

PERSONAL SAFETY

1. Stay alert, watch what you are doing, and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools may result in serious personal injury.

2. Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.

3. Avoid accidental starting. Be sure switch is OFF before plugging in. Carrying tools with your finger on the switch or plugging in tools that have the switch ON invites accidents.

4. Remove adjusting keys or wrenches before turning the tool ON. A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.

5. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enable better control of the tool in unexpected situations.

6. Use safety equipment. Always wear eye protection. Dust mask, nonskid safety shoes, hard hat, or hearing protection must be used for appropriate conditions.

TOOLS USE AND CARE

1. Use clamps or other practical way to secure and support the workpiece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.

2. Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.

3. Do not use tool if switch does not turn it ON or OFF. A tool that cannot be controlled with the switch is dangerous and must be repaired.

4. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.

5. Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.

6. Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools, with sharp cutting edges are less likely to bind and are easier to control.

7. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tool's operation. If damaged, have the tool serviced before using. Many accidents are caused by poorly maintained tools.

8. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool may become hazardous when used on another tool.

SERVICE

1. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel may result in a risk of injury.

2. When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance Section of this manual. Use of unauthorized parts or failure to follow Maintenance Instructions may create a risk of electric shock or injury.

SPECIFIC SAFETY RULES AND SYMBOLS

1. Accessories must be rated for at least the speed recommended on the tool warning label. Wheels and other accessories running over rated speed can fly apart and cause injury.

2. Hold tool by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will also make exposed metal parts of the tool "live" and shock the operator.

3. WARNING: There are certain applications for which this tool was designed. Porter-Cable strongly recommends that this tool NOT be modified and/or used for any application other than for which it was designed. If you have any questions relative to its application DO NOT use the tool until you have written Porter-Cable and we have advised you.

Technical Service Manager Porter-Cable Corporation 4825 Highway 45 North Jackson, TN 38305

SYMBOL

V	 volts				
A	 amperes				
Hz	 hertz				
W	 watts				
kW	 kilowatts				
μF	 microfarads				
I	 liters				
kg	 kilograms				
N/cm ²	 newtons per square centimeter				
Pa	 pascals				
h	 hours				
min	 minutes				
S	 seconds				
\sim	 alternating current				
3 ~	 three-phase alternating current				
3м ∕∕	 three-phase alternating current with neutral				
	 direct current				
n ₀	 no load				
$\overline{\sim}$	 alternating or direct current				
	 Class II Construction				
	 splash-proof construction				
**	 watertight construction				
/min	 revolutions or reciprocation per minute				

DEFINITION

4

MOTOR

Many Porter-Cable tools will operate on either D.C., or single phase 25 to 60 cycle A.C. current and voltage within plus or minus 5 percent of that shown on the specification plate on the tool. Several models, however, are designed for A.C. current only. Refer to the specification plate on your tool for proper voltage and current rating.

CAUTION: Do not operate your tool on a current on which the voltage is not within correct limits. Do not operate tools rated A.C. only on D.C. current. To do so may seriously damage the tool.

EXTENSION CORD SELECTION

If an extension cord is used, make sure the conductor size is large enough to prevent excessive voltage drop which will cause loss of power and possible motor damage. A table of recommended extension cord sizes will be found in this section. This table is based on limiting line voltage drop to 5 volts (10 volts for 230 volts) at 150% of rated amperes.

If an extension cord is to be used outdoors it must be marked with the suffix W-A or W following the cord type designation. For example – SJTW-A to indicate it is acceptable for outdoor use.

Length of Cord in Feet												
115V		25 Ft.	50 Ft.	100 Ft.	150 Ft.	200 Ft.	250 Ft.	300 Ft.	400 Ft.	500 Ft.		
230V		50 Ft.	100 Ft.	200 Ft.	300 Ft.	400 Ft.	500 Ft.	600 Ft.	800 Ft.	1000 Ft.		
Nameplate Ampere Rating	0-2	18	18	18	16	16	14	14	12	12		
	2-3	18	18	16	14	14	12	12	10	10		
	3-4	18	18	16	14	12	12	10	10	8		
	4-5	18	18	14	12	12	10	10	8	8		
	5-6	18	16	14	12	10	10	8	8	6		
	6-8	18	16	12	10	10	8	6	6	6		
	8-10	18	14	12	10	8	8	6	6	4		
	10-12	16	14	10	8	8	6	6	4	4		
	12-14	16	12	10	8	6	6	6	4	2		
	14-16	16	12	10	8	6	6	4	4	2		
	16-18	14	12	8	8	6	4	4	2	2		
	18-20	14	12	8	6	6	4	4	2	2		

RECOMMENDED EXTENSION CORD SIZES FOR USE WITH PORTABLE ELECTRIC TOOLS

FUNCTIONAL DESCRIPTION

FOREWORD

The Porter-Cable Polisher is designed for buffing, polishing, rubbing, and general cleaning jobs.

ASSEMBLY

TO INSTALL BAILING HANDLE

A bailing handle (A), Fig. 1, is furnished with the polisher. The bailing handle may be installed on either side of the front housing to facilitate either right-handed or left-handed operation. **NOTE: This bailing handle SHOULD BE USED AT ALL TIMES to maintain complete control of the machine.**

Attach bailing handle (A) Fig. 2 with two M8 x 1 cap screws provided one of which is shown at (B) Fig. 2. Tighten securely with 6mm allen wrench provided.



Fig. 2

TO INSTALL BACK-UP PAD

The Porter-Cable Polisher has a "Hook & Loop" style back-up pad. No wrenches are required for installation or removal of the back-up pad or accessories.

1. CAUTION: DISCONNECT TOOL FROM POWER SOURCE.

2. Depress spindle lock button (A) Fig. 3 and rotate back-up pad clockwise onto spindle until it is firmly seated.

3. Align "Hook & Loop" accessories with pad and press firmly into place.





OPERATION

TO START AND STOP THE MACHINE

CAUTION: Make sure switch is OFF and power circuit voltage is the same as that shown on the specification plate.

- 1. Connect tool to power source.
- 2. Grip machine firmly to resist starting torque.

Squeeze trigger switch (A), Fig. 4, to turn tool "ON". When released, the 3. switch will return to the "OFF" position.

4. To lock the switch in the "ON" position: with switch "ON" press switch lock button (B) Fig. 4, and hold while releasing the trigger. To release the switch lock: press the trigger switch.



Fig. 4



Fig. 5

VARIABLE SPEED

Speed is adjusted two ways:

1. With switch (A) Fig. 4, in the locked ON position use thumbwheel (C) Fig. 5, to adjust the speed (approximately 1000 RPM to 3000 RPM).

2. Switch (A) Fig. 4, can also be used to adjust the speed, 0 RPM to approximately 3000 RPM, with maximum speed depending on the position of thumbwheel (C) Fig. 5.

USING POLISHER

1. If item to be polished is light enough to be moved by the rotating polishing pad, it should be securely anchored to prevent possible bodily injury.

2. Hold polisher firmly by the rear and auxiliary handles (see Fig. 6), making sure polishing pad is clear of work and foreign objects. Start polisher and lower at an angle so that approximately $1/_2$ or slightly less of the polishing pad contacts the work.





3. Move polisher in long continuous sweeping strokes. **DO NOT HOLD POLISHER IN ONE SPOT** as this will create heat and possibly damage surface being polished.

4. Lift polisher from work before turning off motor.

5. Always be sure motor has stopped before setting polisher down.

6. When using polisher to apply products (polishes, waxes, cleaners, etc). always:

Read and follow directions supplied with product.

Start and stop polisher with pad against work surface, do not run polisher while pad is not in contact with work surface.

POLISHING TIPS

USE ONLY QUALITY POLISH MADE FOR POWER POLISHING APPLICATION and apply per manufacturer's instructions.

For best results, thoroughly clean surface to be polished.

When polishing automobiles, wash the car thoroughly to remove dust, dirt and other abrasives that may scratch the finish.

Buffs or pads may become gummed up after a period of use. They may be washed out with soap and water. Shake out as much water as possible and then spin dry on machine. Do this in an area where you will not splatter articles.

MAINTENANCE

KEEP TOOL CLEAN

Periodically blow out all air passages with dry compressed air. All plastic parts should be cleaned with a soft damp cloth. NEVER use solvents to clean plastic parts. They could possibly dissolve or otherwise damage the material.

CAUTION: Wear safety glasses while using compressed air.

FAILURE TO START

Should your tool fail to start, check to make sure the prongs on the cord plug are making good contact in the outlet. Also, check for blown fuses or open circuit breakers in the line.

LUBRICATION

This tool has been lubricated with a sufficient amount of high grade lubricant for the life of the unit under normal operating conditions. No further lubrication is necessary.

BRUSH INSPECTION AND LUBRICATION

For your continued safety and electrical protection, brush inspection and replacement on this tool should ONLY be performed by an AUTHORIZED PORTER-CABLE SERVICE STATION or a PORTER-CABLE/DELTA SERVICE CENTER.

At approximately 100 hours of use, take or send your tool to your nearest Authorized Porter-Cable Service Station to be thoroughly cleaned and inspected; worn parts replaced, when necessary; relubricated with fresh lubricant, if required; reassembled with new brushes; and performance tested.

Any loss of power before the above maintenance check may indicate the need for immediate servicing of your tool. DO NOT CONTINUE TO OPERATE TOOL UNDER THIS CONDITION. If proper operating voltage is present, return your tool to the service station for immediate service.



SERVICE AND REPAIRS

All quality tools will eventually require servicing or replacement of parts due to wear from normal use. These operations, including brush inspection and replacement, should ONLY be performed by either an AUTHORIZED PORTER-CABLE SERVICE STATION or a PORTER-CABLE/DELTA SERVICE CENTER. All repairs made by these agencies are fully guaranteed against defective material and workmanship. We cannot guarantee repairs made or attempted by anyone other than these agencies.

Should you have any questions about your tool, feel free to write us at any time. In any communications, please give all information shown on the nameplate of your tool (model number, type, serial number, etc.).

ACCESSORIES

A complete line of accessories is available from your Porter-Cable • Delta Supplier, Porter-Cable • Delta Factory Service Centers, and Porter-Cable Authorized Service Stations. Please visit our Web Site **www.porter-cable.com** for a catalog or for the name of your nearest supplier.

WARNING: Since accessories, other than those offered by Porter-Cable
 Delta, have not been tested with this product, use of such accessories could be hazardous. For safest operation, only Porter-Cable
 Delta recommended accessories should be used with this product.

PORTER-CABLE LIMITED ONE YEAR WARRANTY

Porter-Cable warrants its Professional Power Tools for a period of one year from the date of original purchase. We will repair or replace at our option, any part or parts of the product and accessories covered under this warranty which, after examination, proves to be defective in workmanship or material during the warranty period. For repair or replacement return the complete tool or accessory, transportation prepaid, to your nearest Porter-Cable Service Center or Authorized Service Station. Proof of purchase may be required. This warranty does not apply to repair or replacement required due to misuse, abuse, normal wear and tear or repairs attempted or made by other than our Service Centers or Authorized Service Stations.

ANY IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WILL LAST ONLY FOR ONE (1) YEAR FROM THE DATE OF PURCHASE.

To obtain information on warranty performance please write to: PORTER-CABLE CORPORATION, 4825 Highway 45 North, Jackson, Tennessee 38305; Attention: Product Service. THE FOREGOING OBLIGATION IS PORTER-CABLE'S SOLE LIABILITY UNDER THIS OR ANY IMPLIED WARRANTY AND UNDER NO CIRCUMSTANCES SHALL PORTER-CABLE BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights and you may also have other legal rights which vary from state to state.



CANADIAN PORTER-CABLE • DELTA SERVICE CENTERS

ALBERTA Bay 6, 2520-23rd St. N.E.

Calgary, Alberta T2E 8L2 Phone: (403) 735-6166 Fax: (403) 735-6144

BRITISH COLUMBIA 8520 Baxter Place Burnaby, B.C. V5A 4T8

V5A 418 Phone: (604) 420-0102 Fax: (604) 420-3522
 MANITOBA

 1699 Dublin Avenue

 Winnipeg, Manitoba

 R3H 0H2

 Phone: (204) 633-9259

 Fax: (204) 632-1976

 ONTARIO

505 Southgate Drive Guelph, Ontario N1H 6M7 Phone: (519) 836-2840 Fax: (519) 767-4131 1515 Ave. St-Jean Baptiste, Québec, Québec G2E 5E2 Phone: (418) 877-7112 Fax: (418) 877-7123

1447, Begin St-Laurent, (Montréal), Québec H4R 1V8 Phone: (514) 336-8772 Fax: (514) 336-3505

The following are trademarks of PORTER-CABLE • DELTA (Las siguientes son marcas registradas de PORTER-CABLE • DELTA S.A.) (Les marques suivantes sont des marques de fabriquant de la PORTER-CABLE • DELTA): BAMMER, LASERLOC*, OMNJIG*, POCKET CUTTER*, PORTA-BAND*, PORTA-PLANE*, PORTER-CABLE*, QUICKSAND*, SANDTRAP*, SAW BOS*, SPEED-BLOC*, SPEEDMATIC*, SPEEDTRONIC*, STAIR-EASE*, THE PROFESSIONAL EDGE*, THE PROFESSIONAL SELECT*, TIGER CUB*, TIGER SAW*, TORO-BUSTER*, VERSA-PLANE*, WHISPER SERIES*, DURATRONIC*, FRAME SAWTM, INNOVATION THAT WORKSTM, JETSTREAM*, MICRO-SETT*, MORTENT*, NETWORKTM, RIPTIDE**, TRU-MATCHTM, WOODWORKER'S CHOICE**, THE AMERICAN WOOD SHOP** (design), AUTO-SET**, NETWORKTM, RIPTIDE**, SAV*, CONTRACTOR'S SAW**, DELTA**, DELTAC**, DELTAC**, DIMCERAFT**, HOMECRAFT**, HONGCRAFT**, SICHSKICKT**, UNICENSE**, SICHSKICKT**, UNICHSCH**, SAFEGUARD IIT**, SANDING CENTER**, SICHSKICKT**, UNICHSCH**, UNICHSCH**, UNICHSCH**, UNICHSCH***, UNICHSCH***, UNICHSCH***, UNICHSCH***, UNICHSCH***, UNICHSCH***, SICHSKICKT**, UNICHSCH***, UNICHSCH***, UNICHSCH***, UNICHSCH***, UNICHSCH***, UNICH***, UNICH****, UNICH***, UNICH****, UNICH***, UNICH***, UNICH***, UNICH***, UNICH***, UNICH***, UNICH***, UNICH***, UNICH***, UNICH**

Trademarks noted with [™] and [®] are registered in the United States Patent and Trademark Office and may also be registered in other countries. Las Marcas Registradas con el signo de [™] y [®] son registradas por la Oficina de Registros y Patentes de los Estados Unidos y también pueden estar registradas en ortors países. Marques déposées, indiquées par la lettre [™] et [®], sont déposées au Bureau des brevets d'invention et marques déposées aux autres pays.

Printed in U.S.A