



**T612**

User's guide

 ALTEC LANSING®







The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



Caution: To prevent the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

## CAUTION

To prevent electric shock do not use this (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

## WARNING

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

## IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water – This apparatus shall not be exposed to dripping or splashing, and no objects filled with liquids, such as vases, shall be placed on the apparatus.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. The apparatus should not be situated on a bed, sofa, rug or similar surface that may block the ventilation openings. The apparatus must not be placed in a built-in installation, such as a closed bookcase or cabinet that may impede the flow of air through the ventilation openings. Ventilation should not be impeded by covering the openings with items such as newspapers, tablecloths, curtains, etc.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. No naked flame sources, such as lighted candles, should be placed on the apparatus.
10. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for the replacement of the obsolete outlet.
11. Protect the power cord from being walked on or pinched – particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
12. Do not install in an area which impedes the access to the power plug. Disconnecting the power plug is the only way to completely remove power to the product and must be readily accessible at all times.
13. Power source – Use only power supplies of the type specified in the operating instructions or as marked on the appliance. If a separate power supply is included with this apparatus, do not substitute with any other power supply – use only manufacturer-provided power supplies.
14. Unplug this apparatus during lightning storms or when unused for long periods of time.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. For service, refer to qualified service personnel, return to the dealer, or call the Altec Lansing service line for assistance.
16. For products which incorporate batteries, please refer to local regulations for proper battery disposal.
17. Only use attachments/accessories specified by the manufacturer.
18. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



## Altec Lansing One Year Limited Warranty

### (Two-Year Limited Warranty In the European Union and Asia)

**What Does The Warranty Cover?:** Altec Lansing warrants that its products shall be free from defects in materials or workmanship, with the exceptions stated below.

**What Is The Period Of Coverage?:** For units purchased in European Union or Asia, this warranty runs for two years from the date of purchase. For units not purchased in Europe or Asia, this warranty runs for one year from the date of purchase. The term of any warranties implied by law shall expire when your limited warranty expires. Some states and/or Member States in the European Union do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

**What Does The Warranty Not Cover?:** This warranty does not cover any defect, malfunction or failure that occurs as a result of: improper installation; misuse or failure to follow the product directions; abuse; or use with improper, unintended or faulty equipment. (For information on proper installation, operation and use consult the manual supplied with the product. If you require a replacement manual, you may download a manual from [www.alteclansing.com](http://www.alteclansing.com).) Also, consequential and incidental damages are not recoverable under this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

**What Will Altec Lansing Do To Correct The Problem?:** Altec Lansing will, at its option, repair or replace any product that proves to be defective in material or workmanship. If your product is no longer being manufactured, or is out of stock, at its option, Altec Lansing may replace your product with a similar or better Altec Lansing product.

**How To Get Warranty Service:** To get a covered product repaired or replaced, you must contact Altec Lansing during the warranty period by email ([csupport@alteclansing.com](mailto:csupport@alteclansing.com)). You must include in your email, your name, address, email address, telephone number, date of purchase and a complete description of the problem you are experiencing. In the United States, you may alternatively contact Altec Lansing by telephone at 1-800-ALTEC88 — please be prepared to provide the same information. If the problem appears to be related to a defect in material or workmanship, Altec Lansing will provide you a return authorization and instructions for return shipment. Return shipments shall be at the customer's expense, and the return must be accompanied by the original proof of purchase. You should insure the shipment as appropriate because you are responsible for the product until it arrives at Altec Lansing.

**How Will State Law Affect Your Rights?:** This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Please note that in the European Union, you as a consumer might have other legal rights under national legislation of European Union Member States governing the sale of Altec Lansing's goods. Those rights are not affected by this guarantee.

The above limited warranties and remedies are sole warranties and remedies available to purchaser, if, and to the extent, valid and enforceable under the applicable law.

## Customer Service

The answers to most setup and performance questions can be found in the Troubleshooting guide. You can also consult the FAQs in the customer support section of our Web site at [www.alteclansing.com](http://www.alteclansing.com). If you live in North America and still can't find the information you need, please call our customer service team for assistance before returning the speakers to your retailer under their return policy.

Tel: 800-258-3288

Email: [csupport@alteclansing.com](mailto:csupport@alteclansing.com)

If you live outside of North America, please visit our website at [www.alteclansing.com](http://www.alteclansing.com) and select your region to locate your country's distributor.

For the most up-to-date information, be sure to check our Web site at [www.alteclansing.com](http://www.alteclansing.com).

## International Distribution

International customers: For information regarding the distribution of Altec Lansing products in your country, please visit [www.alteclansing.com](http://www.alteclansing.com) and click on your region.

## Disposal of Old Electrical & Electronic Equipment



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office or your household waste disposal service.

# T612 Digital Speaker System for iPhone™

## Big rich sound for iPhone without missing your calls!

Thank you for purchasing the Altec Lansing T612 digital speaker system for iPhone. Made to complement the iPhone model's command of the digital world, the T612 extends your iPhone model's high-end audio capabilities with beautifully transparent music reproduction. 60 Watts of power RMS (120 Watts Peak) fill the room while keeping you perfectly in touch – because with the T612 there's no need to use "Flight Mode" while you listen to music. Instead, keep the phone turned on; when a call comes in the T612 gives priority to the call by interrupting the music.

### Made for:



- iPhone
- iPod touch
- iPod classic
- iPod with video
- iPod nano (3rd generation)
- iPod nano (2nd generation)
- iPod nano (1st generation)
- iPod with color display
- iPod mini
- iPod with dock connector

### Box Contents

- T612 digital speaker system for iPhone and iPod®
- Wireless remote control with battery
- 3.5 mm stereo cable (for auxiliary input)
- Power supply
- Removable docking adapter for iPhone
- User's guide and quick connect instructions

### Placing T612

Position T612 on a stable, level surface.

### Power On/Off

- Insert the barrel connector from the power supply into the DC connector on the rear of the T612 system. After this connection is made, insert the power supply into a wall outlet.
- Turn on the T612 by pressing the power button located on the top of the unit. An LED will light when the power is on.
- Turn off the T612 by pressing the power button located on the top of the unit. The LED will turn off.

Note: To avoid hearing a popping sound when you turn on the T612, always turn on your iPhone (or alternate audio source) first.

### Connecting your iPhone

To connect your iPhone to the T612:

- Place the docking adapter for iPhone inside the universal dock. While the docking adapter is not required for proper functioning of your iPhone and T612, it will provide a better fit.
- Seat your iPhone by sliding your iPhone on top of the T612 docking station.

### Connecting your iPod

To connect your iPod to the T612:

- Remove the docking adapter for iPhone from the T612 docking station.
- Place the appropriate docking adapter for iPod inside the universal dock. Docking adapters may come with your iPod, or may be purchased separately from Apple (see Apple stores or [www.apple.com](http://www.apple.com).)
- Make sure the EQ function on the iPod is disabled. This may happen automatically with some iPod models. See the user's guide for iPod for details on how to disable the EQ settings.
- Seat your iPod by sliding your iPod on top of the T612 docking station.

### Connecting your alternate audio source

The T612 includes an auxiliary input jack that allows you to connect to alternate audio sources, such as older iPod models, CD players, MP3 players, portable DVD players, and laptops. To connect the T612 to an alternate audio source, follow the steps below.

- Locate the 3.5 mm stereo cable.
- Turn off the alternate audio source.
- Connect one end of the 3.5 mm stereo cable into the auxiliary input jack (AUX) located on the back of the T612 system, and the other end to the "line-out," "audio-out," or the headphone jack on your alternate audio source.
- Disable the alternate audio source EQ function, if available. See the alternate audio source user's guide for details.
- Set the volume on the alternate audio source at mid-level.
- Set the volume on the T612 at minimum level and adjust upward to a comfortable listening level.

### Volume

The "+" and "-" buttons on the top of the T612 are the master volume controls. Press and hold the "+" button to increase the volume and the "-" button to decrease the volume. An LED indicator is located on the front of the unit.

## Treble and Bass


To control treble or bass levels, press the TREBLE or BASS buttons on the top of the unit and press and hold the "+" button to increase the corresponding level, or the "-" button to decrease it.

An LED indicator located on the front of the unit will indicate the corresponding level.

Note: After a few seconds, the "+" and "-" controls will automatically reset to controlling the volume.

## Resetting the system to original factory settings

To reset either the treble or bass function to its original factory setting, press and hold the corresponding TREBLE or BASS button on the top of the unit for 5 seconds.


To reset volume, bass and treble functions to original factory settings, press and hold the  button on the top of the unit for 5 seconds.

## Wireless Remote Control

In order to use the remote control, install the supplied battery in the remote's battery compartment.

CAUTION: There's a danger of explosion if the battery is incorrectly replaced. Replace it only with the same or equivalent type.

### Stand-by

The  button can be used to turn the unit on and place the unit in stand-by mode. An LED will light on the T612 when the unit is on.

### Volume







The "+" and "-" buttons marked with the word VOLUME control the master volume. Press the "+" button to increase the volume, and press the "-" to decrease the volume.

### Treble and Bass

To control treble or bass levels using the wireless remote, press the TREBLE or BASS button on the wireless remote, and press and hold the "+" button to increase the corresponding level, or the "-" button to decrease it.

### Song Functions

When an iPhone or iPod is docked into the T612 and the T612 is turned on, some song functions can be controlled using the T612's remote control.

1. Play/Pause Function: Press the  button once to start playing the selected song. Press the  button again to pause the song.
2. Track Forward/Track Back Function: Press the  button to skip to the beginning of the next song. Press and hold the  button to fast-forward through the song. Press the  button to skip to the beginning of the song currently being played. Press and hold the  button to rewind the song.

## Troubleshooting

| Symptom   | Possible Problem  | Solution   |
|---|---|--|
| No Power LED is lit (AC Operation).   | The power supply isn't connected to a wall outlet and/or the power supply connector is not plugged into the power supply jack on the back of the T612 system. | Insert the barrel connector from the power supply into the DC connector on the rear of the T612 system. After this connection is made, insert the power supply into a wall outlet. |
|   | The surge protector (if used) isn't powered on.   | If the power supply is plugged into a surge protector, make sure the surge protector is switched on.   |
|   | The wall outlet is not functioning.   | Plug another device into the same wall outlet to confirm the outlet is working.  |
|   | The power isn't turned on.  | Turn on the T612 by pushing the power button located on the top of the unit. A LED will light when the power is on.  |
| No sound is coming from speakers.   | The volume is set too low.  | Press and hold the "+" button on the top of the T612 to increase the volume.   |
|   |   | Check the volume level on alternate audio source device and set at mid-level.  |
|   | The iPhone or iPod is not correctly seated into the docking station.  | Turn off the iPhone or iPod, remove it from the docking station, reseal it, and turn it on again.  |
|   | If using an alternate audio source, the audio source is not properly connected to the T612 or there is a problem with the alternate audio source.             | Try using another sound source, such as another CD or MP3 player. See the "Connecting to alternate audio source" section for details.  |
| There is a crackling sound coming from speakers.                                  | The iPhone or iPod is not correctly seated into the docking station.  | Turn off the iPhone or iPod, remove it from the docking station, reseal it, and turn it on again.  |
|   | If using an alternate audio source, the audio source is not properly connected to the T612 or there is a problem with the alternate audio source.             | Try using another sound source, such as another CD or MP3 player. See the "Connecting to alternate audio source" section for details.  |
| There is a crackling sound coming from speakers (when connected to PC or laptop). | The operating system's volume level is set too high.  | Check the operating system volume level and decrease it if necessary.  |
| The sound is distorted.   | The T612's volume level is set too high.  | Press and hold the "-" button on the top of the T612 to decrease the volume.   |
|   | The EQ function on the iPhone, iPod or alternate audio source is not disabled.  | Disable the EQ function on the iPhone, iPod or alternate audio source. See the device user's guide for details.  |
| The T612 exhibits erratic or unexpected behavior. Controls do not function.       | Static electricity, momentary interruption of power, or abnormal operating conditions may be responsible.   | <ol style="list-style-type: none"> <li>1. Disconnect the power supply from the wall outlet.</li> <li>2. Reconnect the power supply.</li> </ol>                                     |





This Class B digital apparatus complies with Canadian ICES-003. • Cet appareillage digital de Classe B est conforme au ICES-003 canadien.

"Made for iPod" means that an electronic accessory has been designed to connect specifically to iPod and has been certified by the developer to meet Apple performance standards.

"Works with iPhone" means that an electronic accessory has been designed to connect specifically to iPhone and has been certified by the developer to meet Apple performance standards.

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

© 2007 Plantronics, Inc. All rights reserved.

ALTEC, ALTEC LANSING, the Altec Lansing logo, the swirl design, and XdB are trademarks or registered trademarks of Altec Lansing, a division of Plantronics, Inc. Plantronics, the logo design and Sound Innovation are trademarks or registered trademarks of Plantronics, Inc.

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

iPhone is a trademark of Apple Inc.

All other trademarks appearing herein are the property of their respective owners.

Designed by Altec Lansing in the USA. Made in China.

**CORPORATE HEADQUARTERS:** 535 Rte. 6 & 209, Milford, PA 18337-0277 • 800-ALTEC-88 • 570-296-4434 • Fax 570-296-6887

**EUROPE:** 13 Rue Beaumont, L-1219 Luxembourg, Luxembourg

**ASIA/PACIFIC:** 25 Canton Road, Tsim Sha Tsui, Kowloon, Hong Kong

Engineered in USA. Made in China



A12654 R07