

## INSTALL INSTRUCTIONS C-TCB-4 TELESCOPING COMPUTER BASE 1995-2003 CHEVROLET/GMC S-15 JIMMY, S-15 SONOMA, S-10 BLAZER, S-10 PICK-UP


**TOOLS REQUIRED:**

3/16" Allen wrench  
3/8" Metric socket set  
3/8" Standard socket set

3/8" Ratcheting wrench  
Open-end wrench set  
Powered drill w/ 3/16" drill bit

**HARDWARE & COMPONENTS:**

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1	Pole support assembly	CM93071-4
1	Telescoping pole assembly	CM93072-1
1	Side support brace	CM93115
1	Lateral support brace	CM93126
1	5/16-18 Nylock nut	GSM30017
2	5/16" Flat washer	GSM31006
1	5/16-18 x 1" Hex head bolt	GSM33012
2	1/4" x 3/4" Hex head lag bolt	GSM33060-1



## **SUB ASSEMBLY:**

1. Confirm receipt of all hardware and components.
2. Loosen or remove front inner and outer passenger seat bolts on vehicle.

## **INSTALLATION:**

### **1. Mount C-TCB-4 into vehicle**

- Slide pole support assembly between front inner seat base mount and floor of vehicle.
- Loosely attached factory seat bolt.
- Slide lateral support brace between front outer, seat base mount, and floor of vehicle.
- Attach lateral support brace and side support brace to welded tab on side of pole support assembly and loosely attach using 5/16-18 Hex head bolt, washers and nylock nut.
- Position assembly on passenger seat base and completely tighten factory seat bolts.
- Mount side support brace to vehicle using 1/4" x 3/4" Hex head lag bolts. A 3/16" pilot is required.

*Note: When mounting side support brace to floor of vehicle, be sure to check for obstructions prior to drilling or lag bolting to floor.*

- Mount optional C-3090, computer-mounting platform, to telescoping pole assembly using hardware and instructions provided with C-3090.