

User manual  
mermaid ventura 170/181 TFT Video



**Table of Content:**

<b>Table of Content:</b> .....	<b>2</b>
<b>1. Introduction</b> .....	<b>3</b>
<b>2. Important Information</b> .....	<b>3</b>
<b>3. Content of the Box</b> .....	<b>4</b>
<b>4. Unpacking, Placement and Setup (PC)</b> .....	<b>4</b>
<b>5. OSD Key Functions</b> .....	<b>5</b>
<b>6. OSD Functions &amp; Adjustments</b> .....	<b>6</b>
RGB Main Menu.....	6
RGB Picture Menu .....	6
RGB Advanced Menu .....	7
RGB Advanced Menu - Continued .....	8
RGB Utility Menu .....	8
RGB Utilities Menu .....	9
Video Picture Menu .....	9
<b>7. Guarantee Terms</b> .....	<b>10</b>
<b>8. If you need to contact us!</b> .....	<b>10</b>
<b>9. Troubleshooting</b> .....	<b>11</b>
<b>Appendix A: Connector Specifications</b> .....	<b>12</b>
<b>Appendix B: Power Management Mode: VESA DPMS protocol applied</b> .....	<b>12</b>
<b>Appendix C: Technical Specifications</b> .....	<b>13</b>
<b>Appendix D: Video Mode Support</b> .....	<b>14</b>
<b>Appendix E: Optical Characteristics – ventura 170 TFT</b> .....	<b>15</b>
<b>Appendix F: Optical Characteristics – ventura 181 TFT</b> .....	<b>16</b>

## 1. Introduction

The mermaid ventura 170 TFT and 181 TFT are state of the art high-tech flat panel TFT monitors, incorporating high quality TFT-LCD panels with maximum resolution of 1280x1024. They are based on the newest technology with high brightness 4-lamp CCFL backlight units. The very fast response time provides excellent suitability for video and gaming applications. The monitors are made of steel and hardened glass providing excellent stability and strength. The integrated hinge and high adjustment means you are able to manouvre the monitors for optimal viewing angle and comfort. The monitors are fully DDC 2 compliant, which makes installation very easy.

### **Panel technology:**

- ventura 170 TFT: ACE (Advanced Coplanar Electrode)
- ventura 181 TFT: PVA (Patterned Vertical Alignment)

### **Connections:**

- Analog VGA (D-Sub connector via integrated cable)
- Audio input (Mini Jack)
- S-Video (Y/C) (Mini-DIN connector via integrated cable)
- Composite (CVBS) (RCA connector via integrated cable)

### **Features:**

- State of the art high performance picture quality design
- Analog VGA interface
- Composite (x1) and S-Video (x1) inputs
- Full CRT multi-sync monitor compatibility
- Multi-sync capability up to SXGA resolution, 75Hz max., compatible standard DOS, VGA, SVGA, XGA and SXGA VESA timing
- Expand DOS, VGA, SVGA and XGA to full screen display
- 24 bit (16.7 million) true color data processing and display driving
- Single control operated & transparent On-Screen-Display (hereafter 'OSD') user interface
- Full control of all relevant display and interface parameters via OSD
- Multi language support
- VESA DDC1/2B compliant
- Compatible with VESA DPMS power saving modes
- +12VDC single power: 45watts AC/DC power adapter recommended. (Supplied)
- Operating temperature: 0 to 50°C
- Internal passive speakers (2watt x 2 ch. / 8 ohms)

## 2. Important Information

- When using the ventura 170 TFT and ventura 181 TFT with Windows NT, the computer needs to be started in VGA mode the first time. Log on as administrator and set the resolution to 1280x1024 and refresh rate to 60 Hz. The computer can then be started in normal mode.
- Please save the packaging. It has been designed to provide optimal support and protection for the monitor during transportation.

### 3. Content of the Box

- ventura 170 TFT (17") or ventura 181 TFT (18.1")
- "Quickstart" card

#### Accessories bag including:

- PSU (45 Watt)
- Powercord
- Speaker cable
- Users manual
- Glass cleaner & screen wiping cloth

### 4. Unpacking, Placement and Setup (PC)

**Note: To avoid condensation, please wait ½-1 hour, before operating the unit.**


After the box has been opened, remove the accessories bag.  
Bend the cardboard flaps outward and turn the box upside down, which will ensure the inlay foam with the monitor is able to slide out. Do not drop the content on the floor.  
Remove the foam side pieces and the plastic bag.

The monitor needs to be placed on a smooth and stable surface. This surface must be able to safely support 15 kg

Make sure both the computer and monitor are turned off before connecting the monitor.

- Connect the monitor to the computer by means of the supplied VGA cable. (Attached to the monitor)
- Connect the PSU to the monitor and AC outlet.
- Turn on the computer and monitor.


OSD panel is located  
beneath the monitor



- ventura 170 TFT and ventura 181 TFT are plug & play compatible via VESA DDC1/2B. Windows 98, ME and XP will recognise this and self configure.
- When using the ventura 170 TFT and ventura 181 TFT with Windows NT, the computer needs to be started in VGA mode the first time. Log on as administrator and set the resolution to 1280x1024 and refresh rate to 60 Hz. The computer can then be started in normal mode.

## 5. OSD Key Functions

4-button OSD Panel



Function	Description
Menu (Hot Key)	Activates the OSD
Auto Config (Hot Key)	Auto calibrate the monitor for optimal performance
Source Select *	When both keys are pressed, the monitor selects the next source <div style="text-align: center; margin-top: 5px;"> <pre>                     S-Video → Composite → VGA → S-Video                 </pre> </div>
Enter/Escape	Enters or Escapes the highlighted menu.
Decrease (-)	Moves the cursor down to the next menu item
Increase (+)	Increases the value of the selected. Select the next lower level menu.

\* When the monitor is turned on, it automatically scans the three different inputs (VGA, CVBS, Y/C) for a valid signal, It then stops at the first valid input. The scan routine starts from the last used input.


## 6. OSD Functions & Adjustments

### RGB Main Menu




<b>Picture</b>	Several picture adjustments like brightness, contrast picture position etc.
<b>Advanced</b>	Advanced picture adjustments
<b>Options</b>	Monitor setup
<b>Utilities</b>	Monitor setup

### RGB Picture Menu




<b>Brightness</b>	Adjustment of brightness
<b>Contrast</b>	Adjustment of contrast
<b>H-Position</b>	Adjustment of horizontal picture position
<b>V-Position</b>	Adjustment of vertical picture position
<b>Phase</b>	The phase setting allows slight picture disturbances (snow & shimmering) to be eliminated
<b>Frequency</b>	The frequency setting allows the pixel clock frequency to be adjusted. This will only have to be adjusted, if the automatic alignment was unable to determine the correct pixel clock frequency.

### RGB Advanced Menu



<b>Sharpness</b>	Adjustment of picture sharpness 5 = "Sharp" picture 1 = "Soft" picture
<b>Gamma</b>	<p>Selection of the appropriate "Gamma curve" Two different curves "linear" and "crt" are available. The "linear" gamma curve does not correct any color information, which will be directly transferred to the display panel. The "crt" gamma curve processes the color information according to the scheme below, before it is transferred to the display panel.</p> <div data-bbox="341 1108 950 1402" data-label="Figure"> <p>The graph shows two curves on a coordinate system. The vertical axis is labeled 'Output value (to display)' and has tick marks at 0, 1, and 255. The horizontal axis is labeled 'Input (from the source)' and has tick marks at 0, 1, and 255. A straight orange line labeled 'linear' connects the origin (0,0) to the point (255,255). A blue curve labeled 'crt' also starts at (0,0) and ends at (255,255), but it is concave down, meaning it maps a wider range of input values to a narrower range of output values in the middle of the scale.</p> </div>



### RGB Advanced Menu - Continued



<b>Color temp</b>	Adjustment of the color temperature. Select between 3 pre-defined temperature (6500K, 7300K or 9000K) Or use the "User" setting to select the appropriate values yourself.
-------------------	--


### RGB Utility Menu



<b>OSD</b>	Selection of nine predefined OSD positions.
<b>OSD h-pos</b>	Variable OSD position - horizontal
<b>OSD v-pos</b>	Variable OSD position - vertical
<b>Language</b>	Select OSD language (English/German)
<b>dpms</b>	<p><b>Activates/deactivates the power management</b> If the DPMS is <b>active</b>, then the monitor switches off automatically, when there is no sync signal, eg. When you turn of the computer. Before the monitor turns off, a "No signal" message is displayed.</p> <p>If the DPMS is not active, the "No signal" message is shown until a valid video signal is applied to the monitor.</p> <div style="text-align: right;">    </div>
<b>Info line</b>	Activates automatic source scan.



## RGB Utilities Menu



<b>OSD timeout</b>	Adjustment of OSD turn off time after last key pressed. You can select values between 5 and 60 sec. (5 sec. steps)
<b>OSD background</b>	Changes type of the OSD background Translucent = transparent Opaque = solid (not transparent)
<b>Factory reset</b>	Resets all functions to factory default.

## Video Picture Menu

When the signal source is either CVBS or S-video, the "picture" menu has other functions implemented.



<b>Brightness</b>	Adjustment of the brightness
<b>Contrast</b>	Adjustment of the contrast
<b>Color</b>	Adjustment of the colorsaturation
<b>Tint</b>	Adjustment of the tint
<b>Sharpness</b>	Adjustment of the picture sharpness
<b>Scaling</b>	Selects between different ways to scale the video input

## **7. Guarantee Terms**

mermaid ventura 170 TFT and ventura 181 TFT Video Models are covered by a 1-year Pick-Up service

### **Pick-Up**

Collection from and return to your address. If your mermaid ventura needs repairing, contact mermaid customer service, who will arrange to have your screen collected, repaired and returned to you within 14 working days.

The guarantee terms set out above apply to Europe only.

## **8. If you need to contact us!**

### **Contact mermaid customer support.**

If you need to get in touch with mermaid technology, please contact us via phone or mail:

#### **Phone**

mermaid customer support opening hours are Monday to Friday 12.30-16.30.

#### **By mail**

mermaid technology a/s  
Att.: Customer Support  
Symfonivej 34-36  
DK-2730 Herlev  
Denmark

#### **Telephone**

+45 44 52 92 00

#### **Telefax**

+45 44 52 92 65

#### **E-mail**

kundeservice@mermaid.dk

#### **Internet**

<http://www.mermaid.dk>

## 9. Troubleshooting

If you have troubles using your ventura monitor, please refer to following suggestions for troubleshooting.

If you can not rectify the problem yourself, please contact your distributor or place of purchase.

Symptom	Suggestions
Screen is blank	Ensure that the power cord is connected and the monitor is on.
"Check signal cable" message	Ensure that the signal cable is connected firmly to the signal source. Ensure that the signal source is turned on.
"Sync out of range" message	Check the maximum resolution and the frequency of the video adapter.
The image is too dark or bright	Adjust the brightness and contrast
Horizontal bars appear to flicker, jitter or shimmer on the image	Adjust the "Phase"
Vertical bars appear to flicker, jitter or shimmer on the image	Select "Auto Adjust" in OSD menu
Image is not stable and may appear to vibrate	The system activates power management mode. Just press the PC keyboard or move the PC mouse
Screen is blank	Check the display resolution and frequency from your PC or video board is in available mode for your monitor. On your PC, check "Control Panel -> Display -> Settings" If the setting is incorrect, you may change the setting using PC utility program.
Image is not centered on the screen	Adjust the "Image Position / H-Position or V-position".

## Appendix A: Connector Specifications

### Analog RGB in

Analog RGB Input Connector : D-Sub 15pin



1	RED	Analog Red	9	NC	+5Vdc
2	GREEN	Analog Green	10	SGND	Sync GND
3	BLUE	Analog Blue	11	NC	Reserved
4	GND	Reserved	12	SDA	DDC Serial Data
5	GND	Digital GND	13	HSYNC	Horizontal Sync
6	RGND	Red Return	14	VSYNC	Vertical Sync.
7	GGND	Green Return	15	SCL	DDC Data Clock
8	BGND	Blue Return			

## Appendix B: Power Management Mode: VESA DPMS protocol applied

Mode	Horizontal sync	Vertical sync	Video signal	Power Consumption
<b>On</b>	Active	Active	Active	
<b>Stand.by</b>	Inactive	Active	Blanked	< 3 Watts
<b>Suspend</b>	Active	Inactive	Blanked	
<b>Off</b>	Inactive	Inactive	Blanked	

## Appendix C: Technical Specifications

### Input Video and sync signal

Parameter	Value	Unit
Max. Output Resolution	1280x1024	Pixels
Data Processing	24	Bits
Input impedance <ul style="list-style-type: none"> <li>• Video</li> <li>• Sync</li> </ul>	75 470	Ohms Ohms
Sync Polarities	+/-	
Sync Levels	TTL compatible	
Max. Number of colors	16.7 M	Colors

### Electrical Parameters

reference:  $t_A$  25 °C

Symbo	Description	Min	Typ	Max	Unit
$V_{DD}$	+12V DC power supply	10.8	12.0	13.2	V
$V_{I(RGB)}$	Video input signal (w.r.t. GND)	0.5	0.7	1.0	$V_{PP}$
$f_S$	Video sample rate			80	MHz
$f_{HS}$	Horizontal sync frequency	30		60	KHz
$f_{VS}$	Vertical sync frequency	56		75	Hz
$F_{SIH}$	Sync input high level	2.5			V
$V_{SIL}$	Sync input low level			0.8	VDC
$I_{DD2}$	Supply current @ +12V , ventura 170 TFT		3.0	3.3	A
$I_{DD2}$	Supply current @ +12V , ventura 181 TFT				A

**Note 1.** Power consumption measuring condition is 2pixel checkerboard pattern @ XGA 75Hz and maximum brightness at  $t_A$  25 °C.

## Appendix D: Video Mode Support

The ventura 170 TFT and ventura 181 TFT support any video mode at inputs within the following ranges:

- The signal sample frequency on the input  $\leq 80\text{MHz}$
- The horizontal sync frequency between  $30\text{KHz}$  and  $60\text{KHz}$

The modes are detected when presented to the input and previous alignments for setup are automatically recalled. A true multi-sync monitor emulation is implemented.

The factory preset supported modes include:

Mode	Resolution	Refresh rate	H-freq.	Pixel freq.	Remarks
VGA	640 x 350	70Hz	31.47KHz	25.175MHz	VESA Standard
VGA	720 x 400	59.940Hz	31.469KHz	25.175MHz	IBM VGA 3H
VGA	640 x 480	60Hz	31.5KHz	25.175MHz	Industry Standard
VGA	640 x 480	72Hz	37.9KHz	31.500MHz	VESA Standard
VGA	640 x 480	75Hz	37.5KHz	31.500MHz	VESA Standard
SVGA	800 x 600	60Hz	37.9KHz	40.000MHz	VESA Standard
SVGA	800 x 600	72Hz	48.1KHz	50.000MHz	VESA Standard
SVGA	800 x 600	75Hz	46.9KHz	49.500MHz	VESA Standard
XGA	1024 x 768	60Hz	48.5KHz	65.000MHz	VESA Standard
XGA	1024 x 768	70Hz	56.5KHz	75.000MHz	VESA Standard
XGA	1024 x 768	75Hz	60KHz	78.750MHz	VESA Standard
SXGA	1280 x 1024	60Hz	64KHz	108.000MHz	VESA Standard

### Appendix E: Optical Characteristics – ventura 170 TFT

The following items are measured under stable conditions. The optical characteristics should be measured in a dark room or equivalent

Measuring equipment : TOPCON BM-5A , BM-7, PHOTO RESEARCH PR650

\* Ta = 25 ± 2°C , VDD=5V, fv= 60Hz, fdCLK=54 MHz, IL = 6.5 mA<sub>rms</sub>

Item		Symbol	Condition	Min.	Typ.	Max.	Unit
Contrast Ratio (Center of screen)		C/R	Normal $\phi = 0$ $\theta = 0$	-	300	-	
Response Time	Rising	Tr		-	20	-	msec
	Falling	Tf		-	15	-	
Luminance of White (Center of screen)		YL			-	200	-
Color Chromaticity (CIE 1931)	Red	Rx	Viewing Angle	-	TBD	-	
		Ry					
	Green	Gx					
		Gy					
	Blue	Bx					
		By					
White	Wx		TBD (0.312)				
	Wy		TBD (0.335)				
Viewing Angle	Hor.	$\theta$ L	$CR \geq 10$	-	80	-	Degrees
		$\theta$ R		-	80	-	
	Ver.	$\phi$ H		-	80	-	
		$\phi$ L		-	80	-	

## Appendix F: Optical Characteristics – ventura 181 TFT

The following items are measured under stable conditions. The optical characteristics should be measured in a dark room or equivalent

Measuring equipment : TOPCON BM-5A , BM-7, PHOTO RESEARCH PR650  
Eldim EZ-Contrast

(Inverter Freq. : 54kHz) \* Ta = 25 ± 2°C, VDD=5V, fv= 60Hz, f<sub>DCLK</sub>=54MHz, IL = 6.5mA<sub>rms</sub>

Item	Symbol	Condition	Min.	Typ.	Max.	Unit
Contrast Ratio (Center of screen)	C/R		-	(450)	-	
Response Time	Rising	Tr	-	(15)	-	msec
	Falling	Tf	-	(15)	-	
Luminance of White (Center of screen)	YL	Normal $\phi = 0$ $\theta = 0$	-	(250)	-	cd/m2
Color Chromaticity (CIE 1931)	Red	Rx	Viewing Angle	TBD	TYP. -0.03	TYP. +0.03
		Ry		TBD		
	Green	Gx		TBD		
		Gy		TBD		
	Blue	Bx		TBD		
		By		TBD		
	White	Wx		(0.310)		
		Wy		(0.330)		
Viewing Angle	Hor.	$\theta$ L	-	80	-	Degrees
		$\theta$ R	-	80	-	
	Ver.	$\phi$ H	-	80	-	
		$\phi$ L	-	80	-	