


UNIVERSAL AC ADAPTER  
CPUAC600



USER MANUAL

**WARNING**  
IDENTIFYING THE CORRECT VOLTAGE AND POLARITY SETTINGS FOR THE CONNECT EQUIPMENT AND ADJUSTING THE PRODUCT ACCORDINGLY IS THE USER S RESPONSIBILITY.

**Caution:** This device is intended to input 120V AC power, all necessary safety precautions should be followed. Not recommended for use by children.

Failure to adjust the adapter settings to match the requirements of the connected device can result in damage to the device.

1. Identify the correct plug tip that fits in the device you wish to power.
2. Identify the polarity required for the device you are connecting. The polarity will typically be identified in either the user's manual or on the input specifications on the device itself (see Polarity Markings section). Turn the tip you are inserting into the adapter cord so that the ► text on the tip lines up with either the + or - symbol on the adapter cord depending on whether positive + or negative polarity is required. If the device is not polarized, either setting can be used. If the device does not have a polarity specification, contact the manufacturer of the device and ask them. Using an incorrect polarity can damage the device.
3. Set the voltage switch to the required voltage for the device you are connecting. The voltage required will typically be identified in either the user's manual or on the input specifications on the device itself. If you cannot determine the proper voltage, contact the manufacturer of the device and ask them. Using an incorrect voltage can damage the device.
4. Plug the adapter cord into the device then plug the AC power cord for the adapter into a standard 120V outlet. If the device does not function, unplug the AC power cord from the outlet immediately. Check to make sure the voltage and polarity settings being used are correct.

**POLARITY MARKINGS**  
When looking for polarity markings on the device you wish to power with the CyberPower Universal AC adapter, they will typically be identified as such:

Positive Polarity	Negative Polarity

Depending on the device, the orientation of the positive and negative poles in the depiction may be reversed but, if the device requires positive polarity, the symbol will be on the side with the C shaped arc. If negative polarity is required, the + symbol will be on the side with the C shaped arc.

**1 YEAR LIMITED WARRANTY**  
CyberPower warrants the Universal Power Adapters to be free from defect in material or manufacturing for one years. If a defect results in product failure during its normal use, CyberPower s sole responsibility is to repair or replace (as its sole option) the Universal Power Adapter. The foregoing Limited Warranty is the consumer s sole and exclusive remedy and excludes any incidental or consequential damages. Some States do not allow the exclusion or limitation of incidental and consequential damages, so certain parts of the above limitations or exclusions may not apply to you (the Consumer). This limited warranty gives the Consumer specific legal rights and the Consumer may have other rights, which vary from State to State.

To make a warranty claim call technical support toll-free at 1-877-297-6937 between 8am and 5pm CST, Monday - Friday.

**CONTACT INFORMATION**  
CyberPower Systems, Inc.  
4241 12th Avenue East Suite 400 Shakopee, MN 55379  
Toll-free: 1-877-297-6937 | CPSww.com