



## INSTALL INSTRUCTIONS C-TCB-10 1996-2006 FORD TAURUS

### TOOLS REQUIRED:

3/16" Allen wrench	3/8" Ratcheting Wrench
3/8" Standard Socket Set	Powered drill w/ drill bit set
3/8" Metric Socket Set	Standard Open-end wrench set

### HARDWARE:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1	Pole support assembly	CM93071-10
1	Telescoping pole	CM93072-1
1	Under floor plate	CM93132
1	Lateral support brace	CM93148
1	Side support brace	CM93149
2	1/4-20 Nylock nut	GSM30016
1	5/16-18 Nylock nut	GSM30017
2	3/8-16 Nylock nut	GSM30018
4	1/4" Flat washer	GSM31005
1	5/16" Flat washer	GSM31006
5	3/8" Flat washer	GSM31007
2	1/4-20 x 3/4" Hex head bolt	GSM33001
2	3/8-16 x 3/4" Hex head bolt	GSM33027
1	3/8-16 x 1 1/4" Hex head bolt	GSM33029

### Always!

- Read all instructions before installing any Havis-Shields Equipment Corp products.
- Check for obstructions (Wire, brake lines, fuel tank, etc.) before drilling any holes!
- Use hardware provided with install kit

### SUB ASSEMBLY:

1. Confirm receipt of all hardware and components.
2. Remove front passenger seat base trim.

### INSTALLATION:

#### 1. MOUNT POLE SUPPORT ASSEMBLY:

- Align pole support assembly's slotted hole with similar slot on seat base and loosely attach using 3/8-16 x 3/4" bolt, washer and nut.
- Loosely attach smaller slot on assembly to seat base using 1/4-20 x 3/4"
- Repeat these processes attaching the side support brace to passenger seat base.
- Now loosely attach the side support brace and lateral (forward) support base to pole assembly using 5/16" Nylock nut.

*Note: When mounting side support brace to floor of vehicle, be sure to check for obstructions prior to drilling or lag bolting to floor.*

- With lateral support brace flat to floor of vehicle, mark and drill 3/8" hole.
- Align under floor plate with hole in floor and thread 3/8-16"x 1 1/4" bolt and washer.
- Tighten all hardware being sure that pole support assembly remains level and upright.
- Mount optional C-3090, computer-mounting platform, to telescoping pole assembly using hardware and instructions provided with C-3090.

