



HEADERS #6502

Applications: 2001-2002 GM 1500/2500 Series Pick-Up, Avalanche, Suburban, Tahoe, Yukon 4.8L/5.3L/6.0L V-8 Auto, 2 & 4 WD Dual Catalytic without A.I.R. or EGR 2003 Hummer II 6.0L V8 without A.I.R. or EGR
INSTALLATION INSTRUCTION

- **PLEASE** study these instructions carefully before installing your Headers. If you have any questions or problems, please call our Technical Hotline at: 1-800-416-8628 from 8:00 am - 5:00 pm, Monday-Friday, Pacific Standard Time or e-mail us at edelbrock@edelbrock.com.
- **HEADERS:** These components are designed to improve the exhaust efficiency of the GM C.P.I. (Central Port Injection) V8 engine. **This system does not require welding for installation** and retains all O.E.M. emissions equipment. These Edelbrock headers are street legal in all 50 states.
- **SUGGESTED TOOLS FOR INSTALLATION:** This vehicle has metric fasteners.
 - ✓ 3/8" ratchet socket set with extensions and universal 13mm and 15mm swivel sockets
 - ✓ Set of combination wrenches
 - ✓ Jackstands, screwdrivers, pliers, crescent wrench, etc.
 - ✓ Liquid penetrant, (GM #1052627) anti-seize compound (GM #5613695)
- **SPECIAL NOTICE:** This Edelbrock part has received an Executive Order from the California Air Resources Board (C.A.R.B.) making it legal for street use on pollution-controlled motor vehicles in all 50 states. To assist you with emissions equipment certification, we have included a silver fan shroud decal to help testing personnel verify that this part is a legal replacement part on the vehicle for which it is cataloged. The adhesive-backed decal should be affixed to your fan shroud next to the existing emission and engine specification decal. Do not cover your original equipment specification decal with the Edelbrock fan shroud decal.

WARNING: The use of "Thermal Wrap" or any aftermarket coating process will void the warranty on your headers. Those products can cause excessive heat and moisture buildup resulting in corrosion and early failure of the system.

NOTE: *High temperature spark plug wires and boots are recommended to withstand heat from Headers.*

DISASSEMBLY

1. Disconnect negative battery cable.
2. Unbolt exhaust pipes from manifolds.

RIGHT SIDE

1. Disconnect and remove spark plug wires.
2. Unbolt dipstick tube.
3. Unbolt and remove manifold.
4. Install flange gasket and header from top. Install header bolts, lock washers, and thick flat washers supplied, ensure proper alignment and tighten bolts.
Note: Thick washers are to be used on slotted holes of port flange.
5. Re-install spark plug wires.
6. Re-fasten dipstick tube.

LEFT SIDE

1. Disconnect and remove spark plug wires.
2. Unbolt and remove manifold.
3. Install flange gasket and header from top. Install header bolts, lock washers, and thick flat washers supplied, ensure proper alignment and tighten bolts.
Note: Thick washers are to be used on slotted holes of port flange.
4. Re-install spark plug wires.
Note: Due to production tolerance, it may be necessary to bend the motor mount heat shield for better clearance.

▪ **ASSEMBLY OF EXHAUST PIPE**

Note: The stock donut on 4.8L & 5.3L gasket on right exhaust manifold will be re-used with headers.

This system comes with 2 exhaust crush rings. On 4.8L & 5.3L V8s, one will be used on the left side collector. 6.0L vehicles will use one on the left side and one on the right side to replace factory-installed crush rings.

1. On 4.8L & 5.3L V8s - Remove the donut gasket from right side exhaust manifold. Using a pair of pliers, remove the retaining ring from the donut gasket and place the donut gasket in flare of factory exhaust pipe.
2. Using supplied hardware, re-attach the factory exhaust pipes to the headers and tighten bolts evenly to ensure a tight seal. (**Note:** The 7/16 x 2 bolts are to be used on the right side of 4.8L & 5.3L V8s and the 7/16 x 1 3/4 are for the left side of 4.8L & 5.3L V8s, or both sides on 6.0L V8).

▪ **FINAL INSPECTION**

1. Check all lines (hydraulic, vacuum, air conditioning and fuel) to ensure there is adequate clearance to headers.
2. Re-connect battery.
3. At this point, it is a good idea to look everything over and make sure that nothing was missed in assembly.
4. Start vehicle and bring up to normal operating temperature. Check for possible leaks.
5. Turn engine off and let cool. Tighten all bolts again.

HARDWARE SUPPLIED			
<u>Qty.</u>	<u>Description</u>	<u>Qty.</u>	<u>Description</u>
<input type="checkbox"/> 1	#25-9174 Header left side	<input type="checkbox"/> 6	7/16" Lock washers
<input type="checkbox"/> 1	#25-9156 Header right side	<input type="checkbox"/> 6	7/16" Hex Nuts
<input type="checkbox"/> 4	Hex header bolts; 8mm x 1.25 x 30mm	<input type="checkbox"/> 6	7/16" Flat washers
<input type="checkbox"/> 8	Hex header bolts; 8mm x 1.25 x 25mm	<input type="checkbox"/> 14	5/16" Lock washers (header flange)
<input type="checkbox"/> 2	Port gaskets	<input type="checkbox"/> 4	Hardened washers (for header flange) slotted holes
<input type="checkbox"/> 3	7/16" x 2 Hex bolts		
<input type="checkbox"/> 6	7/16" x 1 3/4 Hex bolts		
<input type="checkbox"/> 2	Exhaust crush rings		

PLEASE complete and mail your warranty card. Be sure to write the model number of this product in the "Part # _____" space. Thank you.

Edelbrock Corporation
2700 California Street
Torrance, California 90503
Toll-Free Tech Line (800) 416-8628
Tech E-mail: edelbrock@edelbrock.com