

USB 2.0 4-Port MicroHub™

GUH274 USER MANUAL

Read this guide thoroughly and follow the installation and operation procedures carefully to prevent any damage to the unit and/or any devices it connects to

GUH274 package contains:

- 1 USB 2.0 4-port MicroHub™
- 1 Power Adapter
- 1 User Manual
- 1 Warranty/Registration Card

Copyright © 2003 IOGEAR™ All Rights Reserved.
All brand names and trademarks are the registered property of their respective owners.
PKG-M0059



1. Welcome

Thank you for purchasing IOGEAR's USB 2.0 MicroHub. IOGEAR brings the cutting edge technology of USB to your Macintosh® or PC compatible computer. You will enjoy the convenience and newfound speed that has made this technology an industry standard.

Note:

Your order has been carefully packaged and inspected, and we hope you are pleased with the IOGEAR product you purchased. Please inspect the contents of the package to ensure that you have received all items and that nothing has been damaged. If you discover a problem, please contact your dealer immediately for assistance.

Contact Information:
949-453-8782
23 Hubble
Irvine, CA 92618
USA
www.iogear.com
support@iogear.com


2. System Requirements and Features

- 1) Windows 98SE, 2000, ME, XP
- 2) Mac OS 8.6 to 9.2 (USB 1.1), Mac OS X 10.1.5 (USB 2.0)
- 3) Available USB port
- 4) 300 MHz or better CPU

• Product Features

- 1) 40 times faster than the original USB
- 2) Support high speed data transfer rates of up to 480 Mbps
- 3) Fully backward compatible with USB 1.1
- 4) 4 downstream type A ports
- 5) Hot swappable
- 6) Plug-N-Play
- 7) PC power management v2.2 compliant
- 8) 3-year limited warranty

3. Overview



1. Root (upstream) connector
 - The connector that plugs into the Hi-Speed USB 2.0 port
2. Power jack
 - The power adapter plugs in here
3. Power LED
 - Lights up when the unit is receiving power from the power source at the correct current level

4. Hardware Installation

Hardware Installation

- Installing the IOGEAR USB 2.0 MicroHub
 - a) Plug the power adapter into the AC source, then plug the power adapter cable into the hub power jack.
 - b) Plug the USB 2.0 Hi-Speed hub into your computer's Hi-Speed USB 2.0 port
 - c) Upon powering up your computer, the USB 2.0 hub will be recognized by the computer's operating system.
 - d) Once complete, you are ready to plug all peripheral devices into your new Hi-Speed USB (4) port hub.

5. Specifications

Function		Specifications
Ports	External	4
Power Mode		Self (Bus) Powered, power supply included
Output voltage (per port)		+5V DC
Output Current (per port)		500mA (max.)
Operating Temperature		5~40° C
Storage Temperature		-20~60° C
Humidity		0~80% RH

Radio & TV Interferences

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

IN NO EVENT SHALL THE DIRECT VENDOR'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, DISK, OR IT'S DOCUMENTATION.

The direct vendor makes no warranty or representation, expressed, implied, or statutory with respect to the contents or use of this documentation, and especially disclaims its quality, performance, merchantability, or fitness for any particular purpose. The direct vendor also reserves the right to revise or update the device or documentation without obligation to notify any individual or entity of such revisions, or update. For further inquiries, please contact your direct vendor.