

- Controls output level of amplifier.
- 3. LED
  - Light indicates power on/off.

tion, or an overdriven rock tone; decreasing gain produces a cleaner sound.

6. POWER Turns amplifier on/off.

- 4. GAIN

Controls input level. Increasing gain adds distor-

## INSTALLING BATTERIES

The MA002 Amplifier operates with two 9-volt alkaline batteries. Two battery compartments can be found on the back of the amp, on either side of the speaker.

Replace both batteries by following these steps:

Open the battery compartment door, pinch the tab, and pull the door to open.

To install a new battery, snap the +/- terminals of the battery into place on the connector pad.


Place the attached battery into the compartment.

Close the compartment door.

Do not mix old and new batteries. Do not mix alkaline standard (carbon-zinc) and rechargeable (nickelcadmium) batteries.

..... SPECIFICATIONS **Output Power: Input Sensitivity:** 4 watts RMS 26 mV**Frequency Range:** Dimensions: (LxWxH) 60 Hz ~ 6 kHz 8" x 3.25" x 7.5" Speaker: Weight: 4" / 8W / 4 ohms 3 lbs. SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

**First Act** 745 Boylston Street Boston, MA 02116 USA firstact.com



## **IMPORTANT SAFETY INSTRUCTIONS**

Please read carefully before operating your amplifier: Follow these basic precautionary measures to ensure a longer life for your amplifier, and to reduce the risk of electric shock.

- ------
- 1. This unit should be protected from contact with water, moisture, or liquids of any kind.
- 2. This amplifier should only be serviced by a qualified repair technician.
- 3. This unit should not be placed near a heat source (permissible operating temperature range  $32-104^{\circ}$ F).
- 4. Turn amplifier power off when not in use.
- 5. The outside of the amplifier may be cleaned with a dry cloth only. Do not use water or chemicals to clean.
- 6. This unit contains digital circuitry and may cause interference if placed too close to radio or television receivers.

- Do not operate the amplifier if: » the unit has been dropped
  - » the unit has been exposed to moisture/liquids of any kind
    » the unit is not functioning properly
    Note: If you suspect that your amp is defective, have it checked and repaired by a qualified service technician.
- 8. Do not expose the unit to:
  - » Direct sunlight
  - » Excessive humidity
  - » Excessive dust
  - » Strong vibration
- 9. To prevent electric shock hazard, do not open the cabinet or chassis of the amplifier.



**Customer Assistance** Phone: 888.551.1115 Email: info@firstact.com

- First Act and the First Act logo are
- trademarks of First Act Inc.
- ©2006-2007 First Act Inc. All rights reserved.
- MA002.M.01