

Solace Active Noise-Canceling Headset RF-JJX15



QUICK SETUP GUIDE

Congratulations on your purchase of the Solace ANC headset. This headset represents the state of the art in headset design and is designed for reliable and trouble-free performance.

Package contents

- Active noise-canceling headset
- Comply[™] Foam Tips and 3 ear bud sizes (S, M, L)
- USB charging cable
- 3.5 mm adapter for extended compatibility (with Nokia, Samsung and LG handsets)
- Carry pouch
- Quick Setup Guide

Features



Charging the battery

Connect the USB charger to the headset and to an open USB port on your computer. Charge the battery for at least two hours. While the battery is charging, the status indicator lights red. When the battery is fully charged, the status indicator dims or turns off.

Note: Charge for two hours before first use (two hours charge will provide 30 hours of playback time with Noise Canceling on).

Using your headset

- **1** Plug the audio cable into a mobile phone or MP3 player.
- 2 If you connected your headset to a mobile phone, you will hear a tone when you have an incoming call. Press the Call Answer/End button to answer the call. Press the button again to end the call.
- **3** If you connected your headset to an MP3 player, turn on the player and start playing music.

Note: If the audio seems distorted, use the audio adapter. Attach the 3.5 mm adapter to the plug on end of the cable. Note: The voice microphone will not function if the headset is connected to a phone that requires the adapter.

Using the ANC (active noise canceling) feature

When the ANC feature is turned on, your headphones block ambient noise. The audio sent though the audio cable is not affected. When the ANC feature is turned on, the status indicator lights green.

- To turn on the ANC feature, slide the ANC ON/OFF switch to the ${\bf ON}$ position.
- To turn off the ANC feature, slide the ANC ON/OFF switch to the **OFF** position.

Inserting Comply[™] Foam Tip



1 Your headset should be turned off. Hold the ear bud as shown. Roll the foam tip into a thin, round cylinder.



2 Position the ear bud for insertion. Pull back and up on the ear to open the canal. Gently insert the entire foam into the ear.



3 Hold the foam tip in place until it expands—15 to 30 seconds—then turn on the head phones. Be sure the ear buds comfortably rest in each ear.

To order additional Comply[™] Foam Tips visit <u>www.complyfoam.com</u>.

Troubleshooting

-	
Problem	Solution
Cannot answer or end a call	 Make sure that your mobile phone supports this feature. Make sure that the audio cable is connected securely to the mobile phone and that nothing on the phone obstructs the cable connection.
Cannot hear any sound	 Make sure that your headset's audio cable is correctly inserted into the audio device and that the volume on the device is turned up. Make sure that the ANC ON/OFF switch is set to the ON or OFF position. Turn off the ANC feature and charge the battery.
Audio is playing through only one ear bud	 Make sure that the ANC ON/OFF switch is set to the ON or OFF position.
Audio is distorted or sounds strange	 Make sure that the audio cable is securely inserted into the audio device. If the audio is still distorted, attach the included audio adapter.
Ambient noise is not reduced	 Make sure that the ANC ON/OFF switch is in the ON position. Make sure that you are using the correct size ear buds. If the ear buds do not fit correctly, they do not block ambient noise. Charge the battery.

	Safety information
	This product contains a non-replaceable, rechargeable lithium battery. Recycle in accordance with local regulations.
e phone	Do not disassemble or try to repair your headset or replace the battery. No user serviceable parts inside.
able is mobile	Excessive volume levels can damage your hearing. Listen with your headset at a safe volume level.
n the phone ction.	Your headset contains small parts that may cause a choking hazard. Keep away from children.
et's audio	This product complies with:
into the volume on	 The essential requirements and other relevant provisions of Directive 1999/5/EC.
N/OFF switch sition. nd charge the	One-year limited warranty Visit <u>www.rocketfishproducts.com</u> for details.
	We're here for you:
N/OFF switch	For customer service call 1-800-620-2790
sition.	www.rocketfishproducts.com
able is	Distributed by Best Buy Purchasing, LLC
audio device. d, attach the	7601 Penn Avenue South, Richfield, MN 55423-3645 USA © 2011 BBY Solutions, Inc., All Rights Reserved. ROCKETFISH is a trademark
	of BBY Solutions, Inc. All other products and brand names are trademarks of their respective owners.
N/OFF switch	Best Buy Connect sM is a registered service mark of Best Buy Connect, LLC. Minneapolis, MN
ng the ear buds do	© 2011 Best Buy Connect, LLC All rights reserved
e ear buds do ot block	Best Buy Connect Customer Care (866) 652-4141
	BestBuyConnect@response.bestbuy.com
	www.BestBuyConnect.com