


Quick installation guide

i6720


Parts checklist:

Check to make sure the phone's package includes the following:

1. AC power adapter
2. Charger
3. Handset
4. Battery compartment cover
5. Belt clip
6. Battery
7. Quick installation guide



1. AC power adapter 2. Charger 3. Handset




4. Battery compartment cover 5. Belt clip 6. Battery 7. Quick installation guide

NOTE:

- To purchase replacement batteries, visit us on the web at www.vtechphones.com or call VTech Communications, Inc. at 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call VTech Telecommunications Canada Ltd. at 1 (800) 267-7377.

Install handset battery

1. Align the two holes in the plug with the socketpins, matching the red and the black connectors, then snap plug into place.
2. Place the battery in the compartment with the wires in the upper right corner.
3. Neatly tuck the wires next to the battery inside the battery compartment.
4. Replace cover by sliding it upwards until it clicks into place.




NOTE:

- Use only the VTech battery and AC power adapter supplied with this unit or the recommended equivalent.
- If you are not going to use the telephone for a long period of time, remove the battery to prevent possible leakage.
- Do not open or mutilate the battery. Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
- Exercise care in handling batteries in order not to create a short circuit with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.
- Do not dispose of the battery in a fire; it might explode.

Connect power to handset charger

Choose the location for your handset charger, and plug charger adapter into an electrical outlet not controlled by a wall switch.



Charge the handset battery


Place the handset in the base unit. **CHARGING...** will display on handset. Be sure to charge the battery for at least 16 hours before using your telephone.

NOTE:

- Return the handset to the base unit when not in use to ensure optimum performance.

Belt clip

Align the pins on the inside edge of the clip with the notches on the sides of the handset.



To attach To remove


Registration

To register the i6720 handset to your original system, you have to first de-register all your handsets, then register the new handset and re-register all the old handsets one at a time.


De-register all handsets

- Press and hold **FIND HANDSET** on the base unit for four seconds, the **IN USE** light will light up.
- Keep pressing **FIND HANDSET** for another six seconds until the **IN USE** light starts to flash, then release the **FIND HANDSET** button.
- Press and release **FIND HANDSET** again. The **IN USE** light will turn off and in a few seconds, all handsets will be de-registered.

On the i6725 base:




On the i6765/75/85/86 base:



Register a handset


- When the handset shows **NOT REGISTERED**, place the handset on a base unit or charger that is connected to a power outlet. The handset screen will display **PRESS FIND HNDST 4 SEC ON BASE**.
- Press and hold **FIND HANDSET** on the base unit until the **IN USE** light comes on. (It takes at least four seconds).
- Release **FIND HANDSET** once the **IN USE** light comes on.




NOTE:

- If **PRESS FIND HNDST 4 SEC ON BASE** does not appear on the screen after a few seconds, lift up handset and place in base unit or charger again.

On the i6725 base:



On the i6765/75/85/86 base:



After a while the handset will emit series of tones, the newly registered handset will be assigned the lowest extension number not previously assigned to another system handset when successfully registered. Repeat the steps in **Register a handset** if the new handset does not successfully register to the base unit within two minutes.

Note:

- If the de-register process does not work, you may need to reset the system and try again. To reset: pick up the handset and press **TALK/FLASH**. Then, press the **OFF** button and place the handset back into the base unit.
- When first purchased you need to charge your handsets for five minutes before registering to base unit.

Important:

If this product is not working properly:

1. Visit our website at www.vtechphones.com or in Canada, www.vtechcanada.com.
2. Call our customer service at 1-800-595-9511 or 1-800-267-7377 in Canada.