


## INSTALL INSTRUCTIONS C-TCB-3 TELESCOPING COMPUTER BASE 1995-1999 CHEVROLET/GMC CK-PICKUP, TAHOE, SUBURBAN, YUKON

**TOOLS REQUIRED:**

- |                          |                                  |
|--------------------------|----------------------------------|
| 3/16" Allen wrench       | 3/8" Ratcheting Wrench           |
| 3/8" Standard Socket Set | Powered drill w/ 3/16" drill bit |
| 3/8" Metric Socket Set   | Open-end wrench set              |

**HARDWARE & COMPONENTS:**

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1	Pole support assembly	CM93071-1
1	Telescoping pole assembly	CM93072-3
1	Side support brace	CM93115
1	Universal support brace	CM93135
1	5/16-18" Nylock nut	GSM30017
2	5/16" Flat washer	GSM31006
1	5/16-18 x 1" Hex head bolt	GSM33012
2	1/4" x 3/4" Hex head lag bolt	GSM33060-1



## **SUB ASSEMBLY:**

1. Confirm receipt of hardware and components.
2. Loosen or remove front inner and outer passenger seat bolts on vehicle.

## **INSTALLATION:**

### **1. Mount C-TCB-3 into vehicle:**

- Slide pole support assembly between front inner seat base mount and floor of vehicle.
- Loosely attached factory seat bolt.
- Slide universal support brace between front outer seat base mount and floor of vehicle.
- Attach universal support brace and side support brace to welded tab on side of pole support assembly and loosely attach using 5/16-18 Hex head bolt, washers and nylock nut.
- Position assembly on passenger seat base and completely tighten factory seat bolts.
- Mount side support brace to vehicle using 1/4" x 3/4" Hex head lag bolts. A 3/16" pilot is required.

*Note: When mounting side support brace to floor of vehicle, be sure to check for obstructions prior to drilling or lag bolting to floor.*

- Mount optional C-3090 computer-mounting platform to telescoping pole assembly using hardware and instructions provided with C-3090.